Manual No.'13•PAC-DB-194 updated June 30, 2017



DATA BOOK

STANDARD INVERTER PACKAGED AIR-CONDITIONERS

(Split system, air to air heat pump type)

CEILING CASSETTE-4WAY TYPE FDT71VNPVF1

FDT90VNPVF1 FDT90VNPVF2

DUCT CONNECTED-HIGH STATIC

PRESSURE TYPE FDU71VNPVF1 FDU90VNPVF1 FDU90VNPVF2

FLOOR STANDING TYPE FDF71VNPVD1 FDF90VNPVD1 FDF90VNPVD2

CEILING SUSPENDED TYPE FDEN71VNPVF1 FDEN90VNPVF1

DUCT CONNECTED-LOW/MIDDLE STATIC PRESSURE TYPE FDUM71VNPVF1 FDUM90VNPVF1 FDUM90VNPVF2

WALL MOUNTED TYPE SRK71VNPZM

Service code

Outdoor unit	History of s	ervice code	Changes
FDC71VNP	1	L	$1 \rightarrow L$: to comply with amended
FDC90VNP	1	L	safety standard for LVD


MITSUBISHI HEAVY INDUSTRIES THERMAL SYSTEMS, LTD.

CONTENTS

1. GENERAL INFORMATION	3
2. SPECIFICATIONS	11
(1) Ceiling cassette-4way type (FDT)	11
(2) Ceiling suspended type (FDEN)	
(3) Duct connected-High static pressure type (FDU)	15
(4) Duct connected-Low / Middle static pressure type (FDUM)	17
(5) Floor standing type (FDF)	19
(6) Wall mounted type (SRK)	21
3. EXTERIOR DIMENSIONS	22
(1) Indoor units	22
(2) Outdoor units	32
(3) Remote control	34
4. ELECTRICAL WIRING	37
(1) Indoor units	37
(2) Outdoor units	45
5. NOISE LEVEL	47
(1) Indoor units	47
(2) Outdoor units	49
6. CHARACTERISTICS OF FAN	50
(1) Duct connected-High static pressure type (FDU)	50
(2) Duct connected-Low / Middle static pressure type (FDUM)	52
7. TEMPERATURE AND VELOCITY DISTRIBUTION	53
(1) Ceiling cassette-4way type (FDT)	53
(2) Ceiling suspended type (FDEN)	
(3) Floor standing type (FDF)	57
8. PIPING SYSTEM	
9. RANGE OF USAGE & LIMITATIONS	60
10. SELECTION CHART	63
10.1 Capacity tables	
10.2 Correction of cooling and heating capacity in relation to air flow rate control (fan speed)	
10.3 Correction of cooling and heating capacity in relation to one way length of refrigerant piping	
10.4 Height difference between the indoor unit and outdoor unit	71
11. APPLICATION DATA	72
11.1 Installation of indoor unit	
(1) Ceiling cassette-4way type (FDT)	
(2) Ceiling suspended type (FDEN)	
(3) Duct connected-High static pressure type (FDU)	
(4) Duct connected-Low / Middle static pressure type (FDUM)	89

(5) Floor standing type (FDF)	
(6) Wall mounted type (SRK)	
(7) Effective range of cool/hot wind (Reference)	
11.2 Electric wiring work installation	
(1) FDT, FDEN, FDUM series 104	
(2) FDU series	
(3) FDF series	
11.3 Installation of wired remote control (option)116	6
11.4 Installation of outdoor unit)
12. OPTION PARTS144	4
12.1 Wireless kit	4
(1) FDT series (RCN-T-36W-E)144	4
(2) FDEN series (RCN-E1R)	3
(3) FDU, FDUM, FDF series (RCN-KIT3-E)	
12.2 Simple wired remote control (RCH-E3)	2
12.3 Filter kit (FDUM series)	3
12.4 Interface kit (SC-BIKN-E)	
12.5 Super link E board (SC-ADNA-E)164	
13. TECHNICAL INFORMATION	6
(1) Ceiling cassette-4way type (FDT)166	6
(2) Ceiling suspended type (FDEN)	8
(3) Duct connected-High static pressure type (FDU)	С
(4) Duct connected-Low / Middle static pressure type (FDUM)	2
(5) Floor standing type (FDF)	4
(6) Wall mounted type (SRK)	

How to read the model name




1. GENERAL INFORMATION

(1) New line-up

1) New Standard Inverter Outdoor unit

FDC71VNP (3HP)

FDC90VNP (3.5HP)



2) Add new indoor unit connection

SRK71ZM-S can connect with FDC71VNP.

			C					
		FDT	FDEN	FDU	FDUM	FDF	SRK-ZM	
				1		*		FDC71VNP &
Outdoor	3HP	9	9		9	0	O	SRC71ZM-S
unit	3.5HP		0		0	0		connected.

	Outdoor units	Indoor units										
		FDTVF (Former mode	el)	FDTVF1 (Latest model)	SRK-ZM-S						
	FDC71VNX	FDT71VF,FDEN71VF	OK	FDT71VF1,FDEN71VF1	OK	SRK71	N/A					
3HP	FDC71VNP	FDUM71VF,FDU71VD FDF71VD	N/A	FDUM71VF1,FDU71VF1 FDF71VD1	OK	ZM-S	ОК					
3.5HP	FDC90VNP	FDT100VF,FDEN100VF	N/A	FDT100VF1,FDEN100VF1	OK							
4HP	FDC100VN/VS FDC100VNX/VSX	FDUM100VF,FDU100VD FDF100VD	OK	FDUM100VF1 FDU100VF1,FDF100VD1	OK	N/A						

• <u>"100"</u> capacity indoor units can be connected to <u>3.5HP</u>.

(2) Specification comparison

	-					
				HYPER	RAC	New
				FDC71VNX	SRC71ZM-S	FDC71VNP
				FDT71VF1	SRK71ZM-S	FDT71VF1
	Power su	pply	V	50Hz 220-240V 60Hz 220V	50Hz 220-240V	50Hz 220-240V 60Hz 220V
	Conceitu	Nominal	kW	7.1	7.1	7.1
	Capacity	Range	kW	3.2 - 8.0	2.15 - 8.0	1.4 - 7.1
	EER		-	3.48	3.29	2.84
Cooling	SEER		-	5.72	6.06	6.14
	Efficiency	class	-	A+	A+	A++
	Sound power		dB(A)	66	66	67
		Nominal	kW	8.0	8.0	7.1
	Capacity	pacity Range		3.6 - 9.0	1.6 – 10	1.0 - 7.1
		PdesignH	kW	6.5	7.6	5.7
Heating	COP		-	4.12	3.74	3.74
	SCOP		-	4.09	4.03	4.27
	Efficiency	class	-	A+	A+	A+
External	dimension		mm	750x880x340	750x880x340	640x800x290
Dining la	nath	Maximum	m	50	30	30
Piping le	ngtn	Charge less	m	30	15	15
llaiabtd	fforman	O/U above	m	30	20	20
neight a	ifference	O/U below	m	15	20	20
Operatio	n rongo	Cooling	deg.C	-15 - +43	-15 - +46	-15 - +46
Operatio	mange	Heating	deg.C	-20 - +20	-15 - +21	-15 - +20


(2)-1 3HP Specification

(2)-2 3.5HP Specification

				Hyper	Micro	New
				FDC100VNX	FDC100VN	FDC90VNP
				FDT100VF1	FDT100VF1	FDT100VF1
	Power su	ipply	V	50Hz 220-240V 60Hz 220V	50Hz 220-240V 60Hz 220V	50Hz 220-240V 60Hz 220V
	Consoitu	Nominal	kW	10.0	10.0	9.0
	Capacity	Range	kW	4.0 - 11.2	4.0 - 11.2	1.9 - 9.0
Cooling	EER		-	4.00	3.62	3.37
Cooling	SEER		-	5.84	5.61	6.73
	Efficiency class		-	A+	A+	A++
	Sound pov	wer level	dB(A)	70	70	69
		Nominal		11.2	11.2	9.0
	Capacity	apacity Range		4.0 - 12.5	4.0 - 12.5	1.5 - 9.0
Llooting		PdesignH	kW	13.5	9.7	8.1
Heating	COP		-	4.34	4.09	4.11
	SCOP	COP		3.96	3.92	4.11
	Efficiency	class	-	А	А	A+
External	dimension		mm	1300x970x370	845x970x370	750x880x340
Dining lo	nath	Maximum	m	100	50	30
Piping le	ngui	Charge less	m	30	30	15
	ifforonoc	O/U above	m	30	30	20
Height d	merence	O/U below	m	15	15	20
Onoratio		Cooling	deg.C	-15 - +43	-15 - +43	-15 - +46
Operatio	mange	Heating	deg.C	-20 - +20	-20 - +20	-15 - +20


(3) Difference from other series

(3)-1 Nominal / Maximum capacity





(3)-2 Efficiency

Nominal efficiency becomes lower, but seasonal efficiency becomes higher by optimizing control.





EER : energy efficiency ratio (efficiency of cooling) COP: coefficient of performance (efficiency of heating) SEER,SCOP : Seasonal EER, Seasonal COP, defined by European standard EN14825. It shows annual efficiency according to European climate condition. (Average)






chargeless pipe length:8m, max pipe length :23m






(3)-5 Piping system





2) 3.5HP




(4) Other features

(4)-1 Combination <Plural control>


NO

Outdoor units do not have plural control. Plural combination is prohibited.





(4)-2 Cooling capacity characteristicWhen ambient temperature is higher...Cooling capacity become smaller to 85%.





(4)-3 Sound level

Sound pressure level becomes higher. Silent mode is prepared. (note: capacity down to around 90%)

1) 3HP

2) 3.5HP






(4)-4 Trial operation


No DIP switch for trial operation.

(4)-5 Maintenance

(1)Mente PC is possible for maintenance.
 Relay cable is necessary.
 New RAM file is also needed.
 RAMDATA_eR25V.xls



(2)Inverter checker is possible for maintenance.Short-connector is necessary.(Short between Pin No.2 and No.3 of CNROM)



CNROM

2. SPECIFICATIONS

(1) Ceiling cassette-4way type (FDT) Model FDT71VNPVF1

			Model		FDT71V				
tem				Indoor unit		Outdoor unit FDC	71VNP		
Power sour			1.3.67		Single phase 220-240				
	Nominal cooling capa		kW		7.1 [1.4(Min.)				
	Nominal heating capa Power		kW		7.1 [1.0(Min.) 2.9				
	consumption	Cooling Heating	kW						
	Max power consumption	5	KVV	<u>1.90</u> 3.27					
	Running	Cooling							
	current	Heating	А		8.5 /				
	Inrush current, max c								
Operation	Initiasi current, max o	Cooling		<u> </u>					
lata	Power factor	Heating	%		97 /				
	EER	Cooling			2.8				
	COP	Heating			3.7				
		Cooling							
	Sound power level	Heating		6	4	67			
		Cooling	dB(A)						
	Sound pressure level	Heating		P-Hi:46 Hi:35	Me:33 Lo:31	54			
	Silent mode sound pr			_	49				
				Unit 246 ×	840 × 840	-			
xterior din	nensions (Height × Wid	th × Depth)	mm	Panel 35 ×		640×800(+71)×	290		
Exterior ap	pearance			Plaster		Stucco White	9		
Munsell co				(6.8Y8.9/0.2)r		(4.2Y7.5/1.1)near ed			
let weight	,		kg	UNIT 24 F		45			
	or type & Q'ty		·······································	-		RMT5113MDE2 (Twin Ro	otary type)×1		
	or motor (Starting metho	od)	kW			Direct line sta			
	oil (Amount, type)	54)	l		-	0.45 MA68			
	(Type, amount, pre-ch	arge length)	kg	B410A 1.6k	a in outdoor unit (incl. t	he amount for the piping of :	15m)		
leat excha		a go longin,	····g	Louver fin & inne	<u> </u>	M shape fin & inner gro	,		
Refrigerant control					Capillary tubes + Elect		over tability		
an type &				Turbo		Propeller fan >	x1		
Fan motor (Starting method)			W	50 < Direct		34 < Direct line s			
	(otarting motiod)	Cooling							
Air flow		Heating	m³/min	P-Hi:28 Hi:21	Me:19 Lo:17	36			
vailable ex	xternal static pressure	ricating	Pa	C					
Outside air			·ια	Poss					
	uality / Quantity			Pocket plastic ne					
	pration absorber			Rubber sleeve	· /	Rubber sleeve (for Co	mpressor)		
lectric hea			W		-	-			
	Remote control			(option) wire	d BC-EX1A BC-E5	BCH-E3 wireless BCN-T-3	86W-F		
Operation	Room temperature co	ontrol		(option) wired : RC-EX1A , RC-E5 , RCH-E3 wireless : RCN-T-36W-E Thermostat by electronics					
control	Operation display					-			
				Com	proper overheat prote	ction, Overcurrent protection,			
S-f-t!						, , , , , , , , , , , , , , , , , , , ,			
Safety equi	pments				• ·	ection, Indoor fan motor error			
					1 1 1	ure control), Cooling overload	<u> </u>		
	Refrigerant piping size	e(OD)	mm			φ6.35(1/4")×0.8 O/Uφ6.35 (1			
						012.7(1/2")×0.8 Ο/Uφ12.7 (1.			
	Connecting method			Flare p	biping	Flare piping			
nstallation	Attached length of pip	bing	m	-					
lata	Insulation for piping				Necessary (both L				
			m		Max.				
Refrigerant line (one way) length			m	Max.20m (Outdo		Max.20m (Outdoor un	it is lower)		
	Vertical height diff. between O.U. and I.U.			Hose Connectab	· /	Holes size ϕ 20 ×	5pcs		
	Drain hose			Built-in Drain pump , 700 –					
	Drain hose o, max lift height		mm	Built-in Drain					
	Drain hose		mm A	Built-in Drain	-	-			
ecommen	Drain hose o, max lift height			Built-in Drain		- 0			
Recommen .R.A. (Loc	Drain hose o, max lift height nded breaker size	e number	A	1.5mm/×4 cores	- 5. (including earth cable)	- 0 / Termainal block (Screw fixin	ng type)		
R.A. (Loc nterconnec number	Drain hose , max lift height ded breaker size ked rotor ampere) cting wires Size × Corr	e number	A	1.5mm/×4 cores	- 5. s (including earth cable) (0	/ Termainal block (Screw fixin IPX4			
R.A. (Loc nterconnec number	Drain hose o, max lift height ided breaker size ked rotor ampere)	e number	A	1.5mm/×4 cores	- 5. s (including earth cable) (0	/ Termainal block (Screw fixin			
ecommen .R.A. (Loc nterconnec number tandard a	Drain hose , max lift height ided breaker size ked rotor ampere) cting wires Size × Corr ccessories	e number	A	1.5mm/×4 cores	- 5. s (including earth cable) (0	/ Termainal block (Screw fixin IPX4			
Recomment R.A. (Loc Interconnect Inumber Itandard a Option part	Drain hose , max lift height ided breaker size ked rotor ampere) cting wires Size × Corr ccessories		A A	1.5mm/×4 cores IP) Mounting kit	- 5. s (including earth cable) (0	/ Termainal block (Screw fixin IPX4			
Recommen .R.A. (Loc nterconnec number Standard a Option part	Drain hose p, max lift height ded breaker size ked rotor ampere) cting wires Size × Corr ccessories is The data are measured	d at the followi	A A ng condit	1.5mm/×4 cores IP) Mounting kit tions.	s (including earth cable) (0 Drain hose	/ Termainal block (Screw fixin IPX4 Drain elbow, Drain hole - The pipe length is 7.5m.			
Recomment R.A. (Locinterconnect P number Standard a Option part Note (1)	Drain hose , max lift height ided breaker size ked rotor ampere) cting wires Size × Corr ccessories is The data are measured Item Indoor	d at the followi air temperatur	A A ng condit	1.5mi [*] ×4 core: IP) Mounting kit tions. Dutdoor air <u>t</u> emperature	s (including earth cable) (0 Drain hose	/ Termainal block (Screw fixin IPX4 Drain elbow, Drain hole			
Recomment Recomment R.A. (Loc Interconnect I	Drain hose p, max lift height ided breaker size ked rotor ampere) cting wires Size × Corr ccessories is The data are measurer Item Indoor peration DB	d at the followi	A A ng condit e C	1.5mm [*] ×4 core: IP) Mounting kit tions. Dutdoor air temperature DB WB		/ Termainal block (Screw fixin IPX4 Drain elbow, Drain hole - The pipe length is 7.5m. andards			
Recomment Recomment Reconnect number Number Recomment Re	Drain hose , max lift height ided breaker size ked rotor ampere) cting wires Size × Corr ccessories is The data are measured Item Indoor	d at the followi air temperatur WB	A A ng condit e C	1.5mi [*] ×4 core: IP) Mounting kit tions. Dutdoor air <u>t</u> emperature		/ Termainal block (Screw fixin IPX4 Drain elbow, Drain hole - The pipe length is 7.5m.			

(d) Select the breaker size according to the own national standard.
(f) When wireless remote control is used, fan is 3 speed setting (Hi-Me-Lo) only.
(g) The operation data indicates when the air-conditioner is operated at 230V 50Hz or 220V 60Hz.

PJF000Z314

Model FDT90VNPVF1

Item				Model		Indoor unit ED	FDT90V					
tem Power sourc	20					Indoor unit FD		Outdoor unit F 0V 50Hz / 220V 60Hz	DC90VNP			
-ower source		ling capacity	(rango)	kW			9.0 [1.9(Min.)					
		<u> </u>		kW			9.0 [1.5(Min.) 9.0 [1.5(Min.)					
		ting capacity	<u>, , , , , , , , , , , , , , , , , , , </u>	KVV			9.0 [1.5(10111.)					
	Power		Cooling	1.3.47								
	consumption		Heating	kW			2.					
		onsumption	0 11			4.19						
	Running		Cooling				11.9 /					
	current		Heating	A			9.9 /					
Operation	Inrush currei	nt, max currer					5,					
lata	Power factor		Cooling	%			97 /					
			Heating				96 /					
	EER		Cooling				3.3					
	COP		Heating				4.	11				
	Sound powe	r lovel	Cooling			65		69				
		i level	Heating			00		000				
	O and a second		Cooling	dB(A)				57				
	Sound press	ure level	Heating	1	Р-н	i:51 Hi:40 M	e:37 Lo:35	55				
	Silent mode	sound pressu		1		_		Cooling:52 / H	eating:50			
						Unit 298 × 84	0 ~ 8/0		oalligioo			
xterior dim	ensions (Heig	$ht \times Width \times$	Depth)	mm		Panel 35 × 95		750 x 880(+8	8) x 340			
utorie								04	/hite			
Exterior app						Plaster W		Stucco W				
Munsell co	ior)				((5.8Y8.9/0.2)nea		(4.2Y7.5/1.1)nea	ir equivalent			
let weight				kg		UNIT 27 PAN	IEL 5.5	57				
	r type & Q'ty					-		RMT5118MDE2 (Twir				
	r motor (Start	<u> </u>		kW		_		Direct line				
Refrigerant	oil (Amount, t	ype)		l		_		0.675 M	468			
Refrigerant	(Type, amou	nt, pre-charge	e length)	kg		R410A 2.1kg	n outdoor unit (incl. t	the amount for the piping of : 15m)				
leat exchar	naer				Lou	ver fin & inner g	ooved tubing	M shape fin & inner grooved tubing				
Refrigerant								tronic expansion valve	<u> </u>			
an type & Q'ty						Turbo fan		Propeller fa	an x1			
Fan motor (Starting method)			W		140 < Direct li		86 < Direct lir					
							63					
sir flow			m ³ /min	P-H	li:37 Hi:27 M	e:24 Lo:20						
Heating							49.5					
	ternal static p	ressure		Pa		0		0				
	utside air intake					Possibl		-				
	ality / Quantit					cket plastic net :	· /					
Shock & vib	ration absorb	er			F R	lubber sleeve(for	fan motor)	Rubber sleeve (for fan m	otor & compress			
Electric heat	ter			W		_		_				
Oneration	Remote con	rol			(option) wired : RC-EX1A , RC-E5 , RCH-E3 wireless : RCN-T-36W-E							
Operation	Room tempe	rature contro			Thermostat by electronics							
control	Operation di	splay					-	_				
		1 2				Compr	esor overheat protec	ction, Overcurrent protection	an			
Safety equip	DITIENTS						• ·	ection, Indoor fan motor er				
					He	· ·		ure control), Cooling overl				
	Pofrigorant		<u> </u>					ϕ 6.35(1/4")x0.8 O/U ϕ 6.3				
		oiping size (O)	mm		Gas line: I/U q	15.88 (5/8") Pipe o	15.88(5/8")x1.0 O/U \$\$\$ 15.8	88 (5/8")			
	Connecting	nethod				Flare pip		Flare pip				
nstallation	Attached len			m								
lata	Insulation fo	0 11 0					Necessary (both L	iquid & Gas lines)				
		ine (one way)	lenath	m			Max.					
		diff. between O.		m	Ma	x.20m (Outdoor		Max.20m (Outdoor	unit is lower)			
	Drain hose	um. Detween U.	0. and 1.0.			se Connectable		Holes size $\phi 2$,			
)roin a		ht			105		· · · ·		o x opus			
	, max lift heig			mm		Built-in Drain pu	inip , 700					
	ded breaker s			A	ļ							
	ed rotor amp	,		A		2 .	5.					
	ting wires S	ze × Core nu	mber				ncluding earth cable)	/ Termainal block (Screw f	ixing type)			
P number						IPX0		IPX4				
Standard ac						Mounting kit, D	rain hose	Drain elbow, Drain	hole grommet			
Option parts	6											
Note (1)	The data are	measured at	the followi	ng cond	itions.			The pipe length is 7.5m.				
\sim	ltem	Indoor air t		<u> </u>		r temperature						
0-	beration	DB	WB	~	DB	WB	Sta	tandards				
	Cooling	27°C	19°C		35°C	24°C						
	Heating	20°C	190			6°C	ISO	5151-T1				
	This air cond	tioner is man	utactured	and test	ed in confo	ormity with the IS	0.					
								The second se				
(3)				anechoi	c chamber	. During operation	n these value are so	mewhat higher due to amb	pient			

(5) When wireless remote control is used, fan is 3 speed setting (Hi-Me-Lo) only.
(6) The operation data indicates when the air-conditioner is operated at 230V 50Hz or 220V 60Hz.

PJF000Z314

Model FDT90VNPVF2

ltem			Model	lı	ndoor unit FDT		DT90VNPV	Outdoor unit FD	C90VNP		
Power source	ce						20-240V 50)Hz / 220V 60Hz			
	Nominal cooling capacit	ty (range)	kW				(Min.)~ 9				
	Nominal heating capacit	, , ,	kW				(Min.)~ 9				
	Power	Cooling					2.67				
	consumption	Heating	kW				2.19				
Max power consumption							4.19				
	Running	Cooling					11.9 / 12.4				
	current	Heating	A				9.9 / 10.3				
Operation	Inrush current, max curr	rent					5, 18.0				
lata	Power factor	Cooling	%				97 / 97				
ata		Heating	,,,				96 / 96				
	EER	Cooling			3.37						
	COP	Heating					4.11				
	Sound power level	Cooling			65			69			
	·	Heating									
	Sound pressure level	Cooling	dB(A)	P-Hi :	51 Hi:40 Me	:37 Lo:35		57			
	•	Heating						55	1. 50		
	Silent mode sound pressure level							Cooling:52 / Hea	ating:50		
xterior dim	ensions (Height × Width	× Depth)	mm		Unit 298 × 840 × 840 Panel 35 × 950 × 950			750 x 880(+88)) x 340		
Exterior app			7		Plaster Whi			Stucco Wh			
Munsell co	lor)			(6.	(6.8Y8.9/0.2)near equivalent			(4.2Y7.5/1.1)near	equivalent		
let weight			kg		UNIT 27 PANEL 5.5			57			
Compressor type & Q'ty					_		I	RMT5118MDE2 (Twin			
	r motor (Starting method))	kW		_			Direct line s			
	oil (Amount, type)		l	_				0.675 MA			
	(Type, amount, pre-char	ge length)	kg		<u>v</u>	,	incl. the ar	he amount for the piping of : 15m)			
leat exchar				Louve	er fin & inner gro			M shape fin & inner gr	rooved tubing		
Refrigerant control							Electronic	c expansion valve			
an type & Q'ty					Turbo fan ×			Propeller far			
Fan motor (Starting method)			W	1	40 < Direct line	: start >		86 < Direct line	e start >		
Air flow Cooling			m³/min	P-Hi	:37 Hi:27 Me	:24 Lo:20		63			
Heating								49.5			
Available external static pressure			Pa		0			0			
Outside air i				Deal	Possible et plastic net ×1	(Mashahla)					
	ality / Quantity pration absorber				bber sleeve(for f	· /	Du	 bber sleeve (for fan mo	tor 9 comprosed		
lectric heat			W	nu	JDel Sleeve(IOLI	an motor)	nu		tor a compresso		
	Remote control		vv					LE3 wiroloss : DCN T	36W/E		
Operation	Room temperature cont	rol		(option) wired : RC-EX1A , RC-E5 , RCH-E3 wireless : RCN-T-36W-E Thermostat by electronics					-3000-L		
control	Operation display					menno	<u> </u>	.00001103			
					Compros	sor overbeat	protoction	, Overcurrent protection	2		
Safaty aquir	amonte			From				n, Indoor fan motor erro	,		
Safety equip	JITIETIUS				•	•			•		
				Heat	• ·	, ,		control), Cooling overlo			
	Refrigerant piping size (O.D.)	mm					5(1/4")x0.8 O/U φ 6.35			
		- /			,	(/	$\frac{1}{100} \phi \frac{15.88}{1}$	B(5/8")x1.0 O/U \u03c6 15.88	()		
ootollet'	Connecting method	a			Flare piping	9		Flare pipir	ıg		
	Attached length of pipin	y	m			Nooccore //-	oth Limit-				
lata	Insulation for piping	w) lon att-				Necessary (b					
	Refrigerant line (one wa Vertical height diff, between		m	Mari	20m (Outdoor ur	nit in history	Max.30m		upit in lower)		
	Drain hose	0.0. and 1.0.	m		Connectable VF	0 /		Max.20m (Outdoor u Holes size ϕ 20	,		
			mm		Built-in Drain pur	. ,		Holes size ϕ 20	x opus		
)rain numn			mm A		unt-in Drain pull	μ, i 00					
	Recommended breaker size						5.0				
Recommend			A	1	5mm*x4 cores (inc	luding earth c		rmainal block (Screw fix	(ing type)		
Recommend R.A. (Lock	ked rotor ampere)	number			IPX0			IPX4			
Recommend .R.A. (Lock		number		IPX0 IPX4 Mounting kit, Drain hose Drain elbow, Drain hole gromr							
Recommend R.A. (Lock nterconnect number	ked rotor ampere) ting wires Size × Core n	number		Ν	lounting kit. Dra	1111056			ole grommet		
Recommend R.A. (Lock nterconnec number Standard ac	ting wires Size × Core n	number		Ν	lounting kit, Dra	1111050		,,, _,, _	ole grommet		
Recommend R.A. (Lock nterconnec P number Standard ac Option parts	xed rotor ampere) ting wires Size × Core n ccessories s		ng condi		Nounting kit, Dra				ole grommet		
R.A. (Lock nterconnec P number Standard ac Option parts	ting wires Size × Core n ccessories s The data are measured a	at the followi	<u> </u>	tions.				e pipe length is 7.5m.	ole grommet		
Recommend R.A. (Lock nterconnec P number Standard ac Option parts Note (1)	ting wires Size × Core n ccessories The data are measured a Item Indoor ai		<u> </u>					e pipe length is 7.5m.	ole grommet		
Recommend R.A. (Lock nterconnec P number Standard ac Option parts Note (1)	xed rotor ampere) ting wires Size × Core n ccessories S The data are measured a Item Indoor ai DB	at the followi r temperatu	e (tions. Dutdoor air t	emperature		Standar	e pipe length is 7.5m. rds	ole grommet		
Recommend .R.A. (Lock nterconnec number Standard ac Option parts Note (1)	ed rotor ampere) ting wires Size × Core n ccessories s The data are measured a ltem Indoor ai peration DB	at the followi r temperatu	e (tions. Dutdoor air t DB	emperature WB			e pipe length is 7.5m. rds	ole grommet		
Recommend R.A. (Lock Interconnec P number Standard ac Option parts Note (1)	ting wires Size × Core n ccessories The data are measured a litem Indoor ai cooling 27°C Heating 20°C	at the followi r temperatu WB 19°C –	re (tions. Dutdoor air t DB 35°C 7°C	emperature WB 24°C 6°C		Standar	e pipe length is 7.5m. rds			
ecommend R.A. (Lock hterconnec number tandard ac option parts Note (1)	xed rotor ampere) ting wires Size × Core n ccessories S The data are measured a Item Indoor ail peration DB Cooling 27°C	at the followi r temperatur WB 19°C anufactured	and teste	tions. Dutdoor air t DB 35°C 7°C ed in conforr	emperature WB 24°C 6°C nity with the ISC).	Standar	e pipe length is 7.5m. rds -T1			

(5) When wireless remote control is used, fan is 3 speed setting (Hi-Me-Lo) only.
(6) The operation data indicates when the air-conditioner is operated at 230V 50Hz or 220V 60Hz.

PJF000Z314

(2) Ceiling suspended type (FDEN) Model FDEN71VNPVF1

Model FDEN71V												
tem						Indoor unit FD		Outdoor unit	DC71VNP			
Power sour			(1.1.0/				OV 50Hz / 220V 60Hz				
		oling capacity	(0)	kW kW			7.1 [1.4(Min.)					
		ating capacity	Cooling	KVV				\sim 7.1(Max.)]				
	Power consumption	2	Heating	kW				50 96				
		consumption	Heating	KVV				90 27				
	Running	consumption	Cooling					/ 11.6				
	current		Heating	A			8.8					
		nt, max curre				5. 14.5						
Operation	Initialiteurie		Cooling				98,					
data	Power facto	r	Heating	%			97		-			
	EER		Cooling					84				
	COP		Heating	1				62				
			Cooling									
	Sound powe	er level	Heating	1		62		67				
			Cooling	dB(A)								
	Sound press	sure level	Heating	1	P-Hi	∶50 Hi∶41 N	le:39 Lo:38	54				
	Silent mode	sound pressu				_		49				
Exterior dim	nensions (Heig			mm		210 × 1,320	× 690	640×800(+7	71)×290			
Exterior app		gint in that in it	Boptil		-	Plaster W		Stucco V				
Munsell co					(6	.8Y8.9/0.2) nea	ir equivalent	(4.2Y7.5/1.1) ne				
Net weight				kg	, 0	37	. squitaioni	45				
	or type & Q'ty							RMT5113MDE2 (Twi	n Rotarv type)×1			
	or motor (Starl	ing method)		kW	1	_		Direct line				
	oil (Amount, 1	<u> </u>		l		_		0.45 MA				
	(Type, amou		e lenath)	kg		R410A 1.6kg	n outdoor unit (incl. 1	he amount for the piping of				
Heat excha			,		Lou	ver fin & inner g		M shape fin & inner	/			
	lefrigerant control							tronic expansion valve				
an type &						Centrifugal		Propeller f	fan ×1			
Fan motor (Starting method)				w		20 ×2 < Direct I		34 < Direct li				
Cooling												
Air flow Heating			m³/mir	n P-Hi	:20 Hi:16 №	le:14 Lo:12	36					
Available ex	ailable external static pressure			Pa		0						
	utside air intake					Not poss	ble					
Air filter, Quality / Quantity					Poo	ket plastic net						
	oration absorb					ubber sleeve(for	, ,	Rubber sleeve(for	Compressor)			
Electric hea				W		0						
o	Remote con	trol				(option) wire	d: RC-EX1A, RC-E	5, RCH-E3 wireless : RC	ON-E1R			
Operation	Room temp	erature contro	bl	1		,	Thermostat b	y electronics				
control	Operation d	isplay				R	UN: Green, TIMER: ۱	ellow, CHECK: Yellow				
						Compr	essor overheat prote	ction, Overcurrent protecti	ion.			
Safety equi	oments				Fro			ection, Indoor fan motor e	,			
outory oqui	pinonto						• ·					
	1				1166	Heating overload protection(High pressure control), Cooling overload protection Liquid line: I/U φ 9.52 (3/8") Pipe φ 6.35(1/4")×0.8 O/U φ 6.35 (1/4")						
	Refrigerant p	oiping size (C).D.)	mm								
					-			b 12.7(1/2")×0.8 Ο/U φ 1				
notellet!-	Connecting					Flare pip	ing	Flare pip	Jing			
	Attached ler			m		_	Nooccessi /	iquid & Cas line-)				
data	Insulation fo		longth				Necessary (both L					
		line (one way)	, <u> </u>	m	M	(20m (0. +da		.30m Max 20m (Outdoor	r unit in lower)			
	<u>~</u>	diff. between O	.u. and I.U.	m		k.20m(Outdoor	U /	Max.20m(Outdoor	,			
	Drain hose , max lift heig	sht			nosé	Connectable wi	h VP20(O.D.26)	Holes size ϕ	20 × opes			
				mm	-	_						
	ded breaker :			A			-	.0				
	ked rotor amp cting wires S	/	mber	A		1 5mm 4 coroc/		. <u>0</u> / Termainal block(Screw f	iving type)			
P number	Jung wires 3					I.SIIIII×4 Cores(I	including earth cable,	IPX4	0 71 /			
Standard a	cressories					Mounting kit, D	rain hose	Drain elbow, Drain				
Option part						Mounting Kit, D			nois gronniet			
	s The data are	measured at	the followi	na cor	ditions			The pipe length is 7.5m.				
				<u> </u>				i ne pipe iengin is 7.5m.	1			
	Item	Indoor air t		re		temperature	Sta	andards				
0	peration		WB 10°C		DB	WB						
	Cooling	27°C	19°C	·	35°C	24°C	ISC	5151-T1				
	Heating	20°C			7°C	6°C			l -			
(3)	Sound level i conditions.	ndicates the v	value in an	anecho	oic chamber.	0.		mewhat higher due to aml	bient			
(5)		s remote con	ntrol is used	d, fan is	s 3 speed set	tting (Hi-Me-Lo)	only. IV 50Hz or 220V 60H	Ζ.				

PFA003Z973

Model FDEN90VNPVF1

Dperation	ce Nominal cooling capacit Nominal heating capacit Power			l Ir	ndoor unit FDI	EN100VF1	Outdoor unit FDC90VNP				
Dperation	Nominal cooling capacit Nominal heating capacit			Single phase 220-240V 50Hz / 220V 60Hz							
Dperation	Nominal heating capacit		1.3.47								
Dperation			kW			9.0 [1.9(Min.)					
Dperation	Power		kW			9.0 [1.5(Min.)					
Dperation		Cooling				2.7					
) peration lata	consumption	Heating	kW			2.2					
Operation ata	Max power consumptio					4.1					
Operation	Running	Cooling				12.2 /					
lata	current	Heating	A			10.1 /	10.6				
lata I	Inrush current, max curr	rent		5, 18.0							
	I Cooling			% 97 / 97							
	Power factor	Heating	90			96 /	96				
	EER	Cooling		1		3.2	27				
F	COP	Heating				4.0	00				
		Cooling									
!	Sound power level	Heating			64		69				
-		Cooling	dB(A)				57				
1	Sound pressure level		UD(A)	P-Hi :	46 Hi:44 M	le:41 Lo:39	55				
		Heating									
	Silent mode sound pres						Cooling:52 / Heating:50				
xterior dime	ensions (Height × Width	× Depth)	mm		250 × 1,620	× 690	750 x 880(+88) x 340				
xterior appe					Plaster W		Stucco White				
Munsell col	lor)			(6.	8Y8.9/0.2) nea	ar equivalent	(4.2Y7.5/1.1) near equivalent				
let weight			kg		49		57				
	r type & Q'ty						RMT5118MDE2 (Twin Rotary type)				
	motor (Starting method)	kW	1	_		Direct line start				
	pil (Amount, type)	/	l				0.675 MA68				
	(Type, amount, pre-char	an longth)			D/100 0 11	n outdoor unit (in -1 +	he amount for the piping of : 15m)				
		ge length)	kg		<u> </u>		· · · · · · · · · · · · · · · · · · ·				
leat exchan	0			Louv	Louver fin & inner grooved tubing M shape fin & inner groove Capillary tubes + Electronic expansion valve						
Refrigerant c							•				
Fan type & Q'ty					Centrifugal		Propeller fan ×1				
Fan motor (Starting method)			W	3	0 ×2 < Direct I	ine start >	86 < Direct line start >				
		Cooling		DUE	00 11: 00 1		63				
ir flow		Heating	m³/min	P-HI .	28 HI 26 N	le:23 Lo:21	49.5				
vailable ext	ternal static pressure		Pa		0		0				
Outside air in					Not poss	ihle	_				
	ality / Quantity			Poo	ket plastic net :						
	, ,					· /					
	ration absorber			RI	ubber sleeve(for	r tan motor)	Rubber sleeve (for fan motor & compre				
lectric heate			W		0						
Operation F	Remote control			(option) wired : RC-EX1A , RC-E5 , RCH-E3 wireless : RCN-E1R							
control	Room temperature cont	rol		Thermostat by electronics							
	Operation display				R	UN: Green, TIMER: Y	ellow, CHECK: Yellow				
					Compr	essor overheat prote	ction, Overcurrent protection,				
afety equip	ments			Fro			ection, Indoor fan motor error protection,				
alety equip	ments					0	,				
				Неа	° '	1 8 1	ure control), Cooling overload protection				
	Refrigerant piping size (00)	mm				φ 6.35(1/4")×0.8 O/U φ 6.35(1/4")				
!	Reingerant piping size (0.D.)			Gas line: I/U ϕ	15.88 (5/8") Pipe φ	15.88(5/8")×1.0 O/U φ 15.88 (5/8")				
(Connecting method				Flare pip	ing	Flare piping				
nstallation	Attached length of pipin	g	m								
	Insulation for piping	-		1		Necessary (both L	iguid & Gas lines)				
H	Refrigerant line (one wa	v) length	m	1		Max.					
	Vertical height diff. between		m	Max	.20m(Outdoor		Max.20m(Outdoor unit is lower)				
		0.0. and 1.0.			· · · · · · · · · · · · · · · · · · ·	0 /	· · · · · · · · · · · · · · · · · · ·				
	Drain hose			nose (Johnectable Wi	th VP20(O.D.26)	Holes size ϕ 20 x 3pcs				
	max lift height		mm		_		—				
	ded breaker size		A			-	-				
	ed rotor ampere)		A			5.					
nterconnecti	ting wires Size × Core r	number			1.5mm [*] ×4 cores(i	ncluding earth cable)	/ Termainal block(Screw fixing type)				
^o number					IPX0		IPX4				
standard acc	cessories			1	Mounting kit, D	rain hose	Drain elbow, Drain hole grommet				
ption parts					, , _		=				
	, The data are measured a	t the followi	na cond	itions			The pipe length is 7.5m.				
			<u> </u>		tomperature						
		r temperatu	e		temperature	Sta	andards				
	peration DB	WB		DB	WB						
	Cooling 27°C	19°C		35°C	24°C	ISO	5151-T1				
	Heating 20°C			7°C	6°C	100					
(2) T	This air-conditioner is ma	anufactured	and test	ed in confor	mity with the IS	SO.					
							mewhat higher due to ambient				
	conditions.				0 11 1 200		S				
0	Select the breaker size a	ccording to	the own	national sta	ndard						

(5) When wireless remote control is used, fan is 3 speed setting (Hi-Me-Lo) only.(6) The operation data indicates when the air-conditioner is operated at 230V 50Hz or 220V 60Hz.

PFA003Z973

(3) Duct connected-High static pressure type (FDU) Model FDU71VNPVF1

Item				Model		Indoor unit FE	FDU71		Outdoor unit FDC71VNP			
Power sour				1.1.47			Single phase 220-240					
	Nominal coolir			kW			7.1 [1.4(Min.)					
	Nominal heatin	ng capacity (<u> </u>	kW			7.1 [1.0(Min.)	,	<.)]			
	Power		Cooling			<u>2.63</u> 1.96						
	consumption		Heating	kW								
	Max power co	nsumption					3.2					
	Running		Cooling		11.7 / 12.2							
	current		Heating	A		8.8 / 9.2						
Operation	Inrush current,	max curren	t				5, 5	14.5				
data	Power factor		Cooling	%			98 /	98				
uala	Fower lactor		Heating	70			97 /	97				
	EER		Cooling				2.7	70				
	COP		Heating				3.0	62				
		lavial.	Cooling			05			67			
	Sound power	level	Heating			65			67			
			Cooling	dB(A)								
	Sound pressur	re level	Heating		P-Hi	:38 Hi:33 N	le:29 Lo:25		54			
	Silent mode so	ound pressu	0			_			49			
- xterior din	nensions (Heigh			mm		280 × 950 ×	(635		640×800(+71)×290			
Exterior app			-opui)			200 × 300 3			Stucco White			
Munsell co						_		1 /	4.2Y7.5/1.1) near equivalent			
·	,			- Le=:		0.4		(4	/			
Net weight				kg		34		D1 47-	45			
	or type & Q'ty	11 15		1.147		_		RM15	113MDE2 (Twin Rotary type)×			
	or motor (Startin	<u> </u>		kW		_			Direct line start			
	oil (Amount, typ			l		_			0.45 MA68			
	(Type, amount	, pre-charge	length)	kg					for the piping of : 15m)			
Heat excha	inger				Lou	iver fin & inner gi			ape fin & inner grooved tubing			
Refrigerant	control					C	apillary tubes + Elect	ronic expa	nsion valve			
Fan type &						Centrifugal t	an ×2		Propeller fan ×1			
Fan motor (Starting method	d)		W		130 < Direct lir	ne start >		34 < Direct line start >			
Airflow			Cooling	m³/min		· 04 18 · 10 M	a : 15 a : 10		26			
Air flow			Heating	m ⁻ /min	P-HI	:24 Hi:19 N	e · 15 LO · 10		36			
Available ex	xternal static pre	essure	<u>Ŭ</u>	Ра		Standard : 35	∕lax : 200		_			
Outside air						Possibl			_			
	uality / Quantity					Procure lo						
	pration absorber	r				Rubber sleeve(for	· ·	Ru	bber sleeve(for Compressor)			
Electric hea				W			lan motor)	110				
	Remote contro	2		~~		(option) wir			wireless : RCN-KIT3-E			
Operation						(option) with						
control	Room tempera						Thermostat b	y electroni	35			
	Operation disp	biay						-				
						Compre	essor overheat protect	ction, Over	current protection,			
Safety equi	pments				Fro	ost protection, S	erial signal error prot	ection, Indo	oor fan motor error protection,			
					He	ating overload p	rotection(High press	ure control), Cooling overload protection			
					-	0 1	(0 1	φ 6.35(1/4")×0.8 O/U φ 6.35 (1/4")				
	Refrigerant pip	oing size (O.	D.)	mm)×0.8 O/U φ 12.7 (1/2")			
	Connecting me	ethod				Flare pip	Flare piping					
nstallation	Attached lengt						''Y					
				m			Nooceeen: /	iquid 0 O				
data	Insulation for p		1 +1				Necessary (both L		s iiiies)			
	Refrigerant lin			m			Max.					
	Vertical height dif	π. between O.l	J. and I.U.	m		x.20m (Outdoor		Ma	x.20m (Outdoor unit is lower)			
	Drain hose				Hose C		5 (I.D.25, O.D.32)		Holes size ϕ 20 × 5pcs			
	o, max lift height			mm		Built-in Drain p	ump,600		_			
	ided breaker siz			Α			-	-				
	ked rotor amper			A			5.					
nterconnec	cting wires Size	e × Core nun	nber			1.5mm*4 cores(i	ncluding earth cable)	/ Termaina	I block(Screw fixing type)			
					IPX0 IPX4							
	ccessories					Mounting kit, D	rain hose	Dra	in elbow, Drain hole grommet			
						2 /	-	-	~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~			
Standard a		easured at t	he followi	na condi	tions.				The pipe length is 7.5m.			
Standard a Option part	The data are m			<u> </u>		temperature	External static pr	essure				
Standard a Option part						Outdoor air temperature External static pr			Standards			
Ĕ	Item				DB WB of indoor u			Standards				
Standard a Option part Note (1)	ltem	DB	WB									
Standard a Option part Note (1)	Item				DB 35°C 7°C	0°C	35Pa	in .	ISO5151-T1			

(a) Select the breaker size according to the own national standard.
(b) When wireless remote control is used, fan is 3 speed setting (Hi-Me-Lo) only.
(c) The operation data indicates when the air-conditioner is operated at 230V 50Hz or 220V 60Hz.
(c) The factory E.S.P. setting is set within the range of 80 - 150 Pa.If SW8-4 is turned to "ON", E.S.P. setting range can be changed to 10 - 200 Pa.(For RC-EX1A and RC-E5 only)

Model FDU90VNPVF1

ltom				Model			FDU90	r			
tem Power sourc						Indoor unit FD	U100VF1 Single phase 220-24		Outdoor unit FDC90VNP		
ower source	1	oling capacity	(rongo)	kW			9.0 [1.9(Min.)				
		ating capacity		kW			9.0 [1.5(Min.)				
	Power	ating capacity	Cooling	NVV				65	×.)]		
	consumptio	מר	Heating	kW				25			
		consumption	rieating	NVV.				19			
	Running	consumption	Cooling					/ 12.3			
	current		Heating	А				/ 10.6			
		ent, max currer		~				18.0			
peration	ini don odno		Cooling				97,				
ata	Power facto	or	Heating	%			96,				
	EER		Cooling					40			
	COP		Heating					40 00			
			Cooling				4.				
	Sound pow	ver level				65			69		
			Heating						F 7		
	Sound pres	sure level	Cooling	dB(A)	P-Hi	:44 Hi:38 M	e:36 Lo:30		57		
	· · ·		Heating						55		
		e sound pressu					7.10		Cooling:52 / Heating:50		
		ight × Width ×	Depth)	mm		280 × 1,370	× 740		750 × 880(+88) × 340		
xterior app						_			Stucco White		
Munsell co	olor)							(4.2Y7.5/1.1)near equivalent		
let weight				kg		54			57		
	r type & Q'ty					—		RMT5	118MDE2 (Twin Rotary type)×1		
ompresso	r motor (Sta	rting method)		kW		_			Direct line start		
	oil (Amount,			l		_			0.675 MA68		
efrigerant	(Type, amor	unt, pre-charge	e length)	kg		R410A 2.1kg i	n outdoor unit (incl. t	he amount	t for the piping of : 15m)		
eat exchar					Lou	ver fin & inner g	ooved tubing	M shape fin & inner grooved tubing			
efrigerant	<u> </u>						apillary tubes + Elec				
an type & (Centrifugal 1			Propeller fan ×1		
	Starting met	hod)		W	10	0 + 130 < Direc			86 < Direct line start >		
	otal ling line		Cooling						63		
ir flow			Heating	m³/min	P-Hi	:36 Hi:28 M	e:25 Lo:19		49.5		
	ternal static	Drossuro	ricating	Pa		Standard : 60	lav : 200		0		
utside air i		pressure		ια		Possibl			0		
	ality / Quant	hity.				Procure lo					
	ration absor							Dubbar	alagua /fax fan matar 9 gamproga		
		ber		14/	F	Rubber sleeve(for	Tan motor)	Rubbers	sleeve (for fan motor & compresso		
lectric hea				W							
Operation	Remote co					(option) wire			wireless : RCN-KIT3-E		
control		perature contro					Thermostat b	by electron	ICS		
	Operation of	display					-	_			
						Compre	essor overheat prote	ction, Over	rcurrent protection,		
afety equip	oments				Frost protection, Serial signal error protection, Indoor fan motor error pro						
					He	Heating overload protection (High pressure control), Cooling overloa					
						• ·		9.52 (3/8") Pipe φ 6.35(1/4")×0.8 O/U φ 6.35 (1/4")			
	Refrigerant	piping size (O	.D.)	mm				φ 0.33(1/4)×0.8 0/0 φ 0.33(1/4) b 15.88(5/8")×1.0 O/U φ 15.88 (5/8")			
	Connecting	method				Flare pip	. , , ,	Flare piping			
etallation		,				i iale pip					
		ength of piping		m		—	Neessar				
ata	Insulation for		law att				Necessary (both L		as iines)		
		line (one way)		m	L	00 (0 : :		.30m			
		t diff. between O.	U. and I.U.	m		x.20m (Outdoor	<u> </u>	Ma	ax.20m (Outdoor unit is lower)		
	Drain hose				Hose C		5(I.D.25, O.D.32)		Holes size $\phi 20 \times 3pcs$		
	, max lift hei	-		mm		Built-in Drain p	ump,600		—		
	ded breaker			A				_			
	ked rotor am			A				.0			
	ting wires	Size × Core nur	mber				ncluding earth cable)	/ Termaina	al block (Screw fixing type)		
o number						IPX0			IPX4		
tandard ac	ccessories					Mounting kit, D	rain hose	Dra	ain elbow, Drain hole grommet		
ption parts	S						-				
		e measured at 1	the followi	ng condi	itions.				The pipe length is 7.5m.		
	Item	,		<u> </u>		r temperature	External static pr	assura			
0.	peration	DB	WB		DB	WB	of indoor ur		Standards		
	Cooling	27°C	19°C		35°C	24°C					
\vdash	<u> </u>						60Pa		ISO5151-T1		
							0		1]		
(3)	Sound level		alue in an	anechoi	c chamber		0.	mewhat hi	gher due to ambient conditi		

(4) Select the breaker size according to the own national standard.
(5) When wireless remote control is used, fan is 3 speed setting (Hi-Me-Lo) only.
(6) The operation data indicates when the air-conditioner is operated at 230V 50Hz or 220V 60Hz.
(7) The factory E.S.P. setting is set within the range of 80 - 150 Pa.If SW8-4 is turned to "ON", E.S.P. setting range can be changed to 10 - 200 Pa.(For RC-EX1A and RC-E5 only)

Model FDU90VNPVF2

ltom				Model				/NPVF2				
tem						Indoor unit FD			Outdoor unit FDC90VNP			
Power source		alian aanaaitu	(*******	14147		;	Single phase 220-24					
		oling capacity		kW kW		9.0 [1.9(Min.) ~ 9.0(Max.)] 9.0 [1.5(Min.) ~ 9.0(Max.)]						
		ating capacity	<u>, , , , , , , , , , , , , , , , , , , </u>	KVV		2.65						
	Power	n	Cooling	kW								
	consumptio	consumption	Heating	KVV		<u>2.25</u> 4.19						
	Running	consumption	Cooling									
	current		Heating	А								
		nt, max currer		A			10.1 /					
peration	inirusii curre	int, max currer	Cooling			<u>5, 18.0</u> 97 / 97						
ata	Power facto	or	Heating	%			96 /					
	EER		Cooling				3.4					
	COP		Heating				4.0					
	COP		Cooling				4.	50				
	Sound pow	er level				65			69			
			Heating									
	Sound pres	sure level	Cooling	dB(A)	P-Hi	:44 Hi:38 M	e:36 Lo:30		57			
			Heating						55			
		sound pressu					7.40		Cooling:52 / Heating:50			
		ght × Width ×	Depth)	mm		280 × 1,370	× /40		750 × 880(+88) × 340			
xterior app						_			Stucco White			
Munsell co	lor)							(4	4.2Y7.5/1.1)near equivalent			
let weight				kg		54			57			
	r type & Q'ty					—		RMT5	118MDE2 (Twin Rotary type)×1			
		ting method)		kW		_			Direct line start			
	oil (Amount,			l		_			0.675 MA68			
efrigerant	(Type, amou	int, pre-charge	e length)	kg		R410A 2.1kg i	n outdoor unit (incl. t	he amount	t for the piping of : 15m)			
eat exchar	nger				Lou	uver fin & inner gi		M shape fin & inner grooved tubing				
efrigerant	control					C	apillary tubes + Elect	tronic expa	ansion valve			
an type & (Q'ty					Centrifugal f	an ×3		Propeller fan ×1			
an motor (S	Starting met	nod)		W	1(00 + 130 < Direc	t line start >		86 < Direct line start >			
	v	,	Cooling	37.1					63			
ir flow			Heating	m³/min	P-Hi	:36 Hi:28 N	e:25 Lo:19		49.5			
vailable ex	ternal static	pressure	J	Pa		Standard : 60	/lax : 200		0			
utside air i						Possibl			_			
	ality / Quant	tv				Procure lo			_			
	ration absor	,			F	Rubber sleeve(for	,	Rubber s	sleeve (for fan motor & compresso			
lectric heat				W					_			
	Remote cor	trol				(option) wire	d BC-EX1A BC-E5	BCH-E3	wireless : RCN-KIT3-E			
Operation		erature contro	1			(option) with	Thermostat b					
control	Operation d							_				
		lopidy				0						
					-		essor overheat prote					
afety equip	oments				Frost protection, Serial signal error protection, Indoor fan motor error p							
					Heating overload protection(High pressure control), (· · · ·			
	Defrigerert					Liquid line: I/U	φ 9.52 (3/8") Pipe (¢ 6.35(1/4	")×0.8 O/U <i>\phi</i> 6.35 (1/4")			
	neingerant	piping size (O	.0.)	mm		Gas line: I/U ϕ	15.88 (5/8") Pipe φ	15.88(5/8")×1.0 Ο/U φ 15.88 (5/8")				
	Connecting	method				Flare pipi	ng	Flare piping				
stallation	Attached le	ngth of piping		m		_		—				
ata	Insulation fo	pr piping					Necessary (both L	iquid & Ga	as lines)			
		line (one way)	length	m			Max		,			
		diff. between O.		m	Ма	ax.20m (Outdoor	unit is hiaher)	Ма	ax.20m (Outdoor unit is lower)			
	Drain hose					Connectable VP2	,		Holes size $\phi 20 \times 3pcs$			
rain pump	, max lift heig	aht		mm		Built-in Drain p						
	ded breaker	-		A				_				
	ed rotor am			A			5.	0				
		Size × Core nur	mber			1.5mm ×4 cores (i			al block (Screw fixing type)			
number						IPX0		,	IPX4			
tandard ac					Mounting kit, D	rain hose	Dra	ain elbow, Drain hole grommet				
						wounting Kit, D	un 11035	Dra				
ption parts		monetari	ho fell'		tions		-		The pipe length is 7 for			
		measured at t		<u> </u>					The pipe length is 7.5m.			
	Item	Indoor air t		e (ir temperature	External static pr		Standards			
Op	eration	DB	WB		DB	WB	of indoor ur	nit				
	Cooling	27°C	19°C		35°C	24°C	60Pa		ISO5151-T1			
	Heating	20°C	-		7°C	6°C						
(3)	Sound level		alue in an	anechoi	c chambe			mewhat hig	gher due to ambient conditions.			

(4) Select the breaker size according to the own national standard.
(5) When wireless remote control is used, fan is 3 speed setting (Hi-Me-Lo) only.
(6) The operation data indicates when the air-conditioner is operated at 230V 50Hz or 220V 60Hz.
(7) The factory E.S.P. setting is set within the range of 80 - 150 Pa.If SW8-4 is turned to "ON", E.S.P. setting range can be changed to 10 - 200 Pa.(For RC-EX1A and RC-E5 only)

(4) Duct connected-Low / Middle static pressure type (FDUM) Model FDUM71VNPVF1

			Model			FDUM71			
tem					Indoor unit FD			Outdoor unit FDC71VNP	
Power sour	1					Single phase 220-24			
	Nominal cooling capac	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	kW			7.1 [1.4(Min.)	\sim 7.1(Ma	x.)]	
	Nominal heating capac		kW			7.1 [1.0(Min.)		x.)]	
	Power	Cooling					63		
	consumption	Heating	kW			1.			
	Max power consumption						27		
	Running	Cooling					/ 12.2		
	current	Heating	A			8.8			
peration	Inrush current, max cu					5,			
lata	Power factor	Cooling	%			98 /			
		Heating				97,			
	EER COP	Cooling					70 62		
	COP	Heating				з.	02		
	Sound power level	Cooling			65			67	
		Heating							
	Sound pressure level	Cooling	dB(A)	P-Hi	:38 Hi:33 N	le:29 Lo:25		54	
	· .	Heating							
	Silent mode sound pre					005		49	
	nensions (Height × Width	n × Depth)	mm		280 × 950 :	< 635		640×800(+71)×290	
xterior app					_			Stucco White	
Munsell co	olor)						(-	4.2Y7.5/1.1)near equivalent	
let weight			kg		34			45	
	r type & Q'ty				_		RMT5	113MDE2 (Twin Rotary type)×1	
	r motor (Starting metho	d)	kW		_			Direct line start	
	oil (Amount, type)		l		_			0.45 MA68	
	(Type, amount, pre-cha	arge length)	kg		<u> </u>		the amount for the piping of : 15m)		
leat exchai				Lou	iver fin & inner g		M shape fin & inner grooved tubing		
efrigerant	control				C	apillary tubes + Elec	tronic expa	ansion valve	
an type & (Q'ty				Centrifugal	an ×2		Propeller fan ×1	
an motor (Starting method)		W		130 < Direct li	ne start >		34 < Direct line start >	
ir flow		Cooling Heating	m³/min	P-Hi	:24 Hi:19 M	le:15 Lo:10		36	
vailable ex	ternal static pressure		Pa		Standard : 35	√lax : 100		_	
Outside air i	intake				Possibl				
ir filter, Qu	ality / Quantity				Procure lo	cally		_	
hock & vib	pration absorber			R	Rubber sleeve(for	fan motor)	Rı	ubber sleeve(for Compressor)	
lectric hea	ter		W		_	,			
Oneration	Remote control				(option) wir	ed :RC-EX1A, RC-E5	,RCH-E3	wireless : RCN-KIT3-E	
Operation	Room temperature cor	ntrol				Thermostat b	y electron	ics	
control	Operation display					-	_		
					Compr	essor overheat prote	ction Over	rcurrent protection	
Safety equip	oments			Frost protection, Serial signal error protection, Indoor fan motor error protectio					
arery equi	Jinonto					e 1		I), Cooling overload protection	
	1			пеа	• •			<u>, </u>	
	Refrigerant piping size	(O.D.)	mm				$\phi 6.35(1/4") \times 0.8 \text{ O/U } \phi 6.35(1/4")$		
		. /				. , , ,	φ 12.7(1/2")×0.8 O/U φ 12.7 (1/2")		
	Connecting method				Flare pip	ing	Flare piping		
	Attached length of pipi	ng	m		_		L	—	
ata	Insulation for piping					Necessary (both L		as lines)	
	Refrigerant line (one w		m				.30m		
	Vertical height diff. between	n O.U. and I.U.	m		x.20m (Outdoor		Ma	ax.20m (Outdoor unit is lower)	
	Drain hose			Hose C	onnectable VP2	5 (I.D.25, O.D.32)		Holes size ϕ 20 x 5pcs	
rain pump	, max lift height		mm		Built-in Drain p	ump,600		—	
lecommen	ded breaker size		A			-			
R.A. (Lock	ked rotor ampere)		Α			5	.0		
terconnec	ting wires Size × Core	number			1.5mm [*] ×4 cores (i	ncluding earth cable)	/ Termaina	al block (Screw fixing type)	
^o number					IPX0		IPX4		
tandard ad	ccessories				Mounting kit, D	rain hose	Dra	ain elbow, Drain hole grommet	
ption parts					<u> </u>	UM-F			
	The data are measured	at the followi	na condi	tions.		2.001		The pipe length is 7.5m.	
		air temperatu	<u> </u>		r temperature	External static pr	ASSUIRA		
0.	peration DB	WB		DB	WB	of indoor ur		Standards	
	Cooling 27°C	19°C		35°C	24°C				
						35Pa		ISO5151-T1	
								<u> </u>	
(3)	Heating 20°C This air-conditioner is m	nanufactured ne value in an	and test	7°C ed in confo c chamber.	6°C ormity with the IS . During operation	60.	mewhat hi	ISO5151-T1 gher due to ambient cor	

(4) Select the breaker size according to the own hautona standard.
(5) When wireless remote control is used, fan is 3 speed setting (Hi-Me-Lo) only.
(6) The operation data indicates when the air-conditioner is operated at 230V 50Hz or 220V 60Hz.
(7) Static pressure of optional air filter "UM-FL2EF" is 5Pa initially.
(8) The external static pressure setting can be changed to 10-100Pa. (For RC-EX1A and RC-E5 only)

PJG000Z159

Model FDUM90VNPVF1

				Model			FDUM90					
Item					lı	Indoor unit FDUM100VF1 Outdoor unit FDC90VNP Single phase 220-240V 50Hz / 220V 60Hz						
Power source	1				Single phase 220-240V 50Hz / 220V 60Hz 9.0 [1.9(Min.) ~ 9.0(Max.)]							
		oling capacity		kW								
		ating capacity	<u> </u>	kW		9.0 [1.5(Min.) ~ 9.0(Max.)] 2.65						
	Power		Cooling				2.					
	consumptio		Heating	kW								
	<u> </u>	consumption	1				4.					
	Running		Cooling				11.8 /					
	current		Heating	A			10.1 /					
Operation	Inrush curre	nt, max curre	nt				5,					
	Power facto	r	Cooling	%			97 /					
Jala	FOWER IACIO	1	Heating	70			96 /	96				
	EER		Cooling				3.4	40				
	COP		Heating]			4.0	00				
	0		Cooling			05			60			
	Sound powe	er level	Heating	1		65			69			
1			Cooling	dB(A)					57			
	Sound press	sure level	Heating		P-Hi	:44 Hi∶38 N	1e:36 Lo:30		55			
	Silent mode	sound pressu	0	1					Cooling:52 / Heating:50			
		ght × Width ×		mm		280 × 1370	× 740		750 × 880(+88) × 340			
Exterior app						200 / 1010			Stucco White			
						—		()				
Munsell co	101)			1.00		54		(2	4.2Y7.5/1.1)near equivalent			
Net weight				kg				DIATE	57			
	r type & Q'ty			1.347		—		RM15	118MDE2 (Twin Rotary type)×1			
	r motor (Star	<u> </u>		kW		_			Direct line start			
	oil (Amount,			l					0.675 MA68			
		nt, pre-charge	e length)	kg					for the piping of : 15m)			
leat exchar					Lou	ver fin & inner g		M shape fin & inner grooved tubing				
Refrigerant of							apillary tubes + Elec					
an type & C						Centrifugal			Propeller fan ×1			
an motor (Starting meth	nod)		W	10	0 + 130 < Direc	ct line start >		86 < Direct line start >			
A : 61			Cooling	m³/min	DU	. 00 LE: 00 N			63			
Air flow			Heating	m'/min	P-HI	:36 Hi:28 N	1e · 25 L0 · 19		49.5			
Available ex	ternal static	oressure		Pa		Standard : 60 I	Max : 100		0			
Outside air i						Possibl			_			
	ality / Quanti	tv				Procure lo			_			
	ration absorb				R	ubber sleeve(for		Rubber s	leeve (for fan motor & compresso			
Electric heat				w			nan motory					
	Remote con	trol		~~		(option) wir	od PC EVIA DC E5		wireless : RCN-KIT3-E			
Operation		erature contro	.1			(option) wit	Thermostat b					
control			1				mennostat L	y electroni	65			
	Operation d	ispiay						-				
							essor overheat prote					
Safety equip	oments				Frost protection, Serial signal error protection, Indoor fan motor error prot							
					Hea	ating overload p	rotection(High press	ure control), Cooling overload protection			
1				i		Liquid line: I/U	φ 9.52 (3/8") Pipe	⊅ 6.35(1/4"	")×0.8 Ο/U φ 6.35 (1/4")			
	Retrigerant	oiping size (C	D.D.)	mm				15.88(5/8")×1.0 O/U φ 15.88 (5/8")				
ļ	Connecting	method				Flare pip		Flare piping				
nstallation	<u>v</u>	ngth of piping		m								
data	Insulation fo						Necessary (both L	iquid & Go	s lines)			
auu		line (one way	longth	m			Max.		0 11100/			
		diff. between O			Max	.20m (Outdoor			x.20m (Outdoor unit is lower)			
	Drain hose	um. Detween O	.o. and 1.0.	m			th VP25(O.D.32)	ivia				
Drain num-		.bt		-	riuse	Built-in Drain p	· · · ·		Holes size ϕ 20 x 3pcs			
	, max lift heig			mm		Built-In Drain p	ump,000					
	ded breaker			A								
	ked rotor amp	,	1	A		4 F = ²	5.	-				
	ting wires S	ize × Core nu	mber			,	ncluding earth cable)	/ Termaina	I block (Screw fixing type)			
P number						IPX0			IPX4			
Standard ac						Mounting kit, D			in elbow, Drain hole grommet			
							UM-F	L3EF				
Option parts	The data are	measured at	the followi	ng cond	tions.				The pipe length is 7.5m.			
Option parts	Note (1) The data are measured at the follow				Outdoor air	temperature	External static pr	essure	Oten dend			
Option parts	Item				DB	WB	of indoor ur		Standards			
Option parts Note (1)		DB	WB				2					
Option parts Note (1)	peration	DB			35°C	24°C						
Option parts Note (1) ⁻ Op	beration Cooling	DB 27°C	19°C		<u>35°C</u> 7°C	24°C 6°C	60Pa		ISO5151-T1			
Option parts Note (1) Op	Cooling Heating	DB 27°C 20°C	19°C —		7°C	24°C 6°C rmity with the IS			ISO5151-T1			

(4) Select the breaker size according to the own hardinar standard.
(5) When wireless remote control is used, fan is 3 speed setting (Hi-Me-Lo) only.
(6) The operation data indicates when the air-conditioner is operated at 230V 50Hz or 220V 60Hz.
(7) Static pressure of optional air filter "UM-FL2EF" is 5Pa initially.
(8) The external static pressure setting can be changed to 10-100Pa. (For RC-EX1A and RC-E5 only)

PJG000Z159

Model FDUM90VNPVF2

			Model		FDUM90VNPVF2 Indoor unit FDUM100VF2 Outdoor unit FDC90VNP						
ce		()	1.14/			Single phase 220-24					
	<u> </u>										
	ating capacity	<u>, , , , , , , , , , , , , , , , , , , </u>	KVV			/		ax.)]			
	-										
<u> </u>		Heating	KVV								
	consumption										
			А								
Inrush curre	nt, max currer	1									
Power facto	or		%								
							-				
COP						4.	00				
Sound pow	er level				65			69			
· · ·		-									
Sound pres	sure level		dB(A)	P-Hi	:44 Hi:38 M	le:36 Lo:30		57			
								55			
					—			Cooling:52 / Heating:50			
	ght × Width ×	Depth)	mm		280 × 1370	× 740		750 × 880(+88) × 340			
pearance			7		_			Stucco White			
olor)							(4.2Y7.5/1.1)near equivalent			
			kg		54			57			
r type & Q'ty					_		RMT5	5118MDE2 (Twin Rotary type)×1			
			kW		_			Direct line start			
oil (Amount,	type)		l		_			0.675 MA68			
(Type, amou	unt, pre-charge	e length)	kg		R410A 2.1kg i	n outdoor unit (incl. t					
				Lou	<u> </u>			hape fin & inner grooved tubing			
0											
		-						Propeller fan ×1			
	nod)		W	10				86 < Direct line start >			
otal ling mot	104)	Cooling		10				63			
		-	m³/min	P-Hi	:36 Hi:28 M	le:25 Lo:19		49.5			
	Drossuro	ricating	Pa		Standard : 60	Max : 100		0			
	pressure		īα					0			
	ity										
							Dubbor	sleeve (for fan motor & compresso			
	Jei		14/			Tan motor)	nubbei				
			VV								
					(option) wire						
		<u> </u>				Thermostat c	by electron	lics			
Operation of	ispiay					-					
pments				Frost protection, Serial signal error protection, Indoor fan motor error pro							
				He	ating overload p), Cooling overload protection					
<u> </u>					Liquid line: I/U	φ 9.52 (3/8") Pipe					
Refrigerant	piping size (O	.D.)	mm								
Connecting	method						Flare piping				
			m			3					
	<u> </u>					Necessary (both I	iauid & G	as lines)			
		length	m					uo micoj			
				Ma	x 20m (Outdoor			ax.20m (Outdoor unit is lower)			
	. um. perween O.	0. and 1.0.				<u> </u>	IVI				
	abt		mm	nuse		· /		Holes size ϕ 20 x 3pcs			
					Built-in Drain p	ump,600					
						-					
R.A. (Locked rotor ampere)					1 Em ² 4 "						
sting wires S	ize × Core nui	mber				ncluding earth cable)	/ Termaina				
IP number								IPX4			
					Mounting kit, D			ain elbow, Drain hole grommet			
S						UM-F	L3EF				
The data are	e measured at t	the followi	ng condi	tions.				The pipe length is 7.5m.			
Item	Indoor air t	emperatur	e (Outdoor aii	r temperature	External static pr	essure	Standards			
				DB	WB	of indoor u		Stanuarus			
	Operation DB WB										
	27°C	19°C		35°C	24°C	60D-	ISO5151-T1				
peration				35°C 7°C	24°C 6°C	60Pa		ISO5151-T1			
	Nominal coo Nominal hea Power consumptio Max power Running current Inrush curren Power facto EER COP Sound power Sound power S	Nominal cooling capacity Nominal heating capacity Power consumption Max power consumption Running current Inrush current, max currer Power factor EER COP Sound power level Sound pressure level Silent mode sound pressumensions (Height × Width × bearance bolor) port type & Q'ty or motor (Starting method) oil (Amount, type) (Type, amount, pre-charge intake iality / Quantity poration absorber intake iality / Quantity poration absorber itter Remote control Room temperature contro Operation display pments Refrigerant piping size (O Connecting method Attached length of piping Insulation for piping Refrigerant line (one way) Vertical height diff. between O. Drain hose o, max lift height ded breaker size ked rotor ampere) <td< td=""><td>Nominal cooling capacity (range) Nominal heating capacity (range) Power Cooling consumption Heating Max power consumption Running Running Cooling current Heating Inrush current, max current Power factor Power factor Cooling EER Cooling COP Heating Sound power level Cooling Heating Gooling Sound pressure level Cooling Heating Cooling Sound pressure level Cooling Heating Cooling Sound pressure level Heating Sound pressure level Cooling remsions (Height × Width × Depth) Depth) Dearance Oor) oil (Amount, type) (Type, amount, pre-charge length) inger control Q'ty Starting method) Gooling Heating Retring method) Cooling Redity / Quantity Datatic pressure ratake Intake I</td><td>Nominal cooling capacity (range) kW Nominal heating capacity (range) kW Power Cooling consumption Heating Running Cooling current Heating Inrush current, max current Heating Power factor Cooling EER Cooling COP Heating Sound power level Cooling Heating Cooling Sound pressure level Cooling Max power consumption Kg Silent mode sound pressure level mm bestrance kg or type & Q'ty kg red type, amount, pre-charge length) kg nger cooling control Q'ty Starting method) W Maxemate m³/min Maternal static pressure Pa intake maity / Quantity oration absorber W Remote control Mixemate Room temperature control Operation display</td><td>Nominal cooling capacity (range) kW Nominal heating capacity (range) kW Power Cooling consumption Heating Max power consumption KW Running Cooling current Heating Power factor Cooling Heating % EER Cooling COP Heating Sound power level Heating Bound pressure level Cooling Heating B(A) Sound pressure level Heating Sound pressure level Cooling Heating B(A) P-Hi P-Hi Silent mode sound pressure level mm nearance kg or motor (Starting method) kW oil (Amount, type) l (Type, anount, pre-charge length) kg nger Lou control W Qity Starting method) W Starting method) W 10 Maxe P-Hi Refrigerant piping size (O.D.)</td><td>Nominal cooling capacity (range) KW Nominal heating capacity (range) KW Power Cooling consumption Heating Running Cooling current Heating Power factor Cooling Power factor Cooling Power factor Cooling Sound power level Cooling Heating MB(A) Sound pressure level Cooling Heating MB(A) Silent mode sound pressure level — heating MB(A) Silent mode sound pressure level — heating MG(A) Vertype & Q'ty — r type & Q'ty —</td><td>Nominal cooling capacity (range) KW 9.0 [1.9(Min.) Nominal heating capacity (range) KW 9.0 [1.5(Min.) Power Cooling consumption KW 9.0 [1.5(Min.) Running Cooling current KW 2.2 Running Cooling current KW 2.2 Power factor Heating Heating 4 Power factor Cooling Heating 96 COP Heating 4. Sound pressure level Cooling Heating 65 Sound pressure level Cooling Heating </td><td>INominal cooling capacity (range)kW9.0 [1.9(Min) \sim 9.0(MaNominal heating capacity (range)kW9.0 [1.5(Min) \sim 9.0(MaPowerCooling consumption2.65Max power consumption4.19RunningCooling urrent11.8 / 12.3CurrentHeatingAPower factorCooling Heating96 / 96EERCooling Heating96 / 96COPHeating Heating65Sound pressure levelCooling HeatingSound pressure levelCooling HeatingSound pressure levelCooling HeatingSound pressure levelCooling HeatingSound pressure levelCooling HeatingSound pressure levelCooling HeatingSound pressure level(fYpe, amount, pre-charge length) rm motor (Starting method)kgR410A2.1kg in outdoor unit (incl. the amoun ngerId (Amount, type)((Type, & Q'tyRefigerant bildigm²/min P-Hi : 36 Hi : 28 Me : 25 Lo : 19Heatingm²/min HeatingProcure locallyP-Hi : 36 Hi : 28 Me : 26 Lo : 30Id (Amount, type)Refigerant piping size (O.D.)mMathed length / QuantityP-Hi : 36 Hi : 28 Me : 25 Lo : 19HeatingP-Hi : 36 Hi : 28 Me : 25 Lo : 19HeatingP-Hi : 36 Hi : 28 Me : 26 Lo : 19HeatingRubber sleeve(for fan motor)</td></td<>	Nominal cooling capacity (range) Nominal heating capacity (range) Power Cooling consumption Heating Max power consumption Running Running Cooling current Heating Inrush current, max current Power factor Power factor Cooling EER Cooling COP Heating Sound power level Cooling Heating Gooling Sound pressure level Cooling Heating Cooling Sound pressure level Cooling Heating Cooling Sound pressure level Heating Sound pressure level Cooling remsions (Height × Width × Depth) Depth) Dearance Oor) oil (Amount, type) (Type, amount, pre-charge length) inger control Q'ty Starting method) Gooling Heating Retring method) Cooling Redity / Quantity Datatic pressure ratake Intake I	Nominal cooling capacity (range) kW Nominal heating capacity (range) kW Power Cooling consumption Heating Running Cooling current Heating Inrush current, max current Heating Power factor Cooling EER Cooling COP Heating Sound power level Cooling Heating Cooling Sound pressure level Cooling Max power consumption Kg Silent mode sound pressure level mm bestrance kg or type & Q'ty kg red type, amount, pre-charge length) kg nger cooling control Q'ty Starting method) W Maxemate m³/min Maternal static pressure Pa intake maity / Quantity oration absorber W Remote control Mixemate Room temperature control Operation display	Nominal cooling capacity (range) kW Nominal heating capacity (range) kW Power Cooling consumption Heating Max power consumption KW Running Cooling current Heating Power factor Cooling Heating % EER Cooling COP Heating Sound power level Heating Bound pressure level Cooling Heating B(A) Sound pressure level Heating Sound pressure level Cooling Heating B(A) P-Hi P-Hi Silent mode sound pressure level mm nearance kg or motor (Starting method) kW oil (Amount, type) l (Type, anount, pre-charge length) kg nger Lou control W Qity Starting method) W Starting method) W 10 Maxe P-Hi Refrigerant piping size (O.D.)	Nominal cooling capacity (range) KW Nominal heating capacity (range) KW Power Cooling consumption Heating Running Cooling current Heating Power factor Cooling Power factor Cooling Power factor Cooling Sound power level Cooling Heating MB(A) Sound pressure level Cooling Heating MB(A) Silent mode sound pressure level — heating MB(A) Silent mode sound pressure level — heating MG(A) Vertype & Q'ty — r type & Q'ty —	Nominal cooling capacity (range) KW 9.0 [1.9(Min.) Nominal heating capacity (range) KW 9.0 [1.5(Min.) Power Cooling consumption KW 9.0 [1.5(Min.) Running Cooling current KW 2.2 Running Cooling current KW 2.2 Power factor Heating Heating 4 Power factor Cooling Heating 96 COP Heating 4. Sound pressure level Cooling Heating 65 Sound pressure level Cooling Heating	INominal cooling capacity (range)kW9.0 [1.9(Min) \sim 9.0(MaNominal heating capacity (range)kW9.0 [1.5(Min) \sim 9.0(MaPowerCooling consumption2.65Max power consumption4.19RunningCooling urrent11.8 / 12.3CurrentHeatingAPower factorCooling Heating96 / 96EERCooling Heating96 / 96COPHeating Heating65Sound pressure levelCooling HeatingSound pressure levelCooling HeatingSound pressure levelCooling HeatingSound pressure levelCooling HeatingSound pressure levelCooling HeatingSound pressure levelCooling HeatingSound pressure level(fYpe, amount, pre-charge length) rm motor (Starting method)kgR410A2.1kg in outdoor unit (incl. the amoun ngerId (Amount, type)((Type, & Q'tyRefigerant bildigm ² /min P-Hi : 36 Hi : 28 Me : 25 Lo : 19Heatingm ² /min HeatingProcure locallyP-Hi : 36 Hi : 28 Me : 26 Lo : 30Id (Amount, type)Refigerant piping size (O.D.)mMathed length / QuantityP-Hi : 36 Hi : 28 Me : 25 Lo : 19HeatingP-Hi : 36 Hi : 28 Me : 25 Lo : 19HeatingP-Hi : 36 Hi : 28 Me : 26 Lo : 19HeatingRubber sleeve(for fan motor)			

(4) Select the breaker size according to the own national standard.
(5) When wireless remote control is used, fan is 3 speed setting (Hi-Me-Lo) only.
(6) The operation data indicates when the air-conditioner is operated at 230V 50Hz or 220V 60Hz.
(7) Static pressure of optional air filter "UM-FL2EF" is 5Pa initially.
(8) The external static pressure setting can be changed to 10-100Pa. (For RC-EX1A and RC-E5 only)

PJG000Z159/J

(5) Floor standing type (FDF) Model FDF71VNPVD1

ltow			Mode				/NPVD1				
tem				+	Indoor unit FI		Outdoor unit FDC71VNP 0V 50Hz / 220V 60Hz				
Power sour	ce Nominal cooling cap	acity (range)	kW								
	Nominal heating cap		kW	_			$(\sim 7.1(Max))$				
	Power	Coolin			7.1 [1.0(Min.) ~ 7.1(Max.)] 2.63						
	consumption	Heatin	<u> </u>		2.08						
	Max power consump				3.27						
	Running	Coolin	1		11.7 / 12.2						
	current	Heatin	<u> </u>		9.3 / 9.8						
	Inrush current, max of				5, 14.5						
Operation		Coolin			-	,	/ 98				
data	Power factor	Heatin					/ 97				
	EER	Coolin					70				
	COP	Heatin					41				
		Coolin				0.					
	Sound power level	Heatin			61		67				
	Sound pressure leve	Coolin	dB(A)	P-Hi	:42 Hi:39 M	e:35 lo:33	54				
	· ·	Heatin	3			C : 00 E0 : 00					
	Silent mode sound p						49				
	nensions (Height × Wi	dth × Depth)	mm	1	1,850 × 600		640×800(+71)×290				
Exterior app					Ceramic V	Vhite	Stucco White				
Munsell co	olor)			1	(N8.0)near eo	quivalent	(4.2Y7.5/1.1) near equivalent				
Net weight			kg		49		45				
Compresso	r type & Q'ty				_		RMT5113MDE2 (Twin Rotary type)×1				
	r motor (Starting meth	nod)	kW		_		Direct line start				
	oil (Amount, type)		l				0.45 MA68				
	(Type, amount, pre-c	harge length)	kg		<u> </u>		the amount for the piping of : 8m)				
Heat excha	nger			Lou	ver fin & inner g		M shape fin & inner grooved tubing				
Refrigerant	control						tronic expansion valve				
Fan type & (Centrifugal	fan ×1	Propeller fan ×1				
Fan motor (Starting method)		W		157 < Direct li	ne start >	34 < Direct line start >				
Air flow		Coolin Heatin	<u> </u>	n P-Hi	:20 Hi:18 M	e:16 Lo:14	36				
Available ex	ternal static pressure		Pa	-	0						
Outside air					Not poss	ible	_				
	ality / Quantity				Plastic net ×1(V		_				
	pration absorber			B	ubber sleeve(for	r fan motor)	Rubber sleeve(for Compressor)				
Electric hea			W		_		_				
o	Remote control				RC-E	5 (Installed) / wir	eless : RCN-KIT3-E (option)				
Operation	Room temperature c	ontrol					by electronics				
control	Operation display					-					
					Compr	essor overheat prote	ction, Overcurrent protection,				
Safety equip	oments			Fro			ection, Indoor fan motor error protection,				
						e 1	sure control), Cooling overload protection				
	1		-	1186							
	Refrigerant piping size	ze (O.D.)	mm	-			ϕ 6.35(1/4")×0.8 O/U ϕ 6.35(1/4")				
	Connecting method		_		Gas line: I/U ϕ 15.88 (5/8") Pipe ϕ 12.7(1/2")×0.8 O/U ϕ 12.7 (1/2")						
Installation	Connecting method	ining			Flare piping Flare piping						
	Attached length of p	ihilià	m			Noocoor (iguid & Cap lines)				
data	Insulation for piping						_iquid & Gas lines)				
	Refrigerant line (one		m		(00mg (0::+-!-		.23m May 20m (Outdoor unit is lawar)				
	Vertical height diff. betw	een 0.0. and 1.0	. m	IVIAX	k.20m (Outdoor Hose Connecta		Max.20m (Outdoor unit is lower)				
Drain	Drain hose				Hose Connecta		Holes size $\phi 20 \times 5pcs$				
	, max lift height		mm								
	ded breaker size		A			-	0				
	ked rotor ampere)		A		4 F m ² · · · 4		.0				
	ting wires Size x Co	e number		+		including earth cable	e)/ Termainal block(Screw fixing type)				
P number					IPX0	. 1.:+	IPX4				
Standard ad					Mounting	j Kil	Drain elbow, Drain hole grommet				
Option parts		1 1 1 1 1 1				-	-				
Note (1)	The data are measure						The pipe length is 7.5m.				
		r air tempera			temperature	St	andards				
	peration DB	M		DB	WB		andards				
Or	Cooling 27°C		Č	35°C	24°C	ISC	05151-T1				
Or		· I _	-	7°C	6°C	.00					
Or	Heating 20°C	/									
			d and tes	sted in confo	rmity with the IS	SO.					
(2)	Heating 20°C This air-conditioner is Sound level indicates	manufacture					mewhat higher due to ambient				
(2) (3)	Heating 20°C This air-conditioner is Sound level indicates conditions.	manufacture the value in	in anech	oic chamber.	. During operation		mewhat higher due to ambient				
(2) (3) (4)	Heating20°CThis air-conditioner isSound level indicatesconditions.Select the breaker siz	manufacture the value in e according	in anech o the ow	oic chamber. n national sta	During operation	on these value are so	mewhat higher due to ambient				
(2) (3) (4) (5)	Heating 20°C This air-conditioner is Sound level indicates conditions.	manufacture the value in e according e control is us	in anech o the ow ed, fan is	oic chamber. n national sta s 3 speed set	. During operatio andard. tting (Hi-Me-Lo)	on these value are so only.	-				

Model FDF90VNPVD1

Item				Model		Indoor unit FD	FDF90\ F100VD1	Outdoor unit F				
Power sour	ce							Outdoor unit F 0V 50Hz / 220V 60Hz				
rower sour		oling capacity	(rango)	kW			9.0 [1.9(Min.)					
		ating capacity		kW			9.0 [1.5(Min.)					
		ating capacity	<u> </u>	KVV			/					
	Power		Cooling					79				
	consumptio		Heating	kW				25				
	<u> </u>	consumption	0 "			4.19						
	Running		Cooling			12.4 / 13.0						
	current		Heating	A		10.1 / 10.6						
Operation	Inrush curre	ent, max currer	nt			5, 18.0						
data	Power facto	or.	Cooling	%		97 / 97						
ala			Heating	70			96 /	96				
	EER		Cooling				3.	23				
	COP		Heating				4.	00				
			Cooling		İ	05						
	Sound pow	er level	Heating			65		69				
			Cooling	dB(A)				57				
	Sound pres	sure level	Heating	GD() ()	P-Hi	:54 Hi:50 M	e:48 Lo:44	55				
	Silont mode	e sound pressu	0					Cooling:52 / H	oating:50			
utorior din						1 950 600						
		ight × Width ×	Deptn)	mm		1,850 × 600		750 × 880(+8				
Exterior app						Ceramic V		Stucco W				
Munsell co	olor)				ļ	(N8.0)near eo	quivalent	(4.2Y7.5/1.1)nea	r equivalent			
let weight				kg		52		57				
	r type & Q'ty					_		RMT5118MDE2 (Twir	Rotary type)×1			
Compresso	r motor (Star	ting method)		kW		_		Direct line	start			
Refrigerant	oil (Amount,	type)		l		_		0.675 MA	468			
		unt, pre-charge	e lenath)	kġ		R410A 2.1ka	in outdoor unit (incl.	the amount for the piping of	of:8m)			
leat excha					Lou	ver fin & inner g			/			
Refrigerant	0							M shape fin & inner grooved tubing tronic expansion valve				
an type &						Centrifugal		Propeller fa	n v1			
	Starting met	had)		W		157 < Direct li		86 < Direct lin				
an motor (Starting met	100)	0 "	VV		157 < Direct III	ie start >		ie start >			
Air flow			Cooling	m³/min	P-Hi	:29 Hi:26 M	e:23 Lo:19	63				
			Heating	-				49.5				
	ternal static	pressure		Pa		0		0				
Dutside air						Not poss						
Air filter, Qu	ality / Quant	ity				Plastic net ×1(V	Vashable)					
Shock & vit	pration absor	ber			R	ubber sleeve(for	r fan motor)	Rubber sleeve (for fan m	otor & compresso			
Electric hea	iter			W		_		_				
0	Remote cor	ntrol			1	RC-E5	(Installed) / wire	eless : RCN-KIT3-E (option)			
Operation	Room temp	erature contro						y electronics				
control	Operation c						-	_				
Safety equi	pments					ost protection, S ating overload p	erial signal error prot rotection(High press	ction, Overcurrent protection ection, Indoor fan motor en sure control), Cooling over	ror protection, load protection			
	Refrigerant	piping size (O	(D)	mm				φ 6.35(1/4")×0.8 O/U φ 6.				
			,					15.88(5/8")×1.0 Ο/U φ 15	. ,			
	Connecting	method				Flare pip	ing	Flare pip	ing			
nstallation	Attached le	ngth of piping		m								
lata	Insulation for	or piping					Necessary (both L	iquid & Gas lines)				
		line (one way)	length	m				.23m				
		t diff. between O.		m	Ma	x.20m(Outdoor			Max.20m(Outdoor unit is lower)			
	Drain hose					ose Connectabl		Holes size $\phi 2$,			
Drain numr	, max lift hei	aht		mm			-		- P			
	ded breaker	•		A			-	_				
	ked rotor am			A			E	.0				
1		,	mber	~		1 5mm 4 00000 (!			ving type)			
	ung wires S	Size × Core nu	nber			,	including earth cable)	/ Termainal block(Screw fit	хіну туре)			
P number	· · · ·					IPX0		IPX4				
	ccessories					Mounting kit, D	rain nose	Drain elbow, Drain	noie grommet			
Option part							-	-				
Note (1)	The data are	e measured at	the followi	ng cond	itions.			The pipe length is 7.5m.				
	/ Item	Indoor air t	emperatur	e	Outdoor air	temperature	~	anderde				
0	peration	DB	WB		DB	WB	Sta	andards				
	Cooling	27°C	19°C		35°C	24°C		5454 T4				
F	Heating	20°C	-		7°C	6°C	ISC	5151-T1				
	This air-cond	ditioner is man	ufactured		ed in confo	rmity with the IS		mewhat higher due to amb	ient			
(5)	Select the bi When wirele		trol is used	l, fan is	3 speed set	tting (Hi-Me-Lo)	only. IV 50Hz or 220V 60H	Z.				

PGA000Z812

Model FDF90VNPVD2

••				Model			FDF90V					
Item						Indoor unit FD		Outdoor unit FD	C90VNP			
Power sour	1	1	(1.34/				OV 50Hz / 220V 60Hz				
		ling capacity ting capacity		kW kW			9.0 [1.9(Min.) 9.0 [1.5(Min.)					
	Power	ting capacity	Cooling	KVV			/	~ 9.0(Max.)] 79				
	consumption		Heating	kW			2.2					
	· · · · · · · · · · · · · · · · · · ·	onsumption	Theating	, rvv				19				
	Running	onsumption	Cooling			12.4 / 13.0						
	current		Heating	A			10.1 /					
		nt, max currei				5, 18.0						
Operation		,	Cooling			97/97						
data	Power factor		Heating	%			96 /					
	EER		Cooling					23				
	COP		Heating				4.0	00				
			Cooling			05		20				
	Sound powe	rievei	Heating	1		65		69				
			Cooling	dB(A)	D.L.			57				
	Sound press	ure level	Heating		P-HI	:54 Hi:50 M	e · 48 LO · 44	55				
	Silent mode	sound pressu	ire level	1		_		Cooling:52 / Hea	ting:50			
Exterior dim	nensions (Heig	ht × Width ×	Depth)	mm		1,850 × 600	× 320	750 × 880(+88)				
Exterior app	bearance					Ceramic W	/hite	Stucco Whi	te			
Munsell co	olor)					(N8.0)near ec	uivalent	(4.2Y7.5/1.1)near e	equivalent			
Vet weight				kg		52		57				
<u> </u>	r type & Q'ty							RMT5118MDE2 (Twin F	Rotary type)×1			
	r motor (Start	ing method)		kW		— Direct line sta						
Refrigerant	oil (Amount, t	ype)		l		_		0.675 MA6	8			
Refrigerant	(Type, amou	nt, pre-charge	e length)	kg		R410A 2.1kg	in outdoor unit (incl.	the amount for the piping of	: 8m)			
leat excha	nger				Louv	Louver fin & inner grooved tubing M shape fin & inner grooved tub						
Refrigerant	control					C	apillary tubes + Elect	tronic expansion valve	ŭ			
an type &	Q'ty					Centrifugal f	an ×1	Propeller fan	×1			
an motor (Starting meth	od)		W		157 < Direct lir	ne start >	86 < Direct line	start >			
, , , , , , , , , , , , , , , , , , ,		,	Cooling	37 .				63				
Air flow			Heating	m³/min	P-Hi	:29 Hi:26 M	e:23 Lo:19	49.5				
Available ex	kternal static p	oressure		Pa		0		0				
Dutside air						Not possi	ble					
Air filter, Qu	ality / Quantit	у				Plastic net ×1(V	/ashable)					
Shock & vib	oration absorb	er			Ri	ubber sleeve(for	fan motor)	Rubber sleeve (for fan mot	or & compresso			
Electric hea	iter			W		_	,					
Oneration	Remote con	trol				RC-E5	(Installed) / wire	eless : RCN-KIT3-E (option)				
Operation	Room tempe	erature contro	ol				Thermostat b	y electronics				
control	Operation di	splay					_	_				
						Compre	essor overheat prote	ction, Overcurrent protection				
Safety equi	oments				Fro			ection, Indoor fan motor erro	,			
salety equi	prinointo						• ·	sure control), Cooling overloa				
	1					° 1	(φ 6.35(1/4")×0.8 O/U φ 6.35				
	Refrigerant p	oiping size (C	.D.)	mm								
	Connecting	mathad						15.88(5/8")×1.0 Ο/U φ 15.88 (5/8") Flare piping				
notallation	Connecting					Flare pipi	ng					
	Attached len			m		_	NI /h - +h - l	 Liquid & Gas lines)				
data	Insulation fo											
		ine (one way)		m		00 (0 1 1	Max.					
		diff. between O	.U. and I.U.	m		20m(Outdoor u	v /	Max.20m(Outdoor ur	,			
Decis	Drain hose	b.t			НС	se Connectable	e with VP20	Holes size ϕ 20	× 3pcs			
	, max lift heig			mm		_		—				
	ded breaker s			A			-	-				
	ked rotor amp	/		A		1 Emm ² 1 /	5.					
nterconnec P number	ting wires S	ze x Gore nu	IIINGL			1.5mm×4 cores(II IPX0	iciuuling earth cable)	/ Termainal block(Screw fixir IPX4	ig type)			
P number Standard ad							rain hoso	Drain elbow, Drain ho	lo grommet			
						Mounting kit, D	ann nose	Drain elbow, Drain no	e gronnet			
Option parts			+ho fell-: '		l		-	The pipe length is 7 Fr				
INOTE (1)	The data are			<u> </u>				The pipe length is 7.5m.				
	Item	Indoor air t		e		temperature	Sta	andards				
I.	peration	DB	WB		DB	WB						
O	Cooling 27°C 19°				35°C	24°C	ISO	5151-T1				
Or					7°C	6°C						
	Heating	20°C					-					
(2)	Heating This air-cond	itioner is man	ufactured			mity with the IS						
(2)	Heating This air-cond Sound level i	itioner is man	ufactured					mewhat higher due to ambie	nt			
(2) (3)	Heating This air-cond Sound level in conditions.	itioner is man ndicates the v	ufactured value in an	anechoi	c chamber.	During operatio		mewhat higher due to ambie	nt			
(2) (3) (4)	Heating This air-cond Sound level in conditions. Select the bro	itioner is man ndicates the v eaker size acc	ufactured value in an	anechoi the own	c chamber. national sta	During operatio	on these value are so	mewhat higher due to ambie	nt			

(6) The operation data indicates when the air-conditioner is operated at 230V 50Hz or 220V 60Hz.


PGA000Z812

(6) Wall mounted type (SRK) Model SRK71VNPZM

				Model				VNPZM				
tem						Indoor unit SR		Outdoor unit F	DC71VNP			
ower sour			()	1.14/				0V 50Hz / 220V 60Hz				
		oling capacity		kW				$) \sim 7.1(Max.)]$				
		ating capacity	<u>, , , , , , , , , , , , , , , , , , , </u>	kW				$) \sim 7.1$ (Max.)]				
	Power	_	Cooling			<u> </u>						
	consumptio		Heating	kW								
	· · · · · · · · · · · · · · · · · · ·	consumption	0 1			<u>3.27</u> 10.9 / 10.5						
	Running		Cooling			8.8 / 8.4						
	current		Heating	A								
Operation	Inrush curre	nt, max curre					14.5					
data	Power facto	r	Cooling	%				/ 98				
			Heating					/ 97				
	EER		Cooling					01				
	COP		Heating				3.	78				
	Sound powe	er level	Cooling			60		67				
	·		Heating	15(4)		61						
	Sound pres	sure level	Cooling	dB(A)		49 Me: 45 Lo		54				
			Heating		Hi :	46 Me:43 Lo	:38 ULo:35	-				
	Silent mode	sound pressu	ure level			-		49				
=xterior dim	ensions (Hei	ght × Width ×	Depth)	mm		318 × 1098	× 248	640×800(+7	1)×290			
		g.it A Width A	20000				-		,			
Exterior app						Fine sno		Stucco W				
Munsell co	olor)				(8.0Y 9.3/0.1)nea	r equivalent	(4.2Y7.5/1.1)nea	ar equivalent			
Net weight				kg		16		45				
Compresso	r type & Q'ty					_		RMT5113MDE2 (Twir	Rotary type)×			
Compresso	r motor (Star	ting method)		kW		_		Direct line	start			
	oil (Amount,			l		_		0.45 MA				
Refrigerant	(Type, amou	nt, pre-charge	e length)	kg		R410A 1.6kg	n outdoor unit (incl.	the amount for the piping o	f:15m)			
Heat exchai	nger				Lou	uver fin & inner g		M shape fin & inner				
Refrigerant	<u> </u>							tronic expansion valve				
an type &						Tangential f		Propeller f	an ×1			
	Starting meth	nod)		W		56 < Direct lin		34 < Direct lir				
		,	Cooling		Hi : 19		: 14.0 ULo : 8.0					
Air flow			Heating	m³/min			: 15.5 ULo : 14.0	36				
Available ex	ternal static	nressure	Trouting	Pa		0	10.0 020 11.0					
Outside air		pressure		14		Not poss	ble					
	ality / Quanti	tv/			De	olypropylene net(
	ration absorb					Rubber sleeve(for	,	Bubbar alaaya/far	Comprosport			
Electric hea		Jei		w	r		Tan motor)	Rubber sleeve(for	Compressor)			
Electric nea		tral		VV			Wireless , D					
Operation	Remote con		.1					emote control				
control		erature contro)			DUN 10		by electronics	2			
	Operation d	ispiay						POWER : Green, ECONO :				
								ction, Overcurrent protection				
Safety equip	oments				Fr	ost protection, S	erial signal error prot	ection, Indoor fan motor er	ror protection,			
					He	eating overload p	rotection(High press	sure control), Cooling over	oad protection			
	Defile 1					Liquid line: I/U	φ 6.35 (1/4") Pipe	φ 6.35(1/4")×0.8 O/U φ 6	.35 (1/4")			
	Retrigerant	oiping size (C	л.)	mm				φ 12.7(1/2")×0.8 O/U φ 12				
	Connecting	method				Flare pip		Flare piping				
nstallation		ngth of piping		m	Lic	quid line : 0.70/G		-	3			
data	Insulation fo						_iquid & Gas lines)					
		line (one way)) lenath	m	Necessary (both Liquid & Gas lines) Max.30m							
		diff. between O		m	Ma	x.20m (Outdoor		Max.20m (Outdoor	unit is lower)			
	Drain hose	ann botwoon O			1410	Hose Connectal	U ,	Holes size ϕ 2				
Drain nump	, max lift heig	nht		mm								
	ded breaker :			A								
	ked rotor amp			A				.0				
,	ize x Core nu	mbor	A		1.5 mm ² x 4 00000		.0 e)/ Termainal block(Screw 1	iving type)				
Interconnec IP number	ung wires S	ize x core nu	INDEI			1.5 mm x 4 cores	including earth cable	P)/ Termainal block(Screw 1	ixing type)			
r number						-	la an filtan	IPX4				
Standard ad	Cossorias					Mounting kit, C (Allergen clear		Drain albour Drain	hole grommet			
Januaru ac	000000000000000000000000000000000000000				Photocat		deodorizing filter×1)	Drain elbow, Drain	note grommet			
Ontion parts				i notocal	any the washable	<u> </u>	I (SC-BIKN-E)					
Option parts		the feller '		tione		interface kit	· · · · · · · · · · · · · · · · · · ·					
inote (1)		measured at						The pipe length is 7.5m.				
	Item Indoor air temperatu					ir temperature	St	andards				
Op	peration	DB	WB		DB	WB	01					
	Cooling	27°C	19°C		35°C	24°C	ISC	05151-T1				
	Heating	20°C	-		7°C	S°∂						
						ormity with the IS						
(0)	Sound level i	ndicates the v	alue in an	anechoi	c chambe	r. During operation	on these value are so	mewhat higher due to amb	pient			
	conditions.	eaker size aco										


(5) The operation data indicates when the air-conditioner is operated at 230V 50Hz or 220V 60Hz.

PCA001Z722



PJF000Z284


'13 • PAC-DB-194





PJF000Z285

#




Make a space of 4500 or more between the units when installing more than one.

PFA003Z817

 \triangleright

'13 • PAC-DB-194

(b) Ceiling suspended type (FDEN) Model FDEN71VF1



Make a space of 5000 or more between the units when installing more than one.


- 25 -

PFA003Z818

 \triangleright

'13 • PAC-DB-194


Model FDEN100VF1




(c) Duct connected-High static pressure type (FDU) Model FDU71VF1


PJG000Z047


Model FDU100VF1, 100VF2





(d) Duct connected-Low / Middle static pressure type (FDUM) Model FDUM71VF1







Note (1) The model name label is attached on the lid of the control box.



Model FDUM100VF1, 100VF2




- 29 -





#


'13 • PAC-DB-194



RKW000Z405


'13 • PAC-DB-194

Symbol	Content	
А	Service valve connection (gas side)	φ 12.7 (1∕2") (Flare)
В	Service valve connection (liquid side)	φ 6.35 (1∕4") (Flare)
С	Pipe / cable draw-out hole	
D	Drain discharge hole	ϕ 20 × 5 places
Е	Anchor bolt hole	M10×4 places



Notes

- It must not be surrounded by walls on the four sides.
 The unit must be fixed with anchor bolts. An anchor bolt must not protrude more than 15mm.
- (3) Where the unit is subject to strong winds, lay it in such a direction that the blower outlet faces perpendicularly to the dominant wind direction.
- (4) Leave 1m or more space above the unit.
- (5) A wall in front of the blower outlet must not exceed the units height.
 (6) The model name label is attached on the lower right corner of the front panel.




Minimum installation space


Examples of installation Dimensions	I	П	Ш	IV
L1	Open	280	280	180
L2	100	75	Open	Open
L3	100	80	80	80
L4	250	Open	250	Open

Unit:mm

(2) Outdoor units Model FDC71VNP

PCA001Z713





'13 • PAC-DB-194

Symbol	Content	
А	Service valve connection (gas side)	¢ 15.88 (5∕8") (Flare)
В	Service valve connection (liquid side)	¢ 6.35 (1∕4") (Flare)
С	Pipe / cable draw-out hole	
D	Drain discharge hole	ϕ 20 x 3 places
Е	Anchor bolt hole	M10 x 4 places

60

310

223


Note

- (1) It must not be surrounded by walls on four sides.
- (2) The unit must be fixed with anchor bolts. An anchor bolt must not protrude more than 15mm.
- (3) Where the unit is subjected to strong winds, lay it in such a direction that the blower outlet faces perpendicularly to the dominant wind direction.
- (4) Leave 1m or more space above the unit.



1

PCA001Z714




'13 • PAC-DB-194

Model FDC90VNP

(3) Remote control

(a) Wired remote control (Option parts) Model RC-E5

Interface kit (SC-BIKN-E) is required to use the wired remote control. (SRK series only)




Wiring specifications

(1) If the prolongation is over 100m, change to the size below.


But, wiring in the remote control case should be under 0.5mm². Change the wire size outside of the case according to wire connecting. Waterproof treatment is necessary at the wire connecting section. Be careful about contact failure.

Length	Wiring thickness
100 to 200m	0.5mm ² ×2 cores
Under 300m	0.75mm ² ×2 cores
Under 400m	1.25mm ² ×2 cores
Under 600m	2.0mm ² ×2 cores



Model : RC-EX1A (Except SRK series)

Dimensions (Viewed from front)




Cautions for selecting installation place

- (1) Installation surface must be flat and sufficiently strong. R/C case must not be deformed.
- (2) Where the R/C can detect room temperatures accurately This is a must when detecting room temperatures with the temperature sensor of R/C.
 - Install the R/C where it can detect the average temperature in the room.
 - · Install the R/C sufficiently separated from a heat source.
 - · Install the R/C where it will not be influenced by the turbulence of air when the door is opened or closed.

Select a place where the R/C is not exposed to direct sunlight or blown by winds from the air conditioner or temperatures on the wall surface will not deviate largely from indoor air temperatures.

Installation space




R/C cable: 0.3 mm² × 2-core

When the cable length is longer than 100 m, the max size for wires used in the R/C case is 0.5 mm^2 . Connect them to wires of larger size near the outside of R/C. When wires are connected, take measures to prevent water, etc. from entering inside.

< 200 m	0.5 mm ² x 2-core
< 300 m	0.75 mm ² x 2-core
< 400 m	1.25 mm ² x 2-core
< 600 m	2.0 mm ² x 2-core


Adapted to **RoHS** directive




(b) Wireless remote control


RCN-E1R (Option parts) (Except SRK series)

A SPEED ONNOFF AIR FLOW




SRK series only (Standard accessory)





Unit: mm

Unit: mm



3. Use twin core cord (0.3mm² X2) at remote control line. 4. Do not put remote control line alongside power source line. 5. Section 1 (%1) is provided on the model FDT100 only.


CNB~Z	Connector) (a)
DM	Drain motor	
F1~3	Fuse	Models
FMI	Fan motor	leli
FS	Float switch	л с П С
L	Reactor	D as
LED•2	Indication lamp (Green-Normal operation)	cassette-4way type (FDT) FDT71VF1, 100VF1, 100VF2
LED•3	Indication lamp (Red-Inspection)	4 E
LM1~4	Louver motor	Š Ľ
PS	Panel switch	_ S∡
SW2	Remote control communication address	type IVF1
SW5	Plural units Master / Slave setting] <u>+</u> _
SW6	Model capacity setting	89
SW7-1	Operation check, Drain motor test run	
SW7-3	Powerful mode Valid ∕ Invalid	N
TB1	Terminal block (Power source) (口mark)	
TB2	Terminal block (Signal line) (口mark)	
Thc	Thermistor (Remote control)	
ThI-A	Thermistor (Return air)	
Thl-R1,2,3	Thermistor (Heat exchanger)	

Color Ma	arks		
Mark	Color	Mark	Color
BK	Black	RD	Red
BL	Blue	WH	White
BR	Brown	YE	Yellow
OR	Orange	YE/GN	Yellow/Green

(1) Indoor units Π CTRICAL WIRING

4

Π



CFI1,2	Capacitor for FMI	
CNB~Z	Connector	
F	Fuse	ਿ
FMI1,2	Fan motor (with thermistor)	⊂ Z O
LED • 2	Indication lamp (Green-Normal operation)	lod
LED · 3	Indication lamp (Red-Inspection)	b) Ceiling Models
LM	Louver motor	
SW2	Remote control communication address	suspended type (FDEN) FDEN71VF1, 100VF1
SW5	Plural units Master / Slave setting	N7
SW6	Model capacity setting	1⊻ I
SW7-1	Operation check, Drain motor test run	Ţd,
TB1	Terminal block (Power source) (□mark)	10 Vp
TB2	Terminal block (Signal line) (□mark)	ŬV (F
Thc	Thermistor (Remote control)	ЧË
ThI-A	Thermistor (Return air)	Ľ,
Thl-R1,2,3	Thermistor (Heat exchanger)	•
Trl	Transformer	
X1~3,6	Relay for FMI	
X4	Relay for DM	
mark	Closed-end connector	

Notes 1. ---- indicates wiring on site.

- 2. See the wiring diagram of outside unit about the line between
- indoor unit and outdoor unit.
- 3. Use twin core cord (0.3mm²X2) at remote control line.
- 4. Do not put remote control line alongside power source line.


Color Marks

Mark	Color	Mark	Color
BK	Black	RD	Red
BL	Blue	WH	White
BR	Brown	YE	Yellow
OR	Orange	YE∕GN	Yellow/Green
PK	Pink		

1


38

1



'13 • PAC-DB-194

Model FDU100VF1, 100VF2



/	,	(Troat ontornal)	9017
Color Ma	rks		
Mark	Color	Mark	Color
BK	Black	RD	Red
BL	Blue	WH	White
YE	Yellow	YE/GN	Yellow / Green

CNB~Z Connector

Drain motor

Float switch

Reactor

Fan motor (with thermostat)

Indication lamp (Red-Inspection)

Plural units Master / Slave setting

Operation check, Drain motor test run

Terminal block (Power source) (□mark)

Terminal block (Signal line) (□mark)

Powerful mode Valid / Invalid

Thermistor (Remote control)

Thermistor (Return air)

Thi-R1,2,3 Thermistor (Heat exchanger)

Model capacity setting

Fuse

DM

F1,3,4

FM:1,2

LED · 2

LED · 3

SW2

SW5

SW6

SW7-1

SW7-3

TB1

TB2

Thc

ThI-A

FS

1

40

1


#

	DM	Drain motor		
	F1,4	Fuse		
	FMI2	Fan motor (v	vith thermo	stat)
	FS	Float switch		
	LED • 2	Indication la	mp (Green-	Normal operation)
	LED•3	Indication la	mp (Red-In	spection)
	SW2	Remote con	trol commu	nication address
	SW5	Plural units	Master/SI	ave setting
	SW6	Model capa	city setting	
	SW7-1	Operation c	heck, Drain	motor test run
	SW7-3	Powerful mo	ode Valid∕	Invalid
Signal line 3 CNW2 CNH CNW1 CNW1 CNW1 CNW1 CNW3 CNH CNW1 SW5 CNW2 CH	TB1	Terminal blo	ck (Power :	source) (□mark)
	TB2	Terminal blo	ock (Signal I	ine) (□mark)
	Thc	Thermistor (Remote co	ntrol)
$\begin{bmatrix} F4\\(2A) \end{bmatrix} \begin{bmatrix} F4\\(2A) \end{bmatrix} \end{bmatrix} \begin{bmatrix} F4\\(2A) \end{bmatrix} \begin{bmatrix} F4\\(2A) \end{bmatrix} \begin{bmatrix} F4\\(2A) \end{bmatrix} \end{bmatrix} \begin{bmatrix} F4\\(2A) \end{bmatrix} \begin{bmatrix} F4\\(2A) \end{bmatrix} \end{bmatrix} \end{bmatrix} \begin{bmatrix} F4\\(2A) \end{bmatrix} \end{bmatrix} \begin{bmatrix} F4\\(2A) \end{bmatrix} \end{bmatrix} \end{bmatrix} \begin{bmatrix} F4\\(2A) \end{bmatrix} \end{bmatrix} \begin{bmatrix} F4\\(2A) \end{bmatrix} \end{bmatrix} \end{bmatrix} \end{bmatrix} \begin{bmatrix} F4\\(2A) \end{bmatrix} \end{bmatrix} \end{bmatrix} \begin{bmatrix} F4\\(2A) \end{bmatrix} \end{bmatrix} \end{bmatrix} \end{bmatrix} \begin{bmatrix} F4\\(2A) \end{bmatrix} \end{bmatrix} \end{bmatrix} \end{bmatrix} \begin{bmatrix} F4\\(2A) \end{bmatrix} \end{bmatrix} \end{bmatrix} \end{bmatrix} \end{bmatrix} \begin{bmatrix} F4\\(2A) \end{bmatrix} \end{bmatrix} \end{bmatrix} \end{bmatrix} \begin{bmatrix} F4\\(2A) \end{bmatrix} \begin{bmatrix} F4\\($	ThI-A	Thermistor (Return air)	
1 4 5 6 7 For HA $12 1$ RD $12 1$ RD $12 1$	Thl-R1,2,3	Thermistor (Heat excha	nger)
	mark	Closed-end	connector	
	Color N		1	1
FMI2 ∠ H → ZR2 + (Operation) CNT 3 + (XR2) + (Heating)	Mark BK	Color Black	Mark RD	Color
$BL 4 = -\frac{1}{2} \frac{1}{2} \frac{1}{2} - \frac{1}{2} $	BK	Black	WH	White
	BR	Brown	YE	Yellow
Notes 1 indicates wiring on site.	OR	Orange	YE/GN	Yellow/Green
inside unit and outside unit.				
3. Use twin core card (0.3mm ²) at remote control line. (Remote operation input:				
4. Do not put remote control line alongside power source line. volt-free contact)				

(d) Duct connected-Low / Middle static pressure type (FDUM) Model FDUM71VF1

CNB~Z Connector

Mod
e
Ē
IM
8
Ę
<u> </u>
00
≤



	input:volt-free
!)	
1 /	
i /1	
L _ J	
(Remote operation input:	
volt-free contact)	
VOIL-ITEE CONILACI/	

CNB~Z

DM

FS

F1,3,4

FMI1,2

LED • 2

LED • 3

SW2

SW5

SW6

SW7-1

SW7-3

TB1

TB2

Thc

ThI-A

mark

Thl-R1,2,3

Color Marks

Mark

ΒK Black

BL Blue

BR Brown

OR

Connector

Drain motor

Float switch

Reactor

Fan motor (with thermostat)

Indication lamp (Green-Normal operation)

Remote control communication address

Operation check, Drain motor test run

Terminal block (Power source) (□mark)

Terminal block (Signal line) (□mark)

Mark

RD

WH

YE

Color

Red

White

Yellow

YE/GN Yellow/Green

Indication lamp (Red-Inspection)

Plural units Master / Slave setting

Powerful mode Valid / Invalid

Thermistor (Remote control)

Thermistor (Heat exchanger)

Thermistor (Return air)

Closed-end connector

Color

Orange

Model capacity setting

Fuse

Notes 1. ---- indicates wiring on site.

- 2. See the wiring diagram of outside unit about the line between
- inside unit and outside unit.
- 3. Use twin core cord (0.3mm² X2) at remote control line.
- 4. Do not put remote control line alongside power source line.

PJG000Z029

6

1


42

1

Color Marks Mark ΒK

BL BR

Color	Mark	Color	Mark	Color	CNB~Z	Connector	SW5	Plural units Master / Slave setting
Black	GR	Gray	WH	White	F200~203	Fuse	SW6	Model capacity setting
Blue	OR	Orange	YE	Yellow	FMI	Fan motor	SW7- 1	Operation check, Drain motor test run
Brown	RD	Red	YE/GN	Yellow/Green	L	Reactor	TB1	Terminal block (Power source)
					LED • 2	Indication lamp		(mark)
						(Green-Normal operation)	TB2	Terminal block (Signal line) (Dmark)
					LED • 3	Indication lamp (Red-Inspection)	Thc	Thermistor (Remote control)
					LM	Louver motor	ThI-A	Thermistor (Return air)
					SW2	Remote control communication	Thl-R1,2,3	Thermistor (Heat exchanger)
						address	X4	Relay for DM




inside unit and outside unit.


3. Use twin core cord (0.3mm²X2) at remote control line.

4. Do not put remote control line alongside power source line.

(e) Floor standing type (FDF) Models FDF71VD1, 100VD1, 100VD2



RWA000Z405



1

45 1

Power cable, indoor-outdoor connecting wires

Model	MAX running current (A)	Power cable size (mm ²)	Power cable length (m)	indoor-outdoor wire size x number	Earth wire size (mm ²)
71	14.5	2.0	15	1.5mm ² x 4	1.5


• The specifications shown in the above table are for units without heaters. For units with heaters, refer to the installation instructions or the construction instructions of the indoor unit.

• Switchgear of Circuit breaker capacity which is calculated from MAX. over current should be chosen along the regulations in each country.

• The cable specifications are based on the assumption that a metal or plastic conduit is used with no more than three cables contained in a conduit and a voltage drop is 2%. For an installation falling outside of these conditions, please follow the internal cabling regulations. Adapt it to the regulation in effect in each country.

Description		Mark	
Compressor motor	В	К	Bla
Connector	В	R	Bro
	0	R	Ora
	R	D	Re
Electric expansion valve (coil)	N	/H	Wh
Fan motor	Y	E	Yel
Reactor	Y	G	Yel
Heat exchanger sensor (outdoor unit)			
Outdoor air temp.sensor			
Discharge pipe temp.sensor			
Solenoid coil for 4 way valve			
	Compressor motor Connector Electric expansion valve (coil) Fan motor Reactor Heat exchanger sensor (outdoor unit) Outdoor air temp.sensor Discharge pipe temp.sensor	Compressor motor B Connector B Connector C Reactor W Heat exchanger sensor (outdoor unit) V Outdoor air temp.sensor Discharge pipe temp.sensor	Compressor motor Connector BK BR OR RD WH YE Reactor Heat exchanger sensor (outdoor unit) Outdoor air temp.sensor Discharge pipe temp.sensor

	1
Mark	Color
вк	Black
BR	Brown
OR	Orange
RD	Red
WН	White
YE	Yellow
YG	Yellow/Green
L	



Power cable, indoor-outdoor connecting wires

М	1odel	MAX running current (A) Power cable size (mm ²)		Power cable length (m)	indoor-outdoor wire size x number	Earth wire size (mm ²)
	90	18	2.5	15	1.5mm² x 4	1.5

The specifications shown in the above table are for units without heaters. For units with heaters, refer
to the installation instructions or the construction instructions of the indoor unit.

- Switchgear of Circuit breaker capacity which is calculated from MAX. over current should be chosen along the regulations in each country.
 The cable specifications are based on the assumption that a metal or plastic conduit is used with no
- The cable specifications are based on the assumption that a metal or plastic conduit is used with no more than three cables contained in a conduit and a voltage drop is 2%. For an installation falling outside of these conditions, please follow the internal cabling regulations. Adapt it to the regulation in effect in each country.

Item	Description	Mark	Color
CM	Compressor motor	ВК	Black
CN20S	Connector	BR	Brown
CNTH CNEEV		OR	Orange
CNFAN		RD	Red
EEV	Electric expansion valve (coil)	WH	White
FMo	Fan motor	YE	Yellow
L	Reactor	YG	Yellow/Gree
TH1	Heat exchanger sensor (outdoor unit)		
TH2	Outdoor air temp.sensor		
TH3	Discharge pipe temp.sensor		
20S	Solenoid coil for 4 way valve		

5. NOISE LEVEL


Notes (1) The data are based on the following conditions.

- Ambient air temperature: Indoor unit 27°CWB. Outdoor unit 35°CDB.
- (2) The data in the chart are measured in an anechoic room.
- (3) The noise levels measured in the field are usually higher than the data because of reflection.


(1) Indoor units

(a) Ceiling cassette-4way type (FDT)

Mid Octave Band Frequency (Hz)



Mid Octave Band Frequency (Hz)




(2) Outdoor units

Measured based on ISO-T1, JIS B 8616 Mike position: at highest noise level in position as mentioned below (sound pressure level) Distance from front side 1m Height 1m

(a) Sound pressure level





6. CHARACTERISTICS OF FAN


(1) Duct connected-Higt static pressure type (FDU)


- · Characteristic FAN (1) shows air flow vs. External Static Pressure (E.S.P.) range where settings of E.S.P. are maximum E.S.P. (SW8-4 OFF : 150Pa, SW8-4 ON : 200Pa), rated E.S.P., and minimum E.S.P. (SW8-4 OFF : 80Pa, SW8-4 ON : 10Pa)
- · Characteristic FAN (2) shows air flow vs. E.S.P curve when set fan tap is set P-Hi with each setting of E.S.P. by remote control.
- External Static Pressure (E.S.P.) can be set by wired remote control.
- You can set required E.S.P. by wired remote control which calculate it with the set air flow rate and pressure loss of the duct connected.


Model FDU71VF1


■SW8-4 : OFF (Range of use limitation : Setting 80Pa-150Pa) Characteristic FAN (1)


---- In case actual E.S.P. correspond setting of E.S.P.



















Model FDU100VF1, 100VF2

SW8-4 : OFF (Range of use limitation : Setting 80Pa-150Pa)



SW8-4 : ON (Range of use limitation : Setting 10Pa-200Pa) Characteristic FAN (1) Cha






(2) Duct connected-Low / Middle static pressure type (FDUM)


- Characteristic FAN (1) shows air flow vs. External Static Pressure (E.S.P.) range where settings of E.S.P. are maximum E.S.P. (100Pa), rated E.S.P., and minimum E.S.P. (10Pa)
- · Characteristic FAN (2) shows air flow vs. E.S.P curve when set fan tap is set P-Hi with each setting of E.S.P by remote control.
- External Static Pressure (E.S.P.) can be set by wired remote control.
- You can set required E.S.P. by wired remote control which calculate it with the set air flow rate and pressure loss of the duct connected.


Model FDUM71VF1 Characteristic FAN(1)

Characteristic FAN(2)




Model FDUM100VF1, 100VF2 Characteristic FAN(1)





Characteristic FAN(2)



- 52 -

7. TEMPERATURE AND VELOCITY DISTRIBUTION

Indoor temperature

Cooling 27°CDB / 19°CWB

Heating 20°CDB

Note: These figures represent the typical main range of temperature and velocity distribution at the center of air outlet within the published conditions.

In the actual installation, they may differ from the typical figures under the influence of air temperature conditions, ceiling height, operation conditions and obstacles.

(1) Ceiling cassett-4way type (FDT) Model FDT71VF1


Cooling Air flow : P-Hi

Louver position

Heating Air flow : P-Hi

Louver position

20°




Model FDT100VF1, 100VF2 Cooling Air flow : P-Hi

Louver position



Temperature distribution °C 5m 5m 18 4m 4п 3m 3m 2m 2m 1m 1m ī 0m 0m 5m 4m 3m 2m 1m 0m 1m 2m 3m 4m 5m Velocity distribution m/sec 5m 5m 5 1.2 4m 4m 0.3 3m 3m 2m 2m 1m 1m 1 0m 0m 4m 3m 0m 2m 3m 4m 5m 5m 2m 1m 1m **Temperature distribution** °C 5m 5m 4m 4m 3m 3m 29 20 2m 2m 26 26 1m 1m 23 23 1 0m 0m 4m 1m 2m 3m 5m 5m 3п 2m 1m 0m 4m Velocity distribution m/sec 5m 5m I 4m 4m 09 Ó. 3m 3m 2m 2m +0.6 0.6 1m 1m 0.3 0.3 I Т I 1 1 1 1 Orr 0m 1m 0m 2m 3m 4m 5m 5m 4m 3m 2m 1m


Heating Air flow : P-Hi Louver position




(2) Ceiling suspended type (FDEN)

Model FDEN71VF1

Cooling Air flow : P-Hi




Model FDEN100VF1




(3) Floor standing type (FDF) Models FDF71VD1, 100VD1, 100VD2(a) Cooling Air flow:Hi (Louver position:Horizontal)

Temperature distribution




(b) Heating Air flow:Hi (Louver position:Horizontal)



8. PIPING SYSTEM


(1) FDT, FDEN, FDU, FDUM, FDF series

Model 71



Preset point of the protective devices

Parts name	Mark	Equipped unit	All models
Thermistor (for protection overloading in heating)	Th: D	Indoor unit	OFF 63℃ , ON 56℃
Thermistor (for frost prevention)	Thı-R	indoor unit	OFF 1.0℃ , ON 10℃
Sensor (for protection high pressure in cooling.)	TH1	Outdoor unit	OFF 63℃ , ON 53℃
Sensor (for detecting discharge pipe temp.)	TH3		OFF 115℃ , ON 95℃



Preset point of the protective devices

Parts name	Mark	Equipped unit	SRK series
Sensor (for protection overloading in heating)	Tho	Indoor unit	OFF 60℃ , ON 48.5℃
Sensor (for frost prevention)	Th2	indoor unit	OFF 2.5℃ , ON 8℃
Sensor (for protection high pressure in cooling.)		Outdanswit	OFF 63℃ , ON 53℃
Sensor (for detecting discharge pipe temp.)	тнз	Outdoor unit	OFF 115℃ , ON 95℃

9. RANGE OF USAGE & LIMITATIONS

		See next page.					
Operating temperature ran	ge	When used below -5° C, install a snow hood (prepared on site).					
Recommendable area to install		Considering to get sufficient heating capacity, the area where the averaged lowest ambient air temperature in day time during winter is above 0°C, and it has no accumulation of snow.					
Installation site		The limitations of installation space are shown in the page for exterior dimensions. Install the indoor unit at least 2.5m higher than the floor surface.					
Temperature and humidity conditions surrounding the indoor unit (Note 2)		Model FDEN, FDF, SRK : Dew point temperature : 23°C or less, relative hummdity : 80% or less Other models : Dew point temperature : 28°C or less, relative hummdity : 80% or less					
Limitations on unit and pipi	ng installation	See page 62					
Compressor	Cycle Time	10 minutes or more (from OFF to OFF) or (from ON to ON)					
ON-OFF cycling	Stop Time	3 minutes or more					
	Voltage range	Rating ±10%					
Power source	Voltage drop at start-up	Min.85% of rating					
	Phase-to-phase imbalance	3% or less					

Note 1. Do not install the unit in places which :

1) Flammable gas may leak.

2) Carbon fiber, metal particles, powder, etc. are floating.

3) Cosmetic or special sprays are used frequently.

4) Exposed to oil splashes or steam (e.g. kitchen and machine plant).

5) Exposed to sea breeze (e.g. coastal area) or calcium chloride (e.g. snow melting agent).

6) Exposed to ammonia substance (e.g. organic fertilizer).

7) Matters affecting devices, such as sulfuric gas, chlorine gas, acid, alkali, etc. may generate or accumulate.

8) Chimney smoke is hanging.

9) Sucking the exhaust gas from heat exchanger.

10) Adjacent to equipment generating electromagnetic waves or high frequency waves.

11) There is light beams that affect the receiving device of indoor unit in case of the wireless specification.

12) Snow falls heavily.

13) At an elevation of 1000 meters or higher.

14) On mobile machine (e.g. vehicle, ship, etc.)


15) Splashed with water to indoor unit (e.g. laundry room).

Note 2. If ambient temperature and humidity exceed the above conditions, add polyurethane foam insulation on the outer plate (10mm or thicker) of indoor unit.

Note 3. Both gas and liquid pipes need to be coverd with 20mm or thicker heat insulation materials at the place where humidity exceeds 70%.

PJF000Z317

Operating temperature range



Decline in cooling and heating capacity or operation stop may occur when the outdoor unit is installed in places where natural wind can increase or decrease its design airflow rate.

PJF000Z317

"CAUTION" Cooling operation under low outdoor air temperature conditions

PAC models can be operated in cooling mode at low outdoor air temperature condition within above temperature range. However in case of severely low temperature conditions if the following precaution is not observed, it may not be operated in spite of operable temperature range mentioned above and cooling capacity may not be established under certain conditions.

[Precaution]

In case of severely low temperature condition

- 1) Install the outdoor unit at the place where strong wind cannot blow directly into the outdoor unit.
- 2) If there is no installation place where can prevent strong wind from directly blowing into the outdoor unit, mount the flex flow adapter (prepared as optional part) or like such devices onto the outdoor unit in order to divert the strong wind.


[Reason]

Under the low outdoor air temperature conditions of -5° C or lower, the outdoor fan is controlled at lower or lowest speed by outdoor fan control, but if strong wind directly blow into the outdoor unit, the outdoor heat exchanger temperature will drop more.

This makes high and low pressures to drop as well. This low pressure drop makes the indoor heat exchanger temperature to drop and will activate anti-frost control at indoor heat exchanger at frequent intervals, that cooling operation may not be established for any given time.

Limitation on unit and piping installation									
Descriptions		Model for outdoor unit	Dimensional limitations	Marks appearing in the drawing					
One-way pipe length			\leq 30m ⁽²⁾	L					
Elevation difference between	When the outdoor unit is positioned higher	FDC71VNP FDC90VNP	≦ 20m						
indoor and outdoor unit	When the outdoor unit is positioned lower		≦ 20m	H					
		•							

Notes(1) FDC71VNP, 90VNP can be used for only single type. (2) In case of FDF series, one way pipe length is not greater than 23m.



PJF000Z317

(kW) Heating Mode · HC

10. SELECTION CHART

Correct the cooling and heating capacity in accordance with the operating conditions. The net cooling and heating capacity can be obtained in the following way.

Net capacity = Capacity shown in the capacity tables (10.1) × Correction factors shown in the table (10.2) (10.3) (10.4).

Caution: In case that the cooling operation during low outdoor air temperature below -5°C is expected, install the outdoor unit where it is not influenced by natural wind. Otherwise protection control by low pressure will be activated much more frequently and it will cause insufficient capacity or breakdown of the compressor in worst case.

10.1 Capacity tables (1) Ceiling cassette-4way type (FDT)

Model FDT71VNPVF1 Indoor unit FDT71VF1 Outdoor unit FDC71VNP Cooling Mode

Cooling		<i>.</i>														((()))	ricatii	19 1110	40.1				(KVV)
Outdoor							Indo	or air t	emper	ature							Out	door	In	door a	or air temperature		
air temp.	18°C	CDB	21°C	DB	23°C	DB	26°0	CDB	27°C	DB	28°C	DB	31°C	DB	33°C	DB	air te	emp.			°CDB		
un tomp.	12°C	WB	14°C	WB	16°C	WB	18℃	WB	19°C	WB	20°C	WB	22°C	WB	24°C	WB	°CDB	°CWB	16	18	20	22	24
°CDB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	-14.5	-15	4.17	4.15	4.13	4.11	4.09
11					4.71	4.62	5.34	5.23	5.65	5.54	5.78	5.66	6.04	5.92	6.30	6.13	-13.5	-14	4.23	4.21	4.19	4.17	4.14
13					5.00	4.90	5.58	5.47	5.87	5.75	5.99	5.87	6.23	6.11	6.48	6.16	-11.5	-12	4.35	4.33	4.31	4.29	4.26
15					5.30	5.19	5.83	5.71	6.09	5.97	6.20	5.98	6.43	6.30	6.66	6.20	-9.5	-10	4.47	4.45	4.43	4.40	4.38
17					5.59	5.48	6.07	5.95	6.31	6.12	6.41	6.04	6.62	6.41	6.83	6.24	-7.5	-8	4.59	4.57	4.55	4.52	4.50
19					5.73	5.61	6.13	6.01	6.34	6.13	6.48	6.05	6.76	6.44	7.04	6.28	-5.5	-6	4.94	4.92	4.89	4.87	4.84
21					5.80	5.63	6.20	6.07	6.36	6.13	6.54	6.07	6.89	6.47	7.25	6.33	-3.0	-4	5.29	5.26	5.24	5.21	5.18
23					6.23	5.78	6.63	6.33	6.81	6.27	6.96	6.19	7.26	6.57	7.56	6.39	-1.0	-2	5.64	5.61	5.58	5.55	5.52
25			6.26	6.13	6.67	5.94	7.07	6.47	7.26	6.40	7.38	6.31	7.63	6.66	7.88	6.46	1.0	0	5.99	5.96	5.93	5.89	5.86
27			6.72	6.32	7.11	6.09	7.51	6.61	7.71	6.54	7.91	6.46	8.31	6.83			2.0	1	6.16	6.13	6.10	6.06	6.03
29			6.60	6.27	6.98	6.05	7.36	6.57	7.56	6.49	7.75	6.41	8.13	6.78			3.0	2	6.37	6.33	6.30	6.26	6.22
31			6.47	6.22	6.85	6.00	7.22	6.52	7.40	6.44	7.59	6.36	7.95	6.74			5.0	4	6.77	6.74	6.70	6.66	6.62
33	6.01	5.72	6.27	6.15	6.72	5.95	7.08	6.47	7.25	6.40	7.43	6.32	7.77	6.69			7.0	6	7.18	7.14	7.10	7.05	7.01
35	5.89	5.67	6.15	6.02	6.59	5.91	6.94	6.43	7.10	6.35	7.26	6.27	7.59	6.65			9.0	8	7.28	7.24	7.19	7.14	7.09
37	5.62	5.50	5.86	5.74	6.27	5.80	6.59	6.32	6.75	6.25	6.91	6.17	7.23	6.56			11.5	10	7.38	7.33	7.29	7.23	7.17
39	5.35	5.24	5.57	5.46	5.95	5.68	6.25	6.12	6.40	6.15	6.55	6.07	6.86	6.47			13.5	12	7.34	7.29	7.24	7.18	7.12
41	5.08	4.97	5.29	5.18	5.62	5.51	5.90	5.78	6.05	5.93	6.20	5.98	6.50	6.37			15.5	14	7.30	7.25	7.19	7.13	7.07
43	4.99	4.89	5.18	5.07	5.47	5.36	5.73	5.62	5.88	5.77	6.04	5.92	6.35	6.22			16.5	16	7.28	7.23	7.17	7.10	7.04

PJF000Z318

(kW)

Cooling	Mode	e			100VF2 (kW										(kW)	H	eatir	ngt Mo	ode : H	IC			(kW	
Outdoor					-											Outo	loor	In	door a	ir temp	peratu	re		
air temp.	18°0	DB	21°C	DB	23°C	DB	26°0	DB	27°C	DB	28°C	DB	31°C	DB	33°C	DB		air te	emp.			°CDB		
an tomp.	12°C	WB	14°C	WB	16°C	WB	18°C	WB	19°C	WB	20°C	WB	22°C	WB	24°C	WB	°	CDB	°CWB	16	18	20	22	24
°CDB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	-1	14.5	-15	5.26	5.24	5.21	5.18	5.15
11					8.35	7.80	8.93	8.56	9.21	8.49	9.59	8.44	10.34	9.03	11.09	8.88	-1	13.5	-14	5.38	5.35	5.32	5.29	5.26
13					8.42	7.83	8.94	8.56	9.20	8.48	9.55	8.43	10.25	9.01	10.96	8.85	-1	11.5	-12	5.61	5.58	5.55	5.52	5.49
15					8.48	7.85	8.96	8.56	9.19	8.48	9.52	8.42	10.17	8.99	10.83	8.82	-	9.5	-10	5.84	5.81	5.78	5.74	5.71
17					8.54	7.87	8.97	8.57	9.18	8.48	9.49	8.41	10.09	8.97	10.70	8.79	-	7.5	-8	6.07	6.04	6.00	5.97	5.93
19					8.51	7.86	8.96	8.57	9.19	8.48	9.48	8.40	10.06	8.96	10.63	8.77	-	5.5	-6	6.50	6.46	6.42	6.38	6.34
21					8.32	7.79	8.96	8.57	9.20	8.48	9.47	8.40	10.02	8.95	10.57	8.76	-	3.0	-4	6.93	6.88	6.84	6.79	6.75
23					8.52	7.86	9.04	8.59	9.21	8.49	9.47	8.40	10.00	8.94	10.52	8.75	-	1.0	-2	7.36	7.31	7.26	7.21	7.15
25			8.10	7.93	8.72	7.94	9.13	8.62	9.23	8.49	9.48	8.40	9.97	8.93	10.47	8.73		1.0	0	7.79	7.73	7.67	7.62	7.56
27			8.38	8.22	8.92	8.01	9.22	8.65	9.24	8.50	9.27	8.34	9.31	8.76				2.0	1	8.00	7.94	7.88	7.82	7.76
29			8.25	8.08	8.77	7.95	9.11	8.61	9.18	8.48	9.26	8.34	9.41	8.79				3.0	2	8.23	8.17	8.11	8.04	7.98
31			8.11	7.95	8.62	7.90	9.00	8.58	9.12	8.46	9.25	8.34	9.50	8.81			1	5.0	4	8.68	8.62	8.55	8.49	8.42
33	7.53	7.38	7.88	7.72	8.46	7.84	8.88	8.54	9.06	8.44	9.24	8.33	9.59	8.83				7.0	6	9.13	9.07	9.00	8.93	8.86
35	7.41	7.26	7.74	7.59	8.31	7.79	8.77	8.51	9.00	8.42	9.23	8.33	9.68	8.86				9.0	8	9.61	9.54	9.47	9.39	9.32
37	7.15	7.01	7.47	7.32	8.00	7.68	8.44	8.27	8.66	8.32	8.88	8.23	9.33	8.77			1	1.5	10	10.09	10.01	9.93	9.85	9.77
39	6.89	6.75	7.20	7.05	7.70	7.54	8.11	7.94	8.32	8.16	8.54	8.13	8.97	8.67			1	3.5	12	10.26	10.18	10.10	10.01	9.93
41	6.63	6.49	6.92	6.78	7.39	7.24	7.77	7.62	7.98	7.82	8.20	8.03	8.62	8.45			1	5.5	14	10.42	10.34	10.26	10.17	10.0
43	6.36	6.24	6.65	6.52	7.08	6.94	7.44	7.29	7.65	7.49	7.85	7.69	8.26	8.10			1	6.5	16	10.51	10.42	10.34	10.25	10.1

Note(1) These data show average statuses.

Depending on the system control, there may be ranges where the operation is not conducted continuously.

These data show the case where the operation frequency of a compressor is same as nominal condition frequency

or follows the protection controls. (2) Capacities are based on the following conditions.

Corresponding refrigerant piping length :7.5m Level difference : 0m

Indoor fan speed : PHi (3) Symbols are as follows.

TC : Total cooling capacity (kW), SHC : Sensible heat capacity (kW), HC : Heating capacity (kW)

Indoor air temperature

°CDB

20

4.19

4.31 4.29 4.26

4.55 4.52 4.50

4.89 4.87 4.84

5.24

5.58

5.93 5.89 5.86

6.10

6.70 6.66 6.62

7.10 7.05 7.01

7.19 7.14 7.09

7.29

7.24 7.18 7.12

7.19 7.13 7.07

7.17 7.10

22

4.17

5.21

5.55 5.52

6.06 6.03

4.13 4.11

16 18

4.17 4.15

4.23 4.21

4.35 4.33

4.47 4.45 4.43 4.40

4.94 4.92

5.99 5.96

6.37 6.33 6.30 6.26 6.22

7.18 7.14

7.28 7.24

7.38 7.33

7.34 7.29

7.30 7.25

7.28 7.23

5.26

5.61

6.13

-8 4.59 4.57

4 6.77 6.74 (kW)

24

4.09

4.14

4.38

5.18

(2) Ceiling suspended type (FDEN)

Model FDEN71VNPVF1 Indoor unit FDEN71VF1 Outdoor unit FDC71VNP Cooling Mode

Cooling	Mode	Э		• •		anne i	DEIG		0	ataooi	unit	1 0 01				(kW)	Heatir	ng Mo	de : ⊢	IC
Outdoor							Indo	or air t	emper	ature] [Out	door	In	ndoo
air temp.	18°C	DB	21°C	DB	23°C	DB	26°C	DB	27°C	DB	28°C	DB	31°C	DB	33°C	DB	11	air te	emp.		
un tomp.	12°C	WB	14°C	WB	16℃	WB	18℃	WB	19℃	WB	20°C	WB	22°C	WB	24°C	WB		°CDB	°CWB	16	1
°CDB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	11	-14.5	-15	4.17	4.
11					4.71	4.37	5.34	4.89	5.65	4.90	5.78	4.85	6.04	5.12	6.30	5.00	11	-13.5	-14	4.23	4.
13					5.00	4.48	5.58	4.98	5.87	4.98	5.99	4.92	6.23	5.18	6.48	5.05	1[-11.5	-12	4.35	4.
15					5.30	4.59	5.83	5.06	6.09	5.05	6.20	4.99	6.43	5.24	6.66	5.10	11	-9.5	-10	4.47	4.
17					5.59	4.71	6.07	5.15	6.31	5.13	6.41	5.06	6.62	5.29	6.83	5.14	11	-7.5	-8	4.59	4.
19					5.73	4.76	6.13	5.17	6.34	5.14	6.48	5.08	6.76	5.33	7.04	5.20	1[-5.5	-6	4.94	4.
21					5.80	4.79	6.20	5.20	6.36	5.15	6.54	5.10	6.89	5.37	7.25	5.25	11	-3.0	-4	5.29	5.
23					6.23	4.96	6.63	5.36	6.81	5.30	6.96	5.24	7.26	5.49	7.56	5.34	11	-1.0	-2	5.64	5.
25			6.26	5.28	6.67	5.14	7.07	5.52	7.26	5.47	7.38	5.38	7.63	5.60	7.88	5.43	11	1.0	0	5.99	5.9
27			6.72	5.49	7.11	5.33	7.51	5.69	7.71	5.63	7.91	5.57	8.31	5.82			11	2.0	1	6.16	6.
29			6.60	5.44	6.98	5.27	7.36	5.64	7.56	5.57	7.75	5.51	8.13	5.76			1[3.0	2	6.37	6.
31			6.47	5.38	6.85	5.22	7.22	5.58	7.40	5.52	7.59	5.45	7.95	5.70				5.0	4	6.77	6.
33	6.01	5.00	6.27	5.29	6.72	5.16	7.08	5.53	7.25	5.46	7.43	5.40	7.77	5.65			11	7.0	6	7.18	7.
35	5.89	4.94	6.15	5.23	6.59	5.11	6.94	5.47	7.10	5.41	7.26	5.34	7.59	5.59			11	9.0	8	7.28	7.
37	5.62	4.81	5.86	5.11	6.27	4.98	6.59	5.34	6.75	5.28	6.91	5.22	7.23	5.48			1[11.5	10	7.38	7.3
39	5.35	4.69	5.57	4.98	5.95	4.85	6.25	5.22	6.40	5.16	6.55	5.10	6.86	5.37			1[13.5	12	7.34	7.
41	5.08	4.56	5.29	4.86	5.62	4.72	5.90	5.09	6.05	5.04	6.20	4.98	6.50	5.26			11	15.5	14	7.30	7.
43	4.99	4.52	5.18	4.81	5.47	4.66	5.73	5.03	5.88	4.98	6.04	4.93	6.35	5.21			11	16.5	16	7.28	7.

PFA003Z975

7.04

7.23 7.17

Model	FDEN90VNPVF1	Indoor unit	FDEN100VF1	Outdoor unit	FDC90VNP
Cooling	Mode				

Cooling	Mode	Э														(kW)	Heatin	ng Mo	de : H	IC			(kW
0							Indo	or air t	emper	ature							Out	door	In	door a	ir tem	peratu	re
Outdoor air temp.	18°C	DB	21°C	DB	23°C	DB	26°C	DB	27°C	DB	28°C	DB	31℃	DB	33°C	DB	air te	emp.			°CDB		
an temp.	12°C	WB	14°C	WB	16°C	WB	18°C	WB	19°C	WB	20°C	WB	22°C	WB	24°C	WB	°CDB	°CWB	16	18	20	22	24
°CDB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	-14.5	-15	5.26	5.24	5.21	5.18	5.15
11					8.35	6.96	8.93	7.54	9.21	7.50	9.59	7.48	10.34	7.96	11.09	7.87	-13.5	-14	5.38	5.35	5.32	5.29	5.26
13					8.42	6.98	8.94	7.55	9.20	7.49	9.55	7.47	10.25	7.93	10.96	7.83	-11.5	-12	5.61	5.58	5.55	5.52	5.49
15					8.48	7.01	8.96	7.56	9.19	7.49	9.52	7.45	10.17	7.90	10.83	7.79	-9.5	-10	5.84	5.81	5.78	5.74	5.71
17					8.54	7.03	8.97	7.56	9.18	7.49	9.49	7.44	10.09	7.88	10.70	7.75	-7.5	-8	6.07	6.04	6.00	5.97	5.93
19					8.51	7.02	8.96	7.56	9.19	7.49	9.48	7.44	10.06	7.87	10.63	7.73	-5.5	-6	6.25	6.21	6.17	6.13	6.09
21					8.32	6.94	8.96	7.56	9.20	7.49	9.47	7.44	10.02	7.85	10.57	7.71	-3.0	-4	6.42	6.37	6.33	6.29	6.25
23					8.52	7.02	9.04	7.59	9.21	7.50	9.47	7.44	10.00	7.85	10.52	7.70	-1.0	-2	6.59	6.54	6.50	6.45	6.41
25			8.10	7.25	8.72	7.11	9.13	7.62	9.23	7.50	9.48	7.44	9.97	7.84	10.47	7.68	1.0	0	6.76	6.71	6.66	6.61	6.56
27			8.38	7.38	8.92	7.19	9.22	7.66	9.24	7.51	9.27	7.36	9.31	7.63			2.0	1	6.84	6.79	6.74	6.69	6.64
29			8.25	7.31	8.77	7.13	9.11	7.61	9.18	7.49	9.26	7.36	9.41	7.66			3.0	2	7.30	7.25	7.19	7.14	7.08
31			8.11	7.25	8.62	7.07	9.00	7.57	9.12	7.46	9.25	7.36	9.50	7.69			5.0	4	8.22	8.16	8.10	8.04	7.97
33	7.53	6.71	7.88	7.15	8.46	7.00	8.88	7.53	9.06	7.44	9.24	7.35	9.59	7.72			7.0	6	9.13	9.07	9.00	8.93	8.86
35	7.41	6.65	7.74	7.09	8.31	6.94	8.77	7.48	9.00	7.42	9.23	7.35	9.68	7.75			9.0	8	9.61	9.54	9.47	9.39	9.32
37	7.15	6.53	7.47	6.97	8.00	6.81	8.44	7.36	8.66	7.30	8.88	7.23	9.33	7.63			11.5	10	10.09	10.01	9.93	9.85	9.77
39	6.89	6.40	7.20	6.85	7.70	6.69	8.11	7.23	8.32	7.17	8.54	7.11	8.97	7.52			13.5	12	10.26	10.18	10.10	10.01	9.93
41	6.63	6.28	6.92	6.73	7.39	6.56	7.77	7.11	7.98	7.05	8.20	6.99	8.62	7.41			15.5	14	10.42	10.34	10.26	10.17	10.08
43	6.36	6.16	6.65	6.52	7.08	6.44	7.44	6.98	7.65	6.93	7.85	6.88	8.26	7.30			16.5	16	10.51	10.42	10.34	10.25	10.16

Note(1) These data show average statuses.

These data show average statuses. Depending on the system control, there may be ranges where the operation is not conducted continuously. These data show the case where the operation frequency of a compressor is same as nominal condition frequency

or follows the protection controls. (2) Capacities are based on the following conditions.

(2) Capacities are based on the following conditions. Corresponding refrigerant piping length :7.5m Level difference : 0m Indoor fan speed : PHi
(3) Symbols are as follows. TC : Total cooling capacity (kW), SHC : Sensible heat capacity (kW), HC : Heating capacity (kW)

PFA003Z975

Indoor air temperature °CDB

20

4.19 4.17 4.14

4.31 4.29 4.26

4.43 4.40 4.38

4.55

4.89

5.24 5.21 5.18

5.58 5.55 5.52 5.86

5.93 5.89

6.10 6.06 6.03

6.30 6.26 6.22

6.70 6.66 6.62

7.10 7.05 7.01

7.19 7.14

4.13 4.11

22

4.52

4.87 4.84

7.33 7.29 7.23 7.17

7.29 7.24 7.18 7.12

(kW)

24

4.09

4.50

7.09

7.07

7.04

(kw) Heating Mode : HC

(3) Duct connected-High static pressure type (FDU)

Model FDU71VNPVF1 Indoor unit FDU71VF1 Outdoor unit FDC71VNP Cooling Mode

Outdoor							Indo	or air t	emper	ature							Out	door	In	door a	ai
air temp.	18°C	DB	21°C	CDB	23°C	DB	26°C	DB	27°C	DB	28°C	DB	31°C	DB	33°C	DB	air t	emp.			
an tomp.	12°C	WB	14°C	WВ	16℃	WB	18℃	WB	19℃	WB	20°C	WB	22°C	WB	24°C	WB	°CDB	°CWB	16	18	
°CDB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	-14.5	-15	4.17	4.15	T
11					4.71	4.62	5.34	5.23	5.65	5.38	5.78	5.32	6.04	5.66	6.30	5.52	-13.5	-14	4.23	4.21	T
13					5.00	4.89	5.58	5.46	5.87	5.45	5.99	5.38	6.23	5.71	6.48	5.56	-11.5	-12	4.35	4.33	T
15					5.30	5.00	5.83	5.54	6.09	5.52	6.20	5.44	6.43	5.76	6.66	5.60	-9.5	-10	4.47	4.45	T
17					5.59	5.10	6.07	5.62	6.31	5.58	6.41	5.50	6.62	5.81	6.83	5.64	-7.5	-8	4.59	4.57	T
19					5.73	5.15	6.13	5.64	6.34	5.59	6.48	5.52	6.76	5.84	7.04	5.69	-5.5	-6	4.94	4.92	T
21					5.80	5.18	6.20	5.66	6.36	5.60	6.54	5.54	6.89	5.88	7.25	5.74	-3.0	-4	5.29	5.26	T
23					6.23	5.34	6.63	5.80	6.81	5.74	6.96	5.67	7.26	5.98	7.56	5.82	-1.0	-2	5.64	5.61	Ī
25			6.26	5.68	6.67	5.50	7.07	5.95	7.26	5.89	7.38	5.80	7.63	6.08	7.88	5.89	1.0	0	5.99	5.96	T
27			6.72	5.87	7.11	5.67	7.51	6.10	7.71	6.03	7.91	5.96	8.31	6.27			2.0	1	6.16	6.13	T
29			6.60	5.82	6.98	5.62	7.36	6.05	7.56	5.98	7.75	5.91	8.13	6.22			3.0	2	6.37	6.33	Ι
31			6.47	5.76	6.85	5.57	7.22	6.00	7.40	5.93	7.59	5.86	7.95	6.17			5.0	4	6.77	6.74	T
33	6.01	5.33	6.27	5.68	6.72	5.52	7.08	5.96	7.25	5.88	7.43	5.81	7.77	6.12			7.0	6	7.18	7.14	I
35	5.89	5.27	6.15	5.63	6.59	5.47	6.94	5.91	7.10	5.83	7.26	5.76	7.59	6.07			9.0	8	7.28	7.24	T
37	5.62	5.15	5.86	5.51	6.27	5.35	6.59	5.79	6.75	5.72	6.91	5.65	7.23	5.97			11.5	10	7.38	7.33	T
39	5.35	5.04	5.57	5.40	5.95	5.23	6.25	5.68	6.40	5.61	6.55	5.55	6.86	5.87			13.5	12	7.34	7.29	T
41	5.08	4.92	5.29	5.18	5.62	5.11	5.90	5.56	6.05	5.50	6.20	5.44	6.50	5.77			15.5	14	7.30	7.25	T
43	4.99	4.88	5.18	5.07	5.47	5.06	5.73	5.51	5.88	5.45	6.04	5.39	6.35	5.74			16.5	16	7.28	7.23	t

PJG000Z190

7.19 7.13

7.17 7.10

Cooling	Mode	e							100	0VF2						(kW)	Heatir	ng Mo	de : H	С			(kV
Outdoor							Indo	or air t	emper	ature							Out	door	In	door a	ir tem	peratu	re
air temp.	18°C	DB	21°C	DB													air te	emp.			°CDB		
an tomp.	12°C	WB	14°C	WB	16°C	WB	18°C	WB	19°C	WB	20°C	WB	22°C	WB	24°C	WB	°CDB	°CWB	16	18	20	22	24
°CDB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	-14.5	-15	5.26	5.24	5.21	5.18	5.1
11					8.35	6.95	8.93	7.59	9.21	7.47	9.59	7.37	10.34	7.83	11.09	7.56	-13.5	-14	5.38	5.35	5.32	5.29	5.2
13					8.42	6.96	8.94	7.59	9.20	7.47	9.55	7.36	10.25	7.82	10.96	7.54	-11.5	-12	5.61	5.58	5.55	5.52	5.4
15					8.48	6.98	8.96	7.59	9.19	7.47	9.52	7.35	10.17	7.80	10.83	7.53	-9.5	-10	5.84	5.81	5.78	5.74	5.7
17					8.54	7.00	8.97	7.60	9.18	7.47	9.49	7.35	10.09	7.79	10.70	7.51	-7.5	-8	6.07	6.04	6.00	5.97	5.9
19					8.51	6.99	8.96	7.60	9.19	7.47	9.48	7.35	10.06	7.78	10.63	7.50	-5.5	-6	6.50	6.46	6.42	6.38	6.3
21					8.32	6.94	8.96	7.60	9.20	7.47	9.47	7.34	10.02	7.78	10.57	7.49	-3.0	-4	6.93	6.88	6.84	6.79	6.7
23					8.52	6.99	9.04	7.62	9.21	7.47	9.47	7.35	10.00	7.77	10.52	7.48	-1.0	-2	7.36	7.31	7.26	7.21	7.1
25			8.10	7.36	8.72	7.05	9.13	7.64	9.23	7.48	9.48	7.35	9.97	7.77	10.47	7.47	1.0	0	7.79	7.73	7.67	7.62	7.5
27			8.38	7.45	8.92	7.11	9.22	7.66	9.24	7.48	9.27	7.30	9.31	7.65			2.0	1	8.00	7.94	7.88	7.82	7.7
29			8.25	7.41	8.77	7.07	9.11	7.63	9.18	7.46	9.26	7.30	9.41	7.67			3.0	2	8.23	8.17	8.11	8.04	7.9
31			8.11	7.36	8.62	7.02	9.00	7.60	9.12	7.45	9.25	7.30	9.50	7.68			5.0	4	8.68	8.62	8.55	8.49	8.4
33	7.53	6.79	7.88	7.29	8.46	6.98	8.88	7.58	9.06	7.44	9.24	7.29	9.59	7.70			7.0	6	9.13	9.07	9.00	8.93	8.8
35	7.41	6.74	7.74	7.24	8.31	6.93	8.77	7.55	9.00	7.42	9.23	7.29	9.68	7.72			9.0	8	9.61	9.54	9.47	9.39	9.3
37	7.15	6.65	7.47	7.16	8.00	6.85	8.44	7.47	8.66	7.35	8.88	7.22	9.33	7.65			11.5	10	10.09	10.01	9.93	9.85	9.7
39	6.89	6.55	7.20	7.05	7.70	6.76	8.11	7.39	8.32	7.27	8.54	7.15	8.97	7.59			13.5	12	10.26	10.18	10.10	10.01	9.9
41	6.63	6.46	6.92	6.78	7.39	6.68	7.77	7.31	7.98	7.20	8.20	7.08	8.62	7.53			15.5	14	10.42	10.34	10.26	10.17	10.0
43	6.36	6.24	6.65	6.52	7.08	6.59	7.44	7.23	7.65	7.12	7.85	7.01	8.26	7.48			16.5	16	10.51	10.42	10.34	10.25	10.1

Note(1) These data show average statuses. Depending on the system control, there may be ranges where the operation is not conducted continuously. These data show the case where the operation frequency of a compressor is same as nominal condition frequency

or follows the protection controls.

(2) Capacities are based on the following conditions Corresponding refrigerant piping length :7.5m

Level difference : 0m Indoor fan speed : PHi

(3) Symbols are as follows.

TC : Total cooling capacity (kW), SHC : Sensible heat capacity (kW), HC : Heating capacity (kW)

(kW)

24 4.09 4.14 4.26 4.38 4.50 4.84 5.18 5.52 5.86 6.03 6.22 6.62 7.01 7.09 7.17 7.12 7.07 7.04

(kW) Heating Mode : HC

(4) Duct connected-Low/Middle static pressure type (FDUM)

Model FDUM71VNPVF1 Indoor unit FDUM71VF1 Cooling Mode Outdoor unit FDC71VNP

| 18°CDB
12°CWB
C SHC | 21°C
14°C
TC | | 23°0
16°0
TC | | 26°C
18°C | DB | emper
27°0
19°0 | DB | 28°0 | DB
 | 31°C | DB

 | 33°C | DB
 | | door
emp.
 | In | door a | ir tem
°CDB | peratu | re |
|---------------------------|---|--|---|---|--|--|---|---|--
--
--|---
--
--
--
---|---
--|--|---|---|--
--|
| 12°CWB | 14°C | WB | 16°C
TC | WB | 18°C | | | | 28°C | DB
 | 31°C | DB

 | 33°C | DB
 | air t | emp.
 | | | °CDB | | |
| | <u> </u> | | TC | | | WB | 19°C | | |
 | |

 | 000 | 00
 | | · P
 | | | | | |
| C SHC | TC | SHC | | SHC | 70 | | | WB | 20°C | WB
 | 22°C | WB

 | 24°C | WB
 | °CDB | °CWB
 | 16 | 18 | 20 | 22 | 2 |
| | | | | | TC | SHC | TC | SHC | TC | SHC
 | TC | SHC

 | TC | SHC
 | -14.5 | -15
 | 4.17 | 4.15 | 4.13 | 4.11 | 4. |
| | | | 4.71 | 4.62 | 5.34 | 5.23 | 5.65 | 5.38 | 5.78 | 5.32
 | 6.04 | 5.66

 | 6.30 | 5.52
 | -13.5 | -14
 | 4.23 | 4.21 | 4.19 | 4.17 | 4. |
| | | | 5.00 | 4.89 | 5.58 | 5.46 | 5.87 | 5.45 | 5.99 | 5.38
 | 6.23 | 5.71

 | 6.48 | 5.56
 | -11.5 | -12
 | 4.35 | 4.33 | 4.31 | 4.29 | 4. |
| | | | 5.30 | 5.00 | 5.83 | 5.54 | 6.09 | 5.52 | 6.20 | 5.44
 | 6.43 | 5.76

 | 6.66 | 5.60
 | -9.5 | -10
 | 4.47 | 4.45 | 4.43 | 4.40 | 4. |
| | | | 5.59 | 5.10 | 6.07 | 5.62 | 6.31 | 5.58 | 6.41 | 5.50
 | 6.62 | 5.81

 | 6.83 | 5.64
 | -7.5 | -8
 | 4.59 | 4.57 | 4.55 | 4.52 | 4. |
| | | | 5.73 | 5.15 | 6.13 | 5.64 | 6.34 | 5.59 | 6.48 | 5.52
 | 6.76 | 5.84

 | 7.04 | 5.69
 | -5.5 | -6
 | 4.94 | 4.92 | 4.89 | 4.87 | 4. |
| | | | 5.80 | 5.18 | 6.20 | 5.66 | 6.36 | 5.60 | 6.54 | 5.54
 | 6.89 | 5.88

 | 7.25 | 5.74
 | -3.0 | -4
 | 5.29 | 5.26 | 5.24 | 5.21 | 5. |
| | | | 6.23 | 5.34 | 6.63 | 5.80 | 6.81 | 5.74 | 6.96 | 5.67
 | 7.26 | 5.98

 | 7.56 | 5.82
 | -1.0 | -2
 | 5.64 | 5.61 | 5.58 | 5.55 | 5. |
| | 6.26 | 5.68 | 6.67 | 5.50 | 7.07 | 5.95 | 7.26 | 5.89 | 7.38 | 5.80
 | 7.63 | 6.08

 | 7.88 | 5.89
 | 1.0 | 0
 | 5.99 | 5.96 | 5.93 | 5.89 | 5. |
| | 6.72 | 5.87 | 7.11 | 5.67 | 7.51 | 6.10 | 7.71 | 6.03 | 7.91 | 5.96
 | 8.31 | 6.27

 | |
 | 2.0 | 1
 | 6.16 | 6.13 | 6.10 | 6.06 | 6. |
| | 6.60 | 5.82 | 6.98 | 5.62 | 7.36 | 6.05 | 7.56 | 5.98 | 7.75 | 5.91
 | 8.13 | 6.22

 | |
 | 3.0 | 2
 | 6.37 | 6.33 | 6.30 | 6.26 | 6. |
| | 6.47 | 5.76 | 6.85 | 5.57 | 7.22 | 6.00 | 7.40 | 5.93 | 7.59 | 5.86
 | 7.95 | 6.17

 | |
 | 5.0 | 4
 | 6.77 | 6.74 | 6.70 | 6.66 | 6. |
| 01 5.33 | 6.27 | 5.68 | 6.72 | 5.52 | 7.08 | 5.96 | 7.25 | 5.88 | 7.43 | 5.81
 | 7.77 | 6.12

 | |
 | 7.0 | 6
 | 7.18 | 7.14 | 7.10 | 7.05 | 7. |
| 89 5.27 | 6.15 | 5.63 | 6.59 | 5.47 | 6.94 | 5.91 | 7.10 | 5.83 | 7.26 | 5.76
 | 7.59 | 6.07

 | |
 | 9.0 | 8
 | 7.28 | 7.24 | 7.19 | 7.14 | 7. |
| 62 5.15 | 5.86 | 5.51 | 6.27 | 5.35 | 6.59 | 5.79 | 6.75 | 5.72 | 6.91 | 5.65
 | 7.23 | 5.97

 | |
 | 11.5 | 10
 | 7.38 | 7.33 | 7.29 | 7.23 | 7. |
| 35 5.04 | 5.57 | 5.40 | 5.95 | 5.23 | 6.25 | 5.68 | 6.40 | 5.61 | 6.55 | 5.55
 | 6.86 | 5.87

 | |
 | 13.5 | 12
 | 7.34 | 7.29 | 7.24 | 7.18 | 7. |
| 08 4.92 | 5.29 | 5.18 | 5.62 | 5.11 | 5.90 | 5.56 | 6.05 | 5.50 | 6.20 | 5.44
 | 6.50 | 5.77

 | |
 | 15.5 | 14
 | 7.30 | 7.25 | 7.19 | 7.13 | 7. |
| 99 4.88 | | 5.07 | 5.47 | | | 5.51 | E 00 | | 6.04 | 5 30
 | | 5.74

 | | _
 | | 16
 | | | - | - | 7. |
| 89
62
35 | 9 5.27 2 5.15 5 5.04 3 4.92 | 6.72 6.60 6.47 5.33 6.27 5.27 6.15 5.15 5.86 5 5.04 5.57 3 4.92 5.29 | 6.72 5.87 6.60 5.82 6.47 5.76 5.33 6.27 5.68 5.27 6.15 5.63 5.15 5.86 5.51 5.504 5.57 5.40 3 4.92 5.29 5.18 | 6.72 5.87 7.11 6.60 5.82 6.98 6.47 5.76 6.85 5.33 6.27 5.68 6.72 5.527 6.15 5.63 6.59 5.51 5.86 5.51 6.27 5 5.04 5.57 5.40 5.95 3 4.92 5.29 5.18 5.62 | 6.72 5.87 7.11 5.67 6.60 5.82 6.98 5.62 6.47 5.76 6.85 5.57 5.33 6.27 5.68 6.72 5.52 5.27 6.15 5.63 6.59 5.47 2 5.15 5.86 5.51 6.27 5.35 5 5.04 5.57 5.40 5.95 5.23 3 4.92 5.29 5.18 5.62 5.11 | 6.72 5.87 7.11 5.67 7.51 6.60 5.82 6.98 5.62 7.36 6.47 5.76 6.85 5.57 7.22 5.33 6.27 5.68 6.72 5.52 7.08 5.27 6.15 5.63 6.59 5.47 6.94 2 5.15 5.86 5.51 6.27 5.35 6.59 5 5.04 5.57 5.40 5.95 5.23 6.25 3 4.92 5.29 5.18 5.62 5.11 5.90 | 6.72 5.87 7.11 5.67 7.51 6.10 6.60 5.82 6.98 5.62 7.36 6.05 6.47 5.76 6.85 5.57 7.22 6.00 5.33 6.27 5.68 6.72 5.52 7.08 5.96 5.27 6.15 5.63 6.59 5.47 6.94 5.91 5 5.27 6.15 5.63 6.59 5.47 6.94 5.91 5 5.15 5.86 5.51 6.27 5.35 6.59 5.79 5 5.04 5.57 5.40 5.95 5.23 6.25 5.68 3 4.92 5.29 5.18 5.62 5.11 5.90 5.56 | 1 6.72 5.87 7.11 5.67 7.51 6.10 7.71 6.60 5.82 6.98 5.62 7.36 6.05 7.56 6.47 5.76 6.85 5.57 7.22 6.00 7.40 5.33 6.27 5.68 6.72 5.52 7.08 5.96 7.55 5.27 6.15 5.63 6.59 5.47 6.94 5.91 7.10 2 5.15 5.86 5.51 6.27 5.35 6.59 5.79 6.75 5 5.47 5.86 5.51 6.27 5.35 6.59 5.79 6.75 5 5.40 5.51 6.27 5.35 6.59 5.79 6.75 5 5.04 5.57 5.40 5.95 5.23 6.25 5.68 6.40 3 4.92 5.29 5.18 5.62 5.11 5.90 5.56 6.57 | 6.72 5.87 7.11 5.67 7.51 6.10 7.71 6.03 6.60 5.82 6.98 5.62 7.36 6.05 7.56 5.98 6.47 5.76 6.85 5.57 7.22 6.00 7.40 5.93 5.33 6.27 5.68 6.72 5.52 7.08 5.96 7.25 5.88 5.27 6.15 5.63 6.59 5.47 6.94 5.91 7.10 5.83 5.27 5.86 5.51 6.27 5.35 6.59 5.72 5.78 5.72 5.83 5.51 5.86 5.51 6.27 5.35 6.59 5.79 6.75 5.72 5.504 5.57 5.40 5.95 5.23 6.25 5.68 6.40 5.61 5.33 4.92 5.29 5.18 5.62 5.11 5.90 5.56 6.05 5.50 | 6.72 5.87 7.11 5.67 7.51 6.10 7.71 6.03 7.91 6.60 5.82 6.98 5.62 7.36 6.05 7.56 5.98 7.75 6.47 5.76 6.85 5.57 7.22 6.00 7.40 5.93 7.59 5.33 6.27 5.68 6.72 5.52 7.08 5.96 7.25 5.88 7.43 5.27 6.15 5.63 6.59 5.47 6.94 5.91 7.10 5.83 7.26 5.27 5.86 5.51 6.27 5.35 6.59 5.79 6.75 5.88 7.43 5.57 5.86 5.51 6.27 5.35 6.59 5.79 6.75 5.72 6.91 5.50 5.54 5.57 5.23 6.55 5.68 6.40 5.61 6.55 5.40 5.95 5.23 5.56 5.60 5.50 6.20 3 4.92 <td>6.72 5.87 7.11 5.67 7.51 6.10 7.71 6.03 7.91 5.96 6.60 5.82 6.98 5.62 7.36 6.05 7.56 5.98 7.75 5.91 6.47 5.76 6.85 5.57 7.22 6.00 7.40 5.93 7.59 5.86 1 5.33 6.27 5.68 6.72 5.52 7.08 5.96 7.25 5.88 7.43 5.81 5 5.27 6.15 5.63 6.59 5.47 6.94 5.91 7.10 5.83 7.26 5.76 5 5.86 5.51 6.27 5.35 6.59 5.71 5.03 5.76 5.76 5.72 5.81 5.76 5 5.86 5.51 6.27 5.35 6.59 5.79 6.75 5.72 6.91 5.65 5 5.04 5.57 5.40 5.95 5.23 6.25 5.86 6.40</td> <td>6.72 5.87 7.11 5.67 7.51 6.10 7.71 6.03 7.91 5.96 8.31 6.00 5.82 6.98 5.62 7.36 6.05 7.56 5.98 7.75 5.91 8.13 6.01 6.47 5.76 6.85 5.57 7.22 6.00 7.40 5.98 7.49 5.86 7.99 5.33 6.27 5.68 6.72 5.25 7.08 5.96 7.25 5.88 7.43 5.81 7.77 5.27 6.15 5.63 6.59 5.47 6.94 5.91 7.10 5.83 7.26 5.76 7.29 5.27 6.15 5.63 6.59 5.47 6.94 5.91 7.10 5.83 7.26 5.76 7.59 5.51 5.53 6.59 5.79 6.75 5.72 6.91 5.65 6.86 5.50 5.50 5.50 5.50 5.50 5.55 5.55 <t< td=""><td>6.72 5.87 7.11 5.67 7.51 6.10 7.71 6.03 7.91 5.96 8.31 6.27 6.00 5.82 6.98 5.62 7.36 6.05 7.56 5.98 7.75 5.91 8.13 6.22 6.01 6.47 5.76 6.85 5.57 7.22 6.00 7.40 5.93 7.59 5.86 7.95 6.17 5.33 6.27 5.68 6.72 5.25 7.08 5.96 7.25 5.88 7.43 5.81 7.77 6.12 5.33 6.27 5.68 6.72 5.25 7.08 5.96 7.25 5.88 7.43 5.81 7.77 6.12 5.27 6.15 5.63 6.59 5.77 7.20 5.88 7.43 5.81 7.77 6.12 5.27 6.15 5.63 6.59 5.79 7.10 5.83 7.26 5.76 7.23 5.97 5.50 <t< td=""><td>6.72 5.87 7.11 5.67 7.51 6.10 7.71 6.03 7.91 5.96 8.31 6.27 6.60 5.82 6.98 5.62 7.36 6.05 7.56 5.98 7.75 5.91 8.13 6.22 6.47 5.76 6.85 5.57 7.22 6.00
 7.40 5.93 7.59 5.86 7.95 6.17 6.12 5.33 6.27 5.68 6.72 5.52 7.08 5.96 7.25 5.88 7.43 5.81 7.77 6.12 5.33 6.27 5.68 6.72 5.52 7.08 5.96 7.25 5.88 7.43 5.81 7.77 6.12 5.27 6.15 5.63 6.59 5.77 7.20 5.88 7.43 5.81 7.77 6.12 5.27 6.15 5.63 6.59 5.79 7.10 5.83 7.26 5.76 7.23 5.97 5.58 <t< td=""><td>6 6.72 5.87 7.11 5.67 7.51 6.10 7.71 6.03 7.91 5.96 8.31 6.27 6.60 5.82 6.98 5.62 7.36 6.05 7.56 5.98 7.75 5.91 8.13 6.22 6.60 5.82 6.98 5.62 7.36 6.05 7.56 5.98 7.75 5.91 8.13 6.22 6.47 5.76 6.85 5.57 7.22 6.00 7.40 5.93 7.59 5.86 7.95 6.17 5.33 6.27 5.68 6.72 5.52 7.08 5.96 7.25 5.88 7.43 5.81 7.77 6.12 5.27 6.15 5.63 6.59 5.47 6.94 5.91 7.10 5.83 7.26 5.76 7.59 6.07 2 5.15 5.66 5.51 6.27 5.35 6.59</td></t<><td>1 6.72 5.87 7.11 5.67 7.51 6.10 7.71 6.03 7.91 5.96 8.31 6.27 1 3.0 1 6.60 5.82 6.98 5.62 7.36 6.05 7.56 5.98 7.75 5.91 8.13 6.27 1 3.0 3.0 1 6.47 5.76 6.85 5.57 7.22 6.00 7.40 5.93 7.59 5.86 7.95 6.17 1 5.0 5.0 5.0 5.01 5.01 6.17 1 5.0 5.0 5.0 5.01 6.17 1 1 5.0 5.0 5.01 6.17 6.01 5.0 5.0 5.0 5.01 5.01 6.07 6.00 7.0 5.03 5.01 6.07 6.00 7.0 5.03 5.01 7.00 5.03 5.01 7.00 5.03 5.01 7.00 5.03 5.01 7.00 5.01 5.01 5.07 6.07 6.07 0.00 11.5 1.5 5.5 5.55 5.55 5.55 5.</td><td>1 6.72 5.87 7.11 5.67 7.51 6.10 7.71 6.03 7.91 5.96 8.31 6.27 1 3.0 2 1 6.60 5.82 6.98 5.62 7.36 6.05 7.56 5.98 7.75 5.91 8.13 6.27 1 3.0 2 1 6.47 5.76 6.85 5.57 7.22 6.00 7.40 5.93 7.59 5.86 7.75 6.17 1 1 5.0 4 1 5.33 6.27 5.68 6.72 5.22 7.08 5.96 7.25 5.88 7.43 5.81 7.77 6.12 1 7.0 6 3 5.27 6.15 5.63 6.59 5.47 6.94 5.91 7.10 5.83 7.26 5.76 7.59 6.07 1 9.0 8 2 5.15 5.86 5.51 6.27 5.35 6.59 5.77 6.75 5.68 5.87 7.23 5.97 6.20 5.48 5.87</td><td>1 6.72 5.87 7.11 5.67 7.51 6.10 7.71 6.03 7.91 5.96 8.31 6.27 1 1 6.16 1 6.60 5.82 6.98 5.62 7.36 6.05 7.56 5.98 7.75 5.91 8.13 6.22 1 1 6.16 2 6.47 5.76 6.85 5.57 7.22 6.00 7.40 5.93 7.59 5.86 7.75 6.17 1 1 5.0 4 6.77 1 5.33 6.27 5.68 6.72 5.22 7.08 5.98 7.43 5.81 7.77 6.12 1 7.0 6 7.70 6 7.70 6.7 2 5.15 5.68 6.57 5.27 7.28 5.97 7.28 5.88 7.43 5.81 7.77 6.12 1 7.0 6 7.78 2 5.15 5.68 5.57 6.72 5.79 6.71 5.78 7.23 5.97 7.23 5.97 7.23 <t< td=""><td>6.72 5.87 7.11 5.67 7.51 6.10 7.71 6.03 7.91 5.96 8.31 6.27 1 6.16 6.13 6.60 5.82 6.98 5.62 7.36 6.05 7.56 5.98 7.75 5.91 8.13 6.22 3.0 2 6.37 6.33 6.47 5.76 6.85 5.57 7.22 6.00 7.40 5.93 7.59 5.86 7.55 6.17 5.0 4 6.77 6.33 5.33 6.27 5.68 6.72 5.52 7.08 5.96 7.25 5.88 7.43 5.81 7.77 6.12 7.0 6 7.18 7.14 5.27 6.15 5.63 6.59 5.47 6.94 5.91 7.10 5.83 7.26 5.76 7.59 6.07 9.0 8 7.28 7.24 2 5.15 5.66 5.51 6.27 5.35 6.59 5.77 6.27 5.55 5.68 5.87</td></t<><td>6.72 5.87 7.11 5.67 7.51 6.10 7.71 6.03 7.91 5.96 8.31 6.27 1 6.16 6.13 6.10 6.60 5.82 6.98 5.62 7.36 6.05 7.56 5.98 7.75 5.91 8.13 6.22 1 6.16 6.13 6.10 6.47 5.76 6.85 5.57 7.22 6.00 7.40 5.93 7.59 5.86 7.95 6.17 1 6.0 4 6.77 6.74 6.70 1 5.33 6.27 5.68 6.72 5.52 7.08 5.96 7.25 5.86 7.45 5.76 6.07 7.04 6.71 6.70 2 5.15 5.68 5.51 6.27 5.52 7.08 5.97 7.25 5.88 7.26 5.76 7.59 6.07 7.0 6 7.18 7.14 7.10 2 5.15 5.66 5.51 6.27 5.35 6.59 5.77 6.27 5.69 5.77 6.20 5.27<!--</td--><td>6.72 5.87 7.11 5.67 7.51 6.10 7.71 6.03 7.91 5.96 8.31 6.27 6.47 5.67 6.13 6.10 6.06 6.60 5.82 6.98 5.62 7.36 6.05 7.56 5.98 7.75 5.91 8.13 6.22 3.0 2 6.37 6.33 6.00 6.26 6.47 5.76 6.85 5.57 7.22 6.00 7.40 5.93 7.59 5.86 7.95 6.17 6.07 6.74 6.77 6.74 6.70 6.66 1 5.33 6.27 5.68 6.72 5.52 7.08 5.96 7.25 5.86 7.43 5.81 7.77 6.12 7.0 6 7.18 7.14 7.10 7.05 5 5.27 6.15 5.63 6.59 5.77 6.75 5.72 6.91 5.65 7.28 5.97 9.0 8 7.28 7.24 7.19 7.14 2 5.15 5.86 5.51</td></td></td></td></t<></td></t<></td> | 6.72 5.87 7.11 5.67 7.51 6.10 7.71 6.03 7.91 5.96 6.60 5.82 6.98 5.62 7.36 6.05 7.56 5.98 7.75 5.91 6.47 5.76 6.85 5.57 7.22 6.00 7.40 5.93 7.59 5.86 1 5.33 6.27 5.68 6.72 5.52 7.08 5.96 7.25 5.88 7.43 5.81 5 5.27 6.15 5.63 6.59 5.47 6.94 5.91 7.10 5.83 7.26 5.76 5 5.86 5.51 6.27 5.35 6.59 5.71 5.03 5.76 5.76 5.72 5.81 5.76 5 5.86 5.51 6.27 5.35 6.59 5.79 6.75 5.72 6.91 5.65 5 5.04 5.57 5.40 5.95 5.23 6.25 5.86 6.40 | 6.72 5.87 7.11 5.67 7.51 6.10 7.71 6.03 7.91 5.96 8.31 6.00 5.82 6.98 5.62 7.36 6.05 7.56 5.98 7.75 5.91 8.13 6.01 6.47 5.76 6.85 5.57 7.22 6.00 7.40 5.98 7.49 5.86 7.99 5.33 6.27 5.68 6.72 5.25 7.08 5.96 7.25 5.88 7.43 5.81 7.77 5.27 6.15 5.63 6.59 5.47 6.94 5.91
 7.10 5.83 7.26 5.76 7.29 5.27 6.15 5.63 6.59 5.47 6.94 5.91 7.10 5.83 7.26 5.76 7.59 5.51 5.53 6.59 5.79 6.75 5.72 6.91 5.65 6.86 5.50 5.50 5.50 5.50 5.50 5.55 5.55 <t< td=""><td>6.72 5.87 7.11 5.67 7.51 6.10 7.71 6.03 7.91 5.96 8.31 6.27 6.00 5.82 6.98 5.62 7.36 6.05 7.56 5.98 7.75 5.91 8.13 6.22 6.01 6.47 5.76 6.85 5.57 7.22 6.00 7.40 5.93 7.59 5.86 7.95 6.17 5.33 6.27 5.68 6.72 5.25 7.08 5.96 7.25 5.88 7.43 5.81 7.77 6.12 5.33 6.27 5.68 6.72 5.25 7.08 5.96 7.25 5.88 7.43 5.81 7.77 6.12 5.27 6.15 5.63 6.59 5.77 7.20 5.88 7.43 5.81 7.77 6.12 5.27 6.15 5.63 6.59 5.79 7.10 5.83 7.26 5.76 7.23 5.97 5.50 <t< td=""><td>6.72 5.87 7.11 5.67 7.51 6.10 7.71 6.03 7.91 5.96 8.31 6.27 6.60 5.82 6.98 5.62 7.36 6.05 7.56 5.98 7.75 5.91 8.13 6.22 6.47 5.76 6.85 5.57 7.22 6.00 7.40 5.93 7.59 5.86 7.95 6.17 6.12 5.33 6.27 5.68 6.72 5.52 7.08 5.96 7.25 5.88 7.43 5.81 7.77 6.12 5.33 6.27 5.68 6.72 5.52 7.08 5.96 7.25 5.88 7.43 5.81 7.77 6.12 5.27 6.15 5.63 6.59 5.77 7.20 5.88 7.43 5.81 7.77 6.12 5.27 6.15 5.63 6.59 5.79 7.10 5.83 7.26 5.76 7.23 5.97 5.58 <t< td=""><td>6 6.72 5.87 7.11 5.67 7.51 6.10 7.71 6.03 7.91 5.96 8.31 6.27 6.60 5.82 6.98 5.62 7.36 6.05 7.56 5.98 7.75 5.91 8.13 6.22 6.60 5.82 6.98 5.62 7.36 6.05 7.56 5.98 7.75 5.91 8.13 6.22 6.47 5.76 6.85 5.57 7.22 6.00 7.40 5.93 7.59 5.86 7.95 6.17 5.33 6.27 5.68 6.72 5.52 7.08 5.96 7.25 5.88 7.43 5.81 7.77 6.12 5.27 6.15 5.63 6.59 5.47 6.94 5.91 7.10 5.83 7.26 5.76 7.59 6.07 2 5.15 5.66 5.51 6.27 5.35 6.59</td></t<><td>1 6.72 5.87 7.11 5.67 7.51 6.10 7.71 6.03 7.91 5.96 8.31 6.27 1 3.0 1 6.60 5.82 6.98 5.62 7.36 6.05 7.56 5.98 7.75 5.91 8.13 6.27 1 3.0 3.0 1 6.47 5.76 6.85 5.57 7.22 6.00 7.40 5.93 7.59 5.86 7.95 6.17 1 5.0 5.0 5.0 5.01 5.01 6.17 1 5.0 5.0 5.0 5.01 6.17 1 1 5.0 5.0 5.01 6.17 6.01 5.0 5.0 5.0 5.01 5.01 6.07 6.00 7.0 5.03 5.01 6.07 6.00 7.0 5.03 5.01 7.00 5.03 5.01 7.00 5.03 5.01 7.00 5.03 5.01 7.00 5.01 5.01 5.07 6.07 6.07 0.00 11.5 1.5 5.5 5.55 5.55 5.55 5.</td><td>1 6.72 5.87 7.11 5.67 7.51 6.10 7.71 6.03 7.91 5.96 8.31 6.27 1 3.0 2 1 6.60 5.82 6.98 5.62 7.36 6.05 7.56 5.98 7.75 5.91 8.13 6.27 1 3.0 2 1 6.47 5.76 6.85 5.57 7.22 6.00 7.40 5.93 7.59 5.86 7.75 6.17 1 1 5.0 4 1 5.33 6.27 5.68 6.72 5.22 7.08 5.96 7.25 5.88 7.43 5.81 7.77 6.12 1 7.0 6 3 5.27 6.15 5.63 6.59 5.47 6.94 5.91 7.10 5.83 7.26 5.76 7.59 6.07 1 9.0 8 2 5.15 5.86 5.51 6.27 5.35 6.59 5.77 6.75 5.68 5.87 7.23 5.97 6.20 5.48 5.87</td><td>1 6.72 5.87 7.11 5.67 7.51 6.10 7.71 6.03 7.91 5.96 8.31 6.27 1 1 6.16 1 6.60 5.82 6.98 5.62 7.36 6.05 7.56 5.98 7.75 5.91 8.13 6.22 1 1 6.16 2 6.47 5.76 6.85 5.57 7.22 6.00 7.40 5.93 7.59 5.86 7.75 6.17 1 1 5.0 4 6.77 1 5.33 6.27 5.68 6.72 5.22 7.08 5.98 7.43 5.81 7.77 6.12 1 7.0 6 7.70 6 7.70 6.7 2 5.15 5.68 6.57 5.27 7.28 5.97 7.28 5.88 7.43 5.81 7.77 6.12 1 7.0 6 7.78 2 5.15 5.68 5.57 6.72 5.79 6.71 5.78 7.23 5.97 7.23 5.97 7.23 <t< td=""><td>6.72 5.87 7.11 5.67 7.51 6.10 7.71 6.03 7.91 5.96 8.31 6.27 1 6.16 6.13 6.60 5.82 6.98 5.62 7.36 6.05 7.56 5.98 7.75 5.91 8.13 6.22 3.0 2 6.37 6.33 6.47 5.76 6.85 5.57 7.22 6.00 7.40 5.93 7.59 5.86 7.55 6.17 5.0 4 6.77 6.33 5.33 6.27 5.68 6.72 5.52 7.08 5.96 7.25 5.88 7.43 5.81 7.77 6.12 7.0 6 7.18 7.14 5.27 6.15 5.63 6.59 5.47 6.94 5.91 7.10 5.83 7.26 5.76 7.59 6.07 9.0 8 7.28 7.24 2 5.15 5.66 5.51 6.27 5.35 6.59 5.77 6.27 5.55 5.68 5.87</td></t<><td>6.72 5.87 7.11 5.67 7.51 6.10 7.71 6.03 7.91 5.96 8.31 6.27 1 6.16 6.13 6.10 6.60 5.82 6.98 5.62 7.36 6.05 7.56 5.98 7.75 5.91 8.13 6.22 1 6.16 6.13 6.10 6.47 5.76 6.85 5.57 7.22 6.00 7.40 5.93 7.59 5.86 7.95 6.17 1 6.0 4 6.77 6.74 6.70 1 5.33 6.27 5.68 6.72 5.52 7.08 5.96 7.25 5.86 7.45 5.76 6.07 7.04 6.71 6.70 2 5.15 5.68 5.51 6.27 5.52 7.08 5.97 7.25 5.88 7.26 5.76 7.59 6.07 7.0 6 7.18 7.14 7.10 2 5.15 5.66 5.51 6.27 5.35 6.59 5.77 6.27 5.69 5.77 6.20 5.27<!--</td--><td>6.72 5.87 7.11 5.67 7.51 6.10 7.71 6.03 7.91 5.96 8.31 6.27 6.47 5.67 6.13 6.10 6.06 6.60 5.82 6.98 5.62 7.36 6.05 7.56 5.98 7.75 5.91 8.13 6.22 3.0 2 6.37 6.33 6.00 6.26 6.47 5.76 6.85 5.57 7.22 6.00 7.40 5.93 7.59 5.86 7.95 6.17 6.07 6.74 6.77 6.74 6.70 6.66 1 5.33 6.27 5.68 6.72 5.52 7.08 5.96 7.25 5.86 7.43 5.81 7.77 6.12 7.0 6 7.18 7.14 7.10 7.05 5 5.27 6.15 5.63 6.59 5.77 6.75 5.72 6.91
5.65 7.28 5.97 9.0 8 7.28 7.24 7.19 7.14 2 5.15 5.86 5.51</td></td></td></td></t<></td></t<> | 6.72 5.87 7.11 5.67 7.51 6.10 7.71 6.03 7.91 5.96 8.31 6.27 6.00 5.82 6.98 5.62 7.36 6.05 7.56 5.98 7.75 5.91 8.13 6.22 6.01 6.47 5.76 6.85 5.57 7.22 6.00 7.40 5.93 7.59 5.86 7.95 6.17 5.33 6.27 5.68 6.72 5.25 7.08 5.96 7.25 5.88 7.43 5.81 7.77 6.12 5.33 6.27 5.68 6.72 5.25 7.08 5.96 7.25 5.88 7.43 5.81 7.77 6.12 5.27 6.15 5.63 6.59 5.77 7.20 5.88 7.43 5.81 7.77 6.12 5.27 6.15 5.63 6.59 5.79 7.10 5.83 7.26 5.76 7.23 5.97 5.50 <t< td=""><td>6.72 5.87 7.11 5.67 7.51 6.10 7.71 6.03 7.91 5.96 8.31 6.27 6.60 5.82 6.98 5.62 7.36 6.05 7.56 5.98 7.75 5.91 8.13 6.22 6.47 5.76 6.85 5.57 7.22 6.00 7.40 5.93 7.59 5.86 7.95 6.17 6.12 5.33 6.27 5.68 6.72 5.52 7.08 5.96 7.25 5.88 7.43 5.81 7.77 6.12 5.33 6.27 5.68 6.72 5.52 7.08 5.96 7.25 5.88 7.43 5.81 7.77 6.12 5.27 6.15 5.63 6.59 5.77 7.20 5.88 7.43 5.81 7.77 6.12 5.27 6.15 5.63 6.59 5.79 7.10 5.83 7.26 5.76 7.23 5.97 5.58 <t< td=""><td>6 6.72 5.87 7.11 5.67 7.51 6.10 7.71 6.03 7.91 5.96 8.31 6.27 6.60 5.82 6.98 5.62 7.36 6.05 7.56 5.98 7.75 5.91 8.13 6.22 6.60 5.82 6.98 5.62 7.36 6.05 7.56 5.98 7.75 5.91 8.13 6.22 6.47 5.76 6.85 5.57 7.22 6.00 7.40 5.93 7.59 5.86 7.95 6.17 5.33 6.27 5.68 6.72 5.52 7.08 5.96 7.25 5.88 7.43 5.81 7.77 6.12 5.27 6.15 5.63 6.59 5.47 6.94 5.91 7.10 5.83 7.26 5.76 7.59 6.07 2 5.15 5.66 5.51 6.27 5.35 6.59</td></t<><td>1 6.72 5.87 7.11 5.67 7.51 6.10 7.71 6.03 7.91 5.96 8.31 6.27 1 3.0 1 6.60 5.82 6.98 5.62 7.36 6.05 7.56 5.98 7.75 5.91 8.13 6.27 1 3.0 3.0 1 6.47 5.76 6.85 5.57 7.22 6.00 7.40 5.93 7.59 5.86 7.95 6.17 1 5.0 5.0 5.0 5.01 5.01 6.17 1 5.0 5.0 5.0 5.01 6.17 1 1 5.0 5.0 5.01 6.17 6.01 5.0 5.0 5.0 5.01 5.01 6.07 6.00 7.0 5.03 5.01 6.07 6.00 7.0 5.03 5.01 7.00 5.03 5.01 7.00 5.03 5.01 7.00 5.03 5.01 7.00 5.01 5.01 5.07 6.07 6.07 0.00 11.5 1.5 5.5 5.55 5.55 5.55 5.</td><td>1 6.72 5.87 7.11 5.67 7.51 6.10 7.71 6.03 7.91 5.96 8.31 6.27 1 3.0 2 1 6.60 5.82 6.98 5.62 7.36 6.05 7.56 5.98 7.75 5.91 8.13 6.27 1 3.0 2 1 6.47 5.76 6.85 5.57 7.22 6.00 7.40 5.93 7.59 5.86 7.75 6.17 1 1 5.0 4 1 5.33 6.27 5.68 6.72 5.22 7.08 5.96 7.25 5.88 7.43 5.81 7.77 6.12 1 7.0 6 3 5.27 6.15 5.63 6.59 5.47 6.94 5.91 7.10 5.83 7.26 5.76 7.59 6.07 1 9.0 8 2 5.15 5.86 5.51 6.27 5.35 6.59 5.77 6.75 5.68 5.87 7.23 5.97 6.20 5.48 5.87</td><td>1 6.72 5.87 7.11 5.67 7.51 6.10 7.71 6.03 7.91 5.96 8.31 6.27 1 1 6.16 1 6.60 5.82 6.98 5.62 7.36 6.05 7.56 5.98 7.75 5.91 8.13 6.22 1 1 6.16 2 6.47 5.76 6.85 5.57 7.22 6.00 7.40 5.93 7.59 5.86 7.75 6.17 1 1 5.0 4 6.77 1 5.33 6.27 5.68 6.72 5.22 7.08 5.98 7.43 5.81 7.77 6.12 1 7.0 6 7.70 6 7.70 6.7 2 5.15 5.68 6.57 5.27 7.28 5.97 7.28 5.88 7.43 5.81 7.77 6.12 1 7.0 6 7.78 2 5.15 5.68 5.57 6.72 5.79 6.71 5.78 7.23 5.97 7.23 5.97 7.23 <t< td=""><td>6.72 5.87 7.11 5.67 7.51 6.10 7.71 6.03 7.91 5.96 8.31 6.27 1 6.16 6.13 6.60 5.82 6.98 5.62 7.36 6.05 7.56 5.98 7.75 5.91 8.13 6.22 3.0 2 6.37 6.33 6.47 5.76 6.85 5.57 7.22 6.00 7.40 5.93 7.59 5.86 7.55 6.17 5.0 4 6.77 6.33 5.33 6.27 5.68 6.72 5.52 7.08 5.96 7.25 5.88 7.43 5.81 7.77 6.12 7.0 6 7.18 7.14 5.27 6.15 5.63 6.59 5.47 6.94 5.91 7.10 5.83 7.26 5.76 7.59 6.07 9.0 8 7.28 7.24 2 5.15 5.66 5.51 6.27 5.35 6.59 5.77 6.27 5.55 5.68 5.87</td></t<><td>6.72 5.87 7.11 5.67 7.51 6.10 7.71 6.03 7.91 5.96 8.31 6.27 1 6.16 6.13 6.10 6.60 5.82 6.98 5.62 7.36 6.05 7.56 5.98 7.75 5.91 8.13 6.22 1 6.16 6.13 6.10 6.47 5.76 6.85 5.57 7.22 6.00 7.40 5.93 7.59 5.86 7.95 6.17 1 6.0 4 6.77 6.74 6.70 1 5.33 6.27 5.68 6.72 5.52 7.08 5.96 7.25 5.86 7.45 5.76 6.07 7.04 6.71 6.70 2 5.15 5.68 5.51 6.27 5.52 7.08 5.97 7.25 5.88 7.26 5.76 7.59 6.07 7.0 6 7.18 7.14 7.10 2 5.15 5.66 5.51 6.27 5.35 6.59 5.77 6.27 5.69 5.77 6.20 5.27<!--</td--><td>6.72 5.87 7.11 5.67 7.51 6.10 7.71 6.03 7.91 5.96 8.31 6.27 6.47 5.67 6.13 6.10 6.06 6.60 5.82 6.98 5.62 7.36 6.05 7.56 5.98 7.75 5.91 8.13 6.22 3.0 2 6.37 6.33 6.00 6.26 6.47 5.76 6.85 5.57 7.22 6.00 7.40 5.93 7.59 5.86 7.95 6.17 6.07 6.74 6.77 6.74 6.70 6.66 1 5.33 6.27 5.68 6.72 5.52 7.08 5.96 7.25 5.86 7.43 5.81 7.77 6.12 7.0 6 7.18 7.14 7.10 7.05 5 5.27 6.15 5.63 6.59 5.77 6.75 5.72 6.91 5.65 7.28 5.97 9.0 8 7.28 7.24 7.19 7.14 2 5.15 5.86 5.51</td></td></td></td></t<> | 6.72 5.87 7.11 5.67 7.51 6.10 7.71 6.03 7.91 5.96
8.31 6.27 6.60 5.82 6.98 5.62 7.36 6.05 7.56 5.98 7.75 5.91 8.13 6.22 6.47 5.76 6.85 5.57 7.22 6.00 7.40 5.93 7.59 5.86 7.95 6.17 6.12 5.33 6.27 5.68 6.72 5.52 7.08 5.96 7.25 5.88 7.43 5.81 7.77 6.12 5.33 6.27 5.68 6.72 5.52 7.08 5.96 7.25 5.88 7.43 5.81 7.77 6.12 5.27 6.15 5.63 6.59 5.77 7.20 5.88 7.43 5.81 7.77 6.12 5.27 6.15 5.63 6.59 5.79 7.10 5.83 7.26 5.76 7.23 5.97 5.58 <t< td=""><td>6 6.72 5.87 7.11 5.67 7.51 6.10 7.71 6.03 7.91 5.96 8.31 6.27 6.60 5.82 6.98 5.62 7.36 6.05 7.56 5.98 7.75 5.91 8.13 6.22 6.60 5.82 6.98 5.62 7.36 6.05 7.56 5.98 7.75 5.91 8.13 6.22 6.47 5.76 6.85 5.57 7.22 6.00 7.40 5.93 7.59 5.86 7.95 6.17 5.33 6.27 5.68 6.72 5.52 7.08 5.96 7.25 5.88 7.43 5.81 7.77 6.12 5.27 6.15 5.63 6.59 5.47 6.94 5.91 7.10 5.83 7.26 5.76 7.59 6.07 2 5.15 5.66 5.51 6.27 5.35 6.59</td></t<> <td>1 6.72 5.87 7.11 5.67 7.51 6.10 7.71 6.03 7.91 5.96 8.31 6.27 1 3.0 1 6.60 5.82 6.98 5.62 7.36 6.05 7.56 5.98 7.75 5.91 8.13 6.27 1 3.0 3.0 1 6.47 5.76 6.85 5.57 7.22 6.00 7.40 5.93 7.59 5.86 7.95 6.17 1 5.0 5.0 5.0 5.01 5.01 6.17 1 5.0 5.0 5.0 5.01 6.17 1 1 5.0 5.0 5.01 6.17 6.01 5.0 5.0 5.0 5.01 5.01 6.07 6.00 7.0 5.03 5.01 6.07 6.00 7.0 5.03 5.01 7.00 5.03 5.01 7.00 5.03 5.01 7.00 5.03 5.01 7.00 5.01 5.01 5.07 6.07 6.07 0.00 11.5 1.5 5.5 5.55 5.55 5.55 5.</td> <td>1 6.72 5.87 7.11 5.67 7.51 6.10 7.71 6.03 7.91 5.96 8.31 6.27 1 3.0 2 1 6.60 5.82 6.98 5.62 7.36 6.05 7.56 5.98 7.75 5.91 8.13 6.27 1 3.0 2 1 6.47 5.76 6.85 5.57 7.22 6.00 7.40 5.93 7.59 5.86 7.75 6.17 1 1 5.0 4 1 5.33 6.27 5.68 6.72 5.22 7.08 5.96 7.25 5.88 7.43 5.81 7.77 6.12 1 7.0 6 3 5.27 6.15 5.63 6.59 5.47 6.94 5.91 7.10 5.83 7.26 5.76 7.59 6.07 1 9.0 8 2 5.15 5.86 5.51 6.27 5.35 6.59 5.77 6.75 5.68 5.87 7.23 5.97 6.20 5.48 5.87</td> <td>1 6.72 5.87 7.11 5.67 7.51 6.10 7.71 6.03 7.91 5.96 8.31 6.27 1 1 6.16 1 6.60 5.82 6.98 5.62 7.36 6.05 7.56 5.98 7.75 5.91 8.13 6.22 1 1 6.16 2 6.47 5.76 6.85 5.57 7.22 6.00 7.40 5.93 7.59 5.86 7.75 6.17 1 1 5.0 4 6.77 1 5.33 6.27 5.68 6.72 5.22 7.08 5.98 7.43 5.81 7.77 6.12 1 7.0 6 7.70 6 7.70 6.7 2 5.15 5.68 6.57 5.27 7.28 5.97 7.28 5.88 7.43 5.81 7.77 6.12 1 7.0 6 7.78 2 5.15 5.68 5.57 6.72 5.79 6.71 5.78 7.23 5.97 7.23 5.97 7.23 <t< td=""><td>6.72 5.87 7.11 5.67 7.51 6.10 7.71 6.03 7.91 5.96 8.31 6.27 1 6.16 6.13 6.60 5.82 6.98 5.62 7.36 6.05 7.56 5.98 7.75 5.91 8.13 6.22 3.0 2 6.37 6.33 6.47 5.76 6.85 5.57 7.22 6.00 7.40 5.93 7.59 5.86 7.55 6.17 5.0 4 6.77 6.33 5.33 6.27 5.68 6.72 5.52 7.08 5.96 7.25 5.88 7.43 5.81 7.77 6.12 7.0 6 7.18 7.14 5.27 6.15 5.63 6.59 5.47 6.94 5.91 7.10 5.83 7.26 5.76 7.59 6.07 9.0 8 7.28 7.24 2 5.15 5.66 5.51 6.27 5.35 6.59 5.77 6.27 5.55 5.68 5.87</td></t<><td>6.72 5.87 7.11 5.67 7.51 6.10 7.71 6.03 7.91 5.96 8.31 6.27 1 6.16 6.13 6.10 6.60 5.82 6.98 5.62 7.36 6.05 7.56 5.98 7.75 5.91 8.13 6.22 1 6.16 6.13 6.10 6.47 5.76 6.85 5.57 7.22 6.00 7.40 5.93 7.59 5.86 7.95 6.17 1 6.0 4 6.77 6.74 6.70 1 5.33 6.27 5.68 6.72 5.52 7.08 5.96 7.25 5.86 7.45 5.76 6.07 7.04 6.71 6.70 2 5.15 5.68 5.51 6.27 5.52 7.08 5.97 7.25 5.88 7.26 5.76 7.59 6.07 7.0 6 7.18 7.14 7.10 2 5.15 5.66 5.51 6.27 5.35 6.59 5.77 6.27 5.69 5.77 6.20 5.27<!--</td--><td>6.72 5.87 7.11 5.67 7.51 6.10 7.71 6.03 7.91 5.96 8.31 6.27 6.47 5.67 6.13 6.10 6.06 6.60 5.82 6.98 5.62 7.36 6.05 7.56 5.98 7.75 5.91 8.13 6.22 3.0 2 6.37 6.33 6.00 6.26 6.47 5.76 6.85 5.57 7.22 6.00 7.40 5.93 7.59 5.86 7.95 6.17 6.07 6.74 6.77 6.74 6.70 6.66 1 5.33 6.27 5.68 6.72 5.52 7.08 5.96 7.25 5.86 7.43 5.81 7.77 6.12 7.0 6 7.18 7.14 7.10 7.05 5 5.27 6.15 5.63 6.59 5.77 6.75 5.72 6.91 5.65 7.28 5.97 9.0 8 7.28 7.24 7.19 7.14 2 5.15 5.86 5.51</td></td></td> | 6 6.72 5.87 7.11 5.67 7.51 6.10 7.71 6.03 7.91 5.96 8.31 6.27 6.60 5.82 6.98 5.62 7.36 6.05 7.56 5.98 7.75 5.91 8.13 6.22 6.60 5.82 6.98 5.62 7.36 6.05 7.56 5.98 7.75 5.91 8.13 6.22 6.47 5.76 6.85 5.57 7.22 6.00 7.40 5.93 7.59 5.86 7.95 6.17 5.33 6.27 5.68 6.72 5.52 7.08 5.96 7.25 5.88 7.43 5.81 7.77 6.12 5.27 6.15 5.63 6.59 5.47 6.94 5.91 7.10 5.83 7.26 5.76 7.59 6.07 2 5.15 5.66 5.51 6.27 5.35 6.59 | 1 6.72 5.87 7.11 5.67 7.51 6.10 7.71 6.03 7.91 5.96 8.31 6.27 1 3.0 1 6.60 5.82 6.98 5.62 7.36 6.05 7.56 5.98 7.75 5.91 8.13 6.27 1 3.0 3.0 1 6.47 5.76 6.85 5.57 7.22 6.00 7.40 5.93 7.59 5.86 7.95 6.17 1 5.0 5.0 5.0
5.01 5.01 6.17 1 5.0 5.0 5.0 5.01 6.17 1 1 5.0 5.0 5.01 6.17 6.01 5.0 5.0 5.0 5.01 5.01 6.07 6.00 7.0 5.03 5.01 6.07 6.00 7.0 5.03 5.01 7.00 5.03 5.01 7.00 5.03 5.01 7.00 5.03 5.01 7.00 5.01 5.01 5.07 6.07 6.07 0.00 11.5 1.5 5.5 5.55 5.55 5.55 5. | 1 6.72 5.87 7.11 5.67 7.51 6.10 7.71 6.03 7.91 5.96 8.31 6.27 1 3.0 2 1 6.60 5.82 6.98 5.62 7.36 6.05 7.56 5.98 7.75 5.91 8.13 6.27 1 3.0 2 1 6.47 5.76 6.85 5.57 7.22 6.00 7.40 5.93 7.59 5.86 7.75 6.17 1 1 5.0 4 1 5.33 6.27 5.68 6.72 5.22 7.08 5.96 7.25 5.88 7.43 5.81 7.77 6.12 1 7.0 6 3 5.27 6.15 5.63 6.59 5.47 6.94 5.91 7.10 5.83 7.26 5.76 7.59 6.07 1 9.0 8 2 5.15 5.86 5.51 6.27 5.35 6.59 5.77 6.75 5.68 5.87 7.23 5.97 6.20 5.48 5.87 | 1 6.72 5.87 7.11 5.67 7.51 6.10 7.71 6.03 7.91 5.96 8.31 6.27 1 1 6.16 1 6.60 5.82 6.98 5.62 7.36 6.05 7.56 5.98 7.75 5.91 8.13 6.22 1 1 6.16 2 6.47 5.76 6.85 5.57 7.22 6.00 7.40 5.93 7.59 5.86 7.75 6.17 1 1 5.0 4 6.77 1 5.33 6.27 5.68 6.72 5.22 7.08 5.98 7.43 5.81 7.77 6.12 1 7.0 6 7.70 6 7.70 6.7 2 5.15 5.68 6.57 5.27 7.28 5.97 7.28 5.88 7.43 5.81 7.77 6.12 1 7.0 6 7.78 2 5.15 5.68 5.57 6.72 5.79 6.71 5.78 7.23 5.97 7.23 5.97 7.23 <t< td=""><td>6.72 5.87 7.11 5.67 7.51 6.10 7.71 6.03 7.91 5.96 8.31 6.27 1 6.16 6.13 6.60 5.82 6.98 5.62 7.36 6.05 7.56 5.98 7.75 5.91 8.13 6.22 3.0 2 6.37 6.33 6.47 5.76 6.85 5.57 7.22 6.00 7.40 5.93 7.59 5.86 7.55 6.17 5.0 4 6.77 6.33 5.33 6.27 5.68 6.72 5.52 7.08 5.96 7.25 5.88 7.43 5.81 7.77 6.12 7.0 6 7.18 7.14 5.27 6.15 5.63 6.59 5.47 6.94 5.91 7.10 5.83 7.26 5.76 7.59 6.07 9.0 8 7.28 7.24 2 5.15 5.66 5.51 6.27 5.35 6.59 5.77 6.27 5.55 5.68 5.87</td></t<> <td>6.72 5.87 7.11 5.67 7.51 6.10 7.71 6.03 7.91 5.96 8.31 6.27 1 6.16 6.13 6.10 6.60 5.82 6.98 5.62 7.36 6.05 7.56 5.98 7.75 5.91 8.13 6.22 1 6.16 6.13 6.10 6.47 5.76 6.85 5.57 7.22 6.00 7.40 5.93 7.59 5.86 7.95 6.17 1 6.0 4 6.77 6.74 6.70 1 5.33 6.27 5.68 6.72 5.52 7.08 5.96 7.25 5.86 7.45 5.76 6.07 7.04 6.71 6.70 2 5.15 5.68 5.51 6.27 5.52 7.08 5.97 7.25 5.88 7.26 5.76 7.59 6.07 7.0 6 7.18 7.14 7.10 2 5.15 5.66 5.51 6.27 5.35 6.59 5.77 6.27 5.69 5.77 6.20 5.27<!--</td--><td>6.72 5.87 7.11 5.67 7.51 6.10 7.71 6.03 7.91 5.96 8.31 6.27 6.47 5.67 6.13 6.10 6.06 6.60 5.82 6.98 5.62 7.36 6.05 7.56 5.98 7.75 5.91 8.13 6.22 3.0 2 6.37 6.33 6.00 6.26 6.47 5.76 6.85 5.57 7.22 6.00 7.40 5.93 7.59 5.86 7.95 6.17 6.07 6.74 6.77 6.74 6.70 6.66 1 5.33 6.27 5.68 6.72 5.52 7.08 5.96 7.25 5.86 7.43 5.81 7.77 6.12 7.0 6 7.18 7.14 7.10 7.05 5 5.27 6.15 5.63 6.59 5.77 6.75 5.72 6.91 5.65 7.28 5.97 9.0 8 7.28 7.24 7.19 7.14 2 5.15 5.86 5.51</td></td> | 6.72 5.87 7.11 5.67 7.51 6.10 7.71 6.03 7.91 5.96 8.31 6.27 1 6.16 6.13 6.60 5.82 6.98 5.62 7.36 6.05 7.56 5.98 7.75 5.91 8.13 6.22 3.0 2 6.37 6.33 6.47 5.76 6.85 5.57 7.22 6.00 7.40 5.93 7.59 5.86 7.55 6.17 5.0 4 6.77 6.33 5.33 6.27 5.68 6.72 5.52 7.08 5.96 7.25 5.88 7.43 5.81 7.77 6.12 7.0 6 7.18 7.14 5.27 6.15 5.63 6.59 5.47 6.94 5.91 7.10 5.83 7.26 5.76 7.59 6.07 9.0 8 7.28 7.24 2 5.15 5.66 5.51 6.27 5.35 6.59 5.77 6.27 5.55 5.68 5.87 | 6.72 5.87 7.11 5.67 7.51 6.10 7.71 6.03 7.91 5.96 8.31 6.27 1 6.16 6.13 6.10 6.60 5.82 6.98 5.62 7.36 6.05 7.56 5.98 7.75 5.91 8.13 6.22 1 6.16 6.13 6.10 6.47 5.76 6.85 5.57 7.22 6.00 7.40 5.93 7.59 5.86 7.95 6.17 1 6.0 4 6.77 6.74 6.70 1 5.33 6.27 5.68 6.72 5.52 7.08 5.96 7.25 5.86 7.45 5.76 6.07 7.04 6.71 6.70 2 5.15 5.68 5.51 6.27 5.52 7.08 5.97 7.25 5.88 7.26 5.76 7.59 6.07 7.0 6 7.18 7.14 7.10 2 5.15 5.66 5.51 6.27 5.35 6.59 5.77 6.27 5.69 5.77 6.20 5.27 </td <td>6.72 5.87 7.11 5.67 7.51 6.10 7.71 6.03 7.91 5.96 8.31 6.27 6.47 5.67 6.13 6.10 6.06 6.60 5.82 6.98 5.62 7.36 6.05 7.56 5.98 7.75 5.91 8.13 6.22 3.0 2 6.37 6.33 6.00 6.26 6.47 5.76 6.85 5.57 7.22 6.00 7.40 5.93 7.59 5.86 7.95 6.17 6.07 6.74 6.77 6.74 6.70 6.66 1 5.33 6.27 5.68 6.72 5.52 7.08 5.96 7.25 5.86 7.43 5.81 7.77 6.12 7.0 6 7.18 7.14 7.10 7.05 5 5.27 6.15 5.63 6.59 5.77 6.75 5.72 6.91 5.65 7.28 5.97 9.0 8 7.28 7.24 7.19 7.14 2 5.15 5.86 5.51</td> | 6.72 5.87 7.11 5.67 7.51 6.10 7.71 6.03 7.91 5.96 8.31 6.27 6.47 5.67 6.13 6.10 6.06 6.60 5.82 6.98 5.62 7.36 6.05 7.56 5.98 7.75 5.91 8.13 6.22 3.0 2 6.37 6.33 6.00 6.26 6.47 5.76 6.85 5.57 7.22 6.00 7.40 5.93 7.59 5.86 7.95 6.17 6.07 6.74 6.77 6.74 6.70 6.66 1 5.33 6.27 5.68 6.72 5.52 7.08 5.96 7.25 5.86 7.43 5.81 7.77 6.12 7.0 6 7.18 7.14 7.10 7.05 5 5.27 6.15 5.63 6.59 5.77 6.75 5.72 6.91 5.65 7.28 5.97 9.0 8 7.28 7.24 7.19 7.14 2 5.15 5.86 5.51 |

PJG000Z189

Cooling		-														(kW)		<u> </u>					(k\
Dutdoor								or air t										door	In	door a		peratu	e
ir temp.	18°0	DB	21°C													DB	air te	emp.			°CDB		
	12°C	WB	14°C	WB	16℃								WB	°CDB	°CWB	16	18	20	22	24			
°CDB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	-14.5	-15	5.26	5.24	5.21	5.18	5.1
11					8.35	6.95	8.93	7.59	9.21	7.47	9.59	7.37	10.34	7.83	11.09	7.56	-13.5	-14	5.38	5.35	5.32	5.29	5.2
13					8.42	6.96	8.94	7.59	9.20	7.47	9.55	7.36	10.25	7.82	10.96	7.54	-11.5	-12	5.61	5.58	5.55	5.52	5.4
15					8.48	6.98	8.96	7.59	9.19	7.47	9.52	7.35	10.17	7.80	10.83	7.53	-9.5	-10	5.84	5.81	5.78	5.74	5.7
17					8.54	7.00	8.97	7.60	9.18	7.47	9.49	7.35	10.09	7.79	10.70	7.51	-7.5	-8	6.07	6.04	6.00	5.97	5.9
19					8.51	6.99	8.96	7.60	9.19	7.47	9.48	7.35	10.06	7.78	10.63	7.50	-5.5	-6	6.50	6.46	6.42	6.38	6.3
21					8.32	6.94	8.96	7.60	9.20	7.47	9.47	7.34	10.02	7.78	10.57	7.49	-3.0	-4	6.93	6.88	6.84	6.79	6.7
23					8.52	6.99	9.04	7.62	9.21	7.47	9.47	7.35	10.00	7.77	10.52	7.48	-1.0	-2	7.36	7.31	7.26	7.21	7.1
25			8.10	7.36	8.72	7.05	9.13	7.64	9.23	7.48	9.48	7.35	9.97	7.77	10.47	7.47	1.0	0	7.79	7.73	7.67	7.62	7.5
27			8.38	7.45	8.92	7.11	9.22	7.66	9.24	7.48	9.27	7.30	9.31	7.65			2.0	1	8.00	7.94	7.88	7.82	7.7
29			8.25	7.41	8.77	7.07	9.11	7.63	9.18	7.46	9.26	7.30	9.41	7.67			3.0	2	8.23	8.17	8.11	8.04	7.9
31			8.11	7.36	8.62	7.02	9.00	7.60	9.12	7.45	9.25	7.30	9.50	7.68			5.0	4	8.68	8.62	8.55	8.49	8.4
33	7.53	6.79	7.88	7.29	8.46	6.98	8.88	7.58	9.06	7.44	9.24	7.29	9.59	7.70			7.0	6	9.13	9.07	9.00	8.93	8.8
35	7.41	6.74	7.74	7.24	8.31	6.93	8.77	7.55	9.00	7.42	9.23	7.29	9.68	7.72			9.0	8	9.61	9.54	9.47	9.39	9.3
37	7.15	6.65	7.47	7.16	8.00	6.85	8.44	7.47	8.66	7.35	8.88	7.22	9.33	7.65			11.5	10	10.09	10.01	9.93	9.85	9.7
39	6.89	6.55	7.20	7.05	7.70	6.76	8.11	7.39	8.32	7.27	8.54	7.15	8.97	7.59			13.5	12	10.26	10.18	10.10	10.01	9.9
41	6.63	6.46	6.92	6.78	7.39	6.68	7.77	7.31	7.98	7.20	8.20	7.08	8.62	7.53			15.5	14	10.42	10.34	10.26	10.17	10.
43	6.36	6.24	6.65	6.52	7.08	6.59	7.44	7.23	7.65	7.12	7.85	7.01	8.26	7.48			16.5	16	10.51	10.42	10.34	10.25	10.

Note(1) These data show average statuses. Depending on the system control, there may be ranges where the operation is not conducted continuously. These data show the case where the operation frequency of a compressor is same as nominal condition frequency or follows the protection controls.
 (2) Capacities are based on the following conditions. Corresponding refrigerant piping length :7.5m Leavel difference : 0m

Level difference : Om Indoor fan speed : PHi (3) Symbols are as follows. TC : Total cooling capacity (kW), SHC : Sensible heat capacity (kW), HC : Heating capacity (kW)

#

(5) Floor standing type (FDF)

Model FDF71VNPVD1 Indoor unit FDF71VD1 Cooling Mode Outdoor unit FDC71VNP

Outdoor			-		-		Indo	or air t	emper	ature	-		-		-			Οι
air temp.	18°0	DB	21°C	DB	23°C	DB	26°0	DB	27°C	DB	28°C	DB	31°C	DB	33°C	DB	Ш	air
an temp.	12°C	WB	14°C	WB	16℃	WB	18°C	WB	19°C	WB	20°C	WB	22°C	WB	24°C	WB	°	CDE
°CDB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	1 -1	14.5
11					4.71	4.18	5.34	4.67	5.65	4.66	5.78	4.60	6.04	4.85	6.30	4.71	1 -1	13.5
13					5.00	4.28	5.58	4.75	5.87	4.73	5.99	4.66	6.23	4.90	6.48	4.75	1 -1	11.5
15					5.30	4.39	5.83	4.83	6.09	4.80	6.20	4.72	6.43	4.95	6.66	4.79	11.	-9.5
17					5.59	4.49	6.07	4.91	6.31	4.87	6.41	4.78	6.62	5.00	6.83	4.83	11-	-7.5
19					5.73	4.54	6.13	4.93	6.34	4.88	6.48	4.80	6.76	5.03	7.04	4.87	11-	-5.5
21					5.80	4.57	6.20	4.95	6.36	4.88	6.54	4.82	6.89	5.07	7.25	4.92	11-	-3.0
23					6.23	4.73	6.63	5.09	6.81	5.03	6.96	4.95	7.26	5.17	7.56	4.99	11-	-1.0
25			6.26	5.07	6.67	4.90	7.07	5.25	7.26	5.17	7.38	5.08	7.63	5.27	7.88	5.07		1.0
27			6.72	5.26	7.11	5.07	7.51	5.40	7.71	5.32	7.91	5.25	8.31	5.46			11	2.0
29			6.60	5.21	6.98	5.02	7.36	5.35	7.56	5.27	7.75	5.19	8.13	5.41			11	3.0
31			6.47	5.16	6.85	4.97	7.22	5.30	7.40	5.22	7.59	5.14	7.95	5.36			117	5.0
33	6.01	4.81	6.27	5.07	6.72	4.91	7.08	5.25	7.25	5.17	7.43	5.09	7.77	5.31			11	7.0
35	5.89	4.75	6.15	5.02	6.59	4.86	6.94	5.20	7.10	5.12	7.26	5.04	7.59	5.26				9.0
37	5.62	4.63	5.86	4.90	6.27	4.74	6.59	5.08	6.75	5.01	6.91	4.93	7.23	5.16			1	11.5
39	5.35	4.51	5.57	4.78	5.95	4.62	6.25	4.96	6.40	4.90	6.55	4.82	6.86	5.06			1	13.5
41	5.08	4.39	5.29	4.67	5.62	4.50	5.90	4.85	6.05	4.79	6.20	4.72	6.50	4.97			1	15.5
43	4.99	4.35	5.18	4.62	5.47	4.45	5.73	4.80	5.88	4.74	6.04	4.67	6.35	4.93			1	16.5

(kW)	Heat	ing Mo	de : H	IC			(kW)
	Ou	tdoor	In	door a	ir tem	peratu	re
ЭB	air	temp.			°CDB		
VВ	°CDB	°CWB	16	18	20	22	24
SHC	-14.5	-15	4.17	4.15	4.13	4.11	4.09
4.71	-13.5	-14	4.23	4.21	4.19	4.17	4.14
4.75	-11.5	-12	4.35	4.33	4.31	4.29	4.26
4.79	-9.5	-10	4.47	4.45	4.43	4.40	4.38
4.83	-7.5	-8	4.59	4.57	4.55	4.52	4.50
4.87	-5.5	-6	4.94	4.92	4.89	4.87	4.84
4.92	-3.0	-4	5.29	5.26	5.24	5.21	5.18
4.99	-1.0	-2	5.64	5.61	5.58	5.55	5.52
5.07	1.0	0	5.99	5.96	5.93	5.89	5.86
	2.0	1	6.16	6.13	6.10	6.06	6.03
	3.0	2	6.37	6.33	6.30	6.26	6.22
	5.0	4	6.77	6.74	6.70	6.66	6.62
	7.0	6	7.18	7.14	7.10	7.05	7.01
	9.0	8	7.28	7.24	7.19	7.14	7.09
	11.5	10	7.38	7.33	7.29	7.23	7.17
	13.5	12	7.34	7.29	7.24	7.18	7.12
	15.5	14	7.30	7.25	7.19	7.13	7.07
	16.5	16	7.28	7.23	7.17	7.10	7.04
					_		

PGA000Z814

							Indo	or air t	emper	ature							Out	door	In	door a	ir tem	peratu	re
Dutdoor iir temp.	18°C	DB	21°C	DB	23°C	DB	26°C	DB	27°C	DB	28°C	DB	31°C	DB	33°C	DB	air te	emp.			°CDB		
in tomp.	12°C	WB	14°C	WB	16℃	WB	18°C	WB	19°C	WB	20°C	WB	22°C	WB	24°C	WB	°CDB	°CWB	16	18	20	22	24
°CDB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	-14.5	-15	5.26	5.24	5.21	5.18	5.1
11					8.35	7.12	8.93	7.74	9.21	7.69	9.59	7.68	10.34	8.18	11.09	8.09	-13.5	-14	5.38	5.35	5.32	5.29	5.2
13					8.42	7.15	8.94	7.74	9.20	7.69	9.55	7.66	10.25	8.15	10.96	8.05	-11.5	-12	5.61	5.58	5.55	5.52	5.4
15					8.48	7.17	8.96	7.75	9.19	7.69	9.52	7.65	10.17	8.12	10.83	8.01	-9.5	-10	5.84	5.81	5.78	5.74	5.7
17					8.54	7.20	8.97	7.75	9.18	7.68	9.49	7.64	10.09	8.10	10.70	7.97	-7.5	-8	6.07	6.04	6.00	5.97	5.9
19					8.51	7.19	8.96	7.75	9.19	7.68	9.48	7.64	10.06	8.09	10.63	7.96	-5.5	-6	6.25	6.21	6.17	6.13	6.0
21					8.32	7.11	8.96	7.75	9.20	7.69	9.47	7.63	10.02	8.08	10.57	7.94	-3.0	-4	6.42	6.37	6.33	6.29	6.2
23					8.52	7.19	9.04	7.78	9.21	7.69	9.47	7.64	10.00	8.07	10.52	7.92	-1.0	-2	6.59	6.54	6.50	6.45	6.4
25			8.10	7.41	8.72	7.28	9.13	7.82	9.23	7.70	9.48	7.64	9.97	8.06	10.47	7.91	1.0	0	6.76	6.71	6.66	6.61	6.5
27			8.38	7.54	8.92	7.36	9.22	7.85	9.24	7.70	9.27	7.56	9.31	7.85			2.0	1	6.84	6.79	6.74	6.69	6.6
29			8.25	7.48	8.77	7.30	9.11	7.81	9.18	7.68	9.26	7.56	9.41	7.88			3.0	2	7.30	7.25	7.19	7.14	7.0
31			8.11	7.42	8.62	7.23	9.00	7.76	9.12	7.66	9.25	7.55	9.50	7.91			5.0	4	8.22	8.16	8.10	8.04	7.9
33	7.53	6.85	7.88	7.31	8.46	7.17	8.88	7.72	9.06	7.64	9.24	7.55	9.59	7.94			7.0	6	9.13	9.07	9.00	8.93	8.8
35	7.41	6.79	7.74	7.25	8.31	7.10	8.77	7.68	9.00	7.61	9.23	7.55	9.68	7.97			9.0	8	9.61	9.54	9.47	9.39	9.3
37	7.15	6.67	7.47	7.13	8.00	6.98	8.44	7.55	8.66	7.49	8.88	7.43	9.33	7.85			11.5	10	10.09	10.01	9.93	9.85	9.7
39	6.89	6.54	7.20	7.01	7.70	6.85	8.11	7.42	8.32	7.37	8.54	7.31	8.97	7.74			13.5	12	10.26	10.18	10.10	10.01	9.9
41	6.63	6.42	6.92	6.78	7.39	6.73	7.77	7.30	7.98	7.25	8.20	7.19	8.62	7.63			15.5	14	10.42	10.34	10.26	10.17	10.0
43	6.36	6.24	6.65	6.52	7.08	6.60	7.44	7.17	7.65	7.12	7.85	7.07	8.26	7.51			16.5	16	10.51	10.42	10.34	10.25	10.
Th or (2) Ca Cc Le Inc	pending ese data follows pacities rrespon- vel diffe	on the s show th the prote are base ding refr prence : (speed :	ystem co e case w ction co d on the igerant p m PHi	ontrol, the here the ntrols. followin	operations	n freque ions.					lucted co ominal c		sly. frequenc	cy							PG	<u>4000</u>	<u>Z8</u>

(6) Wall mounted type (SRK)

Model SRK71VNPZM Cooling Mode Indoor unit SRK71ZM-S Outdoor unit FDC71VNP


Cooling)		inc				in o	Cu			DON	••••			(kW)	Heati	ng Mo	de : H	IC			(kW)
Outdoor							Indo	or air te	emper	ature							Out	door	In	door a	ir tem	peratur	re
air temp.	18°C	DB	21°C	CDB	23°C	DB	26°0	DB	27°C	DB	28°C	DB	31°C	DB	33°C	DB	air t	emp.			°CDB		
un tomp.	12°C	WB	14°C	WB	16°C	WB	18°C	WB	19℃	WB	20°C	WB	22°C	WB	24°C	WB	°CDB	°CWB	16	18	20	22	24
°CDB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	-14.5	-15	4.17	4.15	4.13	4.11	4.09
11					4.71	4.21	5.34	4.71	5.65	4.71	5.78	4.65	6.04	4.91	6.30	4.78	-13.5	-14	4.23	4.21	4.19	4.17	4.14
13					5.00	4.32	5.58	4.79	5.87	4.78	5.99	4.72	6.23	4.96	6.48	4.82	-11.5	-12	4.35	4.33	4.31	4.29	4.26
15					5.30	4.43	5.83	4.87	6.09	4.86	6.20	4.78	6.43	5.01	6.66	4.86	-9.5	-10	4.47	4.45	4.43	4.40	4.38
17					5.59	4.54	6.07	4.96	6.31	4.93	6.41	4.85	6.62	5.07	6.83	4.91	-7.5	-8	4.59	4.57	4.55	4.52	4.50
19					5.73	4.59	6.13	4.98	6.34	4.94	6.48	4.87	6.76	5.11	7.04	4.96	-5.5	-6	4.94	4.92	4.89	4.87	4.84
21					5.80	4.62	6.20	5.00	6.36	4.95	6.54	4.89	6.89	5.15	7.25	5.01	-3.0	-4	5.29	5.26	5.24	5.21	5.18
23					6.23	4.79	6.63	5.16	6.81	5.10	6.96	5.03	7.26	5.25	7.56	5.09	-1.0	-2	5.64	5.61	5.58	5.55	5.52
25			6.26	5.12	6.67	4.96	7.07	5.32	7.26	5.25	7.38	5.17	7.63	5.36	7.88	5.18	1.0	0	5.99	5.96	5.93	5.89	5.86
27			6.72	5.32	7.11	5.14	7.51	5.48	7.71	5.41	7.91	5.34	8.31	5.57			2.0	1	6.16	6.13	6.10	6.06	6.03
29			6.60	5.27	6.98	5.09	7.36	5.43	7.56	5.36	7.75	5.29	8.13	5.51			3.0	2	6.37	6.33	6.30	6.26	6.22
31			6.47	5.21	6.85	5.04	7.22	5.37	7.40	5.31	7.59	5.23	7.95	5.46			5.0	4	6.77	6.74	6.70	6.66	6.62
33	6.01	4.86	6.27	5.12	6.72	4.98	7.08	5.32	7.25	5.25	7.43	5.18	7.77	5.40			7.0	6	7.18	7.14	7.10	7.05	7.01
35	5.89	4.80	6.15	5.07	6.59	4.93	6.94	5.27	7.10	5.20	7.26	5.13	7.59	5.35			9.0	8	7.28	7.24	7.19	7.14	7.09
37	5.62	4.67	5.86	4.94	6.27	4.80	6.59	5.14	6.75	5.08	6.91	5.01	7.23	5.24			11.5	10	7.38	7.33	7.29	7.23	7.17
39	5.35	4.55	5.57	4.82	5.95	4.68	6.25	5.02	6.40	4.96	6.55	4.89	6.86	5.14			13.5	12	7.34	7.29	7.24	7.18	7.12
41	5.08	4.42	5.29	4.70	5.62	4.55	5.90	4.90	6.05	4.84	6.20	4.78	6.50	5.03			15.5	14	7.30	7.25	7.19	7.13	7.07
43	4.99	4.38	5.18	4.66	5.47	4.50	5.73	4.84	5.88	4.79	6.04	4.73	6.35	4.99			16.5	16	7.28	7.23	7.17	7.10	7.04

Note(1) These data show average statuses. Depending on the system control, there may be ranges where the operation is not conducted continuously. These data show the case where the operation frequency of a compressor is fixed.
(2) Capacities are based on the following conditions. Corresponding refrigerant piping length :7.5m Level difference of Zero.
(3) Symbols are as follows. TC : Total cooling capacity (kW), SHC : Sensible heat capacity (kW), HC : Heating capacity (kW)


PCA001Z764


[References data]

Capacity variation against outdoor and indoor temperature at the maximum compressor speed capacity compensation coefficient shows the ratio to nominal capacity.




2 Heating





2 Heating



10.2 Correction of cooling and heating capacity in relation to air flow rate control (fan speed)

Fan speed		P-Hi or Hi ⁽¹⁾	Hi	Me	Lo
Coefficient	Cooling	1.00	0.95	0.93	0.90
Coemclent	Heating	1.00	0.97	0.96	0.94

Note (1) SRK series only.

10.3 Correction of cooling and heating capacity in relation to one way length of refrigerant piping

It is necessary to correct the cooling and heating capacity in relation to the one way equivalent piping length between the indoor and outdoor units.

Equivalent piping length (m)	7.5	10	15	20	25	30
Cooling	1	0.99	0.97	0.96	0.94	0.92
Heating	1	1	1	1	1	1

10.4 Height difference between the indoor unit and outdoor unit

When the outdoor unit is located below indoor units in cooling mode, or when the outdoor unit is located above indoor units in heating mode, the correction coefficient mentioned in the below table should be subtracted from the value in the above table.

Height difference between the indoor unit and outdoor unit in the vertical height difference	5m	10m	15m	20m
Adjustment coefficient	0.99	098	0.97	0.96


Piping length limitations

Model	FDT, FDEN, FDU, FDUM, SRK	FDF
Max. one way piping length	30m	23m
Max. vertical height difference	Outdoor unit is higher 20m Outdoor unit is lower 20m	

Note (1) Values in the table indicate the one way piping length between the indoor and outdoor units.

How to obtain the cooling and heating capacity

Example : The net cooling capacity of the model FDT90VNPVF1 with the air flow "P-High", the piping length of 15m, the outdoor unit located 5m lower than the indoor unit, indoor wet-bulb temperature at 19.0°C and outdoor dry-bulb temperature 35°C is



PJF012D016C

11. APPLICATION DATA

11.1 Installation of indoor unit

(1) Ceiling cassette-4way type (FDT)

This manual is for the installation of an indoor unit. For electrical wiring work (Indoor), refer to page 104. For remote control installation, refer to page 116. For wireless kit installation, refer to page 144. For electrical wiring work (Outdoor) and refrigerant pipe work installation for outdoor unit, refer to page 130. This unit always be used with the panel.

SAFETY PRECAUTIONS

- Read the "SAFETY PRECAUTIONS" carefully first of all and then strictly follow it during the installation work in order to protect yourself.
- The precautionary items mentioned below are distinguished into two levels, [<u>AWARNING</u>] an [<u>ACAUTION</u>].
 [<u>AWARNING</u>]: Wrong installation would cause serious consequences such as injuries or death. <u>ACCUTION</u>: Wrong installation might cause serious consequences depending on circumstances. Both mentions the important items to protect your health and safety so strictly follow them by any means.
- The meanings of "Marks" used here are as shown on the right:
- customers about "SAFETY PRECAUTIONS", correct operation method and maintenance method (air filter cleaning, operation method and temperature setting method) with user's manual of this unit. Ask your customers to keep this installation manual together with the user's manual. Also, ask them to hand over the user's manual to the new user when the owner is changed.

Installation should be performed by the specialist. If you install the unit by yourself, it may lead to serious trouble such as water leakage, electric shock, fire, and injury due to overturm	
if you instant the unit of yoursen, it may read to serious address and as water reakage, erectine shock, inc, and injury due to over term	e
Install the system correctly according to these installation manuals.	
Improper installation may cause explosion, injury, water leakage, electric shock, and fire.	e
Check the density refered by the foumula (accordance with ISO5149).	
If the density exceeds the limit density, please consult the dealer and installate the ventilation system.	l
Use the genuine accessories and the specified parts for installation.	
If parts unspecified by our company are used it could cause water leakage, electric shock, fire, and injury due to overturn of the unit.	C
Ventilate the working area well in case the refrigerant leaks during installation.	C
If the refrigerant contacts the fire, toxic gas is produced.	U
Install the unit in a location that can hold heavy weight.	C
Improper installation may cause the unit to fall leading to accidents.	Ľ
Install the unit properly in order to be able to withstand strong winds such as typhoons, and earthquakes.	C
Improper installation may cause the unit to fall leading to accidents.	C
Do not mix air in to the cooling cycle on installation or removal of the air conditioner.	Л
If air is mixed in, the pressure in the cooling cycle will rise abnormally and may cause explosion and injuries.	\underline{C}
Be sure to have the electrical wiring work done by qualified electrical installer, and use exclusive circuit.	C
Power source with insufficient capacity and improper work can cause electric shock and fire.	
Use specified wire for electrical wiring, fasten the wiring to the terminal securely, and hold the cable securely in	
order not to apply unexpected stress on the terminal. Loose connections or hold could result in abnormal heat generation or fire.	e
Arrange the electrical wires in the control box properly to prevent them from rising. Fit the lid of the services	
panel property.	C
Improper fitting may cause abnormal heat and fire.	U
Check for refrigerant gas leakage after installation is completed.	
If the refrigerant gas leaks into the house and comes in contact with a fan heater, a stove, or an oven, toxic gas is produced.	e
Use the specified pipe, flare nut, and tools for R410A.	
Using existing parts (R22) could cause the unit failure and serious accident due to explosion of the cooling cycle.	e
Tighten the flare nut according to the specified method by with torque wrench.	C
If the flare nut were tightened with excess torque, it could cause burst and refrigerant leakage after a long period.	C
Do not put the drainage pipe directly into drainage channels where poisonous gases such as sulfide gas can	~
occur. Poisonous gases will flow into the room through drainage pipe and seriously affect the user's health and safety. This can also	(
cause the corrosion of the indoor unit and a resultant unit failure or refrigerant leak.	
Connect the pipes for refrigeration circuit securely in installation work before compressor is operated.	_
If the compressor is operated when the service valve is open without connecting the pipe, it could cause explosion and injuries due	
to abnormal high pressure in the system.	_
Stop the compressor before removing the pipe after shutting the service valve on pump down work.	
If the pipe is removed when the compressor is in operation with the service valve open, air would be mixed in the refrigeration circuit	e
and it could cause explosion and injuries due to abnormal high pressure in the cooling cycle.	_
	A
Only use prescribed optional parts. The installation must be carried out by the qualified installer.	-
If you install the system by yourself, it can cause serious trouble such as water leaks, electric shocks, fire.	
If you install the system by yourself, it can cause serious trouble such as water leaks, electric shocks, fire. Do not repair by yourself. And consult with the dealer about repair.	\wedge
If you install the system by yourself, it can cause serious trouble such as water leaks, electric shocks, fire. Do not repair by yourself. And consult with the dealer about repair. Improper repair may cause water leakage, electric shock or fire.	0
If you install the system by yourself, it can cause serious trouble such as water leaks, electric shocks, fire. Do not repair by yourself. And consult with the dealer about repair. Improper repair may cause water leakage, electric shock or fire. Consult the dealer or a specialist about removal of the air conditioner.	
If you install the system by yourself, it can cause serious trouble such as water leaks, electric shocks, fire. Do not repair by yourself. And consult with the dealer about repair. Improper repair may cause water leakage, electric shock or fire. Consult the dealer or a specialist about removal of the air conditioner. Improper installation may cause water leakage, electric shock or fire.	_
If you install the system by yourself, it can cause serious trouble such as water leaks, electric shocks, fire. Do not repair by yourself. And consult with the dealer about repair. Improper repair may cause water leakage, electric shock or fire. Consult the dealer or a specialist about removal of the air conditioner.	
If you install the system by yourself, it can cause serious trouble such as water leaks, electric shocks, fire. Do not repair by yourself. And consult with the dealer about repair. Improper repair may cause water leakage, electric shock or fire. Consult the dealer or a specialist about removal of the air conditioner. Improper installation may cause water leakage, electric shock or fire. Turn off the power source during servicing or inspection work.	_
If you install the system by yourself, it can cause serious trouble such as water leaks, electric shocks, fire. Do not repair by yourself. And consult with the dealer about repair. Improper repair may cause water leakage, electric shock or fire. Consult the dealer or a specialist about removal of the air conditioner. Improper installation may cause water leakage, electric shock or fire. Turn off the power source during servicing or inspection work. If the power is supplied during servicing or inspection work, it could cause electric shock and injury by the operating fan.	_
If you install the system by yourself, it can cause serious trouble such as water leaks, electric shocks, fire. Do not repair by yourself. And consult with the dealer about repair. Improper repair may cause water leakage, electric shock or fire. Consult the dealer or a specialist about removal of the air conditioner. Improper installation may cause water leakage, electric shock or fire. Turn off the power source during servicing or inspection work. If the power is supplied during servicing or inspection work, it cauld cause electric shock and injury by the operating fan. Do not run the unit when the panel or protection guard are taken off. Touching the rotating equipment, hot surface, or high valtage section could cause an injury to be caught in the machine, to get	_

Perform earth wiring surely.		
Do not connect the earth wiring to the gas pipe, water pipe, lightning rod a cause unit failure and electric shock due to a short circuit.	Ind telephone earth wiring. Improper earth could	Ŧ
Earth leakage breaker must be installed.		A
If the earth leakage breaker is not installed, it can cause electric shocks. Use the circuit breaker of correct capacity. Circuit breaker sh		•
poles under over current. Using the incorrect one could cause the system failure and fire.	iouiu be the one that disconnect an	0
Do not use any materials other than a fuse of correct capacit		\bigcirc
Connecting the circuit by wire or copper wire could cause unit failure an Do not install the indoor unit near the location where there is		$\underline{\diamond}$
If the gas leaks and gathers around the unit, it could cause fire.	possibility of natiniable gas leakages.	\bigcirc
Do not install and use the unit where corrosive gas (such as sulfu as thinner, petroleum etc.) may be generated or accumulated, or	volatile flammable substances are handled.	
It could cause the corrosion of heat exchanger, breakage of plastic parts		
Secure a space for installation, inspection and maintenance Insufficient space can result in accident such as personal injury due to fa		0
Do not use the indoor unit at the place where water splashes		$\overline{\frown}$
Indoor unit is not waterproof. It could cause electric shock and fire.		\odot
Do not use the indoor unit for a special purpose such as foor instrument, preservation of animals, plants, and a work of ar It could cause the damage of the items.		\bigcirc
Do not install nor use the system near equipments which generate	electromagnetic wave or high harmonics.	_
Equipments like inverter equipment, private power generator, high-frequ equipment might influence the air conditioner and cause a malfunction a influence medical equipments or telecommunication equipments, and ot	and breakdown. Or the air conditioner might	\bigcirc
Do not install the remote control at the direct sunlight.		$\overline{\bigcirc}$
It could cause breakdown or deformation of the remote control.		<u>v</u>
 Do not install the indoor unit at the place listed below. Places where flammable gas could leak. 	· Places where cosmetics or special sprays are	\sim
Places where carbon fiber, metal powder or any powder is floated. Place where the substances which affect the air conditioner are generated	frequently used. • Highly salted area such as beach.	\bigcirc
such as sulfide gas, chloride gas, acid, alkali or ammonic atmospheres.	Heavy snow area	
Places exposed to oil mist or steam directly. On vehicles and ships	 Places where the system is affected by smoke from a chimney. 	
Places where machinery which generates high harmonics is used.	Altitude over 1000m	
Do not install the indoor unit in the locations listed below (Be according to the installation manual for each model because		
· Locations with any obstacles which can prevent inlet and outlet air of f	he unit	\sim
 Locations where vibration can be amplified due to insufficient strength Locations where the infrared receiver is exposed to the direct sunlight 		\odot
infrared specification unit)	T/ act or radio manium in placed within Em)	
 Locations where an equipment affected by high harmonics is placed. (Locations where drainage cannot run off safely. 	i v set or radio receiver is placed within 5m)	
It can affect performance or function and etc		
Do not put any valuables which will break down by getting w		\bigcirc
Condensation could drop when the relative humidity is higher than 80% or drain		
vo not use the pase traine for the outdoor unit which is corrody	ed or damaged after a long period of use.	8
Do not use the base frame for the outdoor unit which is corrode It could cause the unit falling down and injury.	ed or damaged after a long period of use.	$\overline{\bigcirc}$
It could cause the unit falling down and injury. Pay attention not to damage the drain pan by weld sputter w	hen brazing work is done near the unit.	$\overline{\bigcirc}$
It could cause the unit falling down and injury.	hen brazing work is done near the unit. ge (pinhole) of drain pan and leakage of water.	
It could cause the unit falling down and injury. Pay attention not to damage the drain pan by weld sputter w If sputter entered into the unit during brazing work, it could cause dama	hen brazing work is done near the unit. ge (pinhole) of drain pan and leakage of water.	-
It could cause the unit falling down and injury. Pay attention not to damage the drain pan by weld sputter will If sputter entered into the unit during brazing work, it could cause dama To avoid damaging, keep the indoor unit packed or cover the indoor unit Install the drain pipe to drain the water surely according to t Improper connection of the drain pipe may cause dropping water into ro	hen brazing work is done near the unit. e (pinhole) of drain pan and leakage of water. he installation manual. om and damaging user's belongings.	
It could cause the unit falling down and injury. Pay attention not to damage the drain pan by weld sputter w If sputter entered into the unit during brazing work, it could cause dama To avoid damaging, keep the indoor unit packed or cover the indoor unit Install the drain pipe to drain the water surely according to t Improper connection of the drain pipe may cause dropping water intor Do not share the drain pipe for indoor unit and GHP (Gas Hea	hen brazing work is done near the unit. the installation manual. man d damaging user's belongings. t Pump system) outdoor unit.	0
It could cause the unit falling down and injury. Pay attention not to damage the drain pan by weld sputter will If sputter entered into the unit during brazing work, it could cause dama To avoid damaging, keep the indoor unit packed or cover the indoor unit Install the drain pipe to drain the water surely according to t Improper connection of the drain pipe may cause dropping water into ro	hen brazing work is done near the unit. the installation manual. man d damaging user's belongings. t Pump system) outdoor unit.	0
It could cause the unit falling down and injury. Pay attention not to damage the drain pan by weld sputter w If sputter entered into the unit during brazing work, it could cause dama To avoid damaging, keep the indoor unit packed or cover the indoor ruit Install the drain pipe to drain the water surely according to t Improper connection of the drain pipe may cause dropping water into ro Do not share the drain pipe for indoor unit and GHP (Gas Hea Toxic exhaust gas would flow into room and it might cause serious dama user's health and safety. Be sure to perform air tightness test by pressurizing with nitrogen	hen brazing work is done near the unit. ge (pinhole) of drain pan and leakage of water. he installation manual. om and damaging user's belongings. t Pump system) outdoor unit. ge (some poisoning or deficiency of oxygen) to gas after completed refrigerant piping work.	
It could cause the unit falling down and injury. Pay attention not to damage the drain pan by weld sputter w If sputter entered into the unit during brazing work, it could cause dama To avoid damaging, keep the indoor unit packed or cover the indoor unit Install the drain pipe to drain the water surely according to t Improper connection of the drain pipe may cause dropping water into ro D on ots hare the drain pipe for indoor unit and GHP (Gas Hea Toxic exhcuts gas would flow into room and it might cause serious dama user's health and safety.	hen brazing work is done near the unit. ge (pinhole) of drain pan and leakage of water. he installation manual. om and damaging user's belongings. t Pump system) outdoor unit. ge (some poisoning or deficiency of oxygen) to gas after completed refrigerant piping work.	
It could cause the unit falling down and injury. P or attention not to damage the drain pan by weld sputter w If sputter entered into the unit during brazing work, it could cause dama to avoid damaging, keep the indoor unit packed or cover the indoor ruit Install the drain pipe to drain the water surely according to t Improper connection of the drain pipe may cause dropping water into ro D on share the drain pipe for indoor unit and GHP (Gas Hea Toxic exhaust gas would flow into room and it might cause serious dama user's health and safety. B esure to perform air tightness test by pressurizing with nitrogen If the density of refrigerant exceeds the limit in the event of refrigerant ta coccur, which can cause serious accidents. For drain pipe installation, he sure to make descending slope e	hen brazing work is done near the unit. ge (pinhole) of drain pan and leakage of water. he installation manual. om and damaging user's belongings. t Pump system) outdoor unit. geg (some poisoning or deficiency of oxygen) to gas after completed refrigerant piping work. akaage in the small room, lack of oxygen can	
It could cause the unit falling down and injury. P ay attention not to damage the drain pan by weld sputter will sputter referent in the unit during horaing work, it could cause dama To avoid damaging, keep the indoor unit packed or cover the indoor unit improper connection of the drain pipe may cause dropping water into ro Do not share the drain pipe for indoor unit and GHP (Gas Hear Toxic exhaust gas would flow into room and it might cause serious dama user is health and safely. B esure to perform air tightness test by pressurizing with nitrogen it the density of refrigerant exceeds the limit in the event of refrigerant to core, which can cause serious accidents. For drain pipe installation, be sure to make descending slope and not to make air-bleeding.	hen brazing work is done near the unit. ge (pinhole) of drain pan and leakage of water. he installation manual. om and damaging user's belongings. I Pump system) outdoor unit. ge (some poisoning or deficiency of oxygen) to gas after completed refrigerant piping work. akage in the small room, lack of oxygen can of greater than 1/100, not to make traps,	
It could cause the unit falling down and injury. P or attention not to damage the drain pan by weld sputter w If sputter entered into the unit during brazing work, it could cause dama to avoid damaging, keep the indoor unit packed or cover the indoor ruit Install the drain pipe to drain the water surely according to t Improper connection of the drain pipe may cause dropping water into ro D on share the drain pipe for indoor unit and GHP (Gas Hea Toxic exhaust gas would flow into room and it might cause serious dama user's health and safety. B esure to perform air tightness test by pressurizing with nitrogen If the density of refrigerant exceeds the limit in the event of refrigerant ta coccur, which can cause serious accidents. For drain pipe installation, he sure to make descending slope e	hen brazing work is done near the unit. ge (pinhole) of drain pan and leakage of water. he installation manual. om and damaging user's belongings. It Pump system) outdoor unit. ge (some poisoning or deficiency of oxygen) to gas after completed refrigerant piping work. aakage in the small room, lack of oxygen can of greater than 1/100, not to make traps, e the space for inspection and maintenance.	
It could cause the unit falling down and injury.	hen brazing work is done near the unit. ge (pinhole) of drain pan and leakage of water. he installation manual. m and damaging user's belongings. t Pump system) outdoor unit. ge (some poisoning or deficiency of oxygen) to gas after completed refrigerant piping work. akage in the small room, lack of oxygen can of greater than 1/100, not to make traps, e the space for inspection and maintenance. as not to condense water.	
It could cause the unit falling down and injury. P ay attention not to damage the drain pan by weld sputter will sputter refrest in the unit during brazing work, it could cause dama To avoid damaging, keep the indoor unit packed or cover the indoor unit ingroper connection of the drain pipe may cause dropping water into ro Do not share the drain pipe for indoor unit and GHP (Gas Hear Toxic exhaust gas would flow into room and it might cause serious dama user is health and safely. B es ure to perform air tightness test by pressurizing with nitrogen if the density of refrigerant exceeds the limit in the event of refrigerant is coccur, which can cause serious accidents. For drain pipe installation, be sure to make descending slope and not to make air-bleeding. Check if the drainage is correctly done during commissioning and ensur. Denot share the insulation outh acuse condensition and it would wet ceiling. Do not install the outdoor unit where is likely to be a nest for	hen brazing work is done near the unit. ge (pinhole) of drain pan and leakage of water. he installation manual. om and damaging user's belongings. I Pump system youtdoor unit. age (some poisoning or deficiency of oxygen) to gas after completed refrigerant piping work. akade in the small room, lack of oxygen can of greater than 1/100, not to make traps, e the space for inspection and maintenance. as not to condense water. fior, and any other valuables. insects and small animals.	
It could cause the unit falling down and injury.	hen brazing work is done near the unit. ge (pinhole) of drain pan and leakage of water. he installation manual. om and damaging user's belongings. I Pump system youtdoor unit. age (some poisoning or deficiency of oxygen) to gas after completed refrigerant piping work. akade in the small room, lack of oxygen can of greater than 1/100, not to make traps, e the space for inspection and maintenance. as not to condense water. fior, and any other valuables. insects and small animals.	
It could cause the unit falling down and injury.	hen brazing work is done near the unit. ge (pinhole) of drain pan and leakage of water. he installation manual. om and damaging user's belongings. I Pump system youtdoor unit. age (some poisoning or deficiency of oxygen) to gas after completed refrigerant piping work. akade in the small room, lack of oxygen can of greater than 1/100, not to make traps, e the space for inspection and maintenance. as not to condense water. fior, and any other valuables. insects and small animals.	
It could cause the unit falling down and injury.	hen brazing work is done near the unit. ge (pinhole) of drain pan and leakage of water. he installation manual. om and damaging user's belongings. t Pump system) outdoor unit. ges (some poisoning or deficiency of oxygen) to gas after completed refrigerant piping work. aakage in the small room, lack of oxygen can of greater than 1/100, not to make traps, e the space for inspection and maintenance. as not to condense water. (, floor, and any other valuables. insects and small animals. d cause breakdown and fire. Instruct the user to ic straps but the grabbing place, moving the unit	
It could cause the unit falling down and injury.	hen brazing work is done near the unit. ge (pinhole) of drain pan and leakage of water. he installation manual. om and damaging user's belongings. t Pump system) outdoor unit. ges (some poisoning or deficiency of oxygen) to gas after completed refrigerant piping work. aakage in the small room, lack of oxygen can of greater than 1/100, not to make traps, e the space for inspection and maintenance. as not to condense water. (, floor, and any other valuables. insects and small animals. d cause breakdown and fire. Instruct the user to ic straps but the grabbing place, moving the unit	
It could cause the unit falling down and injury.	hen brazing work is done near the unit. ge (pinhole) of drain pan and leakage of water. he installation manual. om and damaging user's belongings. t Pump system) outdoor unit. ge (some poisoning or deficiency of oxygen) to gas after completed refrigerant piping work. akage in the small room, lack of oxygen can of greater than 1/100, not to make traps, e the space for inspection and maintenance. as not to condense water. , floor, and any other valuables. insects and small animals. d cause breakdown and fire. Instruct the user to ic straps but the grabbing place, moving the unit	
It could cause the unit falling down and injury. It could cause the unit falling down and injury. P avaid tarniton not to damage the drain pan by weld sputter will sputter rentered into the unit during brazing work, it could cause dama To avoid damaging, keep the indow runit packed or cover the indow runit in tarkiel or cover the indow runit and GHP (Gas Hea Toxic exhaust gas would flow into room and it might cause serious dama user's health and safely. B esure to perform air tightness test by pressurizing with nitrogen in the deem air the deem air the deem serious dama is defined and safely. B esure to perform air tightness test by pressurizing with nitrogen in the deem air the deem serious accidents. F or drain pipe installation, be sure to make descending slope i and not to make air-bleeding. Check if the drainage is correctly done during commissioning and ensure incomplete insulation could cause condensation and it would wet ceiling. D on to install the outdoor unit where is likely to be a nest for longers and small animals could come into the electronic components an keep the surroundings clean. P ay extra attention, carrying the unit by hand. Carry the unit with 2 people if it is heavier than 20kg. Do not use the plass for the varier than 20kg. Do not use the plass in order to avoid injury by the aluminum fin Make sure to dispose of the packaging material. Leaving the materials may cause injury as metals like mail and woods are independent and star materials may cause injury as metals like nail and woods are independent and the area site as may cause injury as metals like nail and woods are independent and the area site may cause injury as metals like nail and woods are independent and the area site and and the area site may cause injury as metals like nail and woods are independent and the area site and and the area site and and the area site materials may cause injury as metals like nail and woods are independent and the area site and the area site and the area site and the area sindependent and a	hen brazing work is done near the unit. ge (pinhole) of drain pan and leakage of water. he installation manual. om and damaging user's belongings. It Pump system) outdoor unit. geg (some poisoning or deficiency of oxygen) to gas after completed refrigerant piping work. aakage in the small room, lack of oxygen can of greater than 1/100, not to make traps, e the space for inspection and maintenance. as not to condense water. (, floor, and any other valuables. inspects and small animals. d cause breakdown and fire. Instruct the user to ic straps but the grabbing place, moving the unit t.	
It could cause the unit falling down and injury.	hen brazing work is done near the unit. ge (pinhole) of drain pan and leakage of water. he installation manual. om and damaging user's belongings. It Pump system) outdoor unit. geg (some poisoning or deficiency of oxygen) to gas after completed refrigerant piping work. aakage in the small room, lack of oxygen can of greater than 1/100, not to make traps, e the space for inspection and maintenance. as not to condense water. (, floor, and any other valuables. inspects and small animals. d cause breakdown and fire. Instruct the user to ic straps but the grabbing place, moving the unit t.	
It could cause the unit falling down and injury. It could cause the unit falling down and injury. P avaid tarniton not to damage the drain pan by weld sputter will sputter rentered into the unit during brazing work, it could cause dama To avoid damaging, keep the indow runit packed or cover the indow runit in tarkiel or cover the indow runit and GHP (Gas Hea Toxic exhaust gas would flow into room and it might cause serious dama user's health and safely. B esure to perform air tightness test by pressurizing with nitrogen in the deem air the deem air the deem serious dama is defined and safely. B esure to perform air tightness test by pressurizing with nitrogen in the deem air the deem serious accidents. F or drain pipe installation, be sure to make descending slope i and not to make air-bleeding. Check if the drainage is correctly done during commissioning and ensure incomplete insulation could cause condensation and it would wet ceiling. D on to install the outdoor unit where is likely to be a nest for longers and small animals could come into the electronic components an keep the surroundings clean. P ay extra attention, carrying the unit by hand. Carry the unit with 2 people if it is heavier than 20kg. Do not use the plass for the varier than 20kg. Do not use the plass in order to avoid injury by the aluminum fin Make sure to dispose of the packaging material. Leaving the materials may cause injury as metals like mail and woods are independent and star materials may cause injury as metals like nail and woods are independent and the area site as may cause injury as metals like nail and woods are independent and the area site may cause injury as metals like nail and woods are independent and the area site and and the area site may cause injury as metals like nail and woods are independent and the area site and and the area site and and the area site materials may cause injury as metals like nail and woods are independent and the area site and the area site and the area site and the area sindependent and a	hen brazing work is done near the unit. ge (pinhole) of drain pan and leakage of water. he installation manual. om and damaging user's belongings. It Pump system) outdoor unit. geg (some poisoning or deficiency of oxygen) to gas after completed refrigerant piping work. aakage in the small room, lack of oxygen can of greater than 1/100, not to make traps, e the space for inspection and maintenance. as not to condense water. (, floor, and any other valuables. inspects and small animals. d cause breakdown and fire. Instruct the user to ic straps but the grabbing place, moving the unit t.	
It could cause the unit falling down and injury.	hen brazing work is done near the unit. ge (pinhole) of drain pan and leakage of water. he installation manual. om and damaging user's belongings. I Pump system joutdoor unit. age (some poisoning or deficiency of oxygen) to gas after completed refrigerant piping work. akage in the small room, lack of oxygen can of greater than 1/100, not to make traps, e the space for inspection and maintenance. as not to condense water. floor, and any other valuables. insects and small animals. d cause breakdown and fire. Instruct the user to ic straps but the grabbing place, moving the unit e used in the package.	
It could cause the unit falling down and injury.	hen brazing work is done near the unit. ge (pinhole) of drain pan and leakage of water. he installation manual. om and damaging user's belongings. t Pump system) outdoor unit. geg (some poisoning or deficiency of oxygen) to gas after completed refrigerant piping work. aakage in the small room, lack of oxygen can of greater than 1/100, not to make traps, e the space for inspection and maintenance. as not to condense water. (noor, and any other valuables. insects and small animals. d cause breakdown and fire. Instruct the user to is straps but the grabbing place, moving the unit be used in the package. wchanger.	
It could cause the unit falling down and injury.	hen brazing work is done near the unit. ge (pinhole) of drain pan and leakage of water. he installation manual. om and damaging user's belongings. t Pump system) outdoor unit. geg (some poisoning or deficiency of oxygen) to gas after completed refrigerant piping work. aakage in the small room, lack of oxygen can of greater than 1/100, not to make traps, e the space for inspection and maintenance. as not to condense water. (noor, and any other valuables. insects and small animals. d cause breakdown and fire. Instruct the user to is straps but the grabbing place, moving the unit be used in the package. wchanger.	
It could cause the unit falling down and injury. It could cause the unit falling down and injury. P avaid tention not to damage the drain pan by weld sputter w If sputter entered into the unit during brazing work, it could cause dama If sputter entered into the unit during brazing work, it could cause dama If any other entered into the unit during the drain pipe or drain the water surely according to 1 Improper connection of the drain pipe may cause dropping water into ro D on thate the drain pipe for indoor unit and GHP (Gas Hear Toxic exhaust gas would flow into room and it might cause serious dama user's health and safely. B sure to perform air tightness test by pressurizing with nitogen of the density of refrigerant acceds the limit in the event of refrigerant ic coccur, which can cause serious accidents. For drain pipe installation, be sure to make descending slope or and not to make air-bleeding. Check if the drainage is correctly done during commissioning and ensure Incomplete insulation could cause condensation and it would wet celling. Do not install the outdoor unit where is likely to be a nest for Insects and small animals could come into the electronic components an user to dispose of the packaging material. Leaving the materials may cause injury as metals like nail and woods ar D on ot operate the system without the air filter. It may cause the breakdown of the system due to doging of the heat est D on touch the refrigerant piping with we hands. It could cause electric shock. D on touch the refrigerant piping with bare hands when in The pipe during operation would become very hot or cold according to the operation D on touch the refrigerant piping with bare hands when in The pipe during operation would become very hot or cold according to the operation D on touch the refrigerant piping with bare hands when in The pipe during operation would become very hot or cold according to the operation D on touch the refrigerant piping with wate. It coud cause electric shock.	hen brazing work is done near the unit. ge (pinhole) of drain pan and leakage of water. he installation manual. om and damaging user's belongings. I Pump system joutdoor unit. age (some poisoning or deficiency of oxygen) to gas after completed refrigerant piping work. akage in the small room, lack of oxygen can of greater than 1/100, not to make traps, e the space for inspection and maintenance. as not to condense water. fior, and any other valuables. insects and small animals. d cause breakdown and fire. Instruct the user to ic straps but the grabbing place, moving the unit is eused in the package. exchanger.	
It could cause the unit falling down and injury.	hen brazing work is done near the unit. ge (pinhole) of drain pan and leakage of water. he installation manual. om and damaging user's belongings. t Pump system) outdoor unit. geg (some poisoning or deficiency of oxygen) to gas after completed refrigerant piping work. aakage in the small room, lack of oxygen can of greater than 1/100, not to make traps, at the space for inspection and maintenance. as not to condense water. , floor, and any other valuables. insects and small animals. d cause breakdown and fire. Instruct the user to is straps but the grabbing place, moving the unit c straps but the grabbing place, moving the unit c straps. changer. operation. Ing condition, and it could cause a burn or frostbile. eration.	

①Before installation

- Install correctly according to the installation manual.
- Confirm the following points:

OUnit type/Power supply specification OPipes/Wires/Small parts OAccessory items

For unit hanging			For refrigerant pig	90	For drain pipe				
Flat washer (M10)	Level gauge	Pipe cover(big)	Pipe cover (small)	Strap	Pipe cover(big)	Pipe cover(small)	Drain hose	Hose clamp	
\bigcirc		0	6	Π	\bigcirc	Ø	Ĵ	(\mathfrak{G})	
8	1	1	1	4	1	1	1	1	
For unit hanging	For unit hanging and adjustment	For heat insulation of gas pipe	For heat insulation of liquid tube	For pipe cover fixing	For heat insulation of drain socket	For heat insulation of drain socket	For drain pipe connecting	For drain hose mounting	

②Selection of installation location for the indoor unit


① Select the suitable areas to install the unit under approval of the user

- Areas where the indoor unit can deliver hot and cold wind sufficiently. Suggest to the user to use a circulator if the ceiling height is over 3m to avoid warm air being accumulated on the ceilina.
- · Areas where there is enough space to install and service.
- · Areas where it can be drained properly. Areas where drain pipe descending slope can be taken
- Areas where there is no obstruction of airflow on both air return grille and air supply port.
- · Areas where fire alarm will not be accidentally activated by the air conditioner.
- Areas where the supply air does not short-circuit.
 Areas where it is not influenced by draft air.
- · Areas not exposed to direct sunlight. Areas where dew point is lower than around 28°C and relative humidity is lower than 80%.
- This indoor unit is tested under the condition of JIS (Japan Industrial Standard) high humidity condition and confirmed there is no problem. However, there is some risk of condensation drop if the air conditioner is operated under the severer condition than mentioned above.
- If there is a possibility to use it under such a condition, attach additional insulation of 10 to 20mm thick for entire surface of indoor unit, refrigeration pipe and drain pipe.
- Areas where TV and radio stays away more than 1m. (It could cause jamming and noise.) · Areas where any items which will be damaged by getting wet are not placed such as food, table wares, server, or medical equipment under the unit.
- Areas where there is no influence by the heat which cookware generates.
- · Areas where not exposed to oil mist, powder and/or steam directly such as above fryer. · Areas where lighting device such as fluorescent light or incandescent light doesn't affect the
- operation. (A beam from lighting device sometimes affects the infrared receiver for the wireless remote
- control and the air conditioner might not work properly.) (2)Check if the place where the air conditioner is installed can hold the weight of the unit. If it is
- not able to hold, reinforce the structure with boards and beams strong enough to hold it. If the strength is not enough, it could cause injury due to unit falling.
- (3)If there are 2 units of wireless type, keep them away for more than 6m to avoid malfunction due to cross communication.
- (4) When plural indoor units are installed nearby, keep them away for more than 4 to 5m

Space for installation and service

When it is not possible to keep enough space between indoor unit and wall or between indoor units, close the air supply port where it is not possible to keep space and confirm there is no short circuit of airflow






for details

③Preparation before installation

- If suspension bolt becomes longer, do reinforcement of earthquake resistant OFor grid ceiling
 - When suspension bolt length is over 500mm, or the gap between the ceiling and roof is over 700mm, apply earthquake resistant brace to the bolt.
- OIn case the unit is hanged directly from the slab and is installed on the ceiling plane which has enough strength
- When suspension bolt length is over 1000mm, apply the earthquake resistant brace to the bolt. Prepare four (4) sets of suspension bolt, nut and spring washer (M10 or M8) on site.


Ceiling opening, Suspension bolts pitch, Pipe position



④Installation of indoor unit

Work procedure

- Prepare a ceiling hole with the size of from 860 mm \times 860 mm to 910 mm \times 910 mm 1 referring to the template attached in the package.
- 2 Arrange the suspension bolt at the right position (725mm×778mm).
- Make sure to use four suspension bolts and fix them so as to be able to hold 500N load. Ensure that the lower end of the suspension bolt should be 50mm above the ceiling plane. Temporarily put the four lower nuts 150mm above the ceiling plane and the upper 4 nuts on distant place from the lower nuts in order not to obstruct hanging the indoor unit or adjust the indoor unit position, and then hang the indoor unit.
- 5. Adjust the indoor unit position after hanging it by inserting the level gauge attached on the package into the air supply port and checking if the gap between the ceiling plane and the indoor unit is appropriate. In order to adjust the indoor unit position, adjust the lower nuts while the upper nuts are put on distant place. Confirm there is no backlash between the hanger plate for suspension bolt and the lower nut and washer



(4)Installation of indoor unit (continued)

- Make sure to install the indoor unit horizontally. Confirm the levelness of the indoor unit with a level gauge or transparent hose filled with water. Keep the height difference at both ends of the indoor unit within 3mm.
- 7. Tighten four upper nuts and fix the unit after height and levelness adjustment.

Indoor unit 7 hose

Caution

- Do not adjust the height by adjusting upper nuts. It will cause unexpected stress on the indoor unit and it will lead to deformation of the unit, failure of attaching a panel, and generating noise from the fan.
- Make sure to install the indoor unit horizontally and set the gap between the unit underside and the ceiling plane properly. Improper installation may cause air leakage, dew condensation, water leakage and noise.
- Even after decorative panel attached, still the unit height can be adjusted finely. Refer to the installation manual for decorative panel for details.
- Make sure there is no gap between decoration panel and ceiling surface, and between decoration panel and the indoor unit. The gap may cause air leakage, dew condensation and water . leakage
- In case decorative panel is not installed at the same time, or ceiling material is installed after the unit installed, put the cardboard template for installation attached on the package (packing material of cardboard box) on the bottom of the unit in order to avoid dust coming into the indoor unit.

5Refrigerant pipe

Caution

- Be sure to use new pipes for the refrigerant pipes. Use the flare nut attached to the product or a nut compatible with JIS B 8607, Class 2.
- Regarding whether existing pipes can be reused or not, and the washing method, refer to the instruction manual of the

(registing when the scalar pipes can be readed of hot, and the washing method, refer to the instruction manual of the outdoor unit, catalogue or technical data.

 In case of reuse: Do not use old flare nut, but use the one attached to the unit or compatible with JIS B 8607, Class 2.
 In case of reuse: Flare the end of pipe replaced partially for R410A.

	Protruding	D	Pipe dia.	Min. pipe	Protruding dimer	ision for flare, mm	Flare O.D.	Flare nut
1	dimension			wall thickness	Rigid (Cl	utch type)	D	tightening torque
	1	H	mm	mm	For R410A	Conventional tool	mm	N∙m
Flare die			6.35	0.8			$8.9 \simeq 9.1$	$14 \sim 18$
NULL N		(TIT)	9.52	0.8			$12.8 \simeq 13.2$	$32 \sim 42$
			12.7	0.8	$0 \sim 0.5$	$0.7 \sim 1.3$	$16.2 \simeq 16.6$	$49 \sim 61$
			15.88	1			$19.3 \simeq 19.7$	$68 \sim 72$
			19.05	1.2			$23.6 \simeq 24.0$	$100 \sim 120$

- ●Use phosphorus deoxidized copper alloy seamless pipe (C1220T specified in JIS H3300) for refrigeration pipe installation.
- In addition, make sure there is no damage both inside and outside of the pipe, and no harmful substances such as sulfur, oxide, dust or a contaminant stuck on the pipes. Do not use any refrigerant other than R410A.
- Using other refrigerant except R410A (R22 etc.) may degrade inside refrigeration oil. And air getting into refrigeration circuit may cause over-pressure and resultant it may result in bursting,
- Store the copper pipes indoors and seal the both end of them until they are brazed in order to avoid any dust, dirt or water getting into pipe. Otherwise it will cause degradation of refrigeration oil and compressor breakdown, etc.

Use special tools for R410A refrigerant.

Work procedure

- 1. Remove the flare nut and blind flanges on the pipe of the indoor unit.
 - % Make sure to loosen the flare nut with holding the nut on pipe side with a spanner and giving torque to the nut with another spanner in order to avoid unexpected stress to the copper pipe, and then remove them
 - (Gas may come out at this time, but it is not abnormal.)
- Pay attention whether the flare nut pops out. (as the indoor unit is sometimes pressured.) 2. Make a flare on liquid pipe and gas pipe, and connect the refrigeration pipes on the indoor unit. *Bend radius of pipe must be 4D or larger. Once a pipe is bent, do not readjust the bending Do not twist a pipe or collapse to 2/3D or smaller.
 - *Do a flare connection as follows:
 - Make sure to loosen the flare nut with holding the nut on pipe side with a spanner and giving torque to the nut with another spanner in order to avoid unexpected stress to the coppe pipe, and then remove them
- When fastening the flare nut, align the refrigeration pipe with the center of flare nut, screw the nut for 3-4 times by hand and then tighten it by spanner with the specified torque mentioned in the table below. Make sure to hold the pipe on the indoor unit securely by a spanner when tightening the nut in order to avoid unexpected stress on the copper pipe.
- 3. Cover the flare connection part of the indoor unit with attached insulation material after a gas leakage inspection, and tighten both ends with attached straps.
 - Make sure to insulate both gas pipes and liquid pipes completely % Incomplete insulation may cause dew condensation or water dropping.
- Refrigerant is charged in the outdoor unit. As for the additional refrigerant charge for the indoor unit and piping, refer to the installation manual attached to the outdoor unit.

5Refrigerant pipe (continued)

Refrigerating machine oil should not be applied to the threads of union or external surface of flare. It is because, even if the same tightening torque is applied, the oil is likely to decrease the slide friction force on the threads and increase, in turn, the axial component force so that it could crack the flare by the stress corrosion. Refrigerating machine oil may be applied to the internal surface of flare only.

Pipe cover (Accessory) Strap (Accessory 77777 11111 711/111 11111 /The thickness of insulation should be 20mm or more


6Drain pipe

Caution

- Install the drain pipe according to the installation manual in order to drain properly.
- Imperfection in draining may cause flood indoors and wetting the household goods, etc. Do not put the drain pipe directly into the ditch where toxic gas such as sulfur, the other harmful and
 inflammable gas is generated. Toxic gas would flow into the room and it would cause serious damage to user's health and safety (some poisoning or deficiency of oxygen). In addition, it may cause corrosion of heat exchanger and bad smell.
- Connect the pipe securely to avoid water leakage from the joint.
- Insulate the pipe properly to avoid condensation drop.
- Check if the water can flow out properly from both the drain outlet on the indoor unit and the end of the drain pipe after installation.
- Make sure to make descending slope of greater than 1/100 and do not make up-down bend and/or trap in the midway. In addition, do not put air vent on the drain pipe. Check if water is drained out properly from the pipe during commissioning. Also, keep sufficient space for inspection and maintenance.

Work procedure

- 1. Make sure to insert the drain hose (the end mode of soft PVC) to the end of the step part of drain socket.
- Attach the hose clamp to the drain hose around 10mm from the end, and fasten the screw within 5mm left to the nut




- 2. Prepare a joint for connecting VP-25 pipe, adhere and connect the joint to the drain hose (the end made of rigid PVC), and adhere and connect VP-25 pipe (prepare on site). %As for drain pipe, apply VP-25 made of rigid PVC which is on the market.
 - Make sure that the adhesive will not get into the supplied drain hose.
 - It may cause the flexible part broken after the adhesive is dried up and gets rigid. The flexible drain hose is intended to absorb a small difference at installation of the unit or drain pipes. Intentional bending, expanding may cause the flexible hose broken and water leakage.




- 3. Make sure to make descending slope of greater than 1/100 and do not make up-down bend and/or trap in the midway.
 - Pay attention not to give stress on the pipe on the indoor unit side, and support and fix the pipe as close place to the unit as possible when connecting the drain pipe

Do nt set up air vent.

4. Insulate the drain pipe.




below the drain outlet of the unit. In addition, select VP-30 or bigger size for main drain pipe.



۳Ì


- Be sure to insulate the drain socket and rigid PVC pipe installed indoors otherwise it may cause dew condensation and water leakage.
 - *After drainage test implementation, cover the drain socket part with pipe cover (small size), then use the pipe cover (big size) to cover the pipe cover (small size), clamps and part of the drain hose, and fix and wrap it with tapes to wrap and make joint part gapless.




PJF012D003C

PANEL INSTALLATION MANUAL

Read this manual together with the indoor unit's installation manual






9 How to set the airflow direction

It is possible to change the movable range of the louver on the air outlet from the wired remote control. Once the top and bottom position is set, the louver will swing within the range between the top and the bottom when swing operation is chosen. It is also possible to apply different setting to each louver.


For the setting method of the louver's operating range, refer to the instruction manual of the wired remote

- If it is necessary to fix the lower position manually, follow the procedure mentioned below.
 Shut off the main power switch.
 Unplug the connector of the lower motor which you want to fix the position. Make sure to insulate unplugged connectors electrically with a vinyl tape.
 Adjust the lower position slowly by hand so as to be within the applicable range mentioned below table.



10 Attaching the air return grille

- To attach the air return grille, follow the procedure described in (3) Removing the air return grille) in the reverse order. 1. Hang the hooks of the air return grille in the hole of the panel. (The hooks of the grille can be hanged in three side
- A fair of the panel as following).
 After the grille is hanged, close the grille while the stoppers on the grille (2 places) are kept pressed to "OPEN" direction. When the grille comes to the original position, release the stoppers to hold the grille. Make sure to hear the sound of "CLICK" in both stoppers.



OUTDOOR AIR (OA) INTAKE FOR FDT

If it is required to intake OA through FDT unit, make sure to check following points carefully in order to conform to the requirement of customer.


If the OA intake volume through FDT unit is not satisfied with the required ventilation air volume, consider to install an independent ventilation system.

- 1) Be sure to calculate cooling/heating load considering the ventilation heat load and to decide the air-conditioning system.
- Be sure the OA intake volume to FDT unit should not exceed 20% of the Supply Air (SA) volume of FDT unit and it should be less than 2m³/min.
- 3) Be sure to decide the OA intake volume considering the mixed air temperature will be within the usage temperature range of FDT unit.

Especially in following case, please consider to intake OA after processing OA or reducing the OA intake volume.

- Be sure to equip a suitable filter for OA intaken in order to protect the dust. (Because OA does not pass through the filter equipped on FDT unit)
- 5) Be sure to insulate OA duct. (If not, it may have dew condensation.)
- 6) Be sure to interlock the booster fan for OA with the fan of FDT unit by using CNT connector.
- (If not, the dust trapped on the filter of FDT unit may be blown out to the room by the OA being intaken during the fan of FDT unit stopping)
- Be sure to select a suitable booster fan for OA considering the pressure loss in the OA duct and the pressure loss at the inlet port of FDT with following diagram.

(Please take into consideration the noise level as well)



<Selection of booster fan>

Booster fan should have a static pressure calculated with following formula.

Static pressure of booster fan

= the pressure loss at the inlet port of FDT (from above diagram)

+ Pressure loss in the OA duct (In case of ϕ 100 duct, 5Pa/m is required.)

Select the booster fan from the fan characteristic diagram.


PFA012D621B


(2) Ceiling suspended type (FDEN)

This manual is for the installation of an indoor unit. For electrical wiring work (Indoor), refer to page 104. For remote control installation, refer to page 116. For wireless kit installation, refer to page 146. For electrical wiring work (Outdoor) and refrigerant pipe work installation for outdoor unit, refer to the page 130.

SAFETY PRECAUTIONS • Read the "SAFETY PRECAUTIONS" carefully first of all and then strictly follow it during the installation work in order to protect yourself. The precautionary items mentioned below are distinguished into two levels, MWARNING and MCAUTION . WARNING: Wrong installation would cause serious consequences such as injuries or death. ACAUTION : Wrong installation might cause serious consequences depending on circumstances. Both mentions the important items to protect your health and safety so strictly follow them by any means. The meanings of "Marks" used here are as shown as follows:
 Never do it under any circumstances.
 Image: Comparison of the instruction.
 After completing the installation, do commissioning to confirm there are no abnormalities, and explain to the customers about "SAFETY PRECAUTIONS", correct operation method and maintenance method (air filter cleaning, operation method and temperature setting method) with user's manual of this unit. Ask your customers to keep this installation manual together with the user's manual. Also, ask them to hand over the user's manual to the new user when the owner is changed. **WARNING** Installation should be performed by the specialist. 0 If you install the unit by yourself, it may lead to serious trouble such as water leakage, electric shock, fire, and injury due to overturn of the unit. Install the system correctly according to these installation manuals. 0 Improper installation may cause explosion, injury, water leakage, electric shock, and fire. When installing in small rooms, take prevention measures not to exceed the density limit of refrigerant in the event of leakage, referred by the formula (accordance with ISO5149). 0 If the density of refrigerant exceeds the limit, please consult the dealer and install the ventilation system, otherwise lack of oxygen can occur, which can cause serious accidents. Ouse the genuine accessories and the specified parts for installation. 0 If parts unspecified by our company are used it could cause water leakage, electric shock, fire, and injury due to overturn of the unit •Ventilate the working area well in case the refrigerant leaks during installation. a If the refrigerant contacts the fire, toxic gas is produce Install the unit in a location that can hold heavy weight 0 Improper installation may cause the unit to fall leading to accid Install the unit properly in order to be able to withstand strong winds such as typhoons, and earthquakes. 0 ion may cause the unit to fall leading to acciden Do not mix air in to the cooling cycle on installation or removal of the air conditioner \mathcal{O} If air is mixed in, the pressure in the cooling cycle will rise abnormally and may cause explosion and injur Be sure to have the electrical wiring work done by qualified electrical installer, and use exclusive circuit. 0 Power source with insufficient capacity and improper work can cause electric shock and fire Ouse specified wire for electrical wiring, fasten the wiring to the terminal securely, and hold the cable securely in 0 order not to apply unexpected stress on the terminal. ions or hold could result in abnormal heat generation or fire Loose conne Arrange the electrical wires in the control box properly to prevent them from rising. Fit the lid of the services a panel property. roper fitting may cause abnormal heat and fire. Check for refrigerant gas leakage after installation is completed. 0 If the refrigerant gas leaks into the house and comes in contact with a fan heater, a stove, or an oven, toxic gas is produced. Ouse the specified pipe, flare nut, and tools for R410A. a Using existing parts (R22) could cause the unit failure and serious accident due to explosion of the cooling cycle. Tighten the flare nut according to the specified method by with torque wrench. 0 If the flare nut were tightened with excess torque, it could cause burst and refrigerant leakage after a long period. ODo not put the drainage pipe directly into drainage channels where poisonous gases such as sulfide gas can occur. Poisonous gases will flow into the room through drainage pipe and seriously affect the user's health and safety. This can also cause the corrosion of the indoor unit and a resultant unit failure or refrigerant leak. \bigcirc Connect the pipes for refrigeration circuit securely in installation work before compressor is operated. If the compressor is operated when the service valve is open without connecting the pipe, it could cause explosion and injuries due to abnormal high pressure in the system Stop the compressor before removing the pipe after shutting the service valve on pump down work. If the pipe is removed when the compressor is in operation with the service valve open, air would be mixed in the refrigeration circuit and it could cause explosion and injuries due to abnormal high pressure in the cooling cycle. Only use prescribed optional parts. The installation must be carried out by the qualified installer. 0 If you install the system by yourself, it can cause serious trouble such as water leaks, electric shocks, fire Do not repair by yourself. And consult with the dealer about repair. \bigcirc er repair may cause water leakage, electric shock or fire. Consult the dealer or a specialist about removal of the air conditioner. 0 oper installation may cause water leakage, electric shock or fire Turn off the power source during servicing or inspection work. 0 If the power is supplied during servicing or inspection work, it could cause electric shock and injury by the operating fan •Do not run the unit when the panel or protection guard are taken off. \bigcirc Touching the rotating equipment, hot surface, or high voltage section could cause an injury to be caught in the machine, to get urned, or electric shock Shut off the power before electrical wiring work. It could cause electric shock, unit failure and in

A CAUTION		
• Perform earth wiring surely.		
Do not connect the earth wiring to the gas pipe, water pipe, lightning rod a cause unit failure, electric shock and fire due to a short circuit.	and telephone earth wiring. Improper earth could	A
• Earth leakage breaker must be installed. If the earth leakage breaker is not installed, it can cause fire and electric	shocks.	0
 Use the circuit breaker of correct capacity. Circuit breaker st poles under over current. 	hould be the one that disconnect all	0
Using the incorrect one could cause the system failure and fire. Do not use any materials other than a fuse of correct capacity of the system failure and fire.		$\overline{\mathbf{O}}$
Connecting the circuit by wire or copper wire could cause unit failure an Do not install the indoor unit near the location where there is 		X
If the gas leaks and gathers around the unit, it could cause fire.	poolonity of naninable gas loakages.	\bigcirc
 Do not install and use the unit where corrosive gas (such as sulfu as thinner, petroleum etc.) may be generated or accumulated, or it could cause the corrosion of heat exchanger, breakage of plastic parts 	volatile flammable substances are handled	
• Secure a space for installation, inspection and maintenance		
Insufficient space can result in accident such as personal injury due to f Do not use the indoor unit at the place where water splashes 		
 Do not use the indoor unit at the place where water splashes Indoor unit is not waterproof. It could cause electric shock and fire. 	s such as laundry.	\otimes
Do not use the indoor unit for a special purpose such as foou instrument, preservation of animals, plants, and a work of an It could cause the damage of the items.		\bigcirc
Do not install nor use the system near equipments which generate Equipments like inverter equipment, private power generator, high-freque equipment might influence the air conditioner and cause a malfunction on influence medical equipments or telecommunication equipments, and of	ency medical equipment, or telecommunication and breakdown. Or the air conditioner might	\odot
 Do not install the remote control at the direct sunlight. It could cause breakdown or deformation of the remote control. 	saude aren moulea acunty or cause jamming.	\bigcirc
 Do not install the indoor unit at the place listed below. 		
Places where flammable gas could leak. Places where carbon fiber, metal powder or any powder is floated. Place where the substances which affect the air conditioner are generated such as sulfide gas, chickide gas, acid, akali or ammonic atmospheres. Places exposed to oil mist or steam directly.	Places where cosmetics or special sprays are frequently used. Highly saited area such as beach. Heavy snow area Places where the system is affected by mode frequently in the set of the set.	°O
On vehicles and ships Places where machinery which generates high harmonics is used.	smoke from a chimney. • Altitude over 1000m	
 Do not install the indoor unit in the locations listed below (Beaccording to the installation manual for each model because 	e each indoor unit has each limitation)	
 Locations with any obstacles which can prevent inlet and outlet air of Locations where vibration can be amplified due to insufficient strength 	of structure.	
 Locations where the infrared receiver is exposed to the direct sunlight infrared specification unit) 	or the strong light beam. (in case of the	\otimes
Locations where an equipment affected by high harmonics is placed. (Locations where drainage cannot run off safely. It can affect performance or function and etc	TV set or radio receiver is placed within 5m)	
Do not put any valuables which will break down by getting v	vet under the air conditioner.	$\overline{\mathbf{N}}$
Condensation could drop when the relative humidity is higher than 80% or drain Do not use the base frame for the outdoor unit which is corrod		$\underline{\aleph}$
It could cause the unit falling down and injury.	ou or damagou artor a long portou or abo.	\bigcirc
 Pay attention not to damage the drain pan by weld sputter w If sputter entered into the unit during brazing work, it could cause dama To avoid damaging, keep the indoor unit packed or cover the indoor unit 	ge (pinhole) of drain pan and leakage of water.	0
Install the drain pipe to drain the water surely according to t	he installation manual.	0
Improper connection of the drain pipe may cause dropping water into ro Do not share the drain pipe for indoor unit and GHP (Gas Hea		
Toxic exhaust gas would flow into room and it might cause serious dam user's health and safety.		\bigcirc
 Be sure to perform air tightness test by pressurizing with nitrogen If the density of refrigerant exceeds the limit in the event of refrigerant let a succeed the limit is a succeed to be a succeed		0
occur, which can cause serious accidents. • For drain pipe installation, be sure to make descending slope	of greater than 1/100, not to make traps,	
and not to make air-bleeding. Check if the drainage is correctly done during commissioning and ensur	e the space for inspection and maintenance.	Ð
• Ensure the insulation on the pipes for refrigeration circuit so	as not to condense water.	0
Incomplete insulation could cause condensation and it would wet ceiling Do not install the outdoor unit where is likely to be a nest for Insects and small animals could come into the electronic components an	r insects and small animals.	
 Pay extra attention, carrying the unit by hand. 		
Carry the unit with 2 people if it is heavier than 20kg. Do not use the plast by hand. Use protective gloves in order to avoid injury by the aluminum fir		0
Make sure to dispose of the packaging material. Leaving the materials may cause injury as metals like nail and woods an	e used in the package.	0
• Do not operate the system without the air filter. It may cause the breakdown of the system due to clogging of the heat e	xchanger.	\bigcirc
 Do not touch any button with wet hands. It could cause electric shock. 		\bigcirc
 Do not touch the refrigerant piping with bare hands when in The pipe during operation would become very hot or cold according to the operation 		\bigcirc
Do not clean up the air conditioner with water. It could cause electric shock.		\bigcirc
 Do not turn off the power source immediately after stopping the op Be sure to wait for more than 5 minutes. Otherwise it could cause water 		Ŏ
Do not control the operation with the circuit breaker.	-	Ň
It could cause fire or water leakage. In addition, the fan may start operat	tion unexpectedly and it may cause injury.	S)





Caution

Work procedure

⁶Refrigerant pipe


Caution


Use the new refrigerant pipe

- When re-using the existing pipe system for R22 or R407C, pay attention to the following items. Change the flare nuts with the attached ones (JIS category 2), and reprocess the flare parts Do not use thin-walled pipes.
- Use phosphorus deoxidized copper alloy seamless pipe (C1220T specified in JIS H3300) for refrigeration pipe installation.
 In addition, make sure there is no damage both inside and outside of the pipe, and no harmful substances such as sulfur, oxide, dust or a contaminant stuck on the pipes
- Do not use any refrigerant other than R410A. Using other refrigerant except R410A (R22 etc.) may degrade inside refrigeration oil. And air getting
- into refrigeration circuit may cause over-pressure and resultant it may result in bursting, etc. Store the copper pipes indoors and seal the both end of them until they are brazed in order to avoid any dust, dirt or water getting into pipe. Otherwise it will cause degradation of refrigeration oil and compressor breakdown, etc. •Use special tools for R410 refrigerant.

Work procedure

- 1. Remove the flare nut and blind flanges on the pipe of the indoor unit.
- Whake sure to loosen the flare nut with holing the nut or pipe side with a spanner and giving torque to the nut with another spanner in order to avoid unexpected stress to the copper pipe, and then remove them (Gas may come out at this time, but it is not abnormal.)
- •Pay attention whether the flare nut pops out. (as the indoor unit is sometimes pressured.) 2. Make a flare on liquid pipe and gas pipe, and connect the refrigeration pipes on the indoor unit. When taking out the pipe to rear or top, install it together with the electric wire®, passing them through the attached cover.
 - Seal clearances with putty, etc. to shut off dust.
 - *Bend the pipe with as big radius as possible and do not bend the pipe repe In addition, do not twist and crush the pipes.
- *Do a flare connection as follows:
- Make sure to loosen the flare nut with holding the nut on pipe side with a spanner and giving torque to the nut with another spanner in order to avoid unexpected stress to the copper pipe, and then remove them. •When fastening the flare nut, align the refrigeration pipe with the center of flare nut, screw
- the nut for 3-4 times by hand and then tighten it by spanner with the specified torque mentioned in the table below. Make sure to hold the pipe on the indoor unit securely by a spanner when tightening the nut in order to avoid unexpected stress on the copper pipe.
- Cover the flare connection part of the indoor unit with attached insulation material after a gas leakage inspection, and tighten both ends with attached straps. Make sure to insulate both gas pipes and liquid pipes completely.
- %Incomplete insulation may cause dew condensation or water dropping 4. Refrigerant is charged in the outdoor unit.
- As for the additional refrigerant charge for the indoor unit and piping, refer to the installation manual attached to the outdoor unit. Pipe cover (Accessory)







% Give a drain hose a gradient of 10mm as illustrated in the right drawing by laying it without leaving a slack.

1. Insert drain hose completely to the

base, and tighten the drain hose clamp securely. (adhesive must not be used.)

* When plumbing on the left side, move the

A Beware of a possible outflow of water that ma occur upon removal of a drain plug.

2. Fix the drain hose at the lowest point with

a hose clamp supplied as an accessory.

rubber plug and the cylindrical insulating materials by the pipe connecting hole on

Take head of electrical cables so that

they may not run beneath the drain hose. A drain hose must be clamped down with a hose clamp

There is a possibility that drain water overflows. Connect VP-20(prepare on site) to drain hose. (adhesive must not be used.)

Install the drain pipe according to the installation manual in order to drain properly.

Imperfection in draining may cause flood indoors and wetting the household goods, etc

Do not put the drain pipe directly into the ditch where toxic gas such as sulfur, the other harmful and inflammable gas is generated. Toxic gas would flow into the room and

it would cause serious damage to user's health and safety (some poisoning or deficiency

Make sure to make descending slope of greater than 1/100 and do not make up-down bend and/or trap in the midway. In addition, do not put air vent on the drain pipe. Check if water is drained out properly

from the pipe during commissioning. Also, keep sufficient space for inspection and maintenance.


r that may

of oxygen). In addition, it may cause corrosion of heat exchanger and bad smell. Connect the pipe securely to avoid water leakage from the joint. Insulate the pipe properly to avoid condensation drop. Check if the water can flow out properly from both the drain outlet on the indoor unit and the end of the drain pipe after installation.

- X Use commercially available rigid PVC general pipe VP-20 for drain pipe. Do not to make the up-down bending and trap in the mid-way while assum-ing that the drain pipes is downhill. (more than 1/100)
- Never set up air vent. Insulate the drain pipe.
- Insulate the drain hose clamp with the heat insulation supplied as accessories. When the unit is installed in a humid place, consider precautions against dew condensation such as heat insulation for the drain pipe.

Drain test

- After installation of drain pipe, make sure that drain system work in good condition and no water leakage from joint and drain pan.
- Do drain test even if installation of heating season



PJG012D004

(3) Duct connected-High static pressure type (FDU)

(a) Indoor unit

This manual is for the installation of an indoor unit. For electrical wiring work (Indoor), refer to page 108. For remote control installation, refer to page 16. For wireless kit installation, refer to page 150. For electrical wiring work (Outdoor) and refrigerant pipe work installation for outdoor unit, refer to page 130.


SAFETY PRECAUTIONS


- Read the "SAFETY PRECAUTIONS" carefully first of all and then strictly follow it during the installation work in order to protect yourself. • The precautionary items mentioned below are distinguished into two levels, (AWARNING) and (ACAUTION). [<u>AWARNING</u>: Wrong installation would cause serious consequences such as injuries or death. [<u>ACAUTION</u>]: Wrong installation might cause serious consequences depending on circumstances.

- Both mentions the important items to protect your health and safety so strictly follow them by any means. The meanings of 'Marks' used here are as shown on the right: Never do it under any circumstances. After completing the installation, do commissioning to confirm there are no abnormalities, and explain to the customers about "SAFETY PREOAUTIONS", correct operation method and maintenance method (air filter denained and the anti-meantena customers and the used with weard of the mean 16 the instruction. cleaning, operation method and temperature setting method) with user's manual of this unit. Ask your customers to keep this installation manual together with the user's manual. Also, ask them to hand over the user's manual to the new user when the owner is changed.

Installation should be performed by the specialist.	
If you install the unit by yourself, it may lead to serious trouble such as water leakage, electric shock, fire, and injury due to overturn	e
of the unit.	_
Install the system correctly according to these installation manuals.	•
Improper installation may cause explosion, injury, water leakage, electric shock, and fire.	
Check the density refered by the foumula (accordance with ISO5149).	A
If the density exceeds the limit density, please consult the dealer and installate the ventilation system.	e
Use the genuine accessories and the specified parts for installation.	0
If parts unspecified by our company are used it could cause water leakage, electric shock, fire, and injury due to overturn of the unit.	U
Ventilate the working area well in case the refrigerant leaks during installation.	Ø
If the refrigerant contacts the fire, toxic gas is produced.	U
Install the unit in a location that can hold heavy weight.	
Improper installation may cause the unit to fall leading to accidents.	e
Install the unit properly in order to be able to withstand strong winds such as typhoons, and earthquakes.	-
Improper installation may cause the unit to fall leading to accidents.	9
Do not mix air in to the cooling cycle on installation or removal of the air conditioner.	6
If air is mixed in, the pressure in the cooling cycle will rise abnormally and may cause explosion and injuries.	0
Be sure to have the electrical wiring work done by qualified electrical installer, and use exclusive circuit.	
Power source with insufficient capacity and improper work can cause electric shock and fire.	e
Use specified wire for electrical wiring, fasten the wiring to the terminal securely, and hold the cable securely in	_
order not to apply unexpected stress on the terminal.	6
Loose connections or hold could result in abnormal heat generation or fire.	U
Arrange the electrical wires in the control box properly to prevent them from rising. Fit the lid of the services	
panel property.	6
Improper fitting may cause abnormal heat and fire.	-
Check for refrigerant gas leakage after installation is completed.	
If the refrigerant gas leaks into the house and comes in contact with a fan heater, a stove, or an oven, toxic gas is produced.	
Use the specified pipe, flare nut, and tools for R410A.	-
Using existing parts (R22) could cause the unit failure and serious accident due to explosion of the cooling cycle.	e
Tighten the flare nut according to the specified method by with torque wrench.	
If the flare nut were tightened with excess torque, it could cause burst and refrigerant leakage after a long period.	
Do not put the drainage pipe directly into drainage channels where poisonous gases such as sulfide gas can	
OCCUI.	6
Poisonous gases will flow into the room through drainage pipe and seriously affect the user's health and safety. This can also cause the corrosion of the indoor unit and a resultant unit failure or refrigerant leak.	0
Connect the pipes for refrigeration circuit securely in installation work before compressor is operated.	-
If the compressor is operated when the service valve is open without connecting the pipe, it could cause explosion and injuries due	
to abnormal high pressure in the system.	_
Stop the compressor before removing the pipe after shutting the service valve on pump down work.	
If the pipe is removed when the compressor is in operation with the service valve open, air would be mixed in the refrigeration circuit	e
and it could cause explosion and injuries due to abnormal high pressure in the cooling cycle.	6
and it could cause explosion and injuries due to abnormal high pressure in the cooling cycle. Only use prescribed optional parts. The installation must be carried out by the qualified installer.	J
	6
Only use prescribed optional parts. The installation must be carried out by the qualified installer.	0
Only use prescribed optional parts. The installation must be carried out by the qualified installer. If you install the system by yourself, it can cause serious trouble such as water leaks, electric shocks, fire.	_
Only use prescribed optional parts. The installation must be carried out by the qualified installer. If you install the system by yourself, it can cause serious trouble such as water leaks, electric shocks, fire. Do not repair by yourself. And consult with the dealer about repair. Improper repair may cause water leakage, electric shock or fire.	
Only use prescribed optional parts. The installation must be carried out by the qualified installer. If you install the system by yourself, it can cause serious trouble such as water leaks, electric shocks, fire. Do not repair by yourself. And consult with the dealer about repair. Improper repair may cause water leakage, electric shock or fire. Consult the dealer or a specialist about removal of the air conditioner.	e
Only use prescribed optional parts. The installation must be carried out by the qualified installer. If you install the system by yourself, it can cause serious trouble such as water leaks, electric shocks, fire. Do not repair by yourself. And consult with the dealer about repair. Improper repair may cause water leakage, electric shock or fire. Consult the dealer or a specialist about removal of the air conditioner. Improper installation may cause water leakage, electric shock or fire.	e
Only use prescribed optional parts. The installation must be carried out by the qualified installer. If you install the system by yourself, it can cause serious trouble such as water leaks, electric shocks, fire. Do not repair by yourself. And consult with the dealer about repair. Improper repair may cause water leakage, electric shock or fire. Consult the dealer or a specialist about removal of the air conditioner. Improper installation may cause water leakage, electric shock or fire. Turn off the power source during servicing or inspection work.	e
Only use prescribed optional parts. The installation must be carried out by the qualified installer. If you install the system by yourself, it can cause serious trouble such as water leaks, electric shocks, fire. Do not repair by yourself. And consult with the dealer about repair. Improper repair may cause water leakage, electric shock or fire. Consult the dealer or a specialist about removal of the air conditioner. Improper instalation may cause water leakage, electric shock or fire. Turn off the power source during servicing or inspection work. If the power is supplied during servicing or inspection work, it could cause electric shock and injury by the operating fan.	e
Only use prescribed optional parts. The installation must be carried out by the qualified installer. If you install the system by yourself, it can cause serious trouble such as water leaks, electric shocks, fire. Do not repair by yourself. And consult with the dealer about repair. Improper repair may cause water leakage, electric shock or fire. Consult the dealer or a specialist about removal of the air conditioner. Improper installation may cause water leakage, electric shock or fire. Turn off the power source during servicing or inspection work. If the power is supplied during servicing or inspection work, it could cause electric shock and injury by the operating fan. Do not run the unit when the panel or protection guard are taken off.	
Only use prescribed optional parts. The installation must be carried out by the qualified installer. If you install the system by yourself, it can cause serious trouble such as water leaks, electric shocks, fire. Do not repair by yourself. And consult with the dealer about repair. Improper repair may cause water leakage, electric shock or fire. Consult the dealer or a specialist about removal of the air conditioner. Improper instalation may cause water leakage, electric shock or fire. Turn off the power source during servicing or inspection work. If the power is supplied during servicing or inspection work, it could cause electric shock and injury by the operating fan.	
Only use prescribed optional parts. The installation must be carried out by the qualified installer. If you install the system by yourself, it can cause serious trouble such as water leaks, electric shocks, fire. Do not repair by yourself. And consult with the dealer about repair. Improper repair may cause water leakage, electric shock or fire. Consult the dealer or a specialist about removal of the air conditioner. Improper installation may cause water leakage, electric shock or fire. Turn off the power source during servicing or inspection work. If the power is supplied during servicing or inspection work, it could cause electric shock and injury by the operating fan. Do not run the unit when the panel or protection guard are taken off. Touching the rolating equipment, thot surface, or high voltage section could cause an injury to be caught in the machine, to get burned, or electric shock.	
Only use prescribed optional parts. The installation must be carried out by the qualified installer. If you install the system by yourself, it can cause serious trouble such as water leaks, electric shocks, fire. Do not repair by yourself. And consult with the dealer about repair. Improper repair may cause water leakage, electric shock or fire. Consult the dealer or a specialist about removal of the air conditioner. Improper installation may cause water leakage, electric shock or fire. Turn off the power source during servicing or inspection work. If the power is supplied during servicing or inspection work. Do not run the unit when the panel or protection guard are taken off. Touching the rotating equipment, the surface, noting servicince out cause are injury to be caught in the machine, to get	

▲ CAUTION	
Perform earth wiring surely.	
Do not connect the earth wiring to the gas pipe, water pipe, lightning rod and telephone earth wiring. Improper earth co	uld 🌒 📗
cause unit failure and electric shock or fire due to a short circuit.	_
Earth leakage breaker must be installed. If the earth leakage breaker is not installed, it could cause electric shocks or fire.	0
 Use the circuit breaker of correct capacity. Circuit breaker should be the one that disconnect all poles under over current. Using the incorrect one could cause the system failure and fire. 	0
Do not use any materials other than a fuse of correct capacity where a fuse should be used. Connecting the circuit by wire or copper wire could cause unit failure and fire.	\bigcirc
Do not install the indoor unit near the location where there is possibility of flammable gas leakag	
If the gas leaks and gathers around the unit, it could cause fire. • Do not install and use the unit where corrosive gas (such as sulfurous acid gas etc.) or flammable gas (s	
as thinner, petroleum etc.) may be generated or accumulated, or volatile flammable substances are hand It could cause the corrosion of heat exchanger, breakage of plastic parts etc. And inflammable gas could cause fire.	
Secure a space for installation, inspection and maintenance specified in the manual. Insufficient open one result is assident such as present injury due to falling from the installation place.	
Insufficient space can result in accident such as personal injury due to falling from the installation place. Do not use the indoor unit at the place where water splashes such as laundry.	$\overline{\bigcirc}$
Indoor unit is not waterproof. It could cause electric shock and fire. Do not use the indoor unit for a special purpose such as food storage, cooling for precision	
instrument, preservation of animals, plants, and a work of art. It could cause the damage of the items.	\bigcirc
Do not install nor use the system near equipments which generate electromagnetic wave or high harmonic Equipments like inverter equipment, private power generator, high-frequency medical equipment, or telecommunica que aural nuclei nuclei nuclei accordinater and acuse a mathucation and breakdown. Or the air conditioner might influence medical equipments or telecommunication equipments, and obstruct their medical activity or cause jamm	
Do not install the remote control at the direct sunlight. It could cause breakdown or deformation of the remote control.	\bigcirc
Do not install the indoor unit at the place listed below. Places where flammable gas could leak. Places where fammable gas could leak. Places where the substances which fact the air conditioner are generated such as suffice gas, chindre gas, acid, alkai or ammonic atmospheres. Places exposed to oil mist or steam directly. On weindes and ships	
Places where machinery which generates high harmonics is used. Altitude over 1000m Do not install the indoor unit in the locations listed below (Be sure to install the indoor unit	
according to the installation manual for each model because each indicor unit has each limitation - Locations with any obstacles which can prevent inlet and outlet air of the unit - Locations where wheration can be amplified due to insufficient strength of structure. - Locations where the infrared receiver is exposed to the direct sunlight or the strong light beam. (in case of the infrared specification unit) - Locations where an equipment affected by high harmonics is placed. (TV set or radio receiver is placed within 5m) - Locations where drinage cannot run of safely.	\odot
• Do not put any valuables which will break down by getting wet under the air conditioner.	$\overline{\bigcirc}$
Condensation could drop when the relative humidity is higher than 80% or drain pipe is clogged, and it damages user's belongin Do not use the base frame for the outdoor unit which is corroded or damaged after a long period of u	
• Bo not use the base many for the outdoor and which is corrotate of damaged and a long period of a It could cause the unit falling down and injury.	‴ ()
Pay attention not to damage the drain pan by weld sputter when brazing work is done near the un if sputter entered into the unit during brazing work, it could cause damage (pinhole) of drain pan and leakage of wal	
To avoid damaging, keep the indoor unit packed or cover the indoor unit. Install the drain pipe to drain the water surely according to the installation manual.	
Improper connection of the drain pipe may cause dropping water into room and damaging user's belongings.	•
Do not share the drain pipe for indoor unit and GHP (Gas Heat Pump system) outdoor unit. Toxic exhaust gas would flow into room and it might cause serious damage (some poisoning or deficiency of oxyger user's health and safety.	
Be sure to perform air tightness test by pressurizing with nitrogen gas after completed refrigerant piping with the density of refrigerant exceeds the limit in the event of refrigerant leakage in the small room, lack of oxygen ca occur, which can cause serious accidents.	
 For drain pipe installation, be sure to make descending slope of greater than 1/100, not to make tra and not to make air-bleeding. Chest if the descendance of the sure to descend a size of the sure of the sur	
Check if the drainage is correctly done during commissioning and ensure the space for inspection and maintenance Ensure the insulation on the pipes for refrigeration circuit so as not to condense water.	
Incomplete insulation could cause condensation and it would wet ceiling, floor, and any other valuables.	Ð
Do not install the outdoor unit where is likely to be a nest for insects and small animals. Insects and small animals could come into the electronic components and cause breakdown and fire. Instruct the use keep the surroundings clean.	r to 🚫
Pay extra attention, carrying the unit by hand. Carry the unit with 2 people if it is heavier than 20kg. Do not use the plastic straps but the grabbing place, moving the	unit
by hand. Use protective gloves in order to avoid njury by the aluminum fin. Make sure to dispose of the packaging material. Leaving the materials may cause injury as metals like nali and woods are used in the package.	0
• Do not operate the system without the air filter.	$\overline{\bigcirc}$
It may cause the breakdown of the system due to clogging of the heat exchanger. Do not touch any button with wet hands.	
It could cause electric shock.	
Do not touch the refrigerant piping with bare hands when in operation. The pipe during operation would become very hot or cold according to the operating condition, and it could cause a burn or frost	bite. 🚫
Do not clean up the air conditioner with water. It could cause electric shock.	\bigcirc
Do not turn off the power source immediately after stopping the operation.	Ň
Be sure to wait for more than 5 minutes. Otherwise it could cause water leakage or breakdown. Do not control the operation with the circuit breaker.	
It could cause fire or water leakage. In addition, the fan may start operation unexpectedly and it may cause injury.	\bigcirc





2)Selection of installation location for the indoor unit

- ① Select the suitable areas to install the unit under approval of the user.
- Areas where the indoor unit can deliver hot and cold wind sufficiently. Suggest to the user to use a circulator if the ceiling height is over 3m to avoid warm air being accumulated on the ceiling. · Areas where there is enough space to install and service.
- · Areas where it can be drained properly. Areas where drain pipe descending slope can be taken.
- · Areas where there is no obstruction of airflow on both air return grille and air supply port.
- · Areas where fire alarm will not be accidentally activated by the air conditioner.
- · Areas where the supply air does not short-circuit.
- · Areas where it is not influenced by draft air.
- · Areas not exposed to direct sunlight.
- · Areas where dew point is lower than around 28°C and relative humidity is lower than 80%. This indoor unit is tested under the condition of JIS (Japan Industrial Standard) high humidity condition and confirmed there is no problem. However, there is some risk of condensation drop if the air conditioner is operated under the severer condition than mentioned above. If there is a possibility to use it under such a condition, attach additional insulation of 10 to
- 20mm thick for entire surface of indoor unit, refrigeration pipe and drain pipe. · Areas where TV and radio stays away more than 1m. (It could cause jamming and noise.)
- · Areas where any items which will be damaged by getting wet are not placed such as food, table wares, server, or medical equipment under the unit.
- · Areas where there is no influence by the heat which cookware generates.
- · Areas where not exposed to oil mist, powder and/or steam directly such as above fryer. Areas where lighting device such as fluorescent light or incandescent light doesn't affect the operation.

(A beam from lighting device sometimes affects the infrared receiver for the wireless remote control and the air conditioner might not work properly.)

2 Check if the place where the air conditioner is installed can hold the weight of the unit. If it is not able to hold, reinforce the structure with boards and beams strong enough to hold it. If the strength is not enough, it could cause injury due to unit falling.


Space for installation and service

• Make installation altitude over 2.5m.

(Indoor Unit)


Select either of two cases to keep space for installation and services







③Preparation before installation


- If suspension bolt becomes longer, do reinforcement of earthquake resistant. OFor grid ceiling
- When the suspension bolt length is over 500mm, or the gap between the ceiling and roof is over 700mm, apply earthquake resistant brace to the bolt.
- OIn case the unit is hanged directly from the slab and is installed on the ceiling plane which has enough strength
- When suspension bolt length is over 1000mm, apply the earthquake resistant brace to the bolt. Prepare four (4) sets of suspension bolt, nut and spring washer (M10) on site.



(4)Installation of indoor unit








8 Wiring-out position and wiring connection

- Electrical installation work must be performed according to the installation manual by an
 electrical installation service provider qualified by a power provider of the country, and be
 executed according to the technical standards and other regulations applicable to electrical
 installation in the country.
 - Be sure to use an exclusive circuit.
- Use specified cord, fasten the wiring to the terminal securely, and hold the cord securely in order not to apply unexpected stress on the terminal.
- Do not put both power source line and signal line on the same route. It may cause miscommunication and malfunction.
- For the details of electrical wiring work, see attached instruction manual for electrical wiring work.
- 1. Remove a lid of the control box (2 screws).
- 2. Hold each wiring inside the unit and fasten them to terminal block securely.
- 3. Fix the wiring with clamps.
- 4. Install the removed parts back to original place



9 External static pressure setting

You can set External Static Pressure (E.S.P) by method of MANUAL SETTING on remote control. Indoor unit will control fan-speed to keep rated air flow volume at each fan speed setting (Lo-Uhi) You can set required E.S.P. by wired remote control that calculated with the set air flow rate and pressure loss of the duct connected.

3218:883

- How to set E.S.P. by wired remote control
- Push "◆" marked button(E.S.P. button).
 2 Select indoor unit No. by using ◆ button.
- ③ Select setting No. by using ◆ button and set E.S.P. by ◯ button.

See detailed procedure in technical manual.

You can NOT set E.S.P. by wireless remote control.

With E.S.P. setting, confirm that actual E.S.P. agrees with E.S.P. setting.

When E.S.P. setting is higher than actual E.S.P, the airflow rate becomes excessively higher. This will cause water leakage if water splashes.

When E.S.P. setting is lower than actual E.S.P., the airflow rate becomes excessively lower and the cooling or heating may become ineffective.


E.S.P.bu

In order to reduce the risk above the factory ES.P.setting is set within the range of 80 - 150 Pa (E.S.P.setting No. 8 - 15). Be sure to use within the range of 80 - 150 Pa in actual operations. If actual E.S.P.is lower than 80 Pa, it may cause water leakage.

 Setting No.
 8
 9
 10
 11
 12
 13
 14
 15

 E.S.P (Pa)
 80
 90
 100
 110
 120
 130
 140
 150

If 1 – 7 is selected for the setting No. on the remote control, the setting No. shows No. 8. If 16 – 20 is selected for the setting No. on the remote control, the setting No. shows No. 15. Factory default is No. 8.



 Setting No.
 1
 2
 3
 4
 5
 6
 7
 8
 9
 10
 11
 12
 13
 14
 15
 16
 17
 18
 19

 ES.P.(Pa)
 10
 20
 30
 40
 50
 60
 70
 80
 90
 100
 110
 120
 130
 140
 150
 160
 170
 180
 200

 X If 20 is selected for the setting No. on the remote control, the setting No. shows No. 19.

(11) Check list after installation

Check the following items after all installation work completed.


Check if	Expected trouble	Check
The indoor and outdoor units are fixed securely?	Falling, vibration, noise	
Inspection for leakage is done?	Insufficient capacity	
Insulation work is properly done?	Water leakage	
Water is drained properly?	Water leakage	
Supply voltage is same as mentioned in the model name plate?	PCB burnt out, not working at all	
No mis-wiring or mis-connection of piping?	PCB burnt out, not working at all	
Earth wiring is connected properly?	Electric shock	
Cable size comply with specified size?	PCB burnt out, not working at all	
Any obstacle blocks airflow on air inlet and outlet?	Insufficient capacity	
Is setting of E.S.P finished?	Excessive air flow, water drop blow out	

(b) Replacement procedure of the fan unit


Notes(1) The unit is a heavy item. It must be supported securely and handled with care not to drop when it is necessary to replace. (2) For the maintenance space, refer to page 84.

(i) Model FDU71VF1


1) Remove the control box and the side panel, and remove the screws marked in the circles (2 places) in the figure.




2) Take out the fan unit in the arrow direction.



2) Take out the fan unit located at the near side in the arrow direction.




3) Remove the screws marked in the circles (2 places) from the fan unit located at the far side.




(ii) Model FDU100VF1, 100VF2

1) Remove the control box and the side panel, and remove the screws marked in the circles (2 places) from the unit located at the near side.



4) Take out the fan unit in the arrow direction.



(4) Duct connected-Low / Middle static pressure type (FDUM)

(a) Indoor unit

PJG012D008B

This manual is for the installation of an indoor unit. For electrical wiring work (Indoor), refer to page 104. For remote control installation, refer to page 116. For wireless kit installation, refer to the page 150. For electrical wiring work (Outdoor) and refrigerant pipe work installation for outdoor unit, refer to page 130.


SAFETY PRECAUTIONS

- Read the "SAFETY PRECAUTIONS" carefully first of all and then strictly follow it during the installation work in order to protect yourself.
- The precautionary items mentioned below are distinguished into two levels, [<u>AUWARNING</u>] and [<u>ACAUTION</u>], [<u>AWARNING</u>]: Wrong installation would cause serious consequences such as injuries or death. [<u>ACAUTION</u>]: Wrong installation might cause serious consequences depending on circumstances.
- Both mentions the important items to protect your health and safety so strictly follow them by any means. • The meanings of "Marks" used here are as shown on the right:
- The invarings of matrix load field are as shown on iterright.
 Never of lunder any circumstances.
 Object operation method and explain to the customers about "SAFETY PRECAUTIONs", correct operation method and maintenance method (air filter cleaning, operation method and temperature setting method) with user's manual of this unit.
 Ask your customers to keep this installation manual together with the user's manual. Also, ask them to hand over the user's manual. Also, ask them to hand over the user's manual.

A WARNING	
Installation should be performed by the specialist. If you install the unit by yourself, it may lead to serious trouble such as water leakage, electric shock, fire, and injury due to overturn of the unit.	0
Install the system correctly according to these installation manuals. Improper installation may cause explosion, injury, water leakage, electric shock, and fire.	0
Check the density refered by the fournula (accordance with IS05149). If the density exceeds the limit density please consult the dealer and installate the ventilation system.	0
Use the genuine accessories and the specified parts for installation. If parts unspecified by our company are used it could cause water leakage, electric shock, fire, and injury due to overtum of the unit.	0
Ventilate the working area well in case the refrigerant leaks during installation. If the refrigerant contacts the fire, toxic gas is produced.	0
Install the unit in a location that can hold heavy weight. Improper installation may cause the unit to fall leading to accidents.	0
Install the unit properly in order to be able to withstand strong winds such as typhoons, and earthquakes. Improper installation may cause the unit to fall leading to accidents.	0
Do not mix air in to the cooling cycle on installation or removal of the air conditioner. If air is mixed in, the pressure in the cooling cycle will rise abnormally and may cause explosion and injuries.	$\overline{\mathbb{S}}$
Be sure to have the electrical wiring work done by qualified electrical installer, and use exclusive circuit. Power source with insufficient capacity and improper work can cause electric shock and fire.	Ō
Use specified wire for electrical wiring, fasten the wiring to the terminal securely, and hold the cable securely in order not to apply unexpected stress on the terminal. Lose connections or hold could result in abnormal heat generation or fire.	0
Arrange the electrical wires in the control box properly to prevent them from rising. Fit the lid of the services panel property. Improper fitting may cause abnormal heat and fire.	0
Check for refrigerant gas leakage after installation is completed. If the refrigerant gas leaks into the house and comes in contact with a fan heater, a stove, or an oven, toxic gas is produced.	0
Use the specified pipe, flare nut, and tools for R410A. Using existing parts (R22) could cause the unit failure and serious accident due to explosion of the cooling cycle.	0
Tighten the flare nut according to the specified method by with torque wrench. If the flare nut were tightened with excess torque, it could cause burst and refrigerant leakage after a long period.	0
Do not put the drainage pipe directly into drainage channels where poisonous gases such as sulfide gas can occur. Poisonous gases will flow into the room through drainage pipe and seriously affect the user's health and safely. This can also cause the corrosion of the indoor unit and a resultant unit failure or refrigerant leak.	2
Connect the pipes for refrigeration circuit securely in installation work before compressor is operated. If the compressor is operated when the service valve is open without connecting the pipe, it could cause explosion and injuries due to abnormal high pressure in the system.	0
Stop the compressor before removing the pipe after shutting the service valve on pump down work. If the pipe is removed when the compressor is in operation with the service valve open, air would be mixed in the refrigeration circuit (and it could cause explosion and injuries due to abnormal high pressure in the cooling cycle.	O
Only use prescribed optional parts. The installation must be carried out by the qualified installer. If you install the system by yourself, it can cause serious trouble such as water leaks, electric shocks, fire.	0
Do not repair by yourself. And consult with the dealer about repair. Improper repair may cause water leakage, electric shock or fire.	Ś
Consult the dealer or a specialist about removal of the air conditioner. Improper installation may cause water leakage, electric shock or fire.	0
Turn off the power source during servicing or inspection work. If the power is supplied during servicing or inspection work, it could cause electric shock and injury by the operating fan.	0
Do not run the unit when the panel or protection guard are taken off. Touching the rotating equipment, hot surface, or high voltage section could cause an injury to be caught in the machine, to get burned, or electric shock.	2
Shut off the power before electrical wiring work. It could cause electric shock, unit failure and improper running.	A

▲ CAUTION	
Perform earth wiring surely. Do not connect the earth wiring to the gas pipe, water pipe, lightning rod and telephone earth wiring. Improper earth cou cause unit failure and electric shock or fire due to a short circuit. Earth leakage breaker must be installed.	
If the earth leakage breaker is not installed, it could cause electric shocks or fire. Use the circuit breaker of correct capacity. Circuit breaker should be the one that disconnect all poles under over current.	
 bots and/or out call the system failure and fire. Do not use any materials other than a fuse of correct capacity where a fuse should be used. 	
 Or not last any matching output that a fact or or or other capacity which a fact another becau. Connecting the circuit by wire or copper wire could cause unit failure and fire. Do not install the indoor unit near the location where there is possibility of flammable gas leakage 	\bigcirc
 b to not install and use induce that here out the total where outer is possibility of naminate gas reakage if the gas leaks and gathers around the unit, it could cause fire. D to not install and use the unit where corrosive gas (such as sulfurous acid gas etc.) or flammable gas (su 	\bigcirc
• Or hor mission to be the unit where concave gas (buch as sumious act) gas etc.) or naminate gas (bas as thinner, petroleum etc.) may be generated or accumulated, or volatile frammable subscances are handle it could cause the corrosion of heat exchanger, breakage of plastic parts etc. And inflammable gas could cause fire.	
Secure a space for installation, inspection and maintenance specified in the manual. Insufficient space can result in accident such as personal injury due to falling from the installation place.	0
Do not use the indoor unit at the place where water splashes such as laundry. Indoor unit is not waterproof. It could cause electric shock and fire.	\bigcirc
Do not use the indoor unit for a special purpose such as food storage, cooling for precision instrument, preservation of animals, plants, and a work of art. It could cause the damage of the items.	\bigcirc
Do not install nor use the system near equipments which generate electromagnetic wave or high harmonics: Equipments like invester equipment, private power generator, high-frequency medical equipment, or telecommunicati equipment might influence the air conditioner and cause amalfunction and breakdown. Or the air conditioner might influence medical equipments or telecommunication equipments, and obstruct their medical activity or cause jammin	$\square \bigcirc $
 Do not install the remote control at the direct sunlight. It could cause breakdown or deformation of the remote control. 	\bigcirc
Do not install the indoor unit at the place listed below. Places where flammable gas could leak. Places where cosmetics or special sprays a	
Places where carbon fiber, metal powder or any powder is floated Place where carbon fiber, metal powder or any powder is floated Place where the substances which affect the air conditioner are generated Such as suited pas, chirdle gas,	\sim
Do not install the indoor unit in the locations listed below (Be sure to install the indoor unit according to the installation manual for each model because each indoor unit has each limitation) Locations with any obstacks which can prevent init end and utel air of the unit Locations where vibration can be amplified due to insufficient strength of structure. Locations where infrared receiver is exposed to the direct sunlight or the strong light beam. (in case of the infrared specification unit) Locations where an equipment affected by high harmonics is placed. (TV set or radio receiver is placed within 5m) Locations where an equipment affected by high harmonics is placed. (TV set or radio receiver is placed within 5m) Locations where entime cannot run off sately.	\bigcirc
Do not put any valuables which will break down by getting wet under the air conditioner. Condensation could drop when the relative humidity is higher than 80% or drain pipe is dogged, and it damages user's belongings	\odot
Do not use the base frame for the outdoor unit which is corroded or damaged after a long period of us It could cause the unit falling down and injury.	
Pay attention not to damage the drain pan by weld sputter when brazing work is done near the uni If sputter entered into the unit during brazing work, it could cause damage (pinhole) of drain pan and leakage of wate To avoid damaging, keep the indoor unit packed or cover the indoor unit.	
Install the drain pipe to drain the water surely according to the installation manual. Improper connection of the drain pipe may cause dropping water into room and damaging user's belongings.	0
Do not share the drain pipe for indoor unit and GHP (Gas Heat Pump system) outdoor unit. Toxic exhaust gas would flow into room and it might cause serious damage (some poisoning or deficiency of oxygen) user's health and safety.	\odot
Be sure to perform air tightness test by pressurizing with nitrogen gas after completed refrigerant piping wou if the density of refrigerant exceeds the limit in the event of refrigerant leakage in the small room, lack of oxygen can occur, which can cause serious accidents.	
For drain pipe installation, be sure to make descending slope of greater than 1/100, not to make trap and not to make air-bleeding. Check if the drainage is correctly done during commissioning and ensure the space for inspection and maintenance.	
Ensure the insulation on the pipes for refrigeration circuit so as not to condense water. Incomplete insulation could cause condensation and it would wet ceiling, floor, and any other valuables.	0
More than a state of the s	
Pay extra attention, carrying the unit by hand. Carry the unit with 2 people if it is heavier than 20kg. Do not use the plastic straps but the grabbing place, moving the ut by hand. Use protective gloves in order to avoid injury by the aluminum fin.	iit D
Make sure to dispose of the packaging material. Leaving the materials may cause injury as metals like nail and woods are used in the package.	0
Do not operate the system without the air filter. It may cause the breakdown of the system due to clogging of the heat exchanger.	\bigcirc
Do not touch any button with wet hands. It could cause electric shock.	\bigcirc
Do not touch the refrigerant piping with bare hands when in operation. The pipe during operation would become very hot or cold according to the operating condition, and it could cause a burn or frostbi	$\overline{\bigcirc}$
Do not clean up the air conditioner with water.	$\overline{\mathbf{a}}$
It could cause electric shock. Do not turn off the power source immediately after stopping the operation. Be sure to wait for more than 5 minutes. Otherwise it could cause water leakage or breakdown.	$\overline{\Diamond}$
Do not control the operation with the circuit breaker. It could cause fire or water leakage. In addition, the fam may start operation unexpectedly and it may cause injury.	$\overline{\bigcirc}$

OThis model is middle static ducted type air conditioning unit. Therefore, do not use this model for direct blow type air conditioning unit.



2 Selection of installation location for the indoor unit

- Select the suitable areas to install the unit under approval of the user.
 Areas where the indoor unit can deliver hot and cold wind sufficiently. Suggest to the user to use a circulator if the ceiling height is over 3m to avoid warm air being accumulated on the ceiling.
 - Areas where there is enough space to install and service.
 - Areas where it can be drained properly. Areas where drain pipe descending slope can be taken.
 - Areas where there is no obstruction of airflow on both air return grille and air supply port.
 - Areas where fire alarm will not be accidentally activated by the air conditioner.
 - Areas where the supply air does not short-circuit.
 - · Areas where it is not influenced by draft air.
 - Areas not exposed to direct sunlight.
 - Areas where dew point is lower than around 28°C and relative humidity is lower than 80%.
 This indoor unit is tested under the condition of JIS (Japan Industrial Standard) high humidity condition and confirmed there is no problem. However, there is some risk of condensation drop if the air conditioner is operated under the severer condition than mentioned above. If there is a possibility to use it under such a condition, attach additional insulation of 10 to 20mm this densities and the severer will provide a condition at the densities are not severed.
 - 20mm thick for entire surface of indoor unit, refrigeration pipe and drain pipe.
 Areas where TV and radio stays away more than 1m. (It could cause jamming and noise.)
 Areas where any items which will be damaged by getting wet are not placed such as food,
 - table wares, server, or medical equipment under the unit. • Areas where there is no influence by the heat which cookware generates.
 - Areas where not exposed to oil mist, powder and/or steam directly such as above fryer.
 - Areas where lighting device such as fluorescent light or incandescent light doesn't affect the operation.

(A beam from lighting device sometimes affects the infrared receiver for the wireless remote control and the air conditioner might not work properly.)


② Check if the place where the air conditioner is installed can hold the weight of the unit. If it is not able to hold, reinforce the structure with boards and beams strong enough to hold it. If the strength is not enough, it could cause injury due to unit falling.

Space for installation and service

Make installation altitude over 2.5m.


(Indoor Unit)


Select either of two cases to keep space for installation and services.




③Preparation before installation


- If suspension bolt becomes longer, do reinforcement of earthquake resistant. OFor grid ceiling
 - When the suspension bolt length is over 500mm, or the gap between the ceiling and roof is over 700mm, apply earthquake resistant brace to the bolt.
- Oln case the unit is hanged directly from the slab and is installed on the ceiling plane which has enough strength.
- When suspension bolt length is over 1000mm, apply the earthquake resistant brace to the bolt. Prepare four (4) sets of suspension bolt, nut and spring washer (M10) on site.






(4)Installation of indoor unit








8 Wiring-out position and wiring connection

- Electrical installation work must be performed according to the installation manual by an electrical installation service provider qualified by a power provider of the country, and be executed according to the technical standards and other regulations applicable to electrical installation in the country. Be sure to use an exclusive circuit.
- Use specified cord, fasten the wiring to the terminal securely, and hold the cord securely in order not to apply unexpected stress on the terminal.
- Do not put both power source line and signal line on the same route. It may cause miscommunication and mafunction.
- For the details of electrical wiring work, see attached instruction manual for electrical wiring
- work.
- 1. Remove a lid of the control box (2 screws).
- 2. Hold each wiring inside the unit and fasten them to terminal block securely.
- 3. Fix the wiring with clamps.
- 4. Install the removed parts back to original place.



9 External static pressure setting

You can set External Static Pressure (E.S.P.) by either method of MANUAL SETTING or AUTO-MATIC SETTING by remote control.

Indoor unit will control fan-speed to keep rated air flow volume at each fan speed setting (Lo-Uhi)

1. MANUAL SETTING

You can set required E.S.P. by wired remote control that calculated with the set air flow rate and pressure loss of the duct connected.

Select No.1-10 (10Pa-100Pa) from following table according to calculation result.

Setting No.	1	2	3	4	5	6	7	8	9	10
External Static Pressure (Pa)	10	20	30	40	50	60	70	80	90	100
When you set No.11-19 by remote control, unit will control fan-speed with setting of										

No.10 Factory default is at No.5.

How to set E.S.P by wired remote control Push " " "marked button(E.S.P button).

Select indoor unit No. by using \$ button.

You can NOT set E.S.P. by wireless remote control.

③ Select setting No. by using ◆ button and set E.S.P. by button. See detailed procedure in technical manual.

-

E.S.P. button

2755

10 0

Notice You car

Caution Be sure to set E.S.P. according to actual duct connected. Wrong settings causes excessive air flow volume or water drop blown out.

2. AUTOMATIC SETTING

Indoor unit will recognize E.S.P. by itself automatically and select appropriate fan speed No.1-10.

How to start automatic setting

- 1, 2Same setting as MANUAL SETTING.
- 3 Select [AUT] by using \clubsuit button and press \bigodot button .
- 2 After setting E.S.P. at "AUT", operate unit in FAN mode with certain fan speed (Lo-Uhi).

9 External static pressure setting (continued)

Indoor unit fan will run automatically and recognize E.S.P. by itself. The operation for automatic E.S.P. recognition will last about 6 minutes, and it will be stopped after recognition is completed.

Caution

- Be sure to execute AUTOMATIC SETTING by remote control AFTER ducting work is completed.
 When duct specification is changed after AUTOMATIC SETTING, be sure to execute AUTOMATIC SETTING again after power resetting and turning on again.
- · Be sure to execute AUTOMATIC SETTING before trial cooling operation.
- (See ELECTRICAL WIRING WORK INSTRUCTION about trial cooling operation)
- Before AUTOMATIC SETTING, be sure to check that return air filter in duct is installed and damper is opened.
- Wrong procedure causes excessive air flow or water drop blown out.

Notice

- During operation for automatic recognition (the Auto Operation), fan rotates with certain speeds regardless of set fan speed by remote control.
- When duct is set with low static pressure (around 10-50Pa), even if indoor unit operate with higher air flow volume than rated one, but it is not abnormal.
- When you changed operation mode or stop operation with ON/OFF button during Auto Operation, the Auto operation will be canceled.
- \cdot In such case, be sure to execute AUTOMATIC SETTING again according to above procedure.

(1) Check list after installation

Check the following items after all installation work completed.


Check if	Expected trouble	Check
The indoor and outdoor units are fixed securely?	Falling, vibration, noise	
Inspection for leakage is done?	Insufficient capacity	
Insulation work is properly done?	Water leakage	
Water is drained properly?	Water leakage	
Supply voltage is same as mentioned in the model name plate?	PCB burnt out, not working at all	
No mis-wiring or mis-connection of piping?	PCB burnt out, not working at all	
Earth wiring is connected properly?	Electric shock	
Cable size comply with specified size?	PCB burnt out, not working at all	
Any obstacle blocks airflow on air inlet and outlet?	Insufficient capacity	
Is setting of E.S.P finished?	Excessive air flow, water drop blow out	

(b) Replacement procedure of the fan unit


Notes(1) The unit is a heavy item. It must be supported securely and handled with care not to drop when it is necessary to replace. (2) For the maintenance space, refer to page 90.

(i) Model FDUM71VF1

1) Remove the control box and the side panel, and remove the screws marked in the circles (2 places) in the figure.




2) Take out the fan unit in the arrow direction.




(ii) Model FDUM100VF1, 100VF2


 Remove the control box and the side panel, and remove the screws marked in the circles (2 places) from the unit located at the near side.




2) Take out the fan unit located at the near side in the arrow direction.



3) Remove the screws marked in the circles (2 places) from the fan unit located at the far side.



4) Take out the fan unit in the arrow direction.



PGA012D404

 \bigcirc

(5) Floor standing type (FDF)

This manual is for the installation of an indoor unit.

For electrical wiring work (Indoor), refer to page 112. For remote control installation, refer to page 116. For wireless kit installation, refer to page 150. For electrical wiring work (Outdoor) and refrigerant pipe work installation for outdoor unit, refer to Page 130.

SAFETY PRECAUTIONS

- Read the "SAFETY PRECAUTIONS" carefully first of all and then strictly follow it during the installation work in order to protect yourself.
- [<u>AWARNING</u>]: Wrong installation would cause serious consequences such as injuries or death. [<u>ACAUTION</u>]: Wrong installation might cause serious consequences depending on circumstances.
- Both mentions the important items to protect your health and safety so strictly follow them by any means.
- customers about "SAFETY PRECAUTIONS", correct operation method and maintenance method (air filter cleaning, operation method and temperature setting method) with user's manual of this unit. Ask your customers to keep this installation manual together with the user's manual. Also, ask them to hand over the user's manual to the new user when the owner is changed.


MARNING

Installation should be performed by the specialist. If you install the unit by yourself, it may lead to serious trouble such as water leakage, electric shock, fire, and injury due to overturn of the unit.	0
Install the system correctly according to these installation manuals.	0
Improper installation may cause explosion, injury, water leakage, electric shock, and fire.	•
Check the density refered by the foumula (accordance with IS05149).	0
If the density exceeds the limit density, please consult the dealer and installate the ventilation system.	•
Use the genuine accessories and the specified parts for installation.	0
If parts unspecified by our company are used it could cause water leakage, electric shock, fire, and injury due to overturn of the unit.	U
•Ventilate the working area well in case the refrigerant leaks during installation. If the refrigerant contacts the fire, toxic gas is produced.	0
Install the unit in a location that can hold heavy weight.	-
Improper installation may cause the unit to fall leading to accidents.	0
Install the unit properly in order to be able to withstand strong winds such as typhoons, and earthquakes.	
Improper installation may cause the unit to fall leading to accidents.	0
Do not mix air in to the cooling cycle on installation or removal of the air conditioner.	
If air is mixed in, the pressure in the cooling cycle will rise abnormally and may cause explosion and injuries.	$\overline{\mathcal{O}}$
Be sure to have the electrical wiring work done by qualified electrical installer, and use exclusive circuit. Power source with insufficient capacity and improper work can cause electric shock and fire.	0
Use specified wire for electrical wiring, fasten the wiring to the terminal securely, and hold the cable securely in order not to apply unexpected stress on the terminal.	0
Loose connections or hold could result in abnormal heat generation or fire.	-
• Arrange the electrical wires in the control box properly to prevent them from rising. Fit the lid of the services panel property. Improper fitting may cause abnormal heat and fire.	0
Check for refrigerant gas leakage after installation is completed.	0
If the refrigerant gas leaks into the house and comes in contact with a fan heater, a stove, or an oven, toxic gas is produced.	U
●Use the specified pipe, flare nut, and tools for R410A.	0
Using existing parts (R22) could cause the unit failure and serious accident due to explosion of the cooling cycle.	0
Tighten the flare nut according to the specified method by with torque wrench.	0
If the flare nut were tightened with excess torque, it could cause burst and refrigerant leakage after a long period.	0
• Do not put the drainage pipe directly into drainage channels where poisonous gases such as sulfide gas can	~
OCCUT. Poisonous spases will flow into the room through drainage pipe and seriously affect the user's health and safety. This can also cause the corrosion of the indoor unit and a resultant unit failure or refrigerant leak.	0
Connect the pipes for refrigeration circuit securely in installation work before compressor is operated.	_
If the compressor is operated when the service valve is open without connecting the pipe, it could cause explosion and injuries due to abnormal high pressure in the system.	0
Stop the compressor before removing the pipe after shutting the service valve on pump down work.	~
If the pipe is removed when the compressor is in operation with the service valve open, air would be mixed in the refrigeration circuit and it could cause explosion and injuries due to abnormal high pressure in the cooling cycle.	0
•Only use prescribed optional parts. The installation must be carried out by the qualified installer.	-
If you install the system by yourself, it can cause serious trouble such as water leaks, electric shocks, fire.	
Do not repair by yourself. And consult with the dealer about repair.	5
Improper repair may cause water leakage, electric shock or fire.	$\overline{\mathcal{O}}$
Consult the dealer or a specialist about removal of the air conditioner.	
Improper installation may cause water leakage, electric shock or fire.	
Turn off the power source during servicing or inspection work.	0
If the power is supplied during servicing or inspection work, it could cause electric shock and injury by the operating fan.	
ulletDo not run the unit when the panel or protection guard are taken off.	\sim
Touching the rotating equipment, hot surface, or high voltage section could cause an injury to be caught in the machine, to get burned, or electric shock.	\bigcirc
Shut off the power before electrical wirring work. It could cause electric shock, unit failure and improper running.	0

•	△ CAUTION	
	Perform earth wiring surely.	
	Do not connect the earth wiring to the gas pipe, water pipe, lightning rod and telephone earth wiring. Imperfect earth work (grounding) could cause an electric shock or fire if some trouble or earth leakage occurs.	Ð
•	Earth leakage breaker must be installed.	0
•	Unless the earth leakage circuit breaker is provided, if could cause a fire or electric shock. Use the circuit breaker of correct capacity. Circuit breaker should be the one that disconnect all	-
	poles under over current. Using the incorrect one could cause the system failure and fire.	O
(Do not use any materials other than a fuse of correct capacity where a fuse should be used.	$\overline{\bigcirc}$
	Connecting the circuit by wire or copper wire could cause unit failure and fire. Do not install the indoor unit near the location where there is possibility of flammable gas leakages.	$\underline{\bigcirc}$
_	If the gas leaks and gathers around the unit, it could cause fire.	\bigcirc
•	Do not install and use the unit where corrosive gas (such as sulfurous acid gas etc.) or flammable gas (such as thinner, petroleum etc.) may be generated or accumulated, or volatile flammable substances are handled	
_	It could cause the corrosion of heat exchanger, breakage of plastic parts etc. And inflammable gas could cause fire.	
•	Secure a space for installation, inspection and maintenance specified in the manual. Insufficient space can result in accident such as personal injury due to falling from the installation place.	0
C	Do not use the indoor unit at the place where water splashes such as laundry.	$\overline{\frown}$
•	Indoor unit is not waterproof. It could cause electric shock and fire. Do not use the indoor unit for a special purpose such as food storage, cooling for precision	\bigcirc
	instrument, preservation of animals, plants, and a work of art. It could cause the damage of the items.	\bigcirc
•	Do not install nor use the system near equipments which generate electromagnetic wave or high harmonics. Equipments like inverter equipment, private power generator, high-frequency medical equipment, or telecommunication equipment might influence the air conditioner and cause a malfunction and breakdown. Or the air conditioner might	\bigcirc
•	influence medical equipments or telecommunication equipments, and obstruct their medical activity or cause jamming. Do not install the remote control at the direct sunlight.	$\overline{\frown}$
_	It could cause breakdown or deformation of the remote control.	\heartsuit
C	Do not install the indoor unit at the place listed below. Places where fiammable gas could leak. Places where cosmetics or special sprays an	\sim
	Places where carbon fiber, metal powder or any powder is floated. Place where the substances which affect the air conditioner are generated Highly salted area such as beach.	\odot
	such as sulfide gas, chloride gas, acid, alkali or ammonic atmospheres. • Places exposed to oil mist or steam directly. • Places where the system is affected by	
	On vehicles and ships On vehicles and ships Smoke from a chimney. Places where machinery which generates high harmonics is used. Altitude over 1000m	
0	Do not install the indoor unit in the locations listed below (Be sure to install the indoor unit	
	according to the installation manual for each model because each indoor unit has each limitation) • Locations with any obstacles which can prevent inlet and outlet air of the unit	\sim
	 Locations where vibration can be amplified due to insufficient strength of structure. Locations where the infrared receiver is exposed to the direct sunlight or the strong light beam. (in case of the 	\bigcirc
	infrared specification unit)	
	Locations where an equipment affected by high harmonics is placed. (TV set or radio receiver is placed within 5m) Locations where drainage cannot run off safely.	
-	It can affect performance or function and etc Do not put any valuables which will break down by getting wet under the air conditioner.	
_	Condensation could drop when the relative humidity is higher than 80% or drain pipe is clogged, and it damages user's belongings.	
		$\underline{\bigcirc}$
0	Do not use the base frame for the outdoor unit which is corroded or damaged after a long period of use.	$\frac{\Diamond}{\Diamond}$
	Do not use the base frame for the outdoor unit which is corroded or damaged after a long period of use. It could cause the unit falling down and injury. Pay attention not to damage the drain pan by weld sputter when brazing work is done near the unit.	
	It could cause the unit falling down and injury.	$\frac{\otimes}{\otimes}$
	It could cause the unit falling down and injury. Pay attention not to damage the drain pan by weld sputter when brazing work is done near the unit. If sputter entered into the unit during brazing work, it could cause damage (pinhole) of drain pan and leakage of water. To avoid damaging, keep the indoor unit packed or cover the indoor unit. Install the drain pipe to drain the water surely according to the installation manual.	0
	It could cause the unit falling down and injury. Pay attention not to damage the drain pan by weld sputter when brazing work is done near the unit. If sputter entered into the unit during brazing work, it could cause damage (pinhole) of drain pan and leakage of water. To avoid damaging, keep the indoor unit packed or cover the indoor unit. Install the drain pipe to drain the water surely according to the installation manual. Improper connection of the drain pipe may cause dropping water into room and damaging user's belongings.	
	It could cause the unit falling down and injury. Pay attention not to damage the drain pan by weld sputter when brazing work is done near the unit. If sputter entered into the unit during brazing work, it could cause damage (pinhole) of drain pan and leakage of water. To avoid damaging, keep the indoor unit packed or cover the indoor unit. Install the drain pipe to drain the water surely according to the installation manual. Improper connection of the drain pipe may cause dropping water into room and damaging user's belongings. Do not share the drain pipe for indoor unit and GHP (Gas Heat Pump system) outdoor unit. Toxic exhaust gas would flow into room and it might cause serious damage (some poisning or deficiency of oxygen) to	
	It could cause the unit falling down and injury. Pay attention not to damage the drain pan by weld sputter when brazing work is done near the unit. If sputter entered into the unit during brazing work, it could cause damage (pinhole) of drain pan and leakage of water. To avoid damaging, keep the indoor unit packed or cover the indoor unit. Install the drain pipe to drain the water surely according to the installation manual. Improper connection of the drain pipe may cause dropping water into room and damaging user's belongings. Do not share the drain pipe for indoor unit and GHP (Gas Heat Pump system) outdoor unit. Trok exhauts gas would flow into room and it might cause serious damage (some poisoning or deficiency of oxygen) to user's health and safely.	
	It could cause the unit falling down and injury. Pay attention not to damage the drain pan by weld sputter when brazing work is done near the unit. If sputter entered into the unit during brazing work, it could cause damage (pinhole) of drain pan and leakage of water. To avoid damaging, keep the indoor unit packed or cover the indoor unit. Install the drain pipe to drain the water surely according to the installation manual. Improper connection of the drain pipe may cause dropping water into room and damaging user's belongings. Do not share the drain pipe for indoor unit and GHP (Gas Heat Pump system) outdoor unit. Toxic exhaust gas would flow into room and it might cause serious damage (some poisoning or deficiency of oxygen) to user's health and safety. B es ure to perform air tightness test by pressurizing with nitrogen gas after completed refrigerant piping work. If the density of refrigerant exceeds the limit in the event of refrigerant leakage in the small room, lack of oxygen can	
	It could cause the unit falling down and injury. Pay attention not to damage the drain pan by weld sputter when brazing work is done near the unit. If sputter entered into the unit during brazing work, it could cause damage (pinhole) of drain pan and leakage of water. To avoid damaging, keep the indoor unit packed or cover the indoor unit. Install the drain pipe to drain the water surely according to the installation manual. Improper connection of the drain pipe may cause dropping water into room and damaging user's belongings. Do not share the drain pipe for indoor unit and GHP (Gas Heat Pump system) outdoor unit. Toxic exhaust gas would flow inter room and it might cause serious damage (some poisoning or deficiency of oxygen) to user's health and safety. Be sure to perform air tightness test by pressurizing with nitrogen gas after completed refrigerant piping work occur, which can cause serious accidents.	
	It could cause the unit falling down and injury. Pay attention not to damage the drain pan by weld sputter when brazing work is done near the unit. It sputter entered into the unit during brazing work, it could cause damage (pinhole) of drain pan and leakage of water. To avoid damaging, keep the indoor unit packed or cover the indoor unit. Install the drain pipe to drain the water surely according to the installation manual. Improper connection of the drain pipe may cause dropping water into room and damaging user's belongings. D on ot share the drain pipe for indoor unit and GHP (Gas Heat Pump system) outdoor unit. Toxic exhaust gas would fow into room and it might cause serious damage (some poisoning or deficiency of oxygen) to user's health and safety. Be sure to perform air tightness test by pressurizing with nitrogen gas after completed refrigerant piping work if the density of refrigerant exceeds the limit in the event of refrigerant leakage in the small room, lack of oxygen can occur, which can cause serious accidents. For drain pipe installation, be sure to make descending slope of greater than 1/100, not to make traps, and not to make air-bleeding.	
	It could cause the unit falling down and injury. Pay attention not to damage the drain pan by weld sputter when brazing work is done near the unit. If sputter entered into the unit during brazing work, it could cause damage (pinhole) of drain pan and leakage of water. To avoid damaging, keep the indoor unit packed or cover the indoor unit brazing work is done near the unit. Install the drain pipe to drain the water surely according to the installation manual. Improper connection of the drain pipe may cause dropping water into room and damaging user's belongings. Do not share the drain pipe for indoor unit and GHP (Gas Heat Pump system) outdoor unit. Toxic exhaust gas would flow into room and it might cause serious damage (some poisoning or deficiency of oxygen) to user's health and safety. Be sure to perform air tightness test by pressurizing with nitrogen gas after completed refrigerant piping work. If the density of refrigerant exceeds the limit in the event of refrigerant leakage in the small room, lack of oxygen can occur, which can cause serious accidents. For drain pipe installation, be sure to make descending slope of greater than 1/100, not to make traps, and not to make air-bleeding. Check if the drainage is correctly done during commissioning and ensure the space for inspection and maintenance.	
	It could cause the unit falling down and injury. Pay attention not to damage the drain pan by weld sputter when brazing work is done near the unit. If sputter entered into the unit during brazing work, it could cause damage (pinhole) of drain pan and leakage of water. To avoid damaging, keep the indoor unit packed or cover the indoor unit. Install the drain pipe to drain the water surely according to the installation manual. Improper connection of the drain pipe may cause dropping water into room and damaging user's belongings. Do not share the drain pipe in indoor unit and GHP (Gas Heat Purp system) outdoor unit. Toxic exhauts gave would flow into room and it might cause serious damage (some poisoning or deficiency of oxygen) to user's health and safely. Be sure to perform air tightness test by pressurizing with nitrogen gas after completed refrigerant piping work. If the drain pipe installation, be sure to make descending slope of greater than 1/100, not to make traps, and not to make air-bleeding. Check if the draina pie sorretty done during commissioning and ensure the space for inspection and maintenance. Ensure the insulation on the pipes for refirgerant incruit's os as not to condense water. Incomplete insulation could cause condensation and it would wet ceiling, floor, and any other valuables.	
	It could cause the unit falling down and injury. Pay attention not to damage the drain pan by weld sputter when brazing work is done near the unit. It sputter entered into the unit during brazing work, it could cause damage (pinhole) of drain pan and leakage of water. To avoid damaging, keep the indoor unit packed or cover the indoor unit. Install the drain pipe to drain the water surely according to the installation manual. Improper connection of the drain pipe may cause dropping water into room and damaging user's belongings. D on ot share the drain pipe for indoor unit and GHP (Gas Heat Pump system) outdoor unit. Toxic exhaust gas would flow into room and inglet cause serious damage (some poisoning or deficiency of oxygen) to user's health and safety. Be sure to perform air tightness test by pressurizing with nitrogen gas after completed refrigerant piping work if the density of crificerant exceeds the limit in the event of refrigerant leakage in the small room, lack of oxygen can occur, which can cause serious accidents. For drain pipe installation, be sure to make descending slope of greater than 1/100, not to make traps, and not to make air-bleeding. Check if the drainage is correctly done during commissioning and ensure the space for inspection and maintenance. Ensure the insulation on the pipes for refrigeration circuit so as not to condense water. Incomplete insulation could cause condensation and it would wet ceiling, floor, and any other valuables. D o not install the outdoor unit where is likely to be a nest for inspection and aminemals.	
	It could cause the unit falling down and injury. Pay attention not to damage the drain pan by weld sputter when brazing work is done near the unit. If sputter entered into the unit during brazing work, it could cause damage (pinhole) of drain pan and leakage of water. To avoid damaging, keep the indoor unit packed or cover the indoor unit. Install the drain pipe to drain the water surely according to the installation manual. Improper connection of the drain pipe may cause dropping water into room and damaging user's belongings. Do not share the drain pipe in indoor unit and GHP (Gas Heat Purp system) outdoor unit. Toxic exhauts gave would flow into room and it might cause serious damage (some poisoning or deficiency of oxygen) to user's health and safely. Be sure to perform air tightness test by pressurizing with nitrogen gas after completed refrigerant piping work. If the drain pipe installation, be sure to make descending slope of greater than 1/100, not to make traps, and not to make air-bleeding. Check if the draina pie sorrefly done during commissioning and ensure the space for inspection and maintenance. Ensure the insulation on the pipes for refirgerant incruit's os as not to condense water. Incomplete insulation could cause condensation and it would wet ceiling, floor, and any other valuables.	
	It could cause the unit falling down and injury. Pay attention not to damage the drain pan by weld sputter when brazing work is done near the unit. If sputter entered into the unit during brazing work, it could cause damage (pinhole) of drain pan and leakage of water. To avoid damaging, keep the indoor unit packed or cover the indoor unit. Install the drain pipe to drain the water surely according to the installation manual. Improper connection of the drain pipe may cause dropping water into room and damaging user's belongings. Do not share the drain pipe for indoor unit and GHP (Gas Heat Pump system) outdoor unit. Toxic exhauts gav would flow into room and it might cause serious damage (some poisoning or deficiency of oxygen) to user's health and safety. Be sure to perform air tightness test by pressurizing with nitrogen gas after completed refrigerant piping work. If the drains pipe installation, be sure to make descending slope of greater than 1/100, not to make traps, and not to make air-bleeding. Check if the drainage is correctly done during commissioning and ensure the space for inspection and maintenance. Denort install the outdoor unit where is likely to be a nest for inspection and maintenance. Do not install the outdoor unit where is likely to be a nest for inspection and maintenance. Do not install the outdoor unit where is likely to be a nest for inspect and small animals. Insects and small animals could come into the electronic components and cause breakdown and fire. Instruct the user to keep the survinging sedan. Pay extra attention, carrying the unit by hand.	
	It could cause the unit falling down and injury. Pay attention not to damage the drain pan by weld sputter when brazing work is done near the unit. If sputter entered into the unit during brazing work, it could cause damage (pinhole) of drain pan and leakage of water. To avoid damaging, keep the indoor unit acked or cover the indoor unit. Install the drain pipe to drain the water surely according to the installation manual. Improper connection of the drain pipe may cause dropping water into room and damaging user's belongings. Do not share the drain pipe for indoor unit and GHP (Gas Heat Pump system) outdoor unit. Toxic exhaust gas would flow into room and it might cause serious damage (some poisoning or deficiency of oxygen) to user's health and safety. Be sure to perform air tightness test by pressurizing with nitrogen gas after completed refrigerant piping work if the density or freigneant exceeds the limit in the event of refrigerant leakage in the small room, lack of oxygen cau occur, which can cause serious accidents. For drain pipe installation, be sure to make descending slope of greater than 1/100, not to make traps, and not to make air-bleeding. Check if the draing or condension and it would wet ceiling, floor, and any other valuables. Do not install the outdoor unit where is likely to be a nest for inspection and maintenance. Ensure the instulation could cause condensation and it would wet ceiling. Toor, and any other valuables. Do not install the outdoor unit where is likely to be a nest for insects and small animals. Inserts and small animals could come into the electronic components and cause breakdown and fire. Instruct the user to keep the surroundings dean. Pay extra attention, carrying the unit by hand. Carry the unit with 2 people if it is heavier than 20, Do not use the plastic straps but the grabbing place, moving the unit by hand. Use protective glowes in order to avoid nigury by the aluminum fin.	
	It could cause the unit falling down and injury. Pay attention not to damage the drain pan by weld sputter when brazing work is done near the unit. If sputter entered into the unit during brazing work, it could cause damage (pinhole) of drain pan and leakage of water. To avoid damaging, keep the indoor unit active or cover the indoor unit. Install the drain pipe to drain the water surely according to the installation manual. Improper connection of the drain pipe may cause dropping water into room and damaging user's belongings. Do not share the drain pipe for indoor unit and GHP (Gas Heat Pump system) outdoor unit. Toxic exhauts gas would flow into room and it might cause serious damage (some poisoning or deficiency of oxygen) to user's health and safely. Be sure to perform air tightness test by pressurizing with nitrogen gas after completed refrigerant piping work If the density of refrigerant exceeds the limit in the event of refrigerant leakage in the small room, lack of oxygen cau occu, which can cause serious accidents. For drain pipe installation, be sure to make descending slope of greater than 1/100, not to make traps, and not to make air-bleeding. Check if the drainage is correctly done during commissioning and ensure the space for inspection and maintenance. Ensure the insulation on the pipes for refrigeration circuit so as not to condense water. Incomplete insulation could cause condensation and it would wet celling, floor, and any other valuables. Do not install the outdoor unit where is likely to be a nest for inspect and small animals. Irsexts and small animals could come into the electronic components and cause breakdown and fire. Instruct the user to keep the surroundings clean. Pay actra attention, carrying the unit by hand. Carry the unit with 2 people if it is heavier than 20kg.Do not use the plastic straps but the grabbing place, moving the unit by hand. Use proteive glones in order to avoid injury by the aluminum fin. Make sure to dispose of the packaging material.	
	It could cause the unit falling down and injury. Pay attention not to damage the drain pan by weld sputter when brazing work is done near the unit. If sputter entered into the unit during brazing work, it could cause damage (pinhole) of drain pan and leakage of water. To avoid damaging, keep the indoor unit acked or cover the indoor unit. Install the drain pipe to drain the water surely according to the installation manual. Improper connection of the drain pipe may cause dropping water into room and damaging user's belongings. Do not share the drain pipe for indoor unit and GHP (Gas Heat Pump system) outdoor unit. Toxic exhaust gas would flow into room and it might cause serious damage (some poisoning or deficiency of oxygen) to user's health and safety. Be sure to perform air tightness test by pressurizing with nitrogen gas after completed refrigerant piping work if the density or freigneant exceeds the limit in the event of refrigerant leakage in the small room, lack of oxygen cau occur, which can cause serious accidents. For drain pipe installation, be sure to make descending slope of greater than 1/100, not to make traps, and not to make air-bleeding. Check if the draing or condension and it would wet ceiling, floor, and any other valuables. Do not install the outdoor unit where is likely to be a nest for inspection and maintenance. Ensure the instulation could cause condensation and it would wet ceiling. Toor, and any other valuables. Do not install the outdoor unit where is likely to be a nest for insects and small animals. Inserts and small animals could come into the electronic components and cause breakdown and fire. Instruct the user to keep the surroundings dean. Pay extra attention, carrying the unit by hand. Carry the unit with 2 people if it is heavier than 20, Do not use the plastic straps but the grabbing place, moving the unit by hand. Use protective glowes in order to avoid nigury by the aluminum fin.	
	It could cause the unit falling down and injury. Pay attention not to damage the drain pan by weld sputter when brazing work is done near the unit. It sputter entered into the unit during brazing work, it could cause damage (pinhole) of drain pan and leakage of water. To avoid damaging, keep the indoor unit packed or cover the indoor unit. Install the drain pipe to drain the water surely according to the installation manual. Improper connection of the drain pipe may cause dropping water into room and damaging user's belongings. D on ot share the drain pipe for indoor unit and GHP (Gas Heat Pump system) outdoor unit. Toxic exhaust gas would flow into room and it might cause serious damage (some poisoning or deficiency of oxygen) to user's health and safely. Be sure to perform air tightness test by pressurizing with nitrogen gas after completed retrigerant piping work if the density of refrigerant exceeds the limit in the event of refrigerant leakage in the small room, lack of oxygen can occur, which can cause serious accidents. For drain pipe installation, be sure to make descending slope of greater than 1/100, not to make traps, and not to make air-bleeding. Check if the drainage is correctly done during commissioning and ensure the space for inspection and maintenance. Ensure the insulation on the pipes for refrigeration circuit so as not to condense water. Incomplet insulation could cause condenston and it would wet ceiling, floor, and any other valuables. Do not install the outdoor unit where is likely to be a nest for insects and small animals. Insects and small animals could come into the electronic components and cause breakdown and fire. Instruct the user to keep the surroundings clean. Pay cart a attention, carrying the unit by hand. Carry the unit with 2 people if it is heavier than 20kg. Do not use the plastic straps but the grabbing place, moving the unit by hand. Leaving the materials may cause injury as metals like mail and woods are used in the package. Do not operate the system without the air fi	
	It could cause the unit falling down and injury. Pay attention not to damage the drain pan by weld sputter when brazing work is done near the unit. If sputter entered into the unit during brazing work, it could cause damage (pinhole) of drain pan and leakage of water. To avoid damaging, keep the indoor unit packed or cover the indoor unit. Install the drain pipe to drain the water surely according to the installation manual. Improper connection of the drain pipe may cause dropping water into room and damaging user's belongings. Do not share the drain pipe for indoor unit and GHP (Gas Heat Pump system) outdoor unit. Toxic exhaust gas would flow intoir room and it might cause serious damage (some poisoning or deficiency of oxygen) to user's health and safety. Be sure to perform air tightness test by pressurizing with nitrogen gas after completed refrigerant piping work If the density of refrigerant exceeds the limit in the event of refrigerant leakage in the small room, lack of oxygen can occur, which can cause serious accidents. For drain pipe installation, be sure to make descending slope of greater than 1/100, not to make traps, and not to make air-bleeding. Check if the draina pipe so condensation and it would wet ceiling, floor, and any other valuables. Do not install the outdoor unit where is likely to be a nest for insects and small animals. Insects and small animals could ocue into the electronic components and cause breakdown and fire. Instruct the user to keep the surroundings clean. Pay extra attention, cause in the value than and to would ser used in the grabbing place, moving the unit by hand. Use proteive gloves in order to avoid jioury by the aluminum fin. Make sure to dispose of the packaging material. Leaving the matakais miny cause fingury as metals like nail and woods are used in the package. Do not neek the system without the air filter. It may cause the breakdown of the system due to clogging of the heat exchanger.	
	It could cause the unit falling down and injury. Pay attention not to damage the drain pan by weld sputter when brazing work is done near the unit. If sputter entered into the unit during brazing work, it could cause damage (pinhole) of drain pan and leakage of water. To avoid damaging, keep the indoor unit packed or cover the indoor unit. Install the drain pipe to drain the water surely according to the installation manual. Improper connection of the drain pipe may cause dropping water into room and damaging user's belongings. D on otshare the drain pipe for indoor unit and GHP (Gas Heat Pump system) outdoor unit. Toxic exhauts gave would flow into room and it might cause serious damage (some poisoning or deficiency of oxygen) to user's health and safety. Be sure to perform air tightness test by pressurizing with nitrogen gas after completed refrigerant piping work. If the drains pipe isot accelents. For drain pipe installation, be sure to make descending slope of greater than 1/100, not to make traps, and not to make air-bleeding. Check if the drainage is correctly done during commissioning and ensure the space for inspection and maintenance. Ensure the insulation on the pipes for refrigeration circuit so as not to condense water. Incomplete insulation on the pipes for refrigeration circuit so as not to condense water. Incomplete insulation on the pipes for refrigeration circuit so as not to condense water. Incomplete insulation could cause condensation and it would wet ceiling, floor, and any other valuables. D Do not install the outdoor unit where is likely to be a nest for insects and small animals could come into the electronic components and cause breakdown and fire. Instruct the user to keep the surroundings dean. A Pay extra attention, carrying the unit by hand. Carry the unit with 2 people if it is heavier than 20kg. Do not use the plastic straps but the grabbing place, moving the unit by hand. Use protective glowes in order to avoid inyruy bite aluminum fin. Make sure to dispose of the packaging mate	
	It could cause the unit falling down and injury. Pay attention not to damage the drain pan by weld sputter when brazing work is done near the unit. If sputter entered into the unit during brazing work, it could cause damage (pinhole) of drain pan and leakage of water. To avoid damaging, keep the indoor unit packed or cover the indoor unit. Install the drain pipe to drain the water surely according to the installation manual. Improper connection of the drain pipe may cause dropping water into room and damaging user's belongings. D on otshare the drain pipe for indoor unit and GHP (Gas Heat Pump system) outdoor unit. Toxic exhauts gave would flow into room and it might cause serious damage (some poisoning or deficiency of oxygen) to user's health and safety. Be sure to perform air tightness test by pressurizing with nitrogen gas after completed refrigerant piping work If the density of refrigerant exceeds the limit in the event of refrigerant leakage in the small room, lack of oxygen cau occur, which can cause serious accidents. For drain pipe installation, be sure to make descending slope of greater than 1/100, not to make traps, and not to make air-bleeding. Check if the drainage is correctly done during commissioning and ensure the space for inspection and maintenance. Ensure the insulation on the pipes for refrigeration circuit so as not to condense water. Incomplete insulation on the pipes for refrigeration circuit so as not to condense water. Incomplete insulation on the pipes for refrigeration circuit so as not to condense water. Incomplete insulation caud cause condensation and it would wet ceiling, floor, and any other valuables. D Do not install the outdoor unit where is likely to be a nest for insects and small animals. Insects and small animals could come into the electronic components and cause breakdown and fire. Instruct the user to keep the surroundings dean. A Pay extra attention, carrying the unit by hand. Carry the unit with 2 people if it is heavier than 2000, Do not use the plastic straps but	
	It could cause the unit falling down and injury. Pay attention not to damage the drain pan by weld sputter when brazing work is done near the unit. If sputter entered into the unit during brazing work, it could cause damage (pinhole) of drain pan and leakage of water. To avoid damaging, keep the indoor unit packed or cover the indoor unit. Install the drain pipe to drain the water surely according to the installation manual. Improper connection of the drain pipe may cause dropping water into room and damaging user's belongings. D on otshare the drain pipe for indoor unit and GHP (Gas Heat Pump system) outdoor unit. Toxic exhauts gave would flow into room and it might cause serious damage (some poisoning or deficiency of oxygen) to user's health and safety. Be sure to perform air tightness test by pressurizing with nitrogen gas after completed refrigerant piping work. If the drains pipe isotallation, be sure to make descending slope of greater than 1/100, not to make traps, and not to make air-bleeding. Check if the drainage is correctly done during commissioning and ensure the space for inspection and maintenance. Denot install the outdoor unit where is likely to be a nest for inspects and small animals. Insects and small animals could cause condensation and it would wet ceiling, floor, and any other valuables. Do not install the outdoor unit where is likely to be a nest for inspects and small animals. Insects and small animals could come into the electonic components and cause breakdown and fire. Instruct the user to keep the survindings dean. App extra attention, carrying the unit by hand. Carry the unit with 2 people if it is heavier than 20kg. Do not use the plastic straps but the grabbing place, moving the unit by hand. Cary the unit with 2 people if it is heavier than 20kg. Do not use the plastic straps but the grabbing place, moving the unit by hand. Cary the unit with 2 people if it is heavier than 20kg. Do not use the plastic straps but the grabbing place, moving the unit by hand. Cary the unit with 2	
	It could cause the unit falling down and injury. Pay attention not to damage the drain pan by weld sputter when brazing work is done near the unit. If sputter entered into the unit during brazing work, it could cause damage (pinhole) of drain pan and leakage of water. To avoid damaging, keep the indoor unit packed or cover the indoor unit. Install the drain pipe to drain the water surely according to the installation manual. Improper connection of the drain pipe may cause dropping water into room and damaging user's belongings. Do not share the drain pipe for indoor unit and GHP (Gas Heat Pump system) outdoor unit. Toxic exhauts gave would flow into room and it might cause serious damage (some poisoning or deficiency of oxygen) to user's health and safety. Be sure to perform air tightness test by pressurizing with nitrogen gas after completed refrigerant piping work. If the deniang pie is tallation, be sure to make descending slope of greater than 1/100, not to make traps, and not to make air-bleeding. Check if the deniang is is correctly done during commissioning and ensure the space for inspection and maintenance. Ensure the insulation on the pipes for refrigeration circuit so as not to condense water. Incomplete insulation could cause condensation and it would wet celling, floor, and any other valuables. D on ot install the outdoor unit where is likely to be a nest for insects and small animals. Insects and small animals could come into the electonic components and cause breakdown and fire. Instruct the user to keep the surrounding clean. Pay extra attention, carrying the unit by hand. Carry the unit with 2 people if it is heavier than 20kg. Do not use the plastic straps but the grabbing place, moving the unit by hand. Use protective gloves in order to avoid injury by the aluminum fin. Make sure to dispose of the packaging material. Leaving the materials may cause injury as metals like nail and woods are used in the package. D on ot ouch any button with wet hands. It could cause electric shock. D on otouch t	
	It could cause the unit falling down and injury. Pay attention not to damage the drain pan by weld sputter when brazing work is done near the unit. If sputter entered into the unit during brazing work, it could cause damage (pinhole) of drain pan and leakage of water. To avoid damaging, keep the indoor unit packed or cover the indoor unit. Install the drain pipe to drain the water surely according to the installation manual. Improper connection of the drain pipe may cause dropping water into room and damaging user's belongings. Do not share the drain pipe for indoor unit and GHP (Gas Heat Pump system) outdoor unit. Toxic exhaust gas would flow intoir room and it might cause serious damage (some poisoning or deficiency of oxygen) to user's health and safety. Be sure to perform air tightness test by pressurizing with nitrogen gas after completed refrigerant piping work If the density of refrigerant exceeds the limit in the event of refrigerant leakage in the small room, lack of oxygen can occur, which can cause serious accidents. For drain pipe installation, be sure to make descending slope of greater than 1/100, not to make traps, and not to make air-bleeding. Check if the draina pipe so condensation and it would wet ceiling, floor, and any other valuables. Do not install the outdoor unit where is likely to be a nest for insects and small animals. Insects and small animals could doom into the electronic components and cause breakdown and fire. Instruct the user to keep the surroundings clean. Pay extra attention, carrying the unit by hand. Carry the unit with 2 popie if it is heavier than 20kg. Do not use the plastic straps but the grabbing place, moving the unit by hand. Use protective gloves in order to avoid jingiry by the alaunitum fin. Make sure to dispose of the packaging material. Leaving the materials may cause injury as metals like nail and woods are used in the package. Do not touch any button with wet hands. It could cause electric shock. Do not touch the refrigerant piping with bare hands when in ope	

• Do not control the operation with the circuit breaker.

It could cause fire or water leakage. In addition, the fan may start operation unexpectedly and it may cause injury.



(4)Refrigerant piping

Caution


- •Use the new refrigerant pipe.
- When re-using the existing pipe system for R22 or R407C, pay attention to the following items.
- Change the flare nuts with the attached ones (JIS category 2), and reprocess the flare parts.
- Do not use thin-walled pipes.
- •Use phosphorus deoxidized copper alloy seamless pipe (C1220T specified in JIS H3300) for refrigeration pipe installation.
- In addition, make sure there is no damage both inside and outside of the pipe, and no harmful substances such as sulfur, oxide, dust or a contaminant stuck on the pipes.
- Do not use any refrigerant other than R410A. Using other refrigerant except R410A (R22 etc.) may degrade inside refrigeration oil. And if air getting into refrigerant circuit, it may cause anomaously high pres and may result in burst, etc.
- Store the copper pipes indoors and seal the both end of them until they are brazed in order to avoid any dust, dirt or water getting into pipe. Otherwise it will cause degradation of refrigeration oil and compressor breakdown, etc.
- Use special tools for R410A refrigerant.

Work procedure

- 1. Remove the flare nuts and flare caps from the pipes of the indoor unit.
 - Make sure to loosen the flare nut by holding the flared male fitting with a spanner and giving torque to the nut with another spanner in order to avoid unexpected stress to the copper pipe, and then remove them.
 - (Gas may come out a little at this time, but it is no anomaly.)
 - Pay attention that the flare nut may pop out.
 - (Because it is sometimes pressurized in the indoor unit)
- Make a flare on liquid pipe and gas pipe, and connect the refrigrant pipes to the indoor unit.

%Bend the pipe with as big radius as possible and do not bend the pipe repeatedly. In addition, do not twist and crush the pipes.


- ※Do a flare connection as follows:
- Make sure to loosen the flare nut by holding the flared male fitting with a spanner and giving torque to the nut with another spanner in order to avoid unexpected stress to the copper pipe, and then remove them.
- When fastening the flare nut, align the refrigeration pipe with the center of flare nut, screw the nut for 3-4 times by hand and then tighten it with a spanner within the specified torque mentioned in the table below.
- Make sure to hold the flared male fitting on the indoor unit side with another spanner when tightening the nut in order to avoid unexpected stress on the copper pipe.
- Cover the flare connection part of the indoor unit with attached insulation material after a gas leakage inspection, and tighten both ends with attached straps.
 - Make sure to insulate both gas pipes and liquid pipes completely.
 % Incomplete insulation may cause dew condensation and dew dropping.
- 4. Refrigerant is pre-charged in the outdoor unit.
 - As for the additional refrigerant charge for the indoor unit and piping, refer to the installation manual attached to the outdoor unit.



Pipe diameter	Tightening torque N·m
φ 6.35	14 to 18
φ 9.52	34 to 42
φ 12.7	49 to 61
φ 15.88	68 to 82
φ 19.05	100 to 120


(4) Refrigerant piping (Continued)


Pipe and wire extracting position




ATTENTION:


• Do not cut off the flange at the hole on the base plate for the downward extraction.











(6) Wall mounted type (SRK)

RKW012A411

 \bigcirc

• This installation manual illustrates the method of installing an indoor unit For electrical wiring work, please see instructions set out on the

hackside

· For outdoor unit installation and refrigerant piping, please refer to page 130.

- Read the "SAFETY PRECAUTIONS" carefully first of all and strictly follow it during the installation work in order to protect yourself. The precautionary items mentioned below are distinguished into two levels.
- AWARNING and ACAUTION.

0

66

- WARNING : Wrong installation would cause serious consequences such
- as injuries or death. CAUTION : Wrong installation might cause serious consequences
- depending on circumstances.
- Both mentions the important items to protect your health and safety so strictly follow them by any means.

· Be sure to confirm no anomaly on the equipment by commissioning after completed installation and explain the operating methods as well as the maintenance methods of this equipment to the user according to the owner's manual.

· A wired remote control unit is supplied separately as an optional part. . When install the unit, be sure to check whether the selection of installation place, power supply specifications, usage limitation (piping length, height differences between indoor and outdoor units, power supply voltage and etc.) and installation spaces.

SAFETY PRECAUTIONS

- any user can read at any time. Moreover if necessary, ask to hand them to a new user.
 - using suitable protective clothing, groves, etc., and then perform the installation works.
- · Please pay attention not to fall down the tools, etc. when installing the unit at the high position.



room and damaging personal property. **∧** WARNING Be sure to install the drainage pipe with descending slope of 1/100 or more, and not to make traps and air-bleedings. · Installation must be carried out by the qualified installer. • Tighten the flare nut by torque wrench with specified method. Check if the drainage runs off securely during commissioning and ensure If you install the system by yourself, it may cause serious trouble such as If the flare nut were tightened with excess torque, this may cause burst and the space for inspection and maintenance. water leaks, electric shocks, fire and personal injury, as a result of a system refrigerant leakage after a long period. Secure a space for installation, inspection and maintenance malfunction. Do not carry out the installation and maintenance work except • The electrical installation must be carried out by the qualified specified in the manual the by qualified installer electrician in accordance with "the norm for electrical work" and Insufficient space can result in accident such as personal injury due to Install the system in full accordance with the installation manual. "national wiring regulation", and the system must be connected to Incorrect installation may cause bursts, personal injury, water leaks, electric the dedicated circuit Do not install the unit in the locations listed below. Locations where carbon fiber, metal powder or any powder is floating. shocks and fire Power supply with insufficient capacity and incorrect function done by Be sure to use only for household and residence. improper work can cause electric shocks and fire. . Locations where any substances that can affect the unit such as sulphide gas, chloride gas, acid and alkaline can occur. If this appliance is installed in inferior environment such as machine shop · Be sure to shut off the power before starting electrical work. Vehicles and ships. Failure to shut off the power can cause electric shocks, unit failure or · Locations where cosmetic or special sprays are often used. Use the original accessories and the specified components for incorrect function of equipment. . Locations with direct exposure of oil mist and steam such as kitchen and Be sure to use the cables conformed to safety standard and cable ampacity for power distribution work machine plant. · Locations where any machines which generate high frequency harmonics Unconformable cables can cause electric leak, anomalous heat production are used. or fire This appliance must be connected to main power supply by means · Locations with salty atmospheres such as coastlines Locations with heavy snow (If installed, be sure to provide base flame and of a circuit breaker or switch (fuse 20A) with a contact separation of snow hood mentioned in the manual). at least 3mm Locations where the unit is exposed to chimney smoke . When plugging this appliance, a plug conforming to the norm Locations at high altitude (more than 1000m high) IFC60884-1 must be used · Locations with ammonic atmospheres. · Use the prescribed cables for electrical connection, tighten the Locations where heat radiation from other heat source can affect the unit. cables securely in terminal block and relieve the cables correctly to Locations without good air circulation. prevent overloading the terminal blocks. Locations with any obstacles which can prevent inlet and outlet air of the unit. referred by the formula (accordance with ISO5149). Loose connections or cable mountings can cause anomalous heat Locations where short circuit of air can occur (in case of multiple units production or fire. Arrange the wiring in the control box so that it cannot be pushed up installation). Locations where strong air blows against the air outlet of outdoor unit. further into the box. Install the service panel correctly. can cause serious accident . Locations where something located above the unit could fall. Incorrect installation may result in overheating and fire It can cause remarkable decrease in performance, corrosion and damage · Be sure to switch off the power supply in the event of installation, of components, malfunction and fire If refrigerant leaks into the room and comes into contact with an oven or inspection or servicing. Do not install the indoor unit in the locations listed below (Be sure If the power supply is not shut off, there is a risk of electric shocks, unit to install the indoor unit according to the installation manual for failure or personal injury due to the unexpected start of fan. each model because each indoor unit has each limitation). · Be sure to wear protective goggles and gloves while at work. Locations with any obstacles which can prevent inlet and outlet air of the · Earth leakage breaker must be installed. unit. If the earth leakage breaker is not installed, it can cause electric shocks. . Locations where vibration can be amplified due to insufficient strength of On not put the drainage pipe directly into drainage channels where • Do not processing, splice the power cord, or share a socket with structure. other power plugs. Locations where the infrared receiver is exposed to the direct sunlight or This may cause fire or electric shock due to defecting contact, defecting the strong light beam (in case of the infrared specification unit). . Locations where an equipment affected by high harmonics is placed (TV insulation and over-current etc. Do not bundling, winding or processing for the power cord. Or, do set or radio receiver is placed within 1m) not deforming the power plug due to tread it. Locations where drainage cannot run off safely.

- Keep the installation manual together with owner's manual at a place where · For installing qualified personnel, take precautions in respect to themselves by
- . If unusual noise can be heard during operation, consult the dealer
- . The meanings of "Marks" used here are shown as follows:



· For installation work, be careful not to get injured with the heat exchanger, piping flare portion or screws etc. Install isolator or disconnect switch on the power supply wiring in . Be sure to insulate the refrigerant pipes so as not to condense the ambient air moisture on them. The isolator should be locked in OFF state in accordance with EN60204-1. Insufficient insulation can cause condensation, which can lead to moisture Be sure to install indoor unit properly according to the installation damage on the ceiling, floor, furniture and any other valuables. . When perform the air conditioner operation (cooling or drying opera-Improper installation of indoor unit can cause dropping water into the room tion) in which ventilator is installed in the room. In this case, using the air conditioner in parallel with the ventilator, there is the possibility Install the drainage pipe to run off drainage securely according to that drain water may backflow in accordance with the room lapse into the negative pressure status. Therefore, set up the opening port such Incorrect installation of the drainage pipe can cause dropping water into the as incorporate the air into the room that may appropriate to ventilation (For example; Open the door a little). In addition, just as above, so set up the opening port if the room lapse into negative pressure status due to register of the wind for the high rise apartment etc. · Be sure to perform air tightness test by pressurizing with nitroger gas after completed refrigerant piping work. If the density of refrigerant exceeds the limit in the event of refrigerant

· Do not perform any change of protective device itself or its setup

switch and temperature controller or the use of non specified component

The forced operation by short-circuiting protective device of pressure

∧ WARNING

∧ CAUTION

Do not connect the ground lead to the gas line, water line, lightning conductor or telephone line's ground lead. Incorrect grounding can cause unit faults

condition.

falling from the installation place.

• Do not vent R410A into the atmosphere : R410A is a fluorinated

Touching rotating equipments, hot surfaces or high voltage parts can cause can cause fire or burst.

greenhouse gas, covered by the Kyoto Protocol with Groval

Do not run the unit with removed panels or protections

personal injury due to entrapment, burn or electric shocks.

· Carry out the electrical work for ground lead with care.

be the one that disconnect all poles under over current.

Using the incorrect one could cause the system failure and fire

accordance with the local codes and regulations.

manual in order to run off the drainage smoothly.

and damaging personal property.

the installation manual.

Use the circuit breaker of correct capacity. Circuit breaker should

such as electric shocks due to short-circuiting.

Warming Potential (GWP)=1975.

leakage in the small room, lack of oxygen can occur, which can cause serious accidents

If leaked gases accumulate around the unit, it can cause fire . Do not install the unit where corrosive gas (such as sulfurous acid gas etc.) or combustible gas (such as thinner and petroleum gases) can accumulate or collect, or where volatile combustible substances are handled.

Corrosive gas can cause corrosion of heat exchanger, breakage of plastic parts and etc. And combustible gas can cause fire.

Do not use the indoor unit at the place where water splashes may occur such as in laundries.

Since the indoor unit is not waterproof, it can cause electric shocks and fire. Do not install nor use the system close to the equipment that

generates electromagnetic fields or high frequency harmonics. Equipment such as inverters, standby generators, medical high frequency

equipments and telecommunication equipments can affect the system, and cause malfunctions and breakdowns. The system can also affect medical equipment and telecommunication equipment, and obstruct its function or cause iamming

Do not place any variables which will be damaged by getting wet under the indoor unit.

When the relative humidity is higher than 80% or drainage pipe is clogged, condensation or drainage water can drop and it can cause the damage of valuables.

Do not install the remote control at the direct sunlight.

It can cause malfunction or deformation of the remote control. Do not use the unit for special purposes such as storing foods, cooling precision instruments and preservation of animals, plants or

art. It can cause the damage of the items.

. Do not use any materials other than a fuse with the correct rating in the location where fuses are to be used.

Connecting the circuit with cooper wire or other metal thread can cause unit failure and fire.

cold depending the operating condition, and it can cause burn injury or

Do not touch any buttons with wet hands.

It can cause electric shocks. Do not touch any refrigerant pipes with your hands when the system is in operation.

During operation the refrigerant pipes become extremely hot or extremely

frost injury.

- It can affect performance or function and etc.
- Do not install the unit near the location where leakage o

combustible gases can occur.

This may cause fire or heating.

and etc., it can cause malfunction.

installation If parts other than those prescribed by us are used. It may cause water

leaks electric shocks fire and personal injury

Install the unit in a location with good support Linsuitable installation locations can cause the unit to fall and cause

material damage and personal injury Ventilate the working area well in the event of refrigerant leakage

during installation

- If the refrigerant comes into contact with naked flames, poisonous gas is produced
- When installing in small rooms, take prevention measures not to exceed the density limit of refrigerant in the event of leakage,

If the density of refrigerant exceeds the limit, please consult the dealer and install the ventilation system, otherwise lack of oxygen can occur, which

After completed installation, check that no refrigerant leaks from the system.

- other hot surface, poisonous das is produced.

 Use the prescribed pipes, flare nuts and tools for R410A. Using existing parts (for B22 or B407C) can cause the unit failure and

serious accidents due to burst of the refrigerant circuit.

poisonous gases such as sulphide gas can occur.

Poisonous gases will flow into the room through drainage pipe and seriously affect the user's health and safety. This can also cause the corrosion of the indoor unit and a resultant unit failure or refrigerant leak. Ensure that no air enters in the refrigerant circuit when the unit is installed and removed.


If air enters in the refrigerant circuit, the pressure in the refrigerant circuit becomes too high, which can cause burst and personal injury.

BEFORE INSTALLATION

O Before installation check that the power supply matches the air conditioner.

Standard accessories (Installation kit) Accessories for indoor unit				
1	Installation board (Attached to the rear of the indoor unit)	1		
2	Wireless remote control	1		
3	Remote control holder	1		
4	Tapping screws (for installation board ø4 X 25mm)	10		
5	Wood screws (for remote control switch holder ø3.5 X 16mm)	2		
6	Battery [R03 (AAA, Micro) 1.5V]	2		
1	Air-cleaning filters	2		
8	Filter holders (Attached to the front panel of indoor unit)	2		
9	Insulation (#486 50 x 100 t3)	1		

Option parts			
(a)	Sealing plate	1	
b	Sleeve	1	
©	Inclination plate	1	
đ	Putty	1	
e	Drain hose (extension hose)	1	
ſ	Piping cover (for insulation of connection piping)	1	



Sufficient care must be taken not to damage

the panel when connecting pipes.

SELECTION OF INSTALLATION LOCATION 5 cm minimum (Install at location that meets the following conditions, after getting approval from the customer) from the wall 6.5 cm minimum from the ceiling Indoor unit Where there is no obstructions to the air flow and where the cooled and heated air can be evenly distributed A solid place where the unit or the wall will not vibrate. A place where there will be enough space for servicing (Where space mentioned below can be secured) Where wiring and the piping work will be easy to conduct. The place where receiving part is not exposed to the direct rays of the sun or the strong rays of the street lighting. A place where it can be easily drained. A place separated at least in away from the television or the radio. (To prevent interference to images and sounds.)) Places where this unit is not affected by the high frequency equipment or electric equipment.) Avoid installing this unit in place where there is much oil mist. Places where there is no electric equipment or household under the installing unit. Wireless remote control A place where the air conditioner can be received the signal surely during operating the wireless remote control. **▲ CAUTION** Places where there is no affected by the TV and radio etc. Indoor side Outdoor side Do not place where exposed to direct sunlight or near heat devices such as a stove Completely seal the hole on Sleeve (sold separately) the wall with putty. Otherwise, INSTALLATION OF INDOOR UNIT furniture, or other, may be wetted by leaked water or Installation of Installation board dewina. (2) Wireless remote control Look for the inside wall structures (Intermediats support or pillar and firmly install the unit after level surface has been checked.) 3 Remote control holder Fixing on concrete wall Use of nut anchor Use of bolt anchor (Chan (5) Wood screws Bolt Nut (M6×12) (M6) ال Relation between setting plate and indoor unit Mounting Mating mark for board level surface Mounting Max.10 hoard INSTALLATION SPACE (INDOOR UNIT) (FRONT VIEW) Indoor unit O Adjustment of the installation board in the horizontal direction is to be conducted with eight screws in a temporary tightened state. Installation board O Adjust so the board will be for service for service 100 level by turning the board Standard with the standard hole as 106 hole the center. 450 349 Drilling of holes and fixture of sleeve (Option parts) When drilling the wall that contains a metal lath, wire lath or metal plate, be sure to use pipe hole sleeve sold separately. 53.5 77 -)) (()) Turn to Piping for Gas 633.5 Piping hole (ø65) ø65 🕅 tighter Piping for Liquid 703.5 For bolt anchor Thickness of the wall + 1.5cm Indoor side Outdoor side Indoor side Outdoor side Installed state and nut anchor Drain hose 792 (ø16) Piping hole (ø65) In case of rear piping draw out, cut off the lower and the right side portions of the sleeve collar. O Drill a hole with whole core drill. . Matters of special notice when piping from left or central/rear of the unit. Installing the support of piping [Top view] [Drain hose changing procedures] Left-hand-side piping 1. Remove the drain hose 2. Remove the drain cap. In case of piping in the right rear direction Right-hand-side piping Piping in the left rear direction Piping in the right rear direction Taping of the exterior Shaping of pipings Piping Piping in the left direction Piping in the right direction ○ Remove the screw and drain hose O Remove it with hand or pliers. Drain hose making it rotate Piping is possible in the rear, left, left rear, left downward, right or downward direction. 3. Insert the drain cap 4. Connect the drain hose O Hold the bottom of the Tape only the portion piping and fix direction that goes through the before stretching it and O Always tape the wiring shaping it. with the piping

Left downward

0 Insert the drain cap which was removed O Insert the drain hose securely, making rotate. And install the screw. Note: Be careful that If it is not inserted at procedure "2" securely using a hexagonal wrench etc. Note: Be careful that If it is not inserted securely, water leakage may securely, water leakage may occur. occur.

1) Installation board

10 cm minimum


from the wall


the second second


Spa


- CD 2

(Unit : mm)















· Forced cooling operation

INSTALLATION OF WIRELESS REMOTE CONTROL



HOW TO RELOCATE OR DISPOSE OF THE UNIT

In order to protect the environment, be sure to pump down (recovery of refrigerant).
 Pump down is the method of recovering refrigerant from the indoor unit to the outdoor unit when the pipes are removed from the unit.

<How to pump down>

- Connect charge hose to check joint of outdoor unit.
 Q Liquid side : Close the liquid valve with hexagon wrench key.
- Gas side : Fully open the gas valve. Carry out cooling operation. (If indoor temperature is low, operate
- forced cooling operation.)
 (3) After low pressure gauge become 0.01MPa, stop cooling operation and close the gas valve.




Turn on the power supply again after a while after turn off the power supply.

CONCERNING TERMINAL CONNECTION FOR AN INTERFACE

① Remove the air inlet panel, lid and front panel.

- Remove the control cover. (Remove the screw.)
 There is a terminal (respectively marked with CNS) for the indoor control board.
- In connecting an interface, connect to the respective terminal securely with the connection harness
- supplied with an optional "Interface connection kit SC-BIKN-E" and fasten the connection harness
- onto the indoor control box with the clamp supplied with the kit. For more details, please refer to the user's manual of your "Interface connection kit SC-BIKN-E".



INSTALLATION TEST CHECK P	OINTS Check the following points again after completion of the in At the same time, explain to the customer how to use the		
After installation The power supply voltage is correct as the rating. No gas leaks from the joints of the operation valve.	Operation valve is fully open. The pipe joints for indoor and outdoor pipes have been insulated.		The wireless remote control is normal. Operation of the unit has been explained to the customer. (Three-minutes restart preventive timer)
Power cables and crossover wires are securely fixed to the terminal board. The screw of the lid is tightened securely.		Water drains smoothly. Protective functions are not working.	When the air conditioner is restarted or when changing the operation, the unit will not start operating for approximately 3 minutes. This is to protect the unit and it is not a malfunction.

(7) Effective range of cool/hot wind (Reference)

(a) FDT series

Guideline for ceiling height

Fan Speed Setting	Model				
ran speed setting	FDT71VF1	FDT100VF1, 100VF2			
Hi	3.0m	3.2m			
PHi	3.8m	4.3m			

Notes (1) If the ceiling height is over 3m, please consider to add circulators.

This table shows reference values in case of four outlet.

If you shut some outlets, they are different.

Fan speed setting can be changed by using a wired remote control.

(b) FDEN series

Model	Effective range
FDEN71VF1	8.0m
FDEN100VF1	9.0m

[Conditions] 1. Height of unit: 2.4 – 3.0 (m) above floor level

- 2. Fan speed : Hi
- 3. Location: Free space without obstacles
- 4. The effective range means the horizontal distance for wind to reach the floor.
- 5. Wind speed at the effective range: 0.5 m/s

(c) FDF series

Model	Effective range
FDF71VD1	5m
FDF100VD1, 100VD2	8m

[Conditions] 1. Fan speed : Hi

- 2. Location: Free space without obstacles
- 3. The effective range means the horizontal distance for the wind to reach the floor.
- 4. Wind speed at the effective range: 0.5 m/s

11.2 Electric wiring work installation

(1) FDT, FDEN, FDUM, series

PSB012D999

Electrical wiring work must be performed by an electrician qualified by a local power provider according to the electrical installation technical standards and interior wiring regulations applicable to the installation site.

Security instructions

- Read the "SAFETY PRECAUTIONS" carefully first of all and then strictly follow it during the installation work in order to protect yourself.
- The precautionary items mentioned below are distinguished into two levels, [<u>AWARNING</u> and <u>[<u>A</u>CAUTION].</u>

- The meanings of "Marks" used here are as shown on the right:
- Never do it under any circumstances. Always do it according to the instruction.
- Accord with following items. Otherwise, there will be the risks of electric shock and fire caused by overheating or short circuit.

	Be sure to have the electrical wiring work done by qualified electrical installer, and use exclusive circuit.	0
	Power source with insufficient capacity and improper work can cause electric shock and fire.	
	Use specified wire for electrical wiring, fasten the wiring to the terminal securely, and hold the cable securely in order not to apply unexpected stress on the terminal. Losse connections or hold could result in abnormal heat generation or fire.	0
	Arrange the electrical wires in the control box properly to prevent them from rising. Fit the lid of the services panel property. Improper fitting may cause abnormal heat and fire.	0
	Use the genuine optional parts. And installation should be performed by a specialist. If you install the unit by yourself, it could cause water leakage, electric shock and fire	0
	 Do not repair by yourself. And consult with the dealer about repair. 	
	Improper repair may cause water leakage, electric shock or fire.	\odot
	Consult the dealer or a specialist about removal of the air conditioner. Improper installation may cause water leakage, electric shock or fire.	0
	•Turn off the power source during servicing or inspection work. If the power is supplied during servicing or inspection work, it could cause electric shock and injury by the operating fan.	0
	Shut off the power before electrical wiring work. It could cause electric shock, unit failure and improper running.	0
\square	∆CAUTION	
	Perform earth wiring surely. Do not connect the earth wiring to the gas pipe, water pipe, lightning rod and telephone earth wiring. Improper earth could cause unit failure and electric shock due to a short circuit.	Ð
	Earth leakage breaker must be installed. If the earth leakage breaker is not installed, it can cause electric shocks.	0
	 Make sure to install earth leakage breaker on power source line. (countermeasure thing to high harmonics.) Absence of breaker could cause electric shock. 	0
	• Use the circuit breaker of correct capacity. Circuit breaker should be the one that disconnect all poles under over current. Using the incorrect one could cause the system failure and fire.	0
	Do not use any materials other than a fuse of correct capacity where a fuse should be used. Connecting the circuit by wire or copper wire could cause unit failure and fire.	\bigcirc
	● Use power source line of correct capacity. Using incorrect capacity one could cause electric leak, abnormal heat generation and fire	
	Do not mingle solid cord and stranded cord on power source and signal side terminal block. In addition, do not mingle difference capacity solid or stranded cord. Inappropriate cord setting could cause loosing screw on terminal block, bad electrica contact, smoke and fire.	\circ
	• Do not turn off the power source immediately after stopping the operation. Be sure to wait for more than 5 minutes. Otherwise it could cause water leakage or breakdown.	\bigcirc
	Do not control the operation with the circuit breaker. It could cause fire or water leakage. In addition, the fan may start operation unexpectedly and it may cause injury.	\bigcirc

Control mode switching

•	The control content of indoor units can be switched in following way. (is the default setting)							
	Switch No.	Control Content						
SW2 Indoor unit address (0-Fh)								
	SW5-1	r/Slave Switching (plural /Slave unit Setting)						
	, olaro otnannig (plana / olaro ann ootang)							
	SW6-1~4	Model	capacity setting					
	SW7-1	ON	Operation check, Drain motor test run					
	3447 -1	OFF	Normal operation					

9					
provider. These wiring specifications are instructions are observed:	d by an electlician an qualified by a local pow determined on the assumption that the following				
① Do not use cords other than copper ones. Do not use any supply line lighter than one specified in par -braided cord (code designation 60245 IEC 51), if allowed -ordinary tough rubber sheathed cord (code designation 6 -flat twin timsel cord (code designation 60227 IEC 41):	I in the relevant part 2;				
-ordinary polyvinyl chloride sheathed cord (code designat ② Connect the power supply to the outdoor unit.	ion 60227 IEC 53); wer source line connection, because an error in their connection can				
Screw the line to terminal block without any	y looseness, certainly.				
Do not turn on the switch of power source,	before all of line work is done.				
	and never share a branching circuit with oth he circuit breaker may occur, which can cau				
"INSTALLATION MANUAL" of outdoor Unit.	n indoor and outdoor unit. As for detail, refer				
Set earth of D-type.					
route on outside of unit. If connecting point communication.	door power source, remote control and signal) is flooded, it could cause problem as for electric				
(In the case that it is necessary to set connecting point on the signal line way, perform thorough waterproof measurement.)					
Run the lines (power source, remote control and "between indoor and outdoor unit") upper ceiling through iron pipe or other tube protection to avoid the damage by mouse and so on.					
of unit outside.	rce line" away from each other on constructing				
 Do not connect the power source line [220 Otherwise, it could cause failure. 	DV/240V/380V/415V] to signal side terminal bloc				
label of terminal block.	and connect the lines to terminal block according to number pointed				
Furthermore, connect earth line to earth position of terr	b lines, because there is electrical polarity except earth line. ninal block of power source. n, select the type of breaker for inverter circuit as earth leakage breake				
	r earth-fault protection, hand switch (switch itself and type "B" fuse reaker. ing in accordance with the local codes and regulations.				
Cable connection for single u					
-					
DAs for connecting method of power source, sele not directly connect power souce line to inside	ct from following connecting patterns. In principle, o unit.				
* As for exceptional connecting method of pow	wer souce, discuss with the power provider of the				
country with referring to technical documen 2)For cable size and circuit breaker selection ref	er to the outdoor unit installation manual				
country with referring to technical documen For cable size and circuit breaker selection, ref Single-phase model	er to the outdoor unit installation manual. Three-phase model				
2)For cable size and circuit breaker selection, ref					

①Electrical Wiring Connection


Earth leakage breaker	Earth leakage breaker
Circuit breaker	Circuit breaker
Outdoor Unit	Outdoor Unit
Indoor-Outdoor Connecting line	Indoor-Outdoor Connecting line
Indoor Unit	
Remote control line	Remote control line
X Y Remote control	X Y Remote control


Cable connection for a V multi configuration installation

Connect the same pairs number of terminal block ", 2), and 3)"and " \bigotimes and " between master and slave indoor units.

(2) Do the same address setting of all inside units belong to same refrigerant system by rotary switch SW2 on indoor unit's PCB (Printed circuit board).
 (3) Set slave indoor unit as "slave 1" through "slave 3" by address switch SW5-1, 5-2 on PCB.

③Set stave indoor unit as stave 1 unough stave 5 by adures switch swo-1, 5-2 un POB.
④When the [AIR CON NO.] button on the remote control unit is pressed after turning on the power, an indoor unit's address number will be displayed. Do not fail to confirm that the connected indoor unit's numbers are displayed on the remote control unit by pressing the ▲ or ▼ button.





© Operation and setting from remote control

A: Refer to the instruction manual for RC-EX series. B: Refer to the installation manual for RC-EX series. C: Loading a utility software vie Internet \bigcirc : Nearly same function setting and operations are possible. \triangle : Similar function setting and operations are possible.

	Setting & display item	Description	RC-EX series	RC-E5
. Re	emote Control network		001100	
1	Control plural indoor units by a single remote control	A remote control can control plural indoor units up to 16 (in one group of remote control network). An address is set to each indoor unit.	0	0
2	Master/slave setting of remote controls	A maximum of two remote controls (include option wireless) can be connected to one indoor unit. Set one to "Master" and the other to "Slave".	В	0
	P screen, Switch manipulation		Α	
	Menu	"Control", "Settings", or "Details" can be selected. (319.)	Α	
2	Operation mode	"Cooling", "Heating", "Fan", "Dry" or "Auto" can be set.	A	0
3	Set temp.	"Set temperature" can be set by 0.5°C interval.	A	0
4	Air flow direction	"Air flow direction". [Individual flap control setting] can be set.	A	0
5	Fan speed	"Fan speed" can be set.	A	0
6	Timer setting	"Timer operation" can be set.	A	0
7	ON/OFF	"On/Off operation of the system" can be done.	A	0
8	High power SW	"High power operation" or "Normal operation" can be selected.	A	
	Energy-saving SW	"Energy-saving operation" or "Normal operation" can be selected.	A	
	nergy-saving settin		A	
1	Auto OFF timer [Administrator password]	For preventing the timer from keeping ON, set hours to stop operation automatically with this timer. •The selectable range of setting time is from 30 to 240 minutes (10minutes interval) •When setting is "Valid", this timer will activate whenever the ON timer is set.	A	
2	Peak-cut timer [Administrator password]	Power consumption can be reduced by restricting the maximum capacity. Set the [Start time], the [End time] and the capacity limit % (Peak-cut %). '-4-operation patterns per day can be set at maximum. 'The setting time can be changed by 5-minutes interval. 'The setectable range of capacity limit % (Peak-cut %) is from 0% to 40-80% (20% interval). 'Holiday setting is available.	A	
3	Automatic temp. set back [Administrator password]	After the elapse of the set time period, the current set temp. will be set back to the [Set back temp.] • The setting can be done in cooling and heating mode respectively. • The selectable range of the set time is from 20 min. to 120 min. (10 min. interval). • Set the [Set back temp.] by 1°C interval.	A	
I. In	dividual flap control setting		Α	
	Individual flap control setting	The moving range (the positions of upper limit and lower limit) of the flap for individual air outlet port can be set.	Α	
. Ve	entilation	······································		
	External ventilation (In combination with ventilator)	Or/Off operation of the external ventilator can be done. •The settings of [Interlock] with AC (air-conditioner), [Single operation] of ventilator or operation [invalid] of ventilation can be done through [Ventilation settings] in the [Remote controller] menu.	A	0
6.Filt	ter sign reset		Α	0
1	Filter sign reset	The filter sign can be reset.	В	
2	Setting next cleaning date	The next cleaning date can be set.	Α	
.Init	tial settings			
1	Clock setting	The current date and time can be set or revised.	Α	\bigtriangleup
2	Date and time display	[Display] or [Hide] the date and/or time can be set, and the [12H] or [24H] display can be set.	Α	
3	Summer time	When select [Valid], the +1hour adjustment of current time can be set.When select [Invalid], the [Summer time] adjustment can be reset.	Α	
4	Contrast	The contrast of LCD can be adjusted higher or lower.	Α	
5	Backlight	Switching on/off a light can be set and the period of the lighting time can be set within the range of 5sec-90sec (5sec interval).	Α	
6	Controller sound	It can set with or without [Controller sound (beep sound)] at touching panel.	A	
	ner settings		Α	
1	Set On timer by hour	The period of time to start operation after stopping can be set. • The period of set time can be set within the range of Thour-12hours (1hr interval). • The period match start the set of the set o	А	
2	Set Off timer by hour	The operation mode, set temp and fan speed at starting operation can be set. The period of time to stop operation after starting can be set.	A	
		•The period of set time can be set within the range of 1hour-12hours (1hr interval).		
3	Set On timer by clock	The clock time to start operation can be set. •The set clock time can be set by 5 minutes interval. •[Once (one time only)] or [Everyday] operation can be switched.	A	
,	Set Off timer by clock	The operation mode, set temp and fan speed at starting operation can be set.		
4	Set OII unier by clock	The clock time to stop operation can be set. •The set clock time can be set by 5 minutes interval. •[Once (one time only]) or [Everyday] operation can be switched.	A	
	Confirmation of timer settings	Status of timer settings can be seen.	Α	
	ekly timer			
1	Weekly timer	On timer and Off timer on weekly basis can be set.		\bigtriangleup
	[Administrator password]	 •8-operation patterns per day can be set at a maximum. 	А	
		- The setting clock time can be set by 5 minutes interval. + Holiday setting is available.	~	
		•The operation mode, set temp and fan speed at starting operation can be set.		
0.H	lome leave mode			
1	Home leave mode [Administrator password]	When leaving home for a long period like a vacation leave, the unit can be operated to maintain the room temperature not to be hotter in summer or not to be colder in winter. • The judgment to switch the operation mode (Cooling⇔Heating) is done by the both factors of the set temp. and outdoor air temp. • The set temp. and fan speed can be set.	A	

				1
	Setting & display item	Description	RC-EX series	
. A	dministrator settings	[Administrator password]	Α	
1	Enable/Disable setting	Enable/Disable setting of operation can be set. [On/Off] [Change set temp.] [Change operation mode] [Change air flow direction]		
		[Individual flap control setting][Fan speed] [High power operation] [Energy-saving operation] [Timer settings] [Weekly timer setting]	А	
		•Request for administrator password can be set. [Individual flap control setting][Weekly timer][Energy-saving setting][Home leave mode][Administrator settings]		
2	Silent mode timer	The period of time to operate the outdoor unit by prioritizing the quietness can be set.		-
-		•The [Start time] and the [End time] for operating outdoor unit in silent mode can be set. •The period of the operation time can be set once a day by 5 minutes interval.	Α	
	0			-
3	Setting temp. range	The upper/lower limit of indoor temp. setting range can be set.	А	
		•The limitation of indoor temp. setting range can be set for each operation mode in cooling and heating.		_
	Temp. increment setting	The temp increment setting can be changed by 0.5°C or 1.0°C.	A	
5	RC display setting	Register [Room name] [Name of I/U]		
		Display [indoor temp.] or not.	А	
		Display (inspection code) or not.		
		Display [Heating stand-by] [Defrost operation] [Auto cooling/heating] or not		C
3	Change administrator password	The administrator password can be changed. (Default setting is "0000")	Α	
		The administrator password can be reset.	В	1
.In	staller settings	[Service password]	В	
1 [Installation date	The [Installation date] can be registered.	В	
		"When registering the [Installation date], the [Next service date] is displayed automatically. (For changing the [Next service date], please refer the item of [Service & Maintenance].)		
	Service contact	The [Service contact] can be registered and can be displayed on the RC.		+
-	5500 00muot	•The [Contact company] can be registered within 10 characters. •The [Contact phone] can be registered within 13 digits.	В	1
,	Toot run			-
۱	Test run	On/Off operation of the test run can be done.		
	Cooling test run	The [Cooling test run] can be done at 5°C of set temp. for 30 minutes.	В	H
	Drain pump test run	Only the drain pump can be operated.	-	
		The [Test run] operation can be done with fixed compressor Hz set by installer.		C
	Static pressure adjustment	In case of combination with only the ducted indoor unit which has a function of static pressure adjustment, the static pressure is adjustable.	В	-
5	Change auto-address	The set address of each indoor unit decided by auto-address setting method can be changed to any other address. (For multiple KX units only)	В	
3	Address setting of Main IU	Main indoor unit address can be set.		
		•Only the Main indoor unit can change operation mode and the Sub indoor units dominated by the Main indoor unit shall follow.	В	
		The Main indoor unit can domain 10 indoor units at a maximum.		
.R(C function settings	[Service password]	В	
1	Main/Sub RC setting	The setting of [Main/Sub RC] can be changed.	В	C
2	RC sensor	The offset value of [RC sensor] sensing temp. can be set respectively in heating and cooling.	В	C
	9 RC sensor adjustment	The offset value of [RC sensor] sensing temp. can be set respectively in heating and cooling.		<u> </u>
3		The setting range of offset value is ±3° both in cooling and heating.	В	
4	12 Operation mode	The [Valid/Invalid] setting of [Auto][Cooling][Heating] and [Dry] can be done respectively.	В	C
5	13 Fan speed	The setting of [Fan speed] can be done from following patterns. 1-speed, 2-speeds (Hi-Me), 2-speeds (Hi-Lo), 3-speeds, 4-speeds.	B	
			D	
	14 External input	The applicable range ([Individual] or [All units]) of CnT input to the multiple indoor units connected in one control system. -[Individual] : Only the unit received CnT input signal[All units] : All the units connected to one control system received CnT input signal.	В	C
6	4 F Marchille Marca and Marca			
7	15 Ventilation setting	The setting of [Invalid] operation of ventilator, [Interlock] with AC or [Independent] of ventilator can be selected.	В	I C
_		When setting [Interlock], the operation of external ventilator is interlocked with the operation of AC •When setting [Independent], only the operation of external ventilator is available.		-
8	16 Flap control	The [Flap control] method can be switched to [Stop at fixed position] or [Stop at any position]. [Stop at fixed position] : Stop the flap at a certain position	В	
		among the designated 4 positions. (Stop at any position) : Stop the flap at any arbitrary position just after the stopping command from RC was sent.		
- 1	17 Auto-restart	The operation control method after recovery of power blackout happened during operation can be set.	В	C
0	18 Auto temp. setting	[Valid] or [Invalid] of [Auto temp. setting] can be selected.	В	
1	19 Auto fan speed setting	[Valid] or [Invalid] of [Auto fan speed setting] can be selected.	В	
. I/	/U settings	[Service password]	В	
1	High ceiling	The fan tap of indoor fan can be changed. •[Standard] [High ceiling 1] [High ceiling 2] can be selected.	В	
2	Filter sign	The setting of filter sign display timer can be done from following patterns.	В	0
- 1	External input 1	The content of control by external input can be changed. The selectable contents of control are [On/Off] [Permission/Prohibition] [Cooling/heating] [Emergency stop]	В	0
- F	External input 1 signal	The type of external input signal ([Level input]/[Pulse input]) can be changed.	B	T C
· 1				\vdash
· 1	External input 2	The selectable contents of control are [On/Off] [Permission/Prohibition] [Cooling/heating] [Emergency stop] The true of othereal insult cleaned (insult (insult)) can be abaard	B	
6	External input 2 signal	The type of external input signal ([Level input]) (Pulse input]) can be changed.	В	
7		The judgment temp. of heating thermo-off can be adjusted within the range from 0 to $+3^{\circ}C(1^{\circ}C \text{ interval})$	В	
· •	Return air sensor adjust.	The sensing temp, of return air temp, sensor built in the indoor unit can be adjusted within the range of $\pm 2^{\circ}$ C.	В	
9 [Fan control in heating thermo OFF	The fan control method at heating thermo-off can be changed. The selectable fan control methods are [Low] [Set fan speed] [Intermittent] [Stop].	В	0
1	Anti-frost temp.	The judgment temp. of anti-frost control for the indoor unit in cooling can be changed to [Temp. High] or [Temp. Low].	В	0
	Anti-frost control	When the anti-frost control of indoor unit in cooling is activated, the fan speed can be changed.	В	0
	Drain pump operation	In any operation mode in addition to cooling and dry mode, the setting of drain pump operation can be done.	В	ŤŎ
	Residual fan operation in cooling	The time period of residual fan operation after stopping or thermo-off in cooling mode can be set.	B	10
- 1	Residual fan operation in heating	The time period of residual fan operation after stopping of thermo-off in heating mode can be set.	B	
- H				-
	Intermittent fan operation in heating	The fan operation rule following the residual fan operation after stopping or thermo-off in heating mode can be set.	B	
- 1	Fan circulator operation	In case that the fan is operated as the circulator, the fan control rule can be set.	В	- 1
'		When only the OA processing units are operated, control pressure value can be changed.	В	0
:	Auto operation mode	The [Auto rule selection] for switching the operation mode automatically can be selected from 3 patterns.	В	
1	Thermo. rule setting	When selecting [Outdoor air temp. control], the judgment temp can be offset by outdoor temp	В	
ł	Auto fan speed control	Under the [Auto fan speed control] mode, the switching range of fan speed can be selected from following 2 patterns [Auto 1] [Auto 2][Auto 1] : Hi	В	
_	ervice & Maintenance	(Service password)	B	1
۰.	IU address No.	Max. 16 indoor units can be connected to one remote control, and all address No. of the connected indoor units can be displayed.		-
•		•The indoor units conforming to the address No. can be identified by selecting the address No. and tapping [Check] to operate the indoor fan.	В	0
, I	Next service date	The [Next service date] can be registered. The [Next service date] and [Service contact] is displayed on the [Periodical check] message screen.	AB	1
ł	Operation data	Total 39 items of [Operation data] for indoor unit and outdoor unit can be displayed.	B	+
- 1	Error history	[Date and time of error occurred] [I/U address] [Error code] for Max. 16 latest cases of error history can be displayed.	В	
- 1	Display anomaly data	The operation data just before the latest error stop can be displayed.	В	
	Reset periodical check	The timer for the periodical check can be reset.	В	C
5	Saving I/U settings	The I/U settings memorized in the indoor PCB connected to the remote control can be saved in the memory of the remote control.	В	
	Special settings	[Erase I/U address] [CPU reset] [Initializing] [Touch panel calibration]	B	
_a I	· · · · · · · · · · · · · · · · · · ·	Terror to created for a root/fillingering/filogori bener aging gange	J	+
_			•	
In	spection	The end down when a few memory back and a way when a down and a way of a start and a start of the start and a start of the	A	
.In	Confirmation of Inspection	The address No, of anomalous indoor/outdoor unit and error code are displayed.	A	
.In P(· · · · · · · · · · · · · · · · · · ·	The address No, of anomalous indoor/outdoor unit and error code are displayed. Weekly timer setting and etc., can be set from PC.	C	-

PSB012D994

(2) FDU series

Electrical wiring work must be performed by an electrician qualified by a local power provider according to the electrical installation technical standards and interior wiring regulations applicable to the installation site.

Security instructions

- Read the "SAFETY PRECAUTIONS" carefully first of all and then strictly follow it during the installation work in order to protect yourself.
- The precautionary items mentioned below are distinguished into two levels, AWARNING
 and ACAUTION

[<u>AWARNING</u>]: Wrong installation would cause serious consequences such as injuries or death. [<u>ACAUTION</u>]: Wrong installation might cause serious consequences depending on circumstances. Both mentions the important items to protect your health and safety so strictly follow them by any means.


- The meanings of "Marks" used here are as shown on the right:
- Never do it under any circumstances.
- Accord with following items. Otherwise, there will be the risks of electric shock and fire caused by overheating or short circuit.
- Be sure to have the electrical wiring work done by qualified electrical installer, 0 and use exclusive circuit. Power source with insufficient capacity and improper work can cause electric shock and fire. Use specified wire for electrical wiring, fasten the wiring to the terminal securely, and hold the cable securely in order not to apply unexpected stress on the terminal. Loose connections or hold could result in abnormal heat generation or fire. Arrange the electrical wires in the control box properly to prevent them from A rising. Fit the lid of the services panel property. Improper fitting may cause abnormal heat and fire Use the genuine optional parts. And installation should be performed by a specialist. If you install the unit by yourself, it could cause water leakage, electric shock and fire. Do not repair by yourself. And consult with the dealer about repair. \bigcirc Improper repair may cause water leakage, electric shock or fire. Consult the dealer or a specialist about removal of the air conditioner. 0 Improper installation may cause water leakage, electric shock or fire. Turn off the power source during servicing or inspection work. If the power is supplied during servicing or inspection work, it could cause electric 0 shock and injury by the operating fan. Shut off the power before electrical wiring work. 0 It could cause electric shock, unit failure and improper running. **CAUTION** Perform earth wiring surely. Do not connect the earth wiring to the gas pipe, water pipe, lightning rod and telephone earth wiring. Improper earth could cause unit failure and electric shock or fire due to a short circuit. Earth leakage breaker must be installed. If the earth leakage breaker is not installed, it could cause electric shocks or fire. Make sure to install earth leakage breaker on power source line. (countermeasure thing to high harmonics.) A Absence of breaker could cause electric shock • Use the circuit breaker of correct capacity. Circuit breaker should be the one that disconnect all poles under over current. 0 Using the incorrect one could cause the system failure and fire Do not use any materials other than a fuse of correct capacity where a fuse should be used. \sim Connecting the circuit by wire or copper wire could cause unit failure and fire. Use power source line of correct capacity. Using incorrect capacity one could cause electric leak, abnormal heat generation and fire. • Do not mingle solid cord and stranded cord on power source and signal side terminal block. In addition, do not mingle difference capacity solid or stranded cord. \mathcal{O} Inappropriate cord setting could cause loosing screw on terminal block, bad electrical contact, smoke and fire. • Do not turn off the power source immediately after stopping the operation. \bigcirc Be sure to wait for more than 5 minutes. Otherwise it could cause water leakage or breakdown • Do not control the operation with the circuit breaker. \bigcirc It could cause fire or water leakage. In addition, the fan may start operation unexpectedly and it may cause injury.

DElectrical Wiring Connection

- •Use three-core cable as wiring between indoor and outdoor unit. As for detail, refer to "INSTAL-LATION MANUAL" of outdoor Unit.
- Set earth of D-type.
- •Keep "remote control line" and "power source line" away from each other on constructing of unit outside.
- Run the lines (power source, remote control and "between indoor and outdoor unit") upper ceiling through iron pipe or other tube protection to avoid the damage by mouse and so on.
- Do not add cord in the middle of line route (of power source, remote control and "between indoor and outdoor unit") on outside of unit. If connecting point is flooded, it could cause problem as for electric or communication. (In the case that it is necessary to set connecting point on the way, perform thorough waterproof measurement.)
- Do not connect the power source line [220V/240V/380V/415V] to signal side terminal block. Otherwise, it could cause failure.
- Screw the line to terminal block without any looseness, certainly.
- Do not turn on the switch of power source, before all of line work is done.
- •Connection of the line ("Between indoor and outdoor unit", Earth and Remote control) ①Remove lid of control box before connect the above lines, and connect the lines to terminal
- block according to number pointed on label of terminal block. In addition, pay enough attention to confirm the number to lines, because there is electrical polarity except earth line. Furthermore, connect earth line to earth position of terminal block of power source.
- ②Install earth leakage breaker on power source line. In addition, select the type of breaker for inverter circuit as earth leakage breaker.
- ③If the function of selected earth leakage breaker is only for earth-fault protection, hand switch (switch itself and type "B" fuse) or circuit breaker is required in series with the earth leakage breaker
- ④Install isolator or disconnect switch on the power supply wiring in accordance with the local codes and regulations.
- The isolator should be set in the box with key to prevent touching by another person when servicing.

Cable connection for single unit installation

- ①As for connecting method of power source, select from following connecting patterns. In principle, do not directly connect power souce line to inside unit.
- As for exceptional connecting method of power souce, discuss with the power provider of the country with referring to technical documents, and follow its instruction.
- ②For cable size and circuit breaker selection, refer to the outdoor unit installation manual.





Cable connection for a V multi configuration installation

() Connect the same pairs number of terminal block "(1), (2), and (3)" and "(3) and (9)" between master and slave indoor units.

②Do the same address setting of all inside units belong to same refrigerant system by rotary switch SW2 on indoor unit's PCB (Printed circuit board).

③Set slave indoor unit as "slave 1" through "slave 3" by address switch SW5-1, 5-2 on PCB.
 ④When the <u>AIR CON NO.</u> button on the remote control unit is pressed after turning on the power, an indoor unit's address number will be displayed. Do not fail to confirm that the connected indoor unit's numbers are displayed on the remote control unit by pressing the or viton.






Function Setting by Remote Control						
he functional setting The initial function setting for typical using is performed automatically for a remote control unit and an indoor unit by the door unit cont	nected when			etting marked " following table.	≫ " is decided	I by connected indoor and outdoor unit, and is au
remote control and inside unit are connected.	lootod, when		Function No.	Item	Default	Model
As long as they are used in a typical manner, there will be no need to change the initial settings.			Function 02 of remote control	AUTO RUN SET	AUTO RUN ON AUTO RUN OFF	"Auto-RUN" mode selectable indoor unit. Indoor unit without "Auto-RUN" mode
If you would like to change the initial setting marked " ()", set your desired setting as for the selected item. The procedure of functional setting is shown as the following diagram.			Function 06 of	E FAN SPEED SW	송國 VALID	Indoor unit with two or three step of air flow setting
As for detail of setting, refer to the installation manual of remote control.			Function 07 of		8년 INVALID 8년 VALID	Indoor unit with only one of air flow setting Indoor unit with automatically swing louver
[Flow of function setting]			remote control	C LOUVER SW	ండా Invalid	Indoor unit without automatically swing louver
Start : While indoor unit do not operate, press "			Function 13 of		HI-MID-LO HI-LO	Indoor unit with three step of air flow setting Indoor unit with two step of air flow setting
Finalize : Press " I (SET) button.			remote control	I/U FAN	HI-MID	
Reset : Press " (RESET) button. Select : Press ▲ ▼ button.			5 1 15 1		1 FAN SPEED HEAT PUNP	Indoor unit with only one of air flow setting
End : Press OON/OFF button.			Function 15 of remote control	NODEL TYPE	COOLING ONLY	Heat pump unite Exclusive cooling unite
It is possible to finish above setting on the way, and unfinished change of setting is unavailable.			Note O. For cotting		D."	
" () ": Initial settings " % ": Automatic criterion			Note 2: Fan setting		0	Indoor unit air flow setting
As for detail, refer to the installation manual of remote control.			Fan taj) \$\$#1	nii - Atani - Atan	nii - \$1000 \$1000 \$1000 \$2000 11 - \$1000 \$1000 \$1000 \$1000 \$1000 \$1000
During also and different straning much				STANDARD H SPEED1, 2	UH - Hi - Me - UH - UH - Hi -	
(SET) + C (MODE) button	and save the setting		Initial function set			
				•		
						tions to each master and slave indoor unit. he setting change of indoor unit function "05
III (IN T (Remote control function) (Indoor unit function) I/U RANTION A Indoor N (Note3) (Note3)	nen plural indoor units are connected No. selection Function	u		d "06 PERMISSI		
Function ////////////////////////////////////	02 FAN SPEED SET STANDARD					
A000 £9 ₩.D Validate setting of ESP:External Static Pressure	HIGH SPEED	0 1 (Not	ote2)			
OC Invalidate setting of ESP I//003 ± 02 NUTO RUN SET I//004 ± I//004 ±	03 FILTER STON SET	02				
AUTO RIN ON 🕺	INDICATION	IN OFF				
AUTORIN OFF X Automatic operation is impossible	TYPE 1 TYPE 2	O The	e filter sign is indicated a e filter sign is indicated a	tter running for 180 fter running for 600	hours.	
BOZA WILD If to change re-set with other indoor BOZA INVALID Temperature setting button is not working unit, push AIRCON NO.	TYPE 3		e filter sign is indicated a			ill be stopped by compulsion offer 94 hours
04 IF31 MDF SM button, and indoor selection indication	TYPE 4					ill be stopped by compulsion after 24 hours.
(for example: VU 000) is set back. (for example: VU 000) is set back.	04 ST POSITION	If to	to change the indoor func e remote control function	tion "04 simposition" "14 simposition" at	", wild be changed -	accordingly
05 @ 0N/OFF SW	4POSITION	N STOP \mid 🔿 Sele	lect the louver stop positi	on in four.	iouiu be changeu	accordingly.
BO ₩LD ○ BO WHID On/Off button is not working	05 EXTERNAL INPUT	P The	e louver can stop at any j	oositon.		
OG (EETFAN SPEED SW	LEVEL INPUT					
elise Willo in the second sec	PULSE INPUT	UT				
OZ CZ LOLVER SW	INVALID	0				
BC21WLID ∞ BC21WLID ∞ Louver button is not working	07 ENERGENCY STOP	Mak	ake permission/prohibition	n control of function	be in effect.	
OB (@) TIMER SW	INWALID	0	# # - VOC			with the same outdoor unit immediately.
あのWill の Timer button is not working	VALID					", all indoor units are stopped immediately.
09 BSBK0R SET	Proven a con					
BSHSR (IFF O Remote thermistor is not working. BSSHSR (N) Remote thermistor is working.	OFFSET +3.00 OFFSET +2.00		be reset for producing + be reset for producing +			
BSN0R +30c Remote thermistor is working, and to be set for producing +3.0°C increase in temperature. BSN0R +20c Remote thermistor is working, and to be set for producing +2.0°C increase in temperature.	08 X SP OFFSET OFFSET + 1.02 NO OFFSET	01c To b	be reset for producing +			
ESHOR +1.0c Remote thermistor is working, and to be set for producing +1.0°C increase in temperature.						
BSHS0R - L0c Remote thermistor is working, and to be set for producing -1.0°C increase in temperature. ESBISIR-20c Remote thermistor is working, and to be set for producing -2.0°C increase in temperature.	0FFSET +2.00 0FFSET +1.50		be reset producing +2.0' be reset producing +1.5'			
ESHIOR -3.0c Remote thermistor is working, and to be set for producing -3.0°C increase in temperature.	09 RETURN AIR TEMP OFFSET + 1.08	Dic To b	be reset producing +1.0			
10 AUTO RESTART INVALID 0	NO OFFSET OFFSET - 1.02		be reset producing -1.0°	C ingrago in roturn	air tamparatura a	nf indeer unit
VALID	OFFSET - 1.5%	50 To b	be reset producing -1.5°	C increase in return	air temperature o	of indoor unit.
11 VENT LINK SET	0FFSET -2.08 10 [※ FAN CONTROL	Dic To b	be reset producing -2.0°	C increase in return	air temperature o	of indoor unit.
VENT LINK Connect the Single split series and the VRF series to the indoor board CNT and indoor board CND respectively. If a ventilation device is connected, been geared with the motion of indoor device, the ventilation device is operated/stopped	I DH CAN SD		nen heating thermostat is			
NO YEAT LINK By connecting the ventilation device independently by the handling of ventilation button.	SET FAN SPE	PEED	nen heating thermostat is	off, to be operated	with set air flow.	
12 TEMP RANGE SET	INTERMITTE		nen heating thermostat is		intermittently.	
INDERCEMENT If you change the range of set temperature, the indication of set temperature will vary following the control.	FAN OFF	Whe Whe	hen heating thermostat is hen the remote thermisto	un, the fan stops. is working, "FAN C	IFF" is set automa	atically.
NU LINUR LAWROC keep the set temperature.			not set when the indoor			
13 [J/UF#] [H]-ND-10 [X] Airflow of fan becomes the three speed of \$\$ant - \$ant -	11 (RUST PREVENTION TEMP)		ange of indoor heat exch	anger temperature f	o start frost preve	ention control.
HI-L0 🐹 Airflow of fan becomes the two speed of 🖏 at - 🕸 🖒 .	TEMP HUG	on o				
HI-MID Airflow of fan becomes the two speed of #catl - #catl.	12 [FRIST PREVENTION CONTROL]		orking only with the single	solit series		
	FAN CONTRO	KOLON O TO C	control frost prevention,	the indoor fan tap is	raised.	
14 রন্স PISITION If you want to change the remote control function "14 জনসংজ্ঞানত", You must change the indoor function "04 জনসংজ্ঞানত" accordingly.	TAN CONTROL 13 DRAIN PUMP LINK	OL OFF				
4POSITION STOP O You can select the louver stop position in the four.	80		ain pump is on during co			
FREE STOP The louver can stop at any position.	章心 AND ※ 章心 AND ※		ain pump is on during co ain pump is on during co	oling, dry and heating	ig. ad fan	
HEAT PUNP X	©0AND≅	Drai	ain pump is on during col	bling, dry and fan.		
COOLING CONLY ※ 16 [EXTERNAL CONTING SAT]	14 © FAN REMAINING NO REMAINI	NING 0 APPA	ter cooling is stopped or a	noling thermostat is	off the fan dooo	not perform extra operation.
In you input into the indoor printed circuit board CNT from outside, the indoor device will be operated independently	0.5 HOUR	Afte	ter cooling is stopped or o	ooling thermostat is	s off, the fan perfo	orm extra operation for half an hour.
Tonowing the input noni dutside.	1 HOUR 6 HOUR					orm extra operation for an hour. orm extra operation for six hours.
FOR ALL LINITS If you input into indoor printed circuit board CNT from outside, All units which share the same one remote control	15 % FAN REMAINING					
network work following the input from outside.	NO RENAINI					s not perform extra operation. orm extra operation for half an hour.
	0.5 HOUR		ter heating is stopped or I	neating thermostat i	s off,the fan perfo	orm extra operation for two hours.
17.1681.BP1RK0211821 network work following the input from outside. 19.1682.1108.0FF	2 HOUR			ieating thermostat i	s off, the fan perfo	orm extra operation for six hours.
17 [008 HeV MIXINIS] network work following the input from outside. 17 [008 HeV MIXINIS] [MIXININI OF] [MIXININI OF] [INIXINI OF] [MIXININI OF] [INIXINI OF] [INIXINI OF] [INIXINI OF]	2 HOUR 6 HOUR	Afte	tor meaning is stopped or i	J		
retwork work following the input from outside. retwork work following the input from outside. retwork work following the input from outside. retwork work following indicated in the input from outside. retwork work following indicated in the input from outside. retwork work following indicated in the input from outside. retwork work following indicated in the input from outside. retwork work following the input from outside.	16 * FINI INTERNITTENCE 2 HOUR 6 HOUR 10 REMAINTE	Afte			t is off, the fan ner	form intermittent operation for five minutes after twenty
17 [BB/BP/HK020]BF2] network work following the input from outside. 17 [BB/BP/HK020]BF2] [BE(021100 HF] [BE(021100 HF] [In normal working indication, indoor unit temperature is indicated instead of airflow. 16] @MB/BP/BP/BP/BP/BP/BP/BP/BP/BP/BP/BP/BP/BP	2 HOUR 6 HOUR	NING O 5min0N Duri with	ring heating is stopped o th low airflow.	heating thermosta		rform intermittent operation for five minutes after twenty
17/ [BRI INF MIX[III]83] network work following the input from outside. 17/ [BRI INF MIX[III]83] In normal working indication, indoor unit temperature is indicated instead of airflow. 18/ GENITION INF Only the master remote control can be indicated) 18/ GENITION INF MIX[III]10101 19/ EV/ STI Heating preparation indication should not be indicated. 19/ EV/ STI E	16 * FINI INTERNITTENCE 2 HOUR 6 HOUR 10 REMAINTE	Afte	ring heating is stopped o th low airflow.	heating thermosta		rform intermittent operation for five minutes after twenty rform intermittent operation for five minutes after five mi
12 (000 HP (M(2010)97) → 13 (000 HP (M(2010)97) → 14 (M(2010)97) → 15 (M(2010)97) → 16 (M(2010)97) → 17 (M(2010)97) → 18 (M(2010)97) → 19 (M(2010)97) → 19 (M(2010)97) →	2 HOUR 6 HOUR 16 [3: FAN INTERNITION: 10 FEMAINT 20min/FF50	Afte	ring heating is stopped o th low airflow. ring heating is stopped o	heating thermosta		

5 Control mode switching

The control content o	he control content of indoor units can be switched in following way. (is the default setting)							
Switch No.	Contro	Control Content						
SW2	Indoor	unit address (0-Fh)						
SW5-1	Master	er/Slave Switching (plural /Slave unit Setting)						
SW5-2	maoroi	, orano orano anno orano anno orang,						
SW6-1~4	Model	capacity setting						
SW7 — 1	ON	Operation check, Drain motor test run						
	OFF	Normal operation						



Error Code of indoor unit

ontro

Off

F1

E5

E6

E7

E8

E9

E10

E14

E16

E19

E20

E28

0 ver E30

red (checking)

Off

Off

Off

Not sure Blinking twice

Blinking once

Blinking once

Blinking once

Blinking once Blinking twice

Off

king for three tim

Blinking once

Blinking twice

Blinking once

Blinking once

Blinking twice Off

Off

LED on indoor circuit board

green (normal)

Continuous blinking

Off

Continuous blinking

Not sure Continuous blinking

Continuous blinking

Continuous blinking

Continuous blinking

Continuous blinking Continuous blinking

Continuous blinking

Continuous blinking

Continuous blinking

Continuous blinking

Continuous blinkina

Content

Normal ult on power, indoor power off or lac

nase ault on the transmission between ndoor circuit board and remote control

Indoor air inhaling sensor broken or short-circuit The temperature of heat exchange abnormal

Float SW actions (only with FS)

rain pump over current xcess number of remote control

connections The communication fault for mast indoor units

Fan motor (2) abnormal Configuration fault on running che

Fan motor (1) abnormal

Continuous blinking Fan model Continuous blinking Fan motor (1) abnormal rotation Continuous blinking Fan motor (2) abnormal rotation Continuous blinking Remote control sensor interrupte Continuous blinking LED checking)

indoor transmi nor heat exchange se

ndoor computer abnormal

ault on

hort-circui

⑦Troubleshooting

The operation data is saved when the situation of abnormal operation happen, and the data can be confirmed by remote control. [Operating procedure]

- 1. Press the CHECK button.
- The display change " OPFR DATA ¥ "
- 2. Once, press the v button, and the display change " ERROR DATA
- 3. Press the O (SET) button and abnormal operation data mode is started.
- 4. When only one indoor unit is connected to remote control, following is displayed.
- $\textcircled{\sc l}$ The case that there is history of abnormal operation. \rightarrow Error code and " DATA LOADING " is displayed. [Example]: [E8] (ERROR CODE)
- "DATA LOADING" is displayed (blinking indication during data loading). Next, the abnormal operation data of the indoor unit will be displayed Skip to step 8.
- $\textcircled{2}\ensuremath{\mathbb{Z}}\xspace$ The case that there is not history of abnormal operation.
- \rightarrow " NO ERROR " is displayed for 3 seconds and this mode is closed. 5. When plural indoor units is connected, following is displayed.
- $\textcircled{\sc l}$ The case that there is history of abnormal operation. → Error code and the smallest address number of indoor unit
- among all connected indoor unit is displayed. [Example]: [E8] (ERROR CODE)
- I/U000 🛓 " blinking
- (2)The case that there is not history of abnormal operation.
- → Only address number is displayed.
- 6. Select the indoor unit number you would like to have data displayed with the 🔺 💌 button 7. Determine the indoor unit number with the O (SET) button.
- [Example]: [E8] (ERROR CODE)
- " (The address of selected indoor unit is blinking for 2 seconds.) " I/U000
- [E8] "DATA LOADING $\,$ " (A blinking indication appears while data loaded.)
- Next, the abnormal operation data is indicated.
- If the indoor unit doing normal operation is selected, NO ERROR " is displayed for 3 seconds and address of indoor unit is displayed.
- 8. By the 🔺 💌 button, the abnormal operation data is displayed.
- Displayed data item is based on ③ Trial operation . *Depending on models, the items that do not have corresponding data are not displayed.
- 9. To display the data of a different indoor unit, press the AIR CON No. button, which allows you to go back to the indoor unit slection screen. 10.Pressing the ON/OFF button will stop displaying data
- Pressing the / (RESET) button during remote control unit operation will undo your last operation and allow you to go back to the previous screen.

SIf two (2) remote controls are connected to one (1) indoor unit, only the master control is available for trial operation and confirmation of operation data. (The slave remote control is not available.)

PGA012D405

(3) FDF series

Electrical wiring work must be performed by an electrician qualified by a local power provider according to the electrical installation technical standards and interior wiring regulations applicable to the installation site. Security instructio

- Read the "SAFETY PRECAUTIONS" carefully first of all and then strictly follow it during the installation work in order to protect yourself.
- The precautionary items mentioned below are distinguished into two levels,
 AWARNING
 and ACAUTION .

<u>AWARNING</u> : Wrong installation would cause serious consequences such as injuries or death. <u>▲CAUTION</u> : Wrong installation might cause serious consequences depending on circumstances. Both mentions the important items to protect your health and safety so strictly follow them by any means.

- The meanings of "Marks" used here are as shown on the right:
 Never do it under any circumstances.
 O Always do it according to the instruction.
- Accord with following items. Otherwise, there will be the risks of electric shock and fire caused by overheating or short circuit.
- **AWARNING** Be sure to have the electrical wiring work done by qualified electrical installer, and use exclusive circuit. Power source with insufficient capacity and improper work can cause electric shock and fire. OUse specified wire for electrical wiring, fasten the wiring to the terminal securely, and hold the cable securely in order not to apply unexpected stress on the terminal. Loose connections or hold could result in abnormal heat generation or fire. Arrange the electrical wires in the control box properly to prevent them from rising. Fit the lid of the services panel property. ٠ Improper fitting may cause abnormal heat and fire. Ouse the genuine optional parts. And installation should be performed by a D specialist. If you install the unit by yourself, it could cause water leakage, electric shock and fire. Do not repair by yourself. And consult with the dealer about repair. \bigcirc Improper repair may cause water leakage, electric shock or fire. Consult the dealer or a specialist about removal of the air conditioner. 0 Improper installation may cause water leakage, electric shock or fire. Turn off the power source during servicing or inspection work. 0 If the power is supplied during servicing or inspection work, it could cause electric shock and injury by the operating fan. Shut off the power before electrical wiring work. 0 It could cause electric shock, unit failure and improper running.

ACAUTION Perform earth wiring surely. Do not connect the earth wiring to the gas pipe, water pipe, lightning rod and telephone earth wiring. Improper earth could cause unit failure and electric shock due to a short circuit. Earth leakage breaker must be installed. 0 If the earth leakage breaker is not installed, it can cause electric shocks. Make sure to install earth leakage breaker on power source line O (countermeasure thing to high harmonics.) Absence of breaker could cause electric shock • Use the circuit breaker of correct capacity. Circuit breaker should be the one O that disconnect all poles under over current. Using the incorrect one could cause the system failure and fire. Do not use any materials other than a fuse of correct capacity where a fuse should be used. \otimes Connecting the circuit by wire or copper wire could cause unit failure and fire Use nower source line of correct capacity. Using incorrect capacity one could cause electric leak, abnormal heat generation and fire. $oldsymbol{0}$ Do not mingle solid cord and stranded cord on power source and signal side terminal block. In addition, do not mingle difference capacity solid or stranded cord. \bigcirc Inappropriate cord setting could cause loosing screw on terminal block, bad electrical contact smoke and fire Do not turn off the power source immediately after stopping the operation. Be sure to wait for more than 5 minutes. Otherwise it could cause water leakage or \sim breakdown. • Do not control the operation with the circuit breaker. \bigcirc It could cause fire or water leakage. In addition, the fan may start operation unexpectedly and it may cause injury

DElectrical Wiring Connection


Use three-core cable as wiring between indoor and outdoor unit. As for detail, refer to "INSTALLATION MANUAL" of

- outdoor Unit. Set earth of D-type. Keep "remote control line" and "power source line" away from each other on constructing of unit outside. Paun the lines (power source, remote control and "between indoor and outdoor unit") upper ceiling through iron
- And the first glower source, renote control and between indoor and outdoor full () upper centing tending in output renormality of the protection to avoid the damage by mouse and so on.
 Do not add cord in the middle of line route (of power source, renote control and "between indoor and outdoor unit") on outside of unit. If connecting point is flooded, it could cause problem as for electric or communication. (In the case that it is necessary to set connecting point on the way, perform thorough waterproof measurement.)
 Do not connect the power source line (220V/240V/380V/415V) to signal side terminal block. Otherwise, it could not not be avoid to the power source line (220V/240V/380V/415V) to signal side terminal block. cause failure

- cause nature. Screw the line to terminal block without any looseness, certainly. Do not turn on the switch of power source, before all of line work is done. Connection of the line ("Between indoor and outdoor unit", Earth and Remote control) ("Remove lid of control box before connect the above lines, and connect the lines to terminal block according to number pointed on label of terminal block. In addition, pay enough attention to confirm the number to lines, because there is electrical polarity except earth
- In adduction, pay enough addenion to commit the future to times, because there is electrical potantly except early time. Furthermore, connect early time to early position of terminal block of power source. (2)Install earth leakage breaker on power source line. In addition, select the type of breaker for inverter circuit as earth leakage breaker. (3)If the function of selected earth leakage breaker is only for earth-fault protection, hand switch (switch itself and type "B" type) or circuit breaker is required in series with the earth leakage breaker. (4)Install the local switch near the unit.

Cable connection for single unit installation

- () As for connecting method of power source, select from following connecting patterns. In principle, do not directly connect power souce line to inside unit.
- As for exceptional connecting method of power souce, discuss with the power provider of the country with referring to technical documents, and follow its instruction
- (2)For cable size and circuit breaker selection, refer to the outdoor unit installation manual



Cable connection for a V multi configuration installation


①Connect the same pairs number of terminal block "①, ②, and ③"and " ③ and ⑨ " between master and slave indoor units.

- (2)Do the same address setting of all inside units belong to same refrigerant system by rotary switch SW2 on indoor unit's PCB (Printed circuit board).
- 3)Set slave indoor unit as "slave 1" through "slave 3" by address switch SW5-1, 5-2 on PCB.

When the AIR CON NO. button on the remote control unit is pressed after turning on the power, an indoor unit's address number will be displayed. Do not fail to confirm that the connected indoor unit's numbers are displayed on the remote control unit by pressing the 🔺 or 💌 button

Method of setting Master/Slave of indoor unit






Refer to the installation manual attached to the outdoor unit.

2 Wiring for the remote control

For each indoor unit, one more remi	ote control ca	n be conne	cted in addition to the one which is build	. In the main unit.
	Switch	Setting	Contents	
Indoor units	SW1	М	Master remote control	
	3001	S	Slave remote control	
Remote control or	rd (no polarity)			
XY XV Remote control SW1 */ SW1 */		S	Master Slave V1 Lower	
to check room temperature.	or enabled" is	only selecta	set to "Master" for shipment. ole with the master remote control in the po- control regardless of the master/ slave settin	,
* When setting the remote control built i Remove the cover and change the set				



unction Setting I	by Remote Co	ntrol (Continued)			
[Flow of function set			It is possib	la ta finiah abaya a	atting on the year and unfinished alongs of eatting is unavailable
	or unit do not opera) (SET) button.	te, press " O " (SET) and " O " (MODE) button for 3 seconds at the same time.		tial settings	etting on the way, and unfinished change of setting is unavailable.
	" (SET) button:			tomatic criterion	
Select : Press	button.	•			Ilation manual of remote control.
End : Press	button.				
	_				
		During air-conditioner stopping push (C) (SET) + C) (MODE) button	Record and s		
		simultaneously for 3 seconds Consult the technical data etc for each control details	setting	3	
	_	FUNCTION SET V			
			n plural indoor units ar	e connected	
ICTION V (Remote control fu	unction)	(Indoor unit function) 1/U FUNCTION A Indoor No), selection		
01 GRILLE T J SET	setting	(Note3)	Function 02 FAN SPEED SET	setting	
of once it oct	↑↓ INWILID O	I/0001 #	02 min or ceb our	STANDARD ×]
	50Hz ZONE ONLY 60Hz ZONE ONLY	When you use at 50Hz area		HIGH SPEED 1 ×	(Note2)
02 AUTO RUN SET	OURS SURE UNLT	When you use at 60Hz area 1/1003 * 1/1004 *	03 FILTER SIGN SET	HIGH SPEED 2	4
	AUTO RUN ON \star			INDICATION OFF	1
03 12121 TEMP SW	AUTO RUN OFF O	Automatic operation is impossible		TYPE 1 O	The filter sign is indicated after running for 180 hours. The filter sign is indicated after running for 600 hours.
00 000 101 01	SIZE VALID O	If to change re-set with other indoor		TYPE 3	The filter sign is indicated after running for 1000 hours.
04 🖽 MODE SW	©⊠⊠ INWALID	Temperature setting button is not working unit, push <u>AIRCON NO.</u> button, and indoor selection indication		TYPE 4	The filter sign is indicated after running for 1000 hours, then it will be stopped by compulsion after
04 152 nuUt 30	6년 WALID 이	(for example: I/U 000) is set back.	04 ST POSITION		
	5ট INVALID	Mode button is not working		·	4
05 @ ON/OFF SW	60 VALID 0	4		4POSITION STOP ★ FREE STOP ○	The louver can stop at any positon.
	50 INVALID	On/Off button is not working	05 EXTERNAL INPUT		The lower can adp at any position.
06 EXEFAN SPEED SW	14 mm 111 10			LEVEL INPUT O]
	S⊠ WALID × S⊠ INWALID ×	Fan speed button is not working	06 INNINYANSINYAHUUH	PULSE INPUT	-
07 🖾 LOUVER SW				INVALID O	1
	or and the second seco	Louver button is not working	07 EMERGENCY STOP	VALID	Make permission/prohibition control of function be in effect.
08 @ TIMER SW	©E3 INWHLID ★	Louver button is not working	U7 JEMENOENUT STUP	INVALID O	-
	So WALID O			VALID	With the VRF series, it is used to stop all indoor units connected with the same outdoor unit immed When stop signal is inputed from remote on-off terminal "CNT-6", all indoor units are stopped imm
09 ESENSOR SET	80 INVALID	Timer button is not working			when sup signal is inputed noni remote on on terminal. On to , an induor units are supped initi
US Ballour act	SENSOR OFF O	Remote thermistor is not working.		OFFSET +3.0%	To be reset for producing +3.0°C increase in temperature during heating.
	ESENSOR ON	Remote thermistor is working.	a lu es errer	OFFSET +2.0c	To be reset for producing +2.0°C increase in temperature during heating.
	ESENSOR +3.0c	Remote thermistor is working, and to be set for producing +3.0°C increase in temperature. Remote thermistor is working, and to be set for producing +2.0°C increase in temperature.	08 🕸 SP OFFSET	OFFSET + 1.0°C	To be reset for producing +1.0°C increase in temperature during heating.
	ESENSOR +1.0c	Remote thermistor is working, and to be set for producing +1.0°C increase in temperature.			1
	ESENSOR - 1.0c	Remote thermistor is working, and to be set for producing -1.0°C increase in temperature. Remote thermistor is working, and to be set for producing -2.0°C increase in temperature.		OFFSET +2.0% OFFSET +1.5%	To be reset producing +2.0°C increase in return air temperature of indoor unit.
	ESENSOR -3.05	Remote thermistor is working, and to be set for producing -2.0°C increase in temperature.	09 RETURN AIR TEMP	OFFSET + 1.06	To be reset producing +1.5°C increase in return air temperature of indoor unit. To be reset producing +1.0°C increase in return air temperature of indoor unit.
10 AUTO RESTART				NO OFFSET O	1
	INVALID O			OFFSET - 1.0%	To be reset producing -1.0°C increase in return air temperature of indoor unit. To be reset producing -1.5°C increase in return air temperature of indoor unit.
11 VENT LINK SET	·			OFFSET -2.0c	To be reset producing -2.0°C increase in return air temperature of indoor unit.
	NO VENT O	Connect the Single split series and the VRF series to the indoor board CNT and indoor board CND respectively. If a	10 * FAN CONTROL		
	VENT LINK	ventilation device is connected, been geared with the motion of indoor device, the ventilation device is operated/stopped.		LOW FAN SPEED O	When heating thermostat is off, to be operated with low fan speed. (or with ultra low fan speed in case of some When heating thermostat is off, to be operated with set fan speed.
	NO VENT LINK	By connecting the ventilation device with the Single split series device to indoor board CNT, the VRF series device to CND, you can operate/stop the ventilation device independently by the handling of ventilation button.		SET FAN SPEED	
12 TEMP RANGE SET				INTERMITTENCE FAN OFF	When heating thermostat is off, to be operated intermittently. When heating thermostat is off, the fan stops.
	INDN CHANGE O	If you change the range of set temperature, the indication of set temperature will vary following the control. If you change the range of set temperature, the indication of set temperature will not vary following the control, and		prod on	When the remote thermistor is working, "FAN OFF" is set automatically.
	NO INDN CHANGE	If you change the range of set temperature, the indication of set temperature will not vary following the control, and keep the set temperature.			Do not set when the indoor unit's thermistor is working.
13 I/UFAN			1 1 FROST PREVENTION TEMP		Change of indoor heat exchanger temperature to start frost prevention control.
	HI-MID-LO O HI-LO *	Airflow of fan becomes the three speed of #ant - #ant'- #ar()or #anti- #ant- #ant'- #ant'- #ar().		TEMP HIGH TEMP LON O	4
	HL-LU *	•		Denr Low 0	1
	1 FAN SPEED *		12 FROST PREVENTION CONTROL		Working only with the single split series.
14 STPPOSITION				FAN CONTROL ON O	To control frost prevention, the indoor fan tap is raised.
14 97 1001100	1		13 DRAIN PUMPLINK	E-IN OVINIOL OIL	1
	4POSITION STOP ★			\$0 0	Drain pump is on during cooling and dry.
15 NODEL TYPE	FREE STOP O	The louver can stop at any position.		©sõ andix ©õ andixandi≋	Drain pump is on during cooling, dry and heating. Drain pump is on during cooling, dry, heating and fan.
	HEAT PUMP ×		L	©oand≋	Drain pump is on during cooling, dry and fan.
16 EXTERNAL CONTROL SET	COOLING ONLY ×	4	14 © FAN REHAINING	NO REMAINING O	After cooling is stopped the fan does not perform extra operation.
TO LENGTHAL CONTINUE ACT	THEFT	If you input into the indoor printed circuit board CNT from outside, the indoor device will be operated independently		0.5 HOUR	After cooling is stopped the fan does not perform extra operation. After cooling is stopped the fan perform extra operation for half an hour.
	INDIVIDUAL O	following the input from outside.		1 HOUR	After cooling is stopped the fan perform extra operation for an hour.
	FOR ALL UNITS	If you input into indoor printed circuit board CNT from outside, All units which share the same one remote control network work following the input from outside.	15 🔆 FAN REMAINING	6 HOUR	After cooling is stopped the fan perform extra operation for six hours.
17 ROOM TEMP INDICATION SET			soper minoritation	NO REMAINING O	After heating is stopped or heating thermostat is off, the fan does not perform extra operation.
	INDICATION OFF O	In normal working indication, indoor unit temperature is indicated instead of airflow.		0.5 HOUR 2 HOUR	After heating is stopped or heating thermostat is off, the fan perform extra operation for half an hou
	TUNDERLEAN TON ON	In normal working indication, indoor unit temperature is indicated instead of airflow. (Only the master remote control can be indicated.)		2 HUUR 6 HOUR	After heating is stopped or heating thermostat is off, the fan perform extra operation for two hours. After heating is stopped or heating thermostat is off, the fan perform extra operation for six hours.
18 *** INDICATION			16 *FAN INTERNITTENCE		
	INDICATION ON O INDICATION OFF	Heating preparation indication should not be indicated.		NO REMAINING O	During heating is stopped or heating thermostat is off, the fan perform intermittent o
19 b/% SET	59.5			20ninOFF 5ninON	for five minutes after twenty minutes' off with low airflow.
	0	Temperature indication is by degree C		5minOFF 5minON	During heating is stopped or heating thermostat is off, the fan perform intermittent of for five minutes after five minutes' off with low airflow.
	L.	reinherature muication is by degree r]
	F	Temperature indication is by degree F	h ★ are not available o e initial setting]

(4) Trial operation

The method of trial cooling operation

Operate the remote control unit as follows.

1. Starting a cooling test run.

Start the system by pressing the ON/OFF button.

O Select " \clubsuit (Cool)" with the O (MODE) button.

 $\textcircled{3}\ensuremath{\mathsf{Press}}$ the $\fbox{\mathsf{TEST}}$ button for 3 seconds or longer.

The screen display will switch to $\ensuremath{\ensuremath{\mathbb{X}}}\xspace{1.5mu}$ TEST RUN $\ensuremath{\,\mathbb{V}}\xspace{1.5mu}$ "

(a)When the (SET) button is pressed while " $\$ TEST RUN ~ " is indicated, a cooling test run will start.

The screen display will switch to TEST RUN ".

- 2. Ending a cooling test run.
 - Pressing the OON/OFF button, the OON/OFF button the OON/OFF button will end a
 - cooling test run. (Cooling test run will end after 30 minutes pass.)
 - " $\ensuremath{\$}$ TEST RUN " shown on the screen will go off.

(4) Trial operation (Continued)

Checking operation data

Operation data can be checked with remote control unit operation.

- 1. Press the CHECK button. The display change " OPER DATA V "
- 2. Press the O (SET) button while OPER DATA 🛛 🔻 " is displayed.
- 3. When only one indoor unit is connected to remote control, " DATA I NADING " is displayed (blinking indication during data loading).
- Next, operation data of the indoor unit will be displayed. Skip to step 7.
- 4. When plural indoor units is connected, the smallest address number of indoor unit among all connected indoor unit is displayed. [Example]: \textcircled SELECT I/U " (blinking 1 seconds)→
- I/U000 "blinking.
- 5. Select the indoor unit number you would like to have data displayed with the button.
- 6. Determine the indoor unit number with the (SET) button.

(The indoor unit number changes from blinking indication to continuous indication) I/U000 " (The address of selected indoor unit is blinking for 2 seconds.)

Ţ

" <code>DATALOADING</code> " (A blinking indication appears while data loaded.)

- Next, the operation data of the indoor unit is indicated.
- 7. Upon operation of the 🚺 🔽 button, the current operation data is displayed in order from data number 01.

02 SET TEMP

02 SETTERP_ 03 RETURN AIR. 04 ■SENSOR_ 05 THI-R1_ 06 THI-R2_ 07 THI-R3_
08 I/U FANSPEED_ 09 DEMAND_Hz 10 ANSWFR H-

26 27

31 32 <u>SH___</u>c TDSH___c

35 6

36 DEFROST 37 TOTAL POL

DEMAND _____Hz ANSWER _____Hz

_MPa

(Set Temperature)

(Return Air Temperature (Remote Control Thermistor) (Indoor Unit Heat Exchanger The

(Indoor Unit Heat Exchanger Them

(Indoor Unit Fan Speed

(Response Frequency) (Pulse of Indoor Unit Ex

State No. of The Co

 27
 Td____C
 (Discharge Pipe Temperature)

 28
 COMP BOTTOM__C
 (Comp Bottom Temperature)

Couper Heat)
 Couper Heat)
 Couper Heat)
 TDSH___C
 (Discharge Pipe Super Heat)
 PROTECTION No, ___(Protection State No. of The C
 A
 O/U FAINSPEED___(Outdoor Unit Fain Speed)
 COULD

 36
 DEFROS
 (Derrost Control OrVol)

 37
 TOTAL COMP RUN_H (Total Running Hours)

 38
 0./U EEVI_P (Pulse of The Outdoor Unit E

 39
 0./U EEV2_P (Pulse of The Outdoor Unit E

(63H1 On/Off)

ng on outdoor unit model, there are data not sho

(Defrost Control On/Off

H (Total Running Hours of The Com

 29
 CT____AMP
 (Current)

 30
 TARGET SH____C (Target Super Heat)

- The items displayed are in the above table.
- *Depending on models, the items that do not have corresponding data are not displayed.
- 8. To display the data of a different indoor unit, press the AIR CON NO.] button, which allows you to go back to the indoor unit selection screen.
- 9. Pressing the OON/OFF button will stop displaying data.
- Pressing the (RESET) button during remote control unit operation will undo your last operation and allow you to go back to the previous screen


OIf two (2) remote control are connected to one (1) inside unit, only the master control is available for trial operation and confirmation of operation data. (The slave remote control is not available.)

5 Control mode switching

The control content of indoor units can be switched in following way.

Switch No. Control Content					
SW2	Indoor	Indoor unit address (0-Fh)			
SW5-1	Maste	Master/Slave Switching (plural /Slave unit Setting)			
SW5-2	Maste	(blave ownening (plata /blave unit octang)			
SW6-1~4	Model	capacity setting			
SW7 - 1	ON	Operation check, Drain motor test run			
0111	OFF	OFF Normal operation			

©Function of CNT connector of indoor printed circuit board ote (1) 0.3 mm²×2m o not use the length over 2 m 0.75 mm²×0.2m



⑦Troubleshooting

The operation data is saved when the situation of abnormal operation happen, and the data can be confirmed by remote control.

Error Code of indoor unit

Display on remote	LED on indoo	r circuit board	Content
control	red (checking)	green (normal)	Content
	Off	Continuous blinking	Normal
Off	Off	Off	Fault on power, indoor power off or lack phase
E1	Off	Continuous blinking	Fault on the transmission between indoor circuit board and remote control
	Not sure	Not sure	Indoor computer abnormal
E5	Blinking twice	Continuous blinking	Fault on outdoor-indoor transmission
E6	Blinking once	Continuous blinking	Indoor heat exchange sensor interrupted or short-circuit
E7	Blinking once	Continuous blinking	Indoor air inhaling sensor broken or short-circuit
E8	Blinking once	Continuous blinking	The temperature of heat exchange abnormal
E9	Blinking once	Continuous blinking	Float SW actions (only with FS)
E10	Off	Continuous blinking	Excess number of remote control connections
E14	Blinking for three times	Continuous blinking	The communication fault for master/slave indoor units
E16	Blinking once	Continuous blinking	Fan motor abnormal
E19	Blinking once	Continuous blinking	Configuration fault on running checking model
E28	Off	Continuous blinking	Remote control sensor interrupted
0 ver E30	Off	Continuous blinking	Outdoor unit checking (outdoor circuit board LED checking)

[Operating procedure]

- 1. Press the CHECK button.
- The display change " OPER DATA 🛛 🔻 "
- 2. Once, press the 💌 button, and the display change

ERROR DATA

- 3. Press the O (SET) button and abnormal operation data mode is started.
- 4. When only one indoor unit is connected to remote control, following is displayed.
- (1)The case that there is history of abnormal operation.
- \rightarrow Error code and " DATA LOADING " is displayed.
- [Example]: [E8] (ERROR CODE)
- " DATA LOADING" is displayed (blinking indication during data loading).
- Next, the abnormal operation data of the indoor unit will be displayed. Skip to step 8.
- (2) The case that there is not history of abnormal operation.
- → " NO FRROR " is displayed for 3 seconds and this mode is closed.
- 5. When plural indoor units is connected, following is displayed.
- (1)The case that there is history of abnormal operation.
- → Error code and the smallest address number of indoor unit among all connected indoor unit is displayed.
- [Example]: [E8] (ERROR CODE)
- " I/U000 🛓 " blinking
- $\textcircled{2}\$ The case that there is not history of abnormal operation. → Only address number is displayed.
- 6. Select the indoor unit number you would like to have data displayed with the 🔺 💌
- hutton
- 7. Determine the indoor unit number with the O (SET) button. [Example]: [E8] (ERROR CODE)
- I/U000 ▲ " (The address of selected indoor unit is blinking for 2 seconds.)

[E8] " DATA LOADING " (A blinking indication appears while data loaded.)

Next, the abnormal operation data is indicated.

If the indoor unit doing normal operation is selected, " NO FRROR " is displayed for 3 seconds and address of indoor unit is displayed.

- 8. By the **A V** button, the abnormal operation data is displayed. Displayed data item is based on (4) Trial operation
- *Depending on models, the items that do not have corresponding data are not displayed. 9. To display the data of a different indoor unit, press the AIR CON No. button, which allows
- you to go back to the indoor unit slection screen. 10.Pressing the ON/OFF button will stop displaying data.

Pressing the (RESET) button during remote control unit operation will undo your last operation and allow you to go back to the previous screen.


Olf two (2) remote control are connected to one (1) indoor unit, only the master control is available for trial operation and confirmation of operation data. (The slave remote control is not available)

PJA012D730

11.3 Installation of wired remote control (option)

(1) Model RC-E5


Read together with indoor unit's installation manual.




Insert a flat-blade screwdriver into the dented part of the upper part of the remote control, and wrench slightly.

[In case of embedding cord]

③ Embed the erectrical box and remote control cord beforehand.




Prepare two M4 screws (recommended length is 12-16mm) on site, and install the lower case to erectrical box. Choose either of the following two positions in fixing it with screws.





- Connect the remote control cord to the terminal block. Connect the terminal of remote control (X,Y) with the terminal of indoor unit (X,Y). (X and Y are no polarity)
- Install the upper case as before so as not to catch up the remote control cord, and tighten with the screws.

[In case of exposing cord]


- ③ You can pull out the remote control cord from left upper part or center upper part. Cut off the upper thin part of remote control lower case with a nipper or knife, and grind burrs with a file etc.
- ④ Install the lower case to the flat wall with attached two wooden screws.







The wiring inside the remote control case should be within 0.3mm² (recommended) to 0.5mm². The sheath should be peeled off inside the remote control case. The peeling-off length of each wire is as below.



- Install the upper case as before so as not to catch up the remote control cord, and tighten with the screws.
- In case of exposing cord, fix the cord on the wall with cord clamp so as not to slack.


Installation and wiring of remote control

- Wiring of remote control should use 0.3mm² × 2 core wires or cables. (on-site configuration)
- ② Maximum prolongation of remote control wiring is 600 m.
- If the prolongation is over 100m, change to the size below.

But, wiring in the remote control case should be under 0.5mm². Change the wire size outside of the case according to wire connecting. Waterproof treatment is necessary at the wire connecting section. Be careful about contact failure.

Master/ slave setting when more than one remote controls are used

A maximum of two remote controls can be connected to one indoor unit (or one group of indoor units.)



Set SW1 to "Slave" for the slave remote control. It was factory set to "Master" for shipment.

Note: The setting "Remote control thermistor enabled" is only selectable with the master remote control in the position where you want to check room temperature.

The air conditioner operation follows the last operation of the remote control regardless of the master/ slave setting of it.


The indication when power source is supplied

When power source is turned on, the following is displayed on the remote control until the communication between the remote control and indoor unit settled.

Master remote control : " @WAIT@	Μ"
Slave remote control : "	S"

At the same time, a mark or a number will be displayed for two seconds first.

This is the software's administration number of the remote control, not an error cord.



When remote control cannot communicate with the indoor unit for half an hour, the below indication will appear.

Check wiring of the indoor unit and the outdoor unit etc.

The range of temperature setting

When shipped, the range of set temperature differs depending on the operation mode as below.

Heating : 16~30°C (55~86°F)

Except heating (cooling, fan, dry, automatic) : 18~30°C (62~86°F)

Oupper limit and lower limit of set temperature can be changed with remote control.

Upper limit setting: valid during heating operation. Possible to set in the range of 20 to 30°C (68 to 86°F). Lower limit setting: valid except heating (automatic, cooling, fan, dry) Possible to set in the range of 18 to 26°C (62 to 79°F).

When you set upper and lower limit by this function, control as below.

1. When (2) TEMP RANGE SET, remote control function of function setting mode is "INDN CHANGE" (factory setting), [If upper limit value is set]

During heating, you cannot set the value exceeding the upper limit.

[If lower limit value is set]

During operation mode except heating, you cannot set the value below the lower limit.

2. When 0 TEMP RANGE SET, remote control function of function setting mode is "NO INDN CHANGE" [If upper limit value is set]

During heating, even if the value exceeding the upper limit is set, upper limit value will be sent to the indoor unit. But, the indication is the same as the temperature set.

[If lower limit value is set]


During except heating, even if the value lower than the lower limit is set, lower limit value will be sent to the indoor unit. But, the indication is the same as the temperature set.

How to set upper and lower limit value

1. Stop the air-conditioner, and press O (SET) and C (MODE) button at the same time for over three seconds.

The indication changes to "FUNCTION SET ▼".

- 2. Press **▼** button once, and change to the "TEMP RANGE ▲ " indication.
- 3. Press O (SET) button, and enter the temperature range setting mode.
- 4. Select "UPPER LIMIT ▼ " or "LOWER LIMIT ▲ " by using ▲ ▼ button.
- 5. Press <u>(SET)</u> button to fix.
- When "UPPER LIMIT ▼ " is selected (valid during heating)
- ① Indication: " $⊕ \lor \land$ SET UP" → "UPPER 30°C ∨"
 - ② Select the upper limit value with temperature setting button \bigtriangledown . Indication example: "UPPER 26°C $\lor \land$ " (blinking)
 - ③ Press <u>○</u>(SET) button to fix. Indication example: "UPPER 26°C" (Displayed for two seconds) After the fixed upper limit value displayed for two seconds, the indication will return to "UPPER LIMIT ▼".
- 7. When "LOWER LIMIT ****" is selected (valid during cooling, dry, fan, automatic)
 - (1) Indication: " $\textcircled{b} \lor \land$ SET UP" \rightarrow "LOWER 18°C \land "
 - (2) Select the lower limit value with temperature setting button \square \square . Indication example: "LOWER 24°C $\lor \land$ " (blinking)
 - ③ Press (SET) button to fix. Indication for example: "LOWER 24°C" (Displayed for two seconds) After the fixed lower limit value displayed for two seconds, the indication will return to "LOWER LIMIT ▼".
- 8. Press ON/OFF button to finish.



ocedure of functional setting	itial setting marked "(ng is shown as the fol	lowing o	liagram.			
of function setting]			1		
: Stop air-conditioner and pro			seconds. Record and keep the setting			
: Press "O" (SET) butt : Press "Ø" (RESET) b						
: Press 🔺 💌 button.	Julion.		Consult the technical data etc. for each co	entrol dotails		
: Press ON/OFF button. ble to finish above setting or	n the way,					
ished change of setting is ur tial settings utomatic criterion	available.	Ū	top air-conditioner and press .(SET) + (豆).(MODE) buttons same time for over three seconds.			
		L	FUNCTION SET V			Tor
0N ▼ (Remote control fu	nction)					Ton
Function	,					
01 600 ESP SET	setting 6000 ESP VALID		Validate setting of ESP:External Static Pressure			
02 AUTO RUN SET	600 ESP INVALID		Invalidate setting of ESP			
	AUTO RUN ON AUTO RUN OFF	× ×	Automatical operation is impossible			
03 🖾 TEMP SW	SIZE VALID		Automatical operation is impossible			
04 📼 MODE SW	SIZE INVALID	Ť	Temperature setting button is not working			
	8년 VALID 8년 INVALID	10	Mode button is not working			
05 1 ON/OFF SW	50 VALID		Mode batton is not working			
06 [5월] FAN SPEED SW	SO INVALID		On/Off button is not working			
	6년 VALID 6년 1981 INVALID	× ×	Fan speed button is not working			
07 🖾 LOUVER SW	See VALID	 %	Fail speed button is not working			
08 © TIMER SW	SE INVALID	*	Louver button is not working			
06 100 1100 300	ତ୍ତି VALID ତ୍ରତି INVALID	0	Times button is not working			
09 SENSOR SET	SENSOR OFF		Timer button is not working			
	SENSOR ON		Remote thermistor is not working. Remote thermistor is working.	0 in the second se		
	SENSOR +3.0%		Remote thermistor is working, and to be set for producing +3.0° Remote thermistor is working, and to be set for producing +2.0°	C increase in temperature.		
	ESENSOR + 1.0%		Remote thermistor is working, and to be set for producing +1.0° Remote thermistor is working, and to be set for producing -1.0°	C increase in temperature.		
	SENSOR -2.0%		Remote thermistor is working, and to be set for producing -2.0*0 Remote thermistor is working, and to be set for producing -3.0*0			
10 AUTO RESTART	INVALID					
* 11 VENT LINK SET	VALID					
	NO VENT	0	In case of Single split series, by connecting ventilation	device to CNT of the		
	VENT LINK		indoor printed circuit board (in case of VRF series, by indoor printed circuit board), the operation of ventilatic operation of indoor unit.	connecting it to CND of t on device is linked with th		
	NO VENT LINK		In case of Single split series, by connecting ventilation device to circuit board (in case of VRF series, by connecting it to CND of	the indoor printed circuit		
12 TEMP RANGE SET	L		board), you can operate /stop the ventilation device independe		n.	
	INDN CHANGE	0	If you change the range of set temperature, the indicat will vary following the control.			
	NO INDN CHANGE		If you change the range of set temperature, the indicat will not vary following the control, and keep the set terr			
13 I/U FAN	HI-MID-LO	*	Airflow of fan becomes of &util- &util- au lor the four spe		¥∎0Ĺ.	
	HI-LO HI-MID	*	Airflow of fan becomes of anti- and. Airflow of fan becomes of anti- anti-			
	1 FAN SPEED	*	Airflow of fan is fixed at one speed.			
14 ⇒,— POSITION	7		If you change the remote control function "14 🖘 POS you must change the indoor function "04 🖘 POSITION			
	4POSITION STOP FREE STOP	0	You can select the louver stop position in the four.			
15 MODEL TYPE	HEAT PUMP		The louver can stop at any position.			
	COOLING ONLY	× ×				
16 EXTERNAL CONTROL SET	INDIVIDUAL		If you input signal into CNT of the indoor printed circu	it board from external, t	he	
	FOR ALL UNITS	Ť	indoor unit will be operated independently according If you input into CNT of the indoor printed circuit board fror	to the input from externa n external, all units which	al.	
17 ROOM TEMP INDICATION SET			connect to the same remote control are operated accordin	g to the input from externa	I.	
	INDICATION OFF INDICATION ON	0	In normal working indication, indoor unit temperature is	indicated instead of airfl	OW.	
18 ※⑲INDICATION			(Only the master remote control can be indicated.)			
	INDICATION ON INDICATION OFF	0	Heating preparation indication should not be indicate	d.		
19 °c/°F SET						
	ľF	10	Temperature indication is by degree C Temperature indication is by degree F			To n

Note 1: The initial setting marked " X " is decided by connected indoor and outdoor unit, and is automatically defined as following table.				
Function No.	Item	Default	Model	
Remote control	AUTO RUN SET	AUTO RUN ON	"Auto-RUN" mode selectable indoor unit.	
function02		AUTO RUN OFF	Indoor unit without "Auto-RUN" mode	
Remote control	ISSIFAN SPEED S₩	കള്ള VALID	Indoor unit with two or three step of air flow setting	
function06		கன INVALID	Indoor unit with only one of air flow setting	
Remote control	ET LOUVER SW	கன VALID	Indoor unit with automatically swing louver	
function07		கன Invalid	Indoor unit without automatically swing louver	
Remote control	I/U FAN	HI-MID-LO	Indoor unit with three step of air flow setting	
function13		HI-LO	Indoor unit with two step of air flow setting	
		HI-MID		
		1 FAN SPEED	Indoor unit with only one of air flow setting	
Remote control	Model Type	Heat Pump	Heat pump unit	
function15		COOLING ONLY	Exclusive cooling unit	


Note 3: As for plural indoor unit, set indoor functions to each master and slave indoor unit. But only master indoor unit is received the setting change of indoor unit function "05 EXTERNAL INPUT" and "06 PERMISSION / PROHIBISHION".

n previous page					Note2: Fan se	tting of "HI	GH SPEED"			
		init No. are indicated only wh	en		Fan t		Indo	oor unit air flow se		
(Indoor unit function	ndoor unit function) I/U FUNCTION A plural indoor units are connected.				F,	(m#+(m# + 1m# - 11m#	8ai - 8ai - 8ai	***** *****	8ad - 8ad	
	I/U000 🔺	Function * 02 FAN SPEED SET	setting		FAN SPEED	STANDARD	UH - Hi - Me - Lo	Hi - Me - Lo	Hi - Lo	Hi - Me
	I/U001 ≑ I/U002 ≑		STANDARD HIGH SPEED 1	× ×	SET	HIGH SPEED1, 2	UH - UH - Hi - Me	UH - Hi - Me	UH - Me	UH - Hi
	I/U003≑		HIGH SPEED 2		Initial function	setting of s	ome indoor unit is "HIGH S			
	1/0004 ≑	* 03 FILTER SIGN SET	INDICATION OFF				set with wireless remote co	ontrol.		
_			TYPE 1 TYPE 2				ter running for 180 hours. ter running for 600 hours.			
	o set other indoor unit, press IRCON NO. button, which		TYPE 3	1	The filter sign is	indicated af	ter running for 1000 hours.	then the indeer up	it will be store	ad bu
	lows you to go back to the inc	loor	TYPE 4		compulsion after		ter running for 1000 hours,	then the indoor un	it will be stopp	ed by
ur	nit selection screen	04 ST POSITION	7				ction "04 🖘 🖓 POSITION"			
(fo	or example: I/U 000 🔺).		4POSITION STOP				e control function "14	PUSITIUN" accordir	ngiy.	
		05 EXTERNAL INPUT	FREE STOP		The louver can s					
			LEVEL INPUT	0						
		06 OPERATION PERMISSION/PROHIBITION	PULSE INPUT							
			INVALID VALID	\square	Dermission/eveki	hitian aantu	al of an availan will be valid			
		* 07 EMERGENCY STOP		'	Permission/prom	DILION CONT	ol of operation will be valid			
			INVALID VALID	$ \circ $	With the VRE co	rice it is us	ed to stop all indoor units c	opported with the	same outdoor	unit immodiate
			THEFE				from remote on-off termina			
			OFFSET +3.0% OFFSET +2.0%				.0°C increase in temperatu			
		¥ 08 ☆ SP OFFSET	OFFSET +1.0℃				.0°C increase in temperatu .0°C increase in temperatu			
			NO OFFSET							
			OFFSET +2.0°c				C increase in return air terr			
		* 09 RETURN AIR TEMP	OFFSET +1.5% OFFSET +1.0%				C increase in return air terr C increase in return air terr			
			ND OFFSET OFFSET - 1.0%	0		-				
			OFFSET -1.5%				C increase in return air tem			
		* 10 ※ FAN CONTROL	OFFSET -2.0%		To be reset producing -2.0°C increase in return air temperature of indoor unit.					
			LOW FAN SPEED				OFF, fan speed is low spe			
			SET FAN SPEED		When heating thermostat is OFF, fan speed is set speed.					
			INTERMITTENCE FAN OFF				OFF, fan speed is operate OFF the fan is stopped	d intermittently.		
			THRON		When heating thermostal is OFF, the fan is stopped. When the remote thermistor is working, "FAN OFF" is set automatically. Do not set "FAN OFF" when the indoor unit's thermistor is working.					
				ľ	Do not set PAN	OFF when	the indoor unit's thermisto	r is working.		
		* 11 FROST PREVENTION TEMP	TEMP HIGH	(Change of indoo	r heat exch	anger temperature to start	frost prevention cor	ntrol.	
			TEMP LOW	0						
		* 12 FROST PREVENTION CONTROL		\	Working only wit	h the Sinale	split series.			
			FAN CONTROL ON FAN CONTROL OFF				he indoor fan tap is raised.			
		* 13 DRAIN PUMP LINK								
			恭心 恭心AND※		Drain pump is ru Drain pump is ru		oling and dry. oling, dry and heating.			
			#o AND☆AND≋		Drain pump is ru	n during co	oling, dry, heating and fan.			
		¥ 14 │ IIII ¥ FAN REMAINING	\$\$ O AND €		Drain pump is ru	n auring co	oling, dry and fan.			
			NO REMAINING 0.5 HOUR				fan does not perform extra			
			1 HOUR				fan perform extra operatio fan perform extra operatio			
		¥ 15 ₩ FAN REMAINING	6 HOUR		After cooling is s	topped, the	fan perform extra operatio	n for six hours.		
			NO REMAINING			eating is stopped or heating thermostat is OFF, the fan does not perform extra op				
			0.5 HOUR 2 HOUR	HOUR After heating is stopped or heating thermostat is OFF, the fan perfor						
		★ 16	6 HOUR	ļ,	After heating is s	topped or h	eating thermostat is OFF,	the fan perform ext	ra operation f	or six hours.
		+ TO Tax metallour more	NO REMAINING	\square	During handle i			the fee sector it		
			20minOFF sminON				 heating thermostat is OFF nty minutes' OFF. 	, the fan perform ir	itermittent ope	eration for five
			sminOFF sminON	1	During heating is	stopped or	heating thermostat is OFF	, the fan perform ir	ntermittent ope	eration for five
		* 17 PRESSURE CONTROL		-	with low fan spee	su aner nve	minutes OFF.			
		·	STANDARD TYPE1	× (Connected "OA	Proceesing	type indoor unit, and is au	tomatically defined		
n previous page			<u>Luna</u>		USINGULEU UAI	100essiriy	type muoor unit, anu is au	tomatioany denned.		

	v to set function Stop air-conditioner and press ○ (SET) र (MODE) buttons at the same time for over three seconds, and the "FUNCTION SET ▼" will be displayed.	Operation message Function description: Function No. unction No. Func
	FUNCTION SET	Fixing button
	Press (SET) button.	Tinishing button
3.	Make sure which do you want to set, "■ FUNCTION ▼" (remote control function) or "I/U FUNCTION▲ " (indoor unit function).	
4.	Press 🛋 or 💌 button.	ARCENT CONTRACT CONTR
	Selecct " FUNCTION ▼ " (remote control function) or "I/U FUNCTION ▲ " (indoor unit function).	
		6 - (® Indoor unit selection button Previous screen button
5.	Press (SET) button.	
6.	[On the occasion of remote control function selection]	[On the occasion of indoor unit function selection]
	DATA LOADING" (Indication with blinking)	\odot "DATA LOADING" (Blinking for 2 to 23 seconds to read the data) \downarrow
	Display is changed to "01 & 🗹 🖂 ESP SET".	Indication is changed to "02 FAN SPEED SET". Go to ②.
	 Press or button. "No. and function" are indicated by turns on the remote control 	[Note]
	function table, then you can select from them. (For example)	 If plural indoor units are connected to a remote control, the indication is "I/U 000" (blinking) ← The lowest number of
		the indoor unit connected is indicated.
	AUTO RUN SET Function	
	③ Press ◯_(SET) button. The current setting of selected function is indicated. (for example) "AUTO RUN ON" ← If "02 AUTO RUN SET" is selected	(2) Press ▲ or ▼ button. Select the number of the indoor unit you are to set If you select "ALL UNIT ▼", you can set the same setting with
	AUTO RUN ON <	all unites. (3) Press O(SET) button.
	 Press ▲ or ▼ button. Select the setting. 	Press or triangle button. "No. and function" are indicated by turns on the indoor unit function table, then you can select from them.
		(For example)
	AUTO RUN OFF S Press ◯ (SET)	③ Press ○ (SET) button. The current setting of selected function is indicated. (For example) "STANDARD" ← If "02 FAN SPEED SET" is selected.
	"SET COMPLETE" will be indicated, and the setting will be completed.	
	Then after "No. and function" indication returns, Set as the	STANDARD < Setting
	same procedure if you want to set continuously ,and if to finish, go to 7.	④ Press or button.
		Select the setting.
	SET COMPLETE	③ Press 〇)(SET) button. "SET COMPLETE" will be indicated, and the setting will be
7	Press ON/OFF button.	completed. Then after "No. and function" indication returns, set as the same procedure if you want to set continuously, and if to finish, go to 7.
	Setting is finished.	SET COMPLETE
		When plural indoor units are connected to a remote control, press the <u>AIRCON NO.</u> button, which allows you to go back to the indoor unit selection screen. (example "I/U 000 ▲*)
	 It is possible to finish by pressing ON/OFF butt unavailable. During setting, if you press ((RESET) but Setting is memorized in the control and it is save 	tton, you return to the previous screen.
	[How to check the current setting] When you select from "No. and funcion" and press set button setting. (But, if you select "ALL UNIT ▼ ", the setting of the lowest nu	by the previous operation, the "Setting" displayed first is the current mber indoor unit is displayed.)
1		

PJZ012D077

eco touch REMOTE CONTROL RC-EX1A INSTALLATION MANUAL



1. Safety Precautions

This installation manual describes the installation methods and precautions related to the remote control. Use this manual together with the user's manuals for the indoor unit, outdoor unit and other optional equipment. Please read this manual carefully before starting the installation work to install the unit properly.

Safety precautions

Please read this manual carefully before starting installation work to install the unit properly. Every one of the followings is important information to be observed strictly.

Failure to follow these instructions properly may result in serious consequences such as death, severe injury, etc
Failure to follow these instructions properly may cause injury or property damage.

It could have serious consequences depending on the circumstances.

•The following pictograms are used in the text.



Never do.



Always follow the instructions given.

•Keep this manual at a safe place where you can consult with whenever necessary. Show this manual to installers when moving or repairing the unit. When the ownership of the unit is transferred, the "Installation Manual" should be given to a new owner.

Ask a professional contractor to carry out installation work according to the installation manual. Improper installation work may result in electric shocks, fire or break-down.

Shut OFF the main power supply before starting electrical work.

Otherwise, it could result in electric shocks, break-down or malfunction.

Do not install the unit in appropriate environment or where inflammable gas could generate, flow in, accumulate or leak.

If the unit is used at places where air contains dense oil mist, steam, organic solvent vapor, corrosive gas (ammonium, sulfuric compound, acid, etc) or where acidic or alkaline solution, special spray, etc. are used, it could cause electric shocks, break-down, smoke or fire as a result of significant deterioration of its performance or corrosion.

Do not install the unit where water vapor is generated excessively or condensation occurs. It could cause electric shocks, fire or break-down.

Use the specified cables for wiring, and connect them securely with care to protect electronic parts from external forces.

Improper connections or fixing could cause heat generation, fire, etc.

Seal the inlet hole for remote control cable with putty.

If dew, water, insect, etc. enters through the hole, it could cause electric shocks, fire or break-down.

When installing the unit at a hospital, telecommunication facility, etc., take measures to suppress electric noises.

It could cause malfunction or break-down due to hazardous effects on the inverter, private power generator, high frequency medical equipment, radio communication equipment, etc.

The influences transmitted from the remote control to medical or communication equipment could disrupt medical activities, video broadcasting or cause noise interference.

Do not install the remote control at following places.

It could cause break-down or deformation of remote control.

- (1) Where it is exposed to direct sunlight
- (2) Near the equipment to generate heat
- (3) Where the surface is not flat

Do not leave the remote control with its upper case removed.

When the upper case is removed, put it in a packing box or packing bag to protect internal PCBs or other parts from dust, moisture, etc.

2. Accessories & Prepare on site

Accessories

R/C main unit, wood screw (ø3.5 x 16) 2 pcs User's Manual, Installation Manual

Parts procured at site

Item name	Q'ty	Remark
Switch box For 1 piece or 2 pieces (JIS C8340 or equivalent)	1	These are not required when installing
Thin wall steel pipe for electric appliance (JIS C8305 or equivalent)	As required	directly on a wall.
Lock nut, bushing (JIS C8330 or equivalent)	As required	
Lacing (JIS C8425 or equivalent)	As required	Necessary to run R/C cable on the wall.
Putty	Suitably	For sealing gaps
Molly anchor	As required	
R/C cable (0.3 mm ² x 2 pcs)	As required	See right table when longer than 100 m

When the cable length is longer than 100 m, the max size for wires used in the R/C case is 0.5 mm^2 . Connect them to wires of larger size near the outside of R/C. When wires are connected, take measures to prevent water, etc. from entering inside.

< 200 m	0.5 mm ² x 2-core
< 300 m	0.75 mm ² x 2-core
< 400 m	1.25 mm ² x 2-core
< 600 m	2.0 mm ² x 2-core

3. Remote control installation procedure


Determine where to install the remote control

Installation	"Using a switch box"	
	"Installed directly on a wall"	
Wiring direction	"Backward"	
	"Upper center", "Upper left"	

Cautions for selecting installation place

- (1) Installation surface must be flat and sufficiently strong. R/C case must not be deformed.
- (2) Where the R/C can detect room temperatures accurately. This is a must when detecting room temperatures with the temperature sensor of R/C.
 - \cdot Install the R/C where it can detect the average temperature in the room.
 - · Install the R/C separated from a heat source sufficiently.
 - Install the R/C where it will not be influenced by the turbulence of air when the door is opened or closed.

Select a place where the R/C is not exposed to direct sunlight or blown by winds from the air conditioner or temperatures on the wall surface will not deviate largely from actual room temperature.



Request

Be sure not to install R/C at a place where temperatures around the installation surface of R/C may differ largely from actual room temperature.


Difference between detected temperature and actual room temperature could cause troubles. The correction for detected temperature by the R/C cannot offset such temperature difference because it corrects the detected temperatures itself.

Request

Do not install the R/C at a place where it is exposed to direct sunlight or where surrounding air temperature exceeds 40° C or drops below 0° C.

It could cause discoloration, deformation, malfunction or breakdown.

Installation procedure



- ① To remove the upper case from the bottom cases of R/C
 - \cdot Insert the tip of flat head screwdriver or the like in the recess at the lower part of R/C and twist it lightly to remove.

Take care to protect the removed upper case from moisture or dust.

② Connect wires from X and Y terminals of R/C to X and Y terminals of indoor unit.


R/C wires (X, Y) have no polarity.

In case of embedding wiring (When the wiring is retrieved "Backward")

③ Embed the switch box and the R/C wires beforehand.

Seal the inlet hole for the R/C wiring with putty. If dust or insect enters, it could cause electric shocks, fire or breakdown.

PCB side (Viewed from rear)



Switch box

Seal with putty


R/C cable


200

Bushing

<u>50</u> 8

-126 -





⑦ Install the top case with care not to pinch wires of R/C.



LA A I


6888


Main-Sub setting for use of two or more R/Cs

Up to two units of R/C can be used at the maximum for 1 indoor unit or 1 group.


One is main R/C and the other is sub R/C.

Operating range is different depending on the main or sub R/C.





R/C function	Main	Sub
Run/Stop, setting temperature, fan speed and flap direction operations	0	0
High power and energy-saving operations	0	0
Energy-saving setting	0	—
R/C sensor	0	_
Test run menu operation	\bigcirc	—
Room temperature range setting	0	_
Indoor unit settings	\bigcirc	—
Individual flap control	0	—
Operation data display	0	_
Error history display	0	0



Note: Connection to personal computer

It can be set from a personal computer via the USB port (mini-B). Connect after removing the cover for USB port of upper case.

Replace the cover after use.



If dust, insect, etc. enters, it could cause electric shocks or breakdown.


Special software is necessary for the connection.

For details, view the web site or refer to the engineering data.

Do not connect to a personal computer

without using the special software.


Do not connect the personal computer to the USB simultaneously with other USB devices. It could cause malfunction or breakdown of R/C or personal computer.



Note: Initializing of password

Administrator password (for daily setting items) and service password (for installation, test run and maintenance) are used.

- O The administrator password at factory default is "0000". This setting can be changed (Refer to User's Manual). When the administrator password is forgotten, it can be initialized, if the [Highpower] and the [Energy-saving] buttons are pushed simultaneously for 5 seconds on the administrator password input screen.
- Service password is "9999", which cannot be changed.
 When the administrator password is input, the service password is also accepted.



Note: Combination of R/C and indoor unit

(1) It can be used as the combination of Main and Sub with RC-E3 to -E5 type of wireless R/C (option part).

(2) It can be combined with FD-V or FD-KX E6 type and later types of indoor units

(3) In cases of combination with FD-V or FD-KX E6 type unit, there are some controlling items which cannot be used. If operating such items, the message "Invalid request" is displayed.

For details, refer to the installation manual attached to the remote control.

11.4 Installation of outdoor unit

Model FDC71VNP

R410A REFRIGERANT USED

PCA012D057B

- This installation manual deals with outdoor units and general installation specifications only. For indoor units, refer to page 72.
- When install the unit, be sure to check whether the selection of installation place, power supply specifications, usage limitation (piping length, height differences between indoor and outdoor units, power supply voltage and etc.) and installation spaces.

SAFETY PRECAUTIONS

- Read the "SAFETY PRECAUTIONS" carefully first of all and strictly follow it during the installation work in order to protect yourself.
- The precautionary items mentioned below are distinguished into two levels, WARNING and CAUTION. For installing qualified personnel, take precautions in respect to themselves by using suitable protective WARNING : Wrong installation would cause serious consequences such as injuries or death.
- **CAUTION** : Wrong installation might cause serious consequences depending on circumstances. Both mentions the important items to protect your health and safety so strictly follow them by any means.
- Be sure to confirm no anomaly on the equipment by commissioning after completed installation and explain the The meanings of "Marks" used here are shown as follows:
- Keep the installation manual together with owner's manual at a place where any user can read at any time. Moreover if necessary, ask to hand them to a new user.
- clothing, groves, etc., and then perform the installation works.
- Please pay attention not to fall down the tools, etc. when installing the unit at the high position. • If unusual noise can be heard during operation, consult the dealer.
- operating methods as well as the maintenance methods of this equipment to the user according to the owner's manual.
 - \bigcirc 09 Never do it under any circumstances. Always do it according to the instruction. **M WARNING**

	 Installation must be carried out by the qualified installer. If you install the system by yourself, it may cause serious trouble such as water leaks, electric shocks, fire and personal injury, as a result of a system matinuction. Do not carry out the installation and maintenance work except by the qualified installer. Install the system in full accordance with the installation manual. Incorrect installation may cause bursts, personal injury, water leaks, electric shocks and fire. Be sure to use only for household and residence. If this appliance is installed in inferior environment such as machine shop and etc., it can cause malfunction. When installing in small rooms, take prevention measures not to exceed the density limit of refrigerant in the event of leakage, referred by the formula (accordance with ISO5149). If the density of refrigerant exceeds the limit, please consult the dealer and install the ventilation system, otherwise lack of oxygen can occur, which can cause serious accident. Use the original accessories and the specified components for installation. If parts other than those prescribed by us are used, it may cause water leaks, electric shocks, fire and personal injury. Install the unit in a location with good support. Unsuitable installation locations can cause the unit to fall and cause material damage and personal injury. Ensure the unit is stable when installed, so that it can withstand earthquakes and strong winds. Unsuitable installation locations can cause the unit to fall and cause material damage and personal injury. 	If the refrigerant comes into contact with naked flames, poisonous gas is produced. Use the prescribed pipes, flare nuts and tools for R410A. Using existing parts (for R22 or R407C) can cause the unit failure and serious accidents due to burst of the refrigerant circuit. Tighten the flare nut by torque wrench with specified method. If the flare nut were tightend with excess torque, this may cause burst and refrigerant leakage after a long period. Do not open the operation valves for liquid line and gas line until completed refrigerant piping work, air tightness test and evacuation. If the compressor is operated in state of opening operation valves before completed connection of refrigerant piping work, air can be sucked into refrigerant. The electrical installation must be carried out by the qualified electrician in accordance with "the norm for electrical work" and "national wiring regulation", and the system must be connected to the dedicated circuit. Power supply with insufficient capacity and incorrect function done by improper work can cause electric shocks and fire. Be sure to shut off the power before starting electrical work. Failure to shut off the power can cause electric leak, anomalous heat production or fire. This appliance must be connected to main power supply by means of a circuit breaker or switch (fuse:20A) with a contact separation of at least 3mm. Arrange the wiring in the control box so that it cannot be pushed up further into the box. Install the service panel correctly.	 Incorrect installation may result in overheating and fire. Use the prescribed cables for electrical connection, tighten the cables securely in terminal block and relieve the cables correctly to prevent overloading the terminal blocks. Loose connections or cable mountings can cause anomalous heat production or fire Be sure to fix up the service panels. Incorrect fixing can cause electric shocks or fire due to intrusion of dust or water. Be sure to switch off the power supply in the event of installation, inspection or servicing. If the power supply is not shut off, there is a risk of electric shocks, unit failure or personal injury due to the unexpected start of fan. Stop the compressor before removing the pipe after shutting the service valve on pump down work. If the power supply is not shut off, there is a risk of electric use cables cables and injury due to the unexpected start of fan. Stop the compressor before removing the pipe after shutting the service valve on pump down work. If the pipe is removed when the compressor is in operation with the service valve open, air would be mixed in the refrigeration circuit and it could cause explosion and injuries due to abnormal high pressure in the cooling cycle. Only use prescribed optional parts. The installation must be carried out by the qualified installer. If you install the system by yourself, it can cause serious trouble such as water leaks, electric shocks, fire. Be sure to wear protective goggles and gloves while at work. Earth leakage breaker must be installed. If the earth leakage breaker must be installed. If the earth leakage breaker must be installed. If the earth leakage breaker is not installed, it can cause electric shocks. Appliance is not to be used by children or persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they hav
S	 Ensure that no air enters in the refrigerant circuit when the unit is installed and removed. If air enters in the refrigerant circuit, the pressure in the refrigerant circuit becomes too high, which can cause burst and personal injury. Do not processing, splice the power cord, or share a socket with other power plugs. This may cause fire or electric shock due to defecting contact, defecting insulation and over-current etc. 	 Do not bundling, winding or processing for the power cord. Or, do not deforming the power plug due to tread it. This may cause fire or heating. Do not run the unit with removed panels or protections. Touching rotating equipments, hot surfaces or high voltage parts can cause personal injury due to entrapment, burn or electric shocks. 	 Do not perform any change of protective device itself or its setup condition. The forced operation by short-circuiting protective device of pressure switch and temperature controller or the use of non specified component can cause fire or burst.

Ð	• Carry out the electrical work for ground lead with care. Do not connect the ground lead to the gas line, water line, lightning conductor or telephone line's ground lead. Incorrect grounding can cause unit faults such as electric shocks due to short-circuiting.						
	 Use the circuit breaker for all pole correct capacity. Circuit breaker should be the one that disconnect all poles under over current. Using the incorrect circuit breaker, it can cause the unit malfunction and fire. Install isolator or disconnect switch on the power supply wiring in accordance with the local codes and regulations. The isolator should be locked in OFF state in accordance with EN60204-1. After maintenance, all wiring, wiring ties and the like, should be returned to their original state and wiring route, and the necessary clearance from all metal parts should be secured. Secure a space for installation, inspection and maintenance specified in the manual. Insufficient space can result in accident such as personal injury due to falling from the installation place. 	 Take care when carrying the unit by hand. If the unit weights more than 20kg, it must be carried by two or more persons. Do not carry by the plastic straps, always use the carry handle when carrying the unit by hand. Use gloves to minimize the risk of cuts by the aluminum fins. Dispose of any packing materials correctly. Any remaining packing materials can cause personal injury as it contains nails and wood. And to avoid danger of suffocation, be sure to keep the plastic wrapper away from children and to dispose after tear it up. Be sure to insulate the refrigerant pipes so as not to condense the ambient air moisture on them. Insufficient insulation can cause condensation, which can lead to moisture damage on the ceiling, floor, furniture and any other valuables. 	 When perform the air conditioner operation (cooling or drying operation) in which ventilator is installed in the room. In this case, using the air conditioner in parallel with the ventilator, there is the possibility that drain water may backflow in accordance with the room lapse into the negative pressure status. Therefore, set up the opening port such as incorporate the air into the room that may appropriate to ventilation (For example; Open the door a little). In addition, just as above, so set up the opening port if the room lapse into negative pressure status due to register of the wind for the high rise apartment etc. 				
$\overline{\otimes}$	 Do not install the unit in the locations listed below. Locations where carbon fiber, metal powder or any powder is floating. Locations where any substances that can affect the unit such as sulphide gas, chloride gas, acid and alkaline can occur. Vehicles and ships. Locations where cosmetic or special sprays are often used. Locations where cosmetic or special sprays are often used. and interfect the unit such as kitchen and machine plant. Locations with direct exposure of oil mist and steam such as kitchen and machine plant. Locations with salty atmospheres such as coastlines. Locations with salty atmospheres such as coastlines. Locations with salty atmospheres such as coastlines. Locations with anound). Locations with any snow (If installed, be sure to provide base flame and snow hood mentioned in the manual). Locations with altitude (more than 1000m high). Locations with altitude (more than 1000m high). Locations with altitude (more than 1000m high). Locations with aclation form other heat source can affect the unit. Locations with avait acades which can prevent inlet and outlet air of the unit. Locations wither short circuit of air can occur (in case of multiple units installation). Locations where something located above the unit could fall. It can cause remarkable decrease in performance, corrosion and damage of components, malfunction and fire. 	 Do not install the outdoor unit in the locations listed below. Locations where discharged hot air or operating sound of the outdoor unit can bother neighborhood. Locations where vultet air of the outdoor unit blows directly to an animal or plants. The outlet air can affect adversely to the plant etc. Locations where vibration can be amplified and transmitted due to insufficient strength of structure. Locations where vibration and operation sound generated by the outdoor unit can affect seriously (on the wall or at the place near bed room). Locations where vibration and operation sound generated by the outdoor unit can affect seriously (on the wall or at the place near bed room). Locations where an equipment affected by high harmonics is placed (TV set or radio receiver is placed within 5m). Locations where drainage cannot run off safely. It can affect surrounding environment and cause a claim. Do not install the unit near the location where leakage of combustible gases can occur. If leaked gases accumulate around the unit, it can cause fire. Do not install the unit where corrosive gas (such as suffurous acid gas etc.) or combustible gas (such as thinner and petroleum gases) can accumulate or collect, or where volatile combustible substances are handled. Corrosive gas can cause corrosion of heat exchanger, breakage of plastic parts and etc. And combustible gas can cause orrosion of heat exchanger. Do not install no use the system close to the equipment that generates electromagnetic fields or high frequency acquipments and telecommunication equipments can affect medical equipment and telecommunication equipments can alor ation eause and and cause malfunctions and breakdowns. The system can also affect medical equipment and telecommunication equipment and substruct its function or cause jamming. 	 Do not install the outdoor unit in a location where insects and small animals can inhabit. Insects and small animals can enter the electric parts and cause damage or fire. Instruct the user to keep the surroundings clean. Do not use the base flame for outdoor unit which is corroded or damaged due to long periods of operation. Using an old and damage base flame can cause the unit falling down and cause personal injury. Do not use any materials other than a fuse with the correct rating in the location where fuses are to be used. Connecting the circuit with copper wire or other metal thread can cause unit failure and fire. Do not touch any buttons with wet hands. It can cause electric shocks. Do not touch the refrigerant pipes with your hands when the system is in operation. During operation the refrigerant pipes become extremely hot or extremely cold depending the operating condition, and it can cause burn injury. Do not touch the suction or aluminum fin on the outdoor unit. This may cause damage the objects or injury due to falling to the object. Do not use the unit for special purposes such as storing foods, cooling precision instruments and preservation of animals, plants or art. Do not clean up the unit with water. 				

Notabilia as a unit designed for R410A

• Do not use any refrigerant other than R410A. R410A will rise to pressure about 1.6 times higher than that of a conventional refrigerant.

A cylinder containing R410A has a pink indication mark on the top.


• A unit designed for R410A has adopted a different size indoor unit operation valve charge port and a different size check joint provided in the unit to prevent the charging of a wrong refrigerant by mistake. The processed dimension of the flared part of a refrigerant pipe and a flare nut's parallel side measurement have also been altered to raise strength against pressure. Accordingly, you are required to arrange dedicated R410A tools listed in the table on the left before installing or servicing this unit.

- Do not use a charge cylinder. The use of a charge cylinder will cause the refrigerant composition to change, which results in performance degradation.
- In charging refrigerant, always take it out from a cylinder in the liquid phase.
- All indoor units must be models designed exclusively for R410A. Check connectable indoor unit models in a catalog, etc. (A wrong indoor unit, if connected into the system, will impair proper system operation)

(Check before installation work)

Model name and power source
 Refrigerant piping length

Piping, wiring and miscellaneous small parts
Indoor unit installation manual



	Option parts	Q'ty
a	Sealing plate	1
b	Sleeve	1
0	Inclination plate	1
9	Putty	1
Ð	Drain hose (extension hose)	1
f)	Piping cover	1
-	(for insulation of connection piping)	1

	Necessary tools for the installation work		Wrench key (Hexagon) [4m/m]
Necessary tools for the installation work		10	Vacuum pump
1	Plus headed driver	11	Vacuum pump adapter (Anti-reverse flow type)
2	Knife	1''	(Designed specifically for R410A)
3	Saw	12	Gauge manifold (Designed specifically for R410A)
4	Tape measure	13	Charge hose (Designed specifically for R410A)
5	Hammer	14	Flaring tool set (Designed specifically for R410A)
6	Spanner wrench	15	Gas leak detector (Designed specifically for R410A)
7	Torque wrench [14.0~82.0N·m (1.4~8.2kgf·m)]	16	Gauge for projection adjustment
8	Hole core drill (65mm in diameter)	10	(Used when flare is made by using conventional flare tool)

1

1. HAULAGE AND INSTALLATION (Take particular care in carrying in or moving the unit, and always perform such an operation with two or more persons.)

When a unit is hoisted with slings for haulage, take into consideration the offset of its gravity CAUTION When a unit is hoisted with sings for hadrage, take into consideration and fall center position. If not properly balanced, the unit can be thrown off-balance and fall

1) Delivery

- Deliver the unit as close as possible to the installation site before removing it from the packaging
- When you have to unpack the unit for a compelling reason before you haul it to the installation point, hoist the unit with nylon slings or ropes and protection pads so that you may not damage the unit.

2) Portage


• The right hand side of the unit as viewed from the front (diffuser side) is heavier. A person carrying the right hand side must take heed of this fact. A person carrying the left hand side must hold with his right hand the handle provided on the front panel of the unit and with his left hand the corner column section


3) Selection of installation location for the outdoor unit

- Be sure to select a suitable installation place in consideration of following conditions.
- O A place where it is horizontal, stable and can endure the unit weight and will not allow vibration transmittance
- of the unit O A place where it can be free from possibility of bothering neighbors due to noise or exhaust air from the unit.
- O A place where the unit is not exposed to oil splashes.
- O A place where it can be free from danger of flammable gas leakage.
- O A place where drain water can be disposed without any trouble.
- O A place where the unit will not be affected by heat radiation from other heat source.
- O A place where snow will not accumulate.
- O A place where the unit can be kept away 5m or more from TV set and/or radio receiver in order to avoid any radio or TV interference.
- O A place where good air circulation can be secured, and enough service space can be secured for maintenance and service of the unit safely
- O A place where the unit will not be affected by electromagnetic waves and/or high-harmonic waves generated by other equipment.
- O A place where chemical substances like sulfuric gas, chloric gas, acid and alkali (including ammonia), which can harm the unit, will not be generated and not remain.
- Ω If a operation is conducted when the outdoor air temperature is -5°C lower, the outdoor unit should be installed at a place where it is not influenced by natural wind.
- O A place where strong wind will not blow against the outlet air blow of the unit.
- Do not install the unit in places which exposed to sea breeze (e.g. coastal area) or calcium chloride (e.g. snow melting agent), exposed to ammonia substance (e.g. organic fertilizer).

4) Caution about selection of installation location


- (1) If the unit is installed in the area where the snow will accumulate, following measures are required. The bottom plate of unit and intake, outlet may be blocked by snow.
- 1 Install the unit on the base so that the 2 Provide a snow hood to bottom is higher than snow cover surface, and draining water is secured.
- 3 Install the unit under eaves the outdoor unit on site





or provide the roof on site.

- Since drain water generated by defrost control may freeze, following measures are required. • Don't execute drain piping work by using a drain elbow and drain grommets (accessories). [Refer to Drain piping work.]
- Attached heater on a base plate on site, if there is possibility to freeze drain water. In case that the product has a corrective drainage system, the drainage paths should have suitable measure against freezing but be sure not to melt the material of drainage paths with heat.








Wind direction



Over 500 mm 5) Installation space


- Walls surrounding the unit in the four sides are not acceptable.
- There must be a 1-meter or larger space in the above.
- When more than one unit are installed side by side, provide a 250mm or wider interval between them as a service space. In order to facilitate servicing of controllers, please provide a sufficient space between units so that their top plates can be removed easily.
- Where a danger of short-circuiting exists, install guide louvers.
- When more than one unit are installed, provide sufficient intake space consciously so that short-circuiting may not occur.
- Where piling snow can bury the outdoor unit, provide proper snow guards
 - The height of a wall is 1200mm or less.







① Anchor bolt fixed position (2) Notabilia for installation



- In installing the unit, fix the unit's legs with bolts specified on the above.
- The protrusion of an anchor bolt on the front side must be kept within 15 mm.
- Securely install the unit so that it does not fall over during earthquakes or strong winds, etc.
- Refer to the above illustrations for information regarding concrete foundations.
- Install the unit in a level area. (With a gradient of 5 mm or less.)
- Improper installation can result in a compressor failure, broken piping within the unit and abnormal noise generation.

7) To run the unit for a cooling operation, when the outdoor temperature is -5°C or lower.

• When the outdoor air temperature is -5°C or lower, provide a snow hood to the outdoor unit on site. So that strong wind will not blow against the outdoor heat exchanger directly.

2. REFRIGERANT PIPING WORK

1) Restrictions on unit installation and use

• Check the following points in light of the indoor unit specifications and the installation site.

• Observe the following restrictions on unit installation and use. Improper installation can result in a compressor failure or performance degradation.

	Restrictions		Dimensional restrictions	Marks appearing in the drawing on the right		
Indeen weit	FDT, FDEN, FDU, FDUM, SR		FDT, FDEN, FDU, FDUM, SRK		30m or less	L
Indoor unit	FDF	iniani pipe iengui	23m or less	L		
Elevation difference between	fference between When the outdoor unit is positioned higher		20m or less	Н		
indoor and outdoor units	When the outdoor unit is posit	tioned lower	20m or less	Н		

• The use restrictions appearing in the table above are applicable to the standard pipe size combinations shown in the table below. Where an existing pipe system is utilized, different one-way pipe length restrictions should apply depending on its pipe size. For more information, please see "5. UTILIZATION OF EXISTING PIPING."

2) Determination of pipe size

• Determine refrigerant pipe size pursuant to the following guidelines based on the indoor unit specifications.

			Liquid pipe
Outdoor unit co	nnected	ø12.7 Flare	ø6.35 Flare
Refrigerant piping (t	oranch pipeL)	ø12.7	ø6.35
Indoor unit connected	FDT, FDEN, FDU, FDUM, FDF	ø15.88	ø9.52
	SRK	ø15.88	ø6.35

When pipe is brazing.

About brazing


Brazing must be performed under a nitrogen gas flow.

Pine diameter [mm]

Without nitrogen gas, a large quantity of foreign matters (oxidized film) are created.

causing a critical failure from capillary tube or expansion valve clogging.





3) Refrigerant pipe wall thickness and material

- Select refrigerant pipes of the table shown on the right wall thickness and material as specified for each pipe size.
- NOTE Select pipes having a wall thickness larger than the specified minimum pipe thickness.

4) On-site piping work

Take care so that installed pipes may not touch components within a unit. IMPORTANT If touching with an internal component, it will generate abnormal sounds and/or vibrations.

- [Except SRK] Regarding the change in the size of liquid/gas pipe; Use the reducer at indoor unit side. Reducer set is available in the outdoor unit as accessory.
- [SRK] Regarding the change in the size of gas pipe: Use the reducer at indoor unit side. Reducer set is available in the outdoor unit as accessory.


How to remove the side cover Please remove the screw of a side cover and remove to the front.

- Carry out the on site piping work with the operation valve fully closed.
- Give sufficient protection to a pipe end (compressed and blazed, or with an adhesive tape) so Bend a pipe to a radius as large as practical. (R100-R150) Do not bend a pipe repeatedly to correct
- its form
- Flare connection is used between the unit and refrigerant pipe. Flare a pipe after engaging a flare nut onto it. Flare dimensions for R410A are different from those for conventional R407C. Although we recommend the use of flaring tools designed specifically for R410A, conventional flaring tools can also be used by adjusting the measurement of protrusion B with a protrusion control gauge.
- The pipe should be anchored every 1.5m or less to isolate the vibration.
- Tighten a flare joint securely with a double spanner.

A CAUTION Do not apply force beyond proper fastening torque in tightening the flare nut.

Fix both liquid and gas operation valves at the valve main bodies as illustrated on the right, and then fasten them, applying appropriate fastening torque.

Operation valve size (mm)	Tightening torque (N·m)	Tightening angle (°)	Recommended length of a tool handle (mm)
ø6.35	14~18	45~60	150
ø9.52	34~42	30~45	200
ø12.7	49~61	30~45	250
ø15.88	68~82	15~20	300



Do not hold the valve cap area with a spanner.

ø6 35

a12 7

not available, fasten the flare nut manually first and then tighten it further, using the

left table as a guide.


Outdoor unit

Indoor unit + 4

5) Air tightness test

- ① Although outdoor and indoor units themselves have been tested for air tightness at the factory, check the connecting pipes after the installation work for air tightness from the operation valve's check joint equipped on the outdoor unit side. While conducting a test, keep the operation valve shut all the time.
- a) Raise the pressure to 0.5 MPa, and then stop. Leave it for five minutes to see if the pressure drops,
- b) Then raise the pressure to 1.5 MPa, and stop. Leave it for five more minutes to see if the pressure drops.
- c) Then raise the pressure to the specified level (4.15 MPa), and record the ambient temperature and the pressure. d) If no pressure drop is observed with an installation pressurized to the specified level and left for about one day, it is acceptable. When the ambient Temperature fall 1°C, the pressure also fall approximately 0.01 MPa. The pressure, if changed, should be compensated for.
- e) If a pressure drop is observed in checking e) and a) d), a leak exists somewhere. Find a leak by applying bubble test liquid to welded parts and flare joints and repair it. After repair, conduct an air-tightness test again.
- ② In conducting an air-tightness test, use nitrogen gas and pressurize the system with nitrogen gas from the gas side. Do not use a medium other than nitrogen gas under any circumstances.

6) Evacuation



Pay attention to the following points in addition to the above for the R410A and compatible machines.

• To prevent a different oil from entering, assign dedicated tools, etc. to each refrigerant type. Under no circumstances must a gauge manifold and a charge hose in particular be shared with other refrigerant types (R22, R407C, etc.). OUse a counterflow prevention adapter to prevent vacuum pump oil from entering the refrigerant system.

7) Additional refrigerant charge

(1) Calculate a required refrigerant charge volume from the following table.

Indoor unit	Additional charge volume (kg) per meter of refrigerant piping (liquid pipe ø6.35)	Refrigerant volume charged for shipment at the factory (kg)	Installation's pipe length (m) covered without additional refrigerant charge
FDT, FDEN FDU, FDUM, SRK	0.02	1.6	15
FDF	0.02	1.6	8

•This unit contains factory charged refrigerant covering 15m/8m of refrigerant piping and additional refrigerant charge on the installation site is not required for an installation with up to 15m/8m refrigerant piping. When refrigerant piping exceeds 15m/8m, additionally charge an amount calculated from the pipe length and the above

table for the portion in excess of 15m/8m. olf an existing pipe system is used, a required refrigerant charge volume will vary depending on the liquid pipe size.

For further information, please see "5. UTILIZATION OF EXISTING PIPING." Formula to calculate the volume of additional refrigerant required

Additional charge volume (kg) = { Main length (m) - Factory charged volume} x 0.02 (kg/m)

*When an additional charge volume calculation result is negative,


it is not necessary to charge refrigerant additionally

• For an installation measuring 15m/8m or shorter in pipe length, please charge the refrigerant volume charged for shipment at the factory, when you recharge refrigerant after servicing etc.

8) Heating and condensation prevention

(1) Dress refrigerant pipes (both gas and liquid pipes) for heat insulation and prevention of dew condensation.

- Improper heat insulation/anti-dew dressing can result in a water leak or dripping causing damage to household effects, etc. (2) Use a heat insulating material that can withstand 120°C or a higher temperature. Poor heat insulating capacity can cause heat insulation problems or cable
- deterioration. All gas pipes must be securely heat insulated in order to prevent damage from dripping water that comes from the condensation formed on them during a cooling operation
- or personal injury from burns because their surface can reach quite a high temperature due to discharged gas flowing inside during a heating operation. · Wrap indoor units' flare joints with heat insulating parts (pipe cover) for heat insulation (both gas and liquid pipes).
- Give heat insulation to both gas and liquid side pipes. Bundle a heat insulating material and a pipe tightly together so that no gaps may be left between them and wrap them together with a connecting cable by a dressing tape.
- Both gas and liquid pipes need to be dressed with 20 mm or thicker heat insulation materials above the ceiling where relative humidity exceeds 70%.



Securely tighten the operation valve cap and the check joint blind nut after adjustment.

Operation valve size (mm)	Operation valve cap tightening torque (N·m)	Check joint blind nut tightening torque (N·m)
ø6.35 (1/4")	20~30	10~12
ø12.7 (1/2")	25~35	10~12

(2) Charging refrigerant


Operation Valve

Since R410A refrigerant must be charged in the liquid phase, you should charge it, keeping the container cylinder upside down or using a refrigerant cylinder equipped with a siphon tube.

 Charge refrigerant always from the liquid side service port with the operation valve shut. When you find it difficult to charge a required amount, fully open the outdoor unit valves on both liquid and gas sides and charge refrigerant from the gas (suction) side service port, while running the unit in the cooling mode. In doing so, care must be taken so that refrigerant may be discharged from the cylinder in the liquid phase all the time. When the cylinder valve is throttled down or a dedicated conversion tool to change liquid-phase refrigerant into mist is used to protect the compressor, however, adjust charge conditions so that refrigerant will gasify upon entering the unit.


In charging refrigerant, always charge a calculated volume by using a scale to measure the charge volume. •When refrigerant is charged with the unit being run, complete a charge operation within 30 minutes. Running the unit with an insufficient quantity of refrigerant for a long time can cause a compressor failure.

NOTE Put down the refrigerant volume calculated from the pipe length onto the caution label attached on the back side of the service panel.



3. DRAIN PIPING WORK

- Execute drain piping by using a drain elbow and drain grommets supplied separately as accessories, where water drained from the outdoor unit is a problem.
- Water may drip where there is a larger amount of drain water. Seal around the drain elbow and drain grommets with putty or adequate caulking material.
- Condensed water may flow out from vicinity of operation valve or connected pipes.
- Where you are likely to have several days of sub-zero temperatures in a row, do not use a drain elbow and drain grommets. (There is a risk of drain water freezing inside and blocking the drain.)



4. ELECTRICAL WIRING WORK For details of electrical cabling, refer to the indoor unit installation manual.

Electrical installation work must be performed by an electrical installation service provider qualified by a power provider of the country. Electrical installation work must be executed according to the technical standards and other regulations applicable to electrical installations in the country.

- •Do not use any supply cord lighter than one specified in parentheses for each type below.
- braided cord (code designation 60245 IEC 51),
- ordinary tough rubber sheathed cord (code designation 60245 IEC 53)
- flat twin tinsel cord (code designation 60227 IEC 41):
- Use polychloropyrene sheathed flexible cord (code designation 60245 IEC57) for supply cords of parts of appliances for outdoor use. •Ground the unit. Do not connect the arounding wire to a gas pipe, water pipe, lighthing rod or telephone grounding wire.
- If impropery grounded, an electric shock or malfunction may result.
- A grounding wire must be connected before connecting the power cable. Provide a grounding wire longer than the power cable.
- The installation of an impulse withstanding type earth leakage breaker is necessary. A failure to install an earth leakage breaker can result in an acccident such as an electric shock or a fire.
- •Do not turn on the power until the electrical work is completeted
- Do not use a condensive capacitor for power factor improvement under any circumstances. (It dose not improve power factor, while it can cause an abnormal overheat accident)
- For power supply cables, use conduits.

135

- Do not lay electronic control cables (remote control and signaling wires) and other cables together outside the unit. Laying them together can result
 in the malfunctioning or a failure of the unit due to electric noises.
- •Fasten cables so that may not touch the piping, etc.
- When cables are connected, make sure that all electrical components within the electrical component box are free of loose connector coupling or terminal connection and then attach the cover securely. (Improper cover attachment can result in malfunctioning or a failure of the unit, if water penetrates into the box.)
- •Always use a three-core cable for an indoor-outdoor connecting cable. Never use a shield cable.

In case of faulty wiring connection, the indoor unit stops, and then the run lamp turns on and the timer lamp blinks.

Use cables for interconnection wiring to avoid loosening of the wires. CENELEC code for cables Required field cables.

H05RNR4G1.5 (Example) or 245IEC57

- H Harmonized cable type
- 05 300/500 volts
- R Natural-and/or synth. rubber wire insulation
- N Polychloroprene rubber conductors insulation
- R Stranded core
- 4or5 Number of conductors
- G One conductor of the cable is the earth conductor
- (yellow/green)
- 1.5 Section of copper wire (mm²)

Power supply terminal block Cable clamp Olt holds cables in place and protect the terminal connection from external force. This clamp is for the cable in the outside diameter 9-15mm. Please adjust it when not suitable. Cable clamp Olt holds cables in place and protect the terminal connection from external force. Grounding terminal OPlease be sure to carry out D-type (type III) grounding work.

Power cable, indoor-outdoor connecting wires

Outdoor unit

Indoor unit

Earth leakage breaker

(Harmonic resistant type)

Switchgear or Circuit breaker

± N I

1 2/N 3

1 2/N 3 ±

- Always perform grounding system installation work with the power cord unplugged.
- Connect a pair bearing a common terminal number with an indoor-outdoor connecting wire.
- In cabling, fasten cables securely with cable clamps so that no external force may work on terminal connections.
 Grounding terminals are provided in the control box.

CAUTION Always use an earth leakage circuit breaker designed for inverter circuits to prevent a faulty operation.

t			Switchgear or Circuit Breaker		Power souce	Interconnecting and
	Phase	Earth leakage breaker	Switch breaker	Over current protector rated capacity	(minimum)	grounding wires (minimum)
	Single-phase	20A,30mA, 0.1sec or less	30A	20A	2.0mm ²	1.5mm×4


•The specifications shown in the above table are for units without heaters. For units with heaters, refer to

the installation instructions or the construction instructions of the indoor unit.

•Switchgear or Circuit breaker capacity which is calculated from MAX. over current should be chosen along the regulations in each country.

 The cable specifications are based on the assumption that a metal or plastic conduit is used with no more than three cables contained in a conduit and a voltage drop is 2%. For an installation falling outside of these conditions, please follow the internal cabling regulations. Adapt it to the regulation in effect in each country.

5. UTILIZATION OF EXISTING PIPING



INSTALLATION TEST CHECK POINTS Check the following points again after completion of the installation, and before turning on the power. Conduct a test run again and ensure that the unit operates properly. Explain to the customer how to use the unit and how to take care of the unit following the instruction manual. After installation

Power cables and connecting wires are securely fixed to the terminal block.	The pipe joints for indoor and outdoor pipes have been insulated.
The power supply voltage is correct as the rating.	The reverse flow check cap is attached.
The drain hose is fixed securely.	The cover of the pipe cover (A) faces downward to prevent rain from entering.
Operation valve is fully open.	Gaps are properly sealed between the pipe covers (A) (B) and the wall surface / pipes.
No gas leaks from the joints of the operation valve and joint.	The screw of the side cover is tightened securely.

PCA012D058A

Model FDC90VNP

R410A REFRIGERANT USED

- This installation manual deals with outdoor units and general installation specifications only. For indoor units, refer to page 72.
- . When install the unit, be sure to check whether the selection of installation place, power supply specifications, usage limitation (piping length, height differences between indoor and outdoor units, power supply voltage and etc.) and installation spaces.

SAFETY PRECAUTIONS

- Read the "SAFETY PRECAUTIONS" carefully first of all and strictly follow it during the installation work in order Keep the installation manual together with owner's manual at a place where any user can read at any time. to protect yourself
- The precautionary items mentioned below are distinguished into two levels. A WARNING and CAUTION. WARNING : Wrong installation would cause serious consequences such as injuries or death.
- CAUTION : Wrong installation might cause serious consequences depending on circumstances. Both mentions the important items to protect your health and safety so strictly follow them by any means.
- Be sure to confirm no anomaly on the equipment by commissioning after completed installation and explain the operating methods as well as the maintenance methods of this equipment to the user according to the owner's manual.
- Moreover if necessary, ask to hand them to a new user.
- For installing qualified personnel, take precautions in respect to themselves by using suitable protective clothing, groves, etc., and then perform the installation works.
- Please pay attention not to fall down the tools, etc. when installing the unit at the high position.
- If unusual noise can be heard during operation, consult the dealer.
- The meanings of "Marks" used here are shown as follows: Never do it under any circumstances. Always do it according to the instruction.

If the refrigerant comes into contact with naked flames, poisonous gas is produced.

Installation must be carried out by the qualified installer.

- If you install the system by yourself, it may cause serious trouble such as water leaks, electric shocks, fire and personal injury, as a result of a system malfunction. Do not carry out the installation and maintenance work except by the gualified installer.
- Install the system in full accordance with the installation manual. Incorrect installation may cause bursts, personal injury, water leaks, electric shocks and fire
- · Be sure to use only for household and residence. If this appliance is installed in inferior environment such as machine shop and etc.

137

- it can cause malfunction. When installing in small rooms, take prevention measures not to
- exceed the density limit of refrigerant in the event of leakage, referred by the formula (accordance with ISO5149). If the density of refrigerant exceeds the limit, please consult the dealer and install

the ventilation system, otherwise lack of oxygen can occur, which can cause serious accident

- Use the original accessories and the specified components for installation.
- If parts other than those prescribed by us are used, It may cause water leaks, electric shocks, fire and personal injury.
- Install the unit in a location with good support. Unsuitable installation locations can cause the unit to fall and cause material damage and personal injury.
- Ensure the unit is stable when installed, so that it can withstand earthquakes and strong winds. Unsuitable installation locations can cause the unit to fall and cause material
- damage and personal injury
- Ventilate the working area well in the event of refrigerant leakage during installation

. Ensure that no air enters in the refrigerant circuit when the unit is installed and removed.

- If air enters in the refrigerant circuit, the pressure in the refrigerant circuit becomes too high, which can cause burst and personal injury. Do not processing, splice the power cord, or share a socket with other power plugs.
- This may cause fire or electric shock due to defecting contact, defecting insulation and over-current etc.

• Use the prescribed pipes, flare nuts and tools for R410A. Using existing parts (for R22 or R407C) can cause the unit failure and serious accidents due to burst of the refrigerant circuit. • Tighten the flare nut by torque wrench with specified method. If the flare nut were tightened with excess torque, this may cause burst and refrigerant leakage after a long period. . Do not open the operation valves for liquid line and gas line until

completed refrigerant piping work, air tightness test and evacuation. If the compressor is operated in state of opening operation valves before

completed connection of refrigerant piping work, air can be sucked into refrigerant circuit, which can cause bust or personal injury due to anomalously high pressure in the refrigerant

 The electrical installation must be carried out by the qualified electrician in accordance with "the norm for electrical work" and "national wiring regulation", and the system must be connected to the dedicated circuit. Power supply with insufficient capacity and incorrect function done by improper work can cause electric shocks and fire.

· Be sure to shut off the power before starting electrical work.

Failure to shut off the power can cause electric shocks, unit failure or incorrect function of equipment.

· Be sure to use the cables conformed to safety standard and cable ampacity for power distribution work.

Unconformable cables can cause electric leak, anomalous heat production or fire. This appliance must be connected to main power supply by means of a circuit breaker or switch (fuse:20A) with a contact separation of at least 3mm

• Arrange the wiring in the control box so that it cannot be pushed up further into the box. Install the service panel correctly.

Do not bundling, winding or processing for the power cord. Or. do not deforming the power plug due to tread it. This may cause fire or heating.

· Do not run the unit with removed panels or protections.

Touching rotating equipments, hot surfaces or high voltage parts can cause personal injury due to entrapment, burn or electric shocks.

Incorrect installation may result in overheating and fire Use the prescribed cables for electrical connection, tighten the cables securely in terminal block and relieve the cables correctly to prevent overloading the terminal blocks. Loose connections or cable mountings can cause anomalous heat production or fire. · Be sure to fix up the service panels. Incorrect fixing can cause electric shocks or fire due to intrusion of dust or water. · Be sure to switch off the power supply in the event of installation, inspection or servicing. If the power supply is not shut off, there is a risk of electric shocks, unit failure or personal injury due to the unexpected start of fan . Stop the compressor before removing the pipe after shutting the

service valve on pump down work.

If the pipe is removed when the compressor is in operation with the service valve open, air would be mixed in the refrigeration circuit and it could cause explosion and injuries due to abnormal high pressure in the cooling cycle.

· Only use prescribed optional parts. The installation must be carried out by the qualified installer.

If you install the system by yourself, it can cause serious trouble such as water leaks, electric shocks. fire.

• Be sure to wear protective goggles and gloves while at work. · Earth leakage breaker must be installed.

If the earth leakage breaker is not installed, it can cause electric shocks. Appliance is not to be used by children or persons with reduced physical.

sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction. Children being supervised not to play with appliance.

 Do not perform any change of protective device itself or its setup condition. The forced operation by short-circuiting protective device of pressure switch and temperature controller or the use of non specified component can cause fire or burst.

_						
		▲ CAUTION				
9	• Carry out the electrical work for ground lead with care. Do not connect the ground lead to the gas line, water line, lightning conductor or tele	phone line's ground lead. Incorrect grounding can cause unit faults such as electric sh	ocks due to short-circuiting.			
	should be the one that disconnect all poles under over current. Using the incorrect circuit breaker, it can cause the unit malfunction and fire. Install isolator or disconnect switch on the power supply wiring in accordance with the local codes and regulations. The isolator should be locked in OFF state in accordance with EN60204-1. After maintenance, all wiring, wiring ties and the like, should be returned to their original state and wiring route, and the necessary clearance from	 Take care when carrying the unit by hand. If the unit weights more than 20kg, it must be carried by two or more persons. Do not carry by the plastic straps, always use the carry handle when carrying the unit by hand. Use gloves to minimize the risk of cuts by the aluminum fins. Dispose of any packing materials correctly. Any remaining packing materials correctly. Any remaining packing materials correctly. Any remaining having materials correctly. Be sure to insulate the refrigerant pipes so as not to condense the ambient air moisture on them. Insufficient insulation can cause condensation, which can lead to moisture damage on the ceiling, floor, furniture and any other valuables. 	 When perform the air conditioner operation (cooling or drying operation) in which ventilator is installed in the room. In this case, using the air conditioner in parallel with the ventilator, there is the possibility that drain water may backflow in accordance with the room lapse into the negative pressure status. Therefore, set up the opening port such as incorporate the air into the room that may appropriate to ventilation (For example; Open the door a little). In addition, just as above, so set up the opening port if the room lapse into negative pressure status due to register of the wind for the high rise apartment etc. 			
	Locations where heat radiation from other heat source can affect the unit. Locations without good air circulation. Locations with any obstacles which can prevent inlet and outlet air of the unit. Locations where short circuit of air can occur (in case of multiple units		 Do not install the outdoor unit in a location where insects and small animals can inhabit. Insects and small animals can enter the electric parts and cause damage or fire. Instruct the user to keep the surroundings clean. Do not use the base flame for outdoor unit which is corroded or damaged due to long periods of operation. Using an old and damage base flame can cause the unit falling down and cause personal injury. Do not use any materials other than a fuse with the correct rating in the location where fuses are to be used. Connecting the circuit with copper wire or other metal thread can cause unit failure and fire. Do not touch any buttons with wet hands. It can cause electric shocks. Do not touch any refrigerant pipes with your hands when the system is in operation. During operation the refrigerant pipes become extremely hot or extremely cold depending the operating condition, and it can cause burn injury or frost injury. Do not put anything on the outdoor unit and operating unit. This may cause injury. Do not put anything on the objects or injury due to falling to the object. Do not clean up the unit with water. 			

Notabilia as a unit designed for R410A

• Do not use any refrigerant other than R410A. R410A will rise to pressure about 1.6 times higher than that of a conventional refrigerant. A cylinder containing R410A has a pink indication mark on the top.

• A unit designed for R410A has adopted a different size indoor unit operation valve charge port and a different size check joint provided in the unit to prevent the charging of a wrong refrigerant by mistake. The processed dimension of the flared part of a refrigerant pipe and a flare nut's parallel side measurement have also been altered to raise strength against pressure. Accordingly, you are required to arrange dedicated R410A tools listed in the table on the left before installing or servicing this unit.

Q'ty

1

1 1

1

1

1

Do not use a charge cylinder. The use of a charge cylinder will cause the refrigerant composition to change, which results in performance degradation.

Option parts

• In charging refrigerant, always take it out from a cylinder in the liquid phase.

• All indoor units must be models designed exclusively for R410A. Check connectable indoor unit models in a catalog, etc. (A wrong indoor unit, if connected into the system, will impair proper system operation)

(Check before installation work) Model name and power source · Refrigerant piping length a Sealing plate

Piping, wiring and miscellaneous small parts
Indoor unit installation manual

Piping, wiring and miscellaneous small parts				\sim	5111
Indoor unit installation manual				6	Sleeve
Accessories for outdoor unit				0	Inclination plate
				6	Putty
Ð	Grommet (Heat pump type only)	2		~	,
Drain elbow (Heat pump type only)		1		e	Drain hose (extension hose)
(3) Reducer set \emptyset 9.52 \rightarrow \emptyset 6.35		1		Ð	Piping cover
- 1000001 007 00.02 × 50.00 1			'	Ψ	(for insulation of connection piping)

	Nanana an taola fan tha installation word:	9	Wrench key (Hexagon) [4m/m]
	Necessary tools for the installation work		Vacuum pump
1	Plus headed driver		Vacuum pump adapter (Anti-reverse flow type)
2	Knife	1''	(Designed specifically for R410A)
3	Saw	12	Gauge manifold (Designed specifically for R410A)
4	Tape measure	13	Charge hose (Designed specifically for R410A)
5	Hammer	14	Flaring tool set (Designed specifically for R410A)
6	Spanner wrench	15	Gas leak detector (Designed specifically for R410A)
7	Torque wrench [14.0~82.0N·m (1.4~8.2kgf·m)]	16	Gauge for projection adjustment
8	Hole core drill (65mm in diameter)	1'0	(Used when flare is made by using conventional flare tool)

1. HAULAGE AND INSTALLATION (Take particular care in carrying in or moving the unit, and always perform such an operation with two or more persons.)

When a unit is hoisted with slings for haulage, take into consideration the offset of its gravity center position. If not properly balanced, the unit can be thrown off-balance and fall.

1) Deliverv

- Deliver the unit as close as possible to the installation site before removing it from the packaging.
- When you have to unpack the unit for a compelling reason before you haul it to the installation point, hoist the unit with nylon slings or ropes and protection pads so that you may not damage the unit.

2) Portage

• The right hand side of the unit as viewed from the front (diffuser side) is heavier. A person carrying the right hand side must take heed of this fact. A person carrying the left hand side must hold with his right hand the handle provided on the front panel of the unit and with his left hand the corner column section

3) Selection of installation location for the outdoor unit


- Be sure to select a suitable installation place in consideration of following conditions.
- O A place where it is horizontal, stable and can endure the unit weight and will not allow vibration transmittance of the unit.
- O A place where it can be free from possibility of bothering neighbors due to noise or exhaust air from the unit. O A place where the unit is not exposed to oil splashes.
- O A place where it can be free from danger of flammable gas leakage.
- O A place where drain water can be disposed without any trouble
- O A place where the unit will not be affected by heat radiation from other heat source.
- O A place where snow will not accumulate.
- O A place where the unit can be kept away 5m or more from TV set and/or radio receiver in order to avoid any radio or TV interference
- O A place where good air circulation can be secured, and enough service space can be secured for maintenance and service of the unit safely.
- O A place where the unit will not be affected by electromagnetic waves and/or high-harmonic waves generated by other equipment
- A place where chemical substances like sulfuric gas, chloric gas, acid and alkali (including ammonia), which can harm the unit, will not be generated and not remain.
- O If a operation is conducted when the outdoor air temperature is -5℃ lower, the outdoor unit should be installed at a place where it is not influenced by natural wind.
- O A place where strong wind will not blow against the outlet air blow of the unit.


Do not install the unit in places which exposed to sea breeze (e.g. coastal area) or calcium chloride (e.g. snow melting agent), 6) Installation exposed to ammonia substance (e.g. organic fertilizer).

4) Caution about selection of installation location

(1) If the unit is installed in the area where the snow will accumulate, following measures are required.

- The bottom plate of unit and intake, outlet may be blocked by snow.
- 1 Install the unit on the base so that the bottom is higher than snow cover surface, and draining water is secured.
- 2 Provide a snow hood to 3 Install the unit under eaves the outdoor unit on site. or provide the roof on site.






Since drain water generated by defrost control may freeze, following measures are required. Don't execute drain piping work by using a drain elbow and drain grommets (accessories). [Refer to Drain piping work.]

• Attached heater on a base plate on site, if there is possibility to freeze drain water. In case that the product has a corrective drainage system, the drainage paths should have suitable measure against freezing but be sure not to melt the material of drainage paths with heat.





Strong wind can cause damage of fan (fan motor), or can cause performance degradation, or can trigger anomalous stop of the unit due to rising of high pressure.

1. Install the outlet air blow side of the unit to face a wall of building, or provide a fence or a windbreak screen.

2.Install the outlet air blow side of the unit in a position perpendicular to the direction of wind.









5) Installation space

- Walls surrounding the unit in the four sides are not acceptable.
- There must be a 1-meter or larger space in the above.
- When more than one unit are installed side by side, provide a 250mm or wider interval between them as a service space. In order to facilitate servicing of controllers, please provide a sufficient space between units so that their top plates can be removed easily.
- Where a danger of short-circuiting exists, install guide louvers.
- When more than one unit are installed, provide sufficient intake space consciously so that short-circuiting may not occur.
- Where piling snow can bury the outdoor unit, provide proper snow guards.





3. The unit should be installed on

If the foundation is not level the down the unit with wires.

the stable and level foundation



① Anchor bol tfixed position (2) Notabilia for installation Intak Easten with holts (M10-12) Use a long block to Uutlet Use a thicker block to anchor deeper 580 150 87.9 880

- In installing the unit, fix the unit's legs with bolts specified on the above.
- The protrusion of an anchor bolt on the front side must be kept within 15 mm.
- Securely install the unit so that it does not fall over during earthquakes or strong winds, etc.
- Refer to the above illustrations for information regarding concrete foundations.
- Install the unit in a level area. (With a gradient of 5 mm or less.)
- Improper installation can result in a compressor failure, broken piping within the unit and abnormal noise generation.

7) To run the unit for a cooling operation, when the outdoor temperature is -5°C or lower.

• When the outdoor air temperature is -5°C or lower, provide a snow hood to the outdoor unit on site. So that strong wind will not blow against the outdoor heat exchanger directly.

ω

139

2. REFRIGERANT PIPING WORK

1) Restrictions on unit installation and use

• Check the following points in light of the indoor unit specifications and the installation site.

Restrictio	ons			Dimensional restrictions	Marks	appearing in the	drawing on the right	-		
FDT, FDEN, FDU, FDUN		UM Main n	ipe length	30m or less		L		Ī		
Indoor unit	FDF		· ·	23m or less		L		н		
Elevation difference between	When the outdoor u			20m or less		Н		"		
indoor and outdoor units When the outdoor unit is po		nit is positioned	lower	20m or less		Н				
LAUTION Where an		is utilized, differ	rent one-v	applicable to the standard vay pipe length restrictions XISTING PIPING."				<u>+</u>	Outdoor unit	
Determination of p	oipe size				Whe	en pipe is bra	zing.			
Determine refrigerant pipe siz	e pursuant to the fo	ollowing guide	lines bas	ed on the	ſ	About brazing				
indoor unit specifications.						About braziliy				
		Gas pipe	Liqu	uid pipe		Brazing must	be performed under a ni	trogen gas flow.		
Outdoor unit conne	ected	ø15.88		6.35			n gas, a large quantity of f			reated
		Flare	F	Flare		•	al failure from capillary tube		00 0	
Refrigerant piping (bran	ich pipeL)	ø15.88	ø	6.35	If the refrigerant is existing in the pipe at brazing, poisonous		zing, poisonous gas	s is produced.		
Indoor unit connec	cted	ø15.88	88 ø9.52			Plug the end of the pipe with tape, or other Primary side Secondary side material, and fill the pipe with introgen gas. Station valve				side
		0.000	5	0.02					$000^{0.5MPa}$	les
						 CE	Taping <n2></n2>	> " "ि⊧	Ha	10 Л.
						Nitrogen		Nitrogen	Relief valve	m
						Z	Only use nitrogen gas (N2)	Brazing gas	nelici valve	1F
Refrigerant pipe wa	all thickness	and mat	erial				Pipe diameter [mm]		ø6.35	,
Select refrigerant pipes of th	ne table shown on t	he right wall t	thickness	and material as specifie	ed for each	i pipe size.	Minimum pipe wall thick	mess [mm]	0.8	
NOTE • Select pipes have	ving a wall thicknes	s larger than	the speci	fied minimum pipe thick	kness.		Pipe material*		O-type pipe	0-
		0	·				*Phosphorus deoxidized s	eamless conner ni		
						r	Usage of reducer set]			
In-site piping work						Ľ	Liquid side joint (19.52)	①Reducer [L=1	(5mm)
				components within a unit nerate abnormal sounds		rations.)	}	
II touon	•									
Regarding the change in the size Use the reducer at indoor unit							Indoor unit	Ċ	لا لا	

How to remove the side cover Please remove the screw of a side cover and remove to the front.

- Carry out the on site piping work with the operation valve fully closed. Give sufficient protection to a pipe end (compressed and blazed, or with an adhesive tape) so that water or foreign matters may not enter the piping.
 Bend a pipe to a radius as large as practical (R100-R150) Do not bend a pipe repeatedly to correct
- its form.
- Flare connection is used between the unit and refrigerant pipe. Flare a pipe after engaging a flare nut onto it. Flare dimensions for R410A are different from those for conventional R407C. Although we recommend the use of flaring tools designed specifically for R410A, conventional flaring tools can also be used by adjusting the measurement of protrusion B with a protrusion control gauge.
- The pipe should be anchored every 1.5m or less to isolate the vibration.
- Tighten a flare joint securely with a double spanner.


A CAUTION Do not apply force beyond proper fastening torque in tightening the flare nut.

Fix both liquid and gas operation valves at the valve main bodies as illustrated on the right, and then fasten them, applying appropriate fastening torque.

Operation valve size (mm)	Tightening torque (N·m)	Tightening angle (°)	Recommended length of a tool handle (mm)
ø6.35	14~18	45~60	150
ø9.52	34~42	30~45	200
ø12.7	49~61	30~45	250
ø15.88	68~82	15~20	300

side `Ø____ :-Øø15.88 1.0 O-type pipe 15, ICS 77.150.30 15mm](ø9.52-ø6.35) @Flare nut ᠁ᢔᢆ᠋ᢓᡰᡗ᠊ᡕ Gas side joint (ø15.88)

Reducer set (①, ②) is included in the outdoor unit as accessory



Indoor unit +

ø6.35 pipe

ø15.88 pipe

Outdoor unit


1

5) Air tightness test

① Although outdoor and indoor units themselves have been tested for air tightness at the factory, check the connecting pipes after the installation work for air tightness from the operation valve's check joint equipped on the outdoor unit side. While conducting a test, keep the operation valve shut all the time.

- a) Raise the pressure to 0.5 MPa, and then stop. Leave it for five minutes to see if the pressure drops.
- b) Then raise the pressure to 1.5 MPa, and stop. Leave it for five more minutes to see if the pressure drops.
- c) Then raise the pressure to the specified level (4.15 MPa), and record the ambient temperature and the pressure.
- d) If no pressure drop is observed with an installation pressurized to the specified level and left for about one day, it is acceptable. When the ambient Temperature fall 1°C, the pressure also fall approximately 0.01 MPa. The pressure, if changed, should be compensated for.
- e) If a pressure drop is observed in checking e) and a) d), a leak exists somewhere. Find a leak by applying bubble test liquid to welded parts and flare joints and repair it. After repair, conduct an air-tightness test again.
- ② In conducting an air-tightness test, use nitrogen gas and pressurize the system with nitrogen gas from the gas side. Do not use a medium other than nitrogen gas under any circumstances

6) Evacuation



Pay attention to the following points in addition to the above for the R410A and compatible machines.

○To prevent a different oil from entering, assign dedicated tools, etc. to each refrigerant type. Under no circumstances must a gauge manifold and a charge hose in particular be shared with other refrigerant types (R22, R407C, etc.).
○Use a counterflow prevention adapter to prevent vacuum pump oil from entering the refrigerant system.

7) Additional refrigerant charge

(1) Calculate a required refrigerant charge volume from the following table.

Indoor unit	Additional charge volume (kg) per meter of refrigerant piping (liquid pipe ø6.35)	Refrigerant volume charged for shipment at the factory (kg)	Installation's pipe length (m) covered without additional refrigerant charge		
FDT, FDEN FDU, FDUM	0.025	2.1	15		
FDF	0.025	2.1	8		

 This unit contains factory charged refrigerant covering 15m/8m of refrigerant piping and additional refrigerant charge on the installation site is not required for an installation with up to 15m/8m refrigerant piping.

When refrigerant piping exceeds 15m/8m, additionally charge an amount calculated from the pipe length and the above table for the portion in excess of 15m/8m.

•If an existing pipe system is used, a required refrigerant charge volume will vary depending on the liquid pipe size. For further information, please see "5. UTILIZATION OF EXISTING PIPING."

Formula to calculate the volume of additional refrigerant required

Additional charge volume (kg) = { Main length (m) - Factory charged volume} x 0.025 (kg/m)

*When an additional charge volume calculation result is negative,

it is not necessary to charge refrigerant additionally.


• For an installation measuring 15m/8m or shorter in pipe length, please charge the refrigerant volume charged for shipment at the factory, when you recharge refrigerant after servicing etc.

8) Heating and condensation prevention

(1) Dress refrigerant pipes (both gas and liquid pipes) for heat insulation and prevention of dew condensation.

- Improper heat insulation/anti-dew dressing can result in a water leak or dripping causing damage to household effects, etc.
- (2) Use a heat insulating material that can withstand 120°C or a higher temperature. Poor heat insulating capacity can cause heat insulation problems or cable deterioration.
 - All gas pipes must be securely heat insulated in order to prevent damage from dripping water that comes from the condensation formed on them during a cooling operation
 or personal injury from burns because their surface can reach quite a high temperature due to discharged gas flowing inside during a heating operation.
 - Wrap indoor units' flare joints with heat insulating parts (pipe cover) for heat insulation (both gas and liquid pipes).
 - Give heat insulation to both gas and liquid side pipes. Bundle a heat insulating material and a pipe tightly together so that no gaps may be left between them and wrap them together with a connecting cable by a dressing tape.

Both gas and liquid pipes need to be dressed with 20 mm or thicker heat insulation materials above the ceiling where relative humidity exceeds 70%.



Outdoor unit

Gas side

Check joint

operation valve

Indoor unit

Securely tighten the operation valve cap and the check joint blind nut after adjustment.

Operation valve size (mm)	Operation valve cap tightening torque (N·m)	Check joint blind nut tightening torque (N·m)		
ø6.35 (1/4")	20~30	10~12		
ø15.88 (5/8")	30~40	10~12		

(2) Charging refrigerant


•Since R410A refrigerant must be charged in the liquid phase, you should charge it, keeping the container cylinder upside down or using a refrigerant cylinder equipped with a siphon tube.

•Charge refrigerant always from the liquid side service port with the operation valve shut. When you find it difficult to charge a required amount, fully open the outdoor unit valves on both liquid and gas sides and charge refrigerant from the gas (suction) side service port, while running the unit in the cooling mode. In doing so, care must be taken so that refrigerant may be discharged from the cylinder in the liquid phase all the time. When the cylinder valve is throttled down or a dedicated conversion tool to change liquid-phase refrigerant will gasify upon entering the unit.

ein charging refrigerant, always charge a calculated volume by using a scale to measure the charge volume.


•When refrigerant is charged with the unit being run, complete a charge operation within 30 minutes. Running the unit with an insufficient quantity of refrigerant for a long time can cause a compressor failure.

NOTE Put down the refrigerant volume calculated from the pipe length onto the caution label attached on the back side of the service panel.






3. DRAIN PIPING WORK



4. ELECTRICAL WIRING WORK For details of electrical cabling, refer to the indoor unit installation manual

OPlease be sure to carry out D-type (type III)


arounding work.



- •Switchgear or Circuit breaker capacity which is calculated from MAX. over current should be chosen along the regulations in each country.
- •The cable specifications are based on the assumption that a metal or plastic conduit is used with no more than three cables contained in a conduit and a voltage drop is 2%. For an installation falling outside of these conditions, please follow the internal cabling regulations. Adapt it to the regulation in effect in each country.

.

5. UTILIZATION OF EXISTING PIPING





INSTALLATION TEST CHECK POINTS Check the following points again after completion of the installation, and before turning on the power. Conduct a test run again and ensure that the unit operates properly. Explain to the customer how to use the unit and how to take care of the unit following the instruction manual. After installation Power cables and connecting wires are securely fixed to the terminal block. The pipe joints for indoor and outdoor pipes have been insulated. The power supply voltage is correct as the rating. The reverse flow check cap is attached. The drain hose is fixed securely. The cover of the pipe cover (A) faces downward to prevent rain from entering. Operation valve is fully open. Gaps are properly sealed between the pipe covers (A) (B) and the wall surface / pipes.

12. OPTION PARTS

12.1 Wireless kit

(1) FDT series (RCN-T-36W-E)





(2) FDEN series (RCN-E1R)

110163	

Following functions of FDEN Type-F indoor unit series are not able to be set with this wireless remote control (RCN-E1R).

1. Flap control system 2. 4-fan speed setting (P-Hi/Hi/Me/Lo) \rightarrow 3-fan speed setting (Hi/Me/Lo)

• Fasten the wiring to the terminal securely and hold the cable securely so as not to apply unexpected stress on the terminal. Loose connection or hold will cause abnormal heat generation or fire.

 Make sure the power supply is turned off when electric wiring work. Otherwise, electric shock, malfunction and improper running may occur.

• Install a receiver unit where it is not exposed to direct sunrays or intense light from lighting fixtures.

① Accessories

Please make sure that you have all of the following accessories.

Remoto controller holder	AAA dry cell battery (RO3)	Wood screw for holder	Wireless remote control		
\cdot					
1	2	2	1		

2 Installation of the control holder

 \triangle CAUTION DO NOT install it on the following places.


- 1. Places exposed to direct sunlight
- 3. Places near heat devices
- 5. High humidity places
- 2. Hot surface or cold surface enough to generate condensation
- 4. Places exposed to oil mist or steam directly.
- 6. Uneven surface

Installation tips for the remote control holder

- Adjust and keep the holder up right.
- Tighten the screw to the end to avoid scratching the remote control.
- DO NOT attach the holder on plaster wall.

How to insert batteries

- ① Detach the back lid.
- ① Insert the batteries. (two AAA batteries)
- 1) Reattach the back lid.



PFA012D620

.

1

3 FDEN

SW1

SW2


SW3

SW4

Setting on site

To change setting

- 1. Remove the front panel.
- 2. Remove four screws located on the back of the receiver and detach the board.
- 3. Change the setting by the switch on PCB.



Receiver Backside

4. When switch 1 is turned to off position, change the wireless remote control setting. (For the method of changing the setting, refer to Setting to avoid mixed communication on page 4)

Refer to Wireless remote control unit operation distance of FDEN in case of plural setting.

Master/Slave setting when using plural remote controls

mark.

ON : Normal (1ch)

OFF : Customized (2ch)

ON : Master

OFF : Slave

ON : Valid

OFF : Invalid

ON : Valid

OFF : Invalid

Up to two receiver or wired remote control can be installed in one indoor unit group. When two receivers or wired remote control are used, it is necessary to change SW on the PCB to set it as slave.

Control plural indoor units with one remote control

Up to 16 indoor units can be connected.

PCB on the receiver has the following

switches to set the function.

Default setting is shown with

Prevents interference

Receiver master/slave


during plural setting

Buzzer valid/Invalid

setting

Auto restart

- ① Connect indoor units with each other with 2-core wires. As for size, refer to the following note.
- ② The receiver wires must be connected only with the indoor unit that will be operated by the remote control directly.
- ③ Set the indoor unit address with SW2 on the indoor unit PCB from [0] to [F] so as not to duplicate.



***ATTENTION**

In a system configured as shown above, up to two receivers are usable. If two receivers are used, it is necessary to designate one of them as a slave by setting SW2. (For the method of changing the setting, refer to Setting on site .) Since other receivers are not usable, do not couple the connectors for them. (Unless the connector is coupled for a receiver, the LED will not be able to make any indication)


③ FDEN (continued)

Wireless remote control operation distance

① Standard signal receiving range

[Condition]


Illuminance at the receiver area: 360 lux. (When no lighting fixture is located within 1m of indoor unit in an ordinary office)



② Points for attention in connecting a plural number of indoor units

[Condition]

Illuminance at the receiver area: 360 lux. (When no lighting fixture is located within 1m of indoor unit in an ordinary office) When the remote control is used with the aforementioned interference-prevention setting, a minimum distance guaranteeing the prevention of unintended unit responses is 5m.



____ (Top view)

- OPlease operate remote control switches with the unit faced correctly toward the indoor unit's receiver section.
- OEffective operation distance can vary with the luminance around the receiver and the reflection from walls of the room.

OWhen the receiver is exposed to intensive light such as from the direct sun or a strong light, it may become operable only from a short distance or unable to receive signals at all.

Backup button


A backup switch is provided on the receiver section of the panel surface.

When operation from the wireless remote control is not possible (due to flat batteries, a mislaid unit, a unit failure), you can use it as an emergency means. You should operate this switch manually.

(1) If pressed while the air conditioner is in a halt, it will cause the air conditioner to start operation in the automatic mode.

Wind speed: Hi fan, Temperature setting: 23°C, Louver: horizontal

(2) If pressed while the air conditioner is in operation, it will stop the air conditioner.



Cooling test run operation

- After safety confirmation, turn on the power.
- Transmit a cooling operation command with the wireless remote control, while the backup switch on the receiver is depressed.
- If the backup switch on the receiver is pressed during a test run, it will end the test run.
- *If you cannot operate the unit properly during a test run, please check wiring by consulting with inspection guides.

③ FDEN (continued)

How to read the two-digit display

A two-digit indicator (7-segment indicator) is provided on the receiver section.

- (1) An indication will be displayed for one hour after power on.
- (2) An indication appears for 3.5 seconds when a "Stop" command is sent from the wireless remote control while the air conditioner is not running.
- (3) An indication appearing in (1) or (2) above will go off as soon as the unit starts operation.
- (4) When there are no error records to indicate, addresses are displayed for all of the connected units.
- (5) When there are some error records remaining, the error records are displayed.
- (6) Error records can be cleared by transmitting a "Stop" command from the wireless remote control, while the backup switch is depressed.

④ Remote control

Setting to avoid mixed communication


Pressing ACL and AIR FLOW button at the same time or inserting the batteries with pressing AIR FLOW button will customize the signal.

Setting to disable the Auto mode operation

VRF system (except heat recovery 3-pipe system) cannot be operated in Auto mode. Make sure to set the remote control for the models so as not to be able to choose Auto mode.

Pushing ACL and MODE button at the same time or inserting the batteries with pressing MODE button will make auto mode operation.

Radio prevention mode



Auto mode operation setting

***ATTENTION**


When the batteries are removed, the setting will return to the default setting. Please make sure to reset it when the batteries are replaced.


Caution

Instruct the customer to set the mentioned above when replacing the batteries. (How to set is also mentioned in the user's manual attached on the air conditioner.)

(3) FDU, FDUM, FDF series (RCN-KIT3-E)

10163.	
Following functions of FDU indoor unit series are not able to be set with this wirele	ess
remote control (RCN-KIT3-E).	
 4-fan speed setting (PHi/Hi/Me/Lo) →3-fan speed setting (Hi/Me/Lo) 	






2 Wireless remote control's operable area

(1) When installed on ceiling

(1) Standard reachable area of the signal


condition Illuminance at the receiver : 300lux (when no lighting is installed within 1m of the receiver in an ordinary of ce.)



(2) Correlation between illuminance at the receiver and reachable area of the signal in a plain view

condition Correlation between the reachable area of the signal and illuminance at the receiver when the remote control is operated at 1.1m high under the condition of ceiling height of 2.5m.

When the illuminance becomes double, the area is narrowed down to two third



③ How to install the receiver

The following two methods can be used to install the receiver onto a ceiling or a wall. Select a method according to the installation position.

<Installation position> (A) Direct installation onto the ceiling with wood screws.

(B) Installation with accessory's bracket

(1) Drilling of the ceiling (ceiling opening)


Drill the receiver installation holes with the following dimensions at the ceiling position where wires can be connected.

(A) Direct installation onto the ceiling with wood screws.	88mm(H)×101mm(W)	ī	
(B) Installation with enclosed bracket.	108mm(H)×108mm(W)	+	tin i
			w

(2) Wiring connection of receiver



be damaged.




(3) Installation of the receiver

Remove the screw on the side of the receiver and sprit it into the upper case and lower case.Install the receiver with one of the two installation methods (A) or (B) shown below

(A) Direct installation onto the ceiling with screws

Use this installation method when the ceiling is wooden, and there is no problem for strength in installing directly with wood screws




(1)Put through the wiring from the back side to the hole of the lower case.

- (Fit the lower case into the ceiling opening. Make sure that the clearance between the convex part of the back of the lower case and the ceiling opening must be as equal as possible on both sides.
- 3Using the two installation holes shown above, fix the lower case onto the ceiling with the enclosed wood screws. (The other four holes are not used.)
- (Connect the wiring with the wiring from the upper case by the connector 5Take out the connector to the backside from the hole of the lower case putting through the wiring at ①.
- 6Fit the upper case and the lower case, and tighten the screws.

(B) Installation with enclosed bracket

Use this method when installaing onto a gypsum board (7 to 18mm), etc.



O Catch the two protrusion of the enclosed bracket onto the tting as shown above, and temporarily fix with the screws. (The bracket has an up/down and front/back orientation. Con rm the top/bottom protrusion positions and the positional relation of the ø 10 holes on the bracket and the installation hole on the lower case with the above drawing.)

②Insert the end of the installation tting into the back of the ceiling from the opening, and tighten the screws to fix the bracket onto the ceiling.

③Pass the wiring from the rear side through the hole on the lower case.④Fit the lower case onto the bracket, and fix the lower case to the bracket using the two installation holes shown above. (The other four holes are not used.) ⑤Follow step ① to ⑥ for (A) to complete the installation.

④ Remote control

Installation of the control holder

Caution

- DO NOT install it on the follow ng places
- 1) Places exposed to direct sunlight 2) Places near heat devices



- Places near near devices
 Plah humidity places
 Hot surface or cold surface enough to generate condensation
 Places exposed to oil mist or steam directly
 Uneven surface

Installation tips for the remote control holder

- · Adjust and keep the holder upright.
- Tighten the screw to the end to avoid scratching
- the remote control. • DO NOT attach the holder to plaster wall.

How to insert batteries

- 1 Detach the back lid
- 2 Insert the batteries. (two AAA batteries)
- Reattach the back lid.

(5) Cooling test run operation


•After safety con rmation, turn on the power.

•Transmit a cooling operation command with wireless remote control, while the backup button on the receiver is pressed.

Wood screw

If the backup button on the receiver is pressed during a test run, it will end the test run.

If you cannot operate the unit properly during a test run, please check by consulting with inspection guides on the wiring diagram of outdoor units.



6 Setting of wireless remote control and receiver

(A) Methods of avoiding the malfunction due to the mixed communication Do both procedures ① and ②


This setting is to avoid the mixed communication with other household electric appliances or the mixed communication when two receivers are located closely ①Setting change of the wireless remote control

Pressing <u>ACL</u> and <u>AIRFLOW</u> button at the same time or inserting the batteries with pressing <u>AIRFLOW</u> button will customize the signal.

Note *When the batteries are removed, the setting will return to the default setting. Make sure to reset it when the batteries are replaced.

2 Setting the PCB of the receiver Turn SW1-1 off

+ •PCB of the receiver + •Wireless remote control



: Default setting

: Normal : Remote

: Master : Slave

53 53

²0:___:

10



. ①Connect the XY terminal with 2-core wire Restrictions on the thickness and length of wire (Maximun total extension 600m.) As for the size, refer to the following note. Within 100m x 0.3 mm² Within 200m x 0.3 mm² Within 200m x 0.5 mm² Within 300m x 0.75mm² Within 400m x 1.25mm² Within 600m x 2.0 mm² 2 For Packaged air conditioner series, set the Standard indoor unit address with SW2 on the indoor unit PCB from [0] to [F] so as not to duplicate Terminal block Г _ or unit (1 Indoor unit (2) Address (1) Indoor unit (16) Address (F) Address KIT

③For VRF series, set the indoor unit address with SW1, SW2 and SW5-2 on the indoor unit PCB from [000] to [127] so as not to duplicate

(C) Master/Slave setting when using plural remote control

Up to two receivers can be installed in one indoor unit group.

Indoor unit	Remote control line (Non-polarized)
RCN-KIT	RCN-KIT
SW1[Master]	SW1[Slave]

Holder for remote control

Switch	Setting	Function
SW1-2	ON	Master
5001-2	OFF	Slave

(D) Change setting of auto mode operation

Auto mode operation is prohibited to be selected for KX models (except for KXR models).

models). Therefore be sure to change setting of remote control to disable the auto mode operation for these models according to the following procedure. While pressing the <u>MODE</u> button, press the <u>ACL</u> switch, or while pressing the <u>MODE</u> button, insert the batteries to the remote control. Then the auto mode can be involved. can be invalid.

Attention When the batteries are removed, it is returned to initial setting (Auto mode becomes valid).

Accordingly when replacing the batteries, be sure to perform the above operation once again.

(E) Change setting of fan speed

While pressing the [FAN SPEED] button, press the [ACL] switch, or while pressing the [FAN SPEED] button, insert the batteries to the remote control. Then the fan speed can be changed from 2-speed setting to 3-speed setting. When changing fan speed setting of remote control, be sure to perform the same fan speed setting as that of the indoor unit model to be used.


Attention

When the batteries are removed, it is returned to initial setting (Fan speed setting is 2-speed).

Accordingly when replacing the batteries, be sure to perform the above operation once agair

12.2 Simple wired remote control (RCH-E3)

Notes: Following functions of FDU indoor unit series are not able to be set with this simple wired remote control (RCH-E3). 1. 4-fan speed setting (PHi/Hi/Me/Lo) →3-fan speed setting (Hi/Me/Lo)




 (1) Places exposed to direct sunlight
 (4) Hot surface or cold surface enough to generate condensation

 (2) Places near heat devices
 (5) Places exposed to oil mist or steam directly

 (3) High humidity places
 (6) Uneven surface







But, the wiring in the remote control case should be 0.3mm² (recommended) to 0.5mm². Change the wire size outside of the case according to wire connecting. Waterproof treatment is necessary at the wire

connecting section. Be careful about contact failure.

Length	Wiring thickness
100 to 200m	0.5mm ² × 2 cores
Under 300m	0.75mm ² × 2 cores
Under 400m	1.25mm ² × 2 cores
Under 600m	2.0mm ² × 2 cores

Adapted to **RoHS** directive





6. Function setting

Each function of the remote control and the indoor unit is automatically set to the initial setting, which is the standard use, on the occasion of connecting the remote control with the indoor unit. In the case of the standard use, the setting change is unnecessary. However, if you whould like to change the initial setting " () ", change the setting for only the item of the function number. Record the setting contents and stored them.

(1) Function setting item by switch on PCB

(1) Function	n setting ite	em by switch on PCB						SW1
Switch No.	Setting	Setting detail	Initial setting	Switch No.	Setting	Setting detail	Initial setting	OFF 1 2 3 4 5 6 7 8 9 0
SW1-1	ON	Slave remote control		SW1-5	ON	"TEMP" button prohibited		1 2 3 4 5 6 7 8 9 0
5001-1	0FF	Master remote control	0	5001-5	0FF	"TEMP" button enabled	0	
SW1-2	ON	Remote control thermistor enabled		SW1-6	ON	"FAN SPEED" button prohibited	% Note 1	
5001-2	0FF	Remote control thermistor disabled	0	SW1-0	0FF	"FAN SPEED" button enabled	% Note 1	
SW1-3	ON	"MODE" button prohibited		SW1-7	ON	Auto restart function enabled		 As for the slave remote control, fun
5001-5	OFF	"MODE" button enabled	0	SW1-7	0FF	Auto restart function disabled	0	than SW1-1.
SW1-4	ON	"ON/OFF" button prohibited		SW1-8, 9, 0	ON	Notwood		 In the indoor unit with only one fan sp
SvV1-4	0FF	"ON/OFF" button enabled	0	SW1-8, 9, U	0FF	Not used		he enabled



only one fan speed, "FAN SPEED" button cannot

(2) Function setting item by button operation


Classification	Function No.	Function	Setting No.	Setting	Initial setting	
Ţ			01	Fan speed: three steps	※ Note 1	The fan speed is three steps, \$\$ n = # - \$\$ n = - \$\$ n .
	01	Indoor unit fan speed	02	Fan speed: two steps (Hi-Lo)	% Note 1	The fan speed is two steps, 🗱 🖬 🖬 - 🗱 🖬 .
	01		03	Fan speed: two steps (Hi-Me)		The fan speed is two steps, # = = = - .
			04	Fan: one step	% Note 1	The fan speed is fixed to one step.
			01	Remote control thermistor: no offset	0	
			02	Remote control thermistor: +3.0 °C		At the time of cooling, in the case of remote control thermistor enabled, offset temperature at +3.0°C.
		Remote control	03	Remote control thermistor: +2.0 °C		At the time of cooling, in the case of remote control thermistor enabled, offset temperature at +2.0°C.
	03	thermistor at the time	04	Remote control thermistor: +1.0 °C		At the time of cooling, in the case of remote control thermistor enabled, offset temperature at +1.0°C.
		of cooling	05	Remote control thermistor: -1.0 °C		At the time of cooling, in the case of remote control thermistor enabled, offset temperature at -1.0°C.
			06	Remote control thermistor: -2.0 °C		At the time of cooling, in the case of remote control thermistor enabled, offset temperature at -2.0°C.
Remote			07	Remote control thermistor: -3.0 °C		At the time of cooling, in the case of remote control thermistor enabled, offsett temperature at -3.0°C.
control			01	Remote control thermistor: no offset	0	
function			02	Remote control thermistor: +3.0 °C		At the time of heating, in the case of remote control thermistor enabled, offset temperature at +3.0°C.
		Remote control	03	Remote control thermistor: +2.0 °C		At the time of heating, in the case of remote control thermistor enabled, offset temperature at +2.0°C.
	04	thermistor at the time	04	Remote control thermistor: +1.0 °C		At the time of heating, in the case of remote control thermistor enabled, offset temperature at +1.0°C.
l		of heating	05	Remote control thermistor: -1.0 °C		At the time of heating, in the case of remote control thermistor enabled, offset temperature at -1.0°C.
			06	Remote control thermistor: -2.0 °C		At the time of heating, in the case of remote control thermistor enabled, offset temperature at -2.0°C.
			07	Remote control thermistor: -3.0 °C		At the time of heating, in the case of remote control thermistor enabled, offset temperature at -3.0°C.
Ì			01	No ventilator connection	0	
	05	Ventilation setting	02	Ventilator links air-conditioner		In case of Single split series, by connecting ventilation device to CNT of the indoor printed circuit board (in case of VRF series, t connecting it to CND of the indoor printed circuit board), the operation of ventilation device is linked with the operation of indoor unit.
[06	"Auto" operation	01	"Auto" operation enabled	※ Note 1	
	00	setting	02	"Auto" operation disabled	※ Note 1	"Auto" operation disabled
	07	Operation permission/	01	Disabled	0	
	07	prohibition	02	Enabled		Operation permission/prohibition controller is enabled.
	00	- down of lines of	01	Level input	0	
	08	External input	02	Pulse input		
1			01	Standard	Note2	
	09	Fan speed setting	02	High speed 1	Note2	
			03	High speed 2	Note2	
Ì		Fan remaining	01	No remaining operation	0	After cooling stopped, no fan remaining operation
	10		02	0.5 hours		After cooling stopped, fan remaining operation for 0.5 hours
l	10	operation at the time of cooling	03	1 hour		After cooling stopped, fan remaining operation for 1 hour
		or cooling	04	6 hours		After cooling stopped, fan remaining operation for 6 hours
ĺ			01	No remaining operation	0	After heating stopped or after heating thermostat OFF, no fan remaining operation
		Fan remaining	02	0.5 hours		After heating stopped or after heating thermostat OFF, fan remaining operation for 0.5 hours
	11	operation at the time of heating	03	2 hours		After heating stopped or after heating thermostat OFF, fan remaining operation for 2 hours
Indoor unit		of fieaulig	04	6 hours		After heating stopped or after heating thermostat OFF, fan remaining operation for 6 hours
			01	No offset	0	
function		Setting temperature	02	Setting temperature offset + 3.0 °C		The setting temperature at the time of heating is offset by +3.0 °C.
	12	offset at the time of	03	Setting temperature offset + 2.0 °C		The setting temperature at the time of heating is offset by +2.0 °C.
		heating	04	Setting temperature offset + 1.0 °C		The setting temperature at the time of heating is offset by +1.0 °C.
1			01	Low fan speed	% Note 1	At the time of heating thermostat OFF, operate with low fan speed.
			02	Setting fan speed		At the time of heating thermostat OFF, operate with the setting fan speed.
	13	Heating fan controller	03	Intermittent operation	% Note 1	At the time of heatingr thermostat OFF, intermittently operate.
			04	Fan off		At the time of heating thermostat OFF, a fan will be stopped. When the remote control thermistor is enabled, automatically set to "Fan off". Do not set at the time of the indoor unit thermistor.
			01	No offset	0	
			02	Return air temperature offset +2.0 °C		Offset the return air temperature of the indoor unit by +2.0 °C.
1			03	Return air temperature offset +1.5 °C		Offset the return air temperature of the indoor unit by +1.5 °C.
		Return air temperature				
	14		04	Return air temperature offset +1.0 °C		Offset the return air temperature of the indoor unit by +1.0 °C.
	14	Return air temperature offset				
	14		04 05 06	Return air temperature offset +1.0 °C Return air temperature offset -1.0 °C Return air temperature offset -1.5 °C		Offset the return air temperature of the indoor unit by +1.0 °C. Offset the return air temperature of the indoor unit by -1.0 °C. Offset the return air temperature of the indoor unit by -1.5 °C.

Note 1: The symbol " % " in the initial setting varies depending upon the indoor unit and the outdoor unit to be connected, and this is automatically determined as follows:

Function	Setting	Product model
"EAN ODEED"	"FAN SPEED" button prohibited	Product model whose indoor fan speed is only one step
	"EAN SPEED" button onabled	Product model whose indoor fan speed is two steps or three
DULLOIT	TAN SPEED DULLOIT EIIADIEU	Product model whose indoor fan speed is only one step Product model whose indoor fan speed is two steps or t steps Product model whose indoor unit fan speed is three ste Product model whose indoor unit fan speed is two steps
	Fan speed: three steps	Product model whose indoor unit fan speed is three steps
Indoor unit fan	Fan speed: two steps (Hi-Lo)	Product model whose indoor unit fan speed is two steps
speed	Fan speed: two steps (Hi-Me)	
	Fan: one step	Product model whose indoor unit fan speed is only one step
"Auto" operation	"Auto" operation enabled	Product model where "Auto" mode is selectable
setting	"Auto" operation disabled	Product model without "Auto" mode
Heating fan	Low fan speed	Product model except FDUS
control	Intermittent operation	FDUS
	"FAN SPEED" button Indoor unit fan speed "Auto" operation setting Heating fan	"FAN SPEED" button prohibited "FAN SPEED" button prohibited "FAN SPEED" button prohibited "FAN SPEED" button enabled Fan speed: two steps (Hi-Lo) Fan speed: two steps (Hi-Me) Fan: one step "Auto" operation enabled setting Heating fan Low fan speed

Fan speed setting	Indoor unit fan speed setting					
r an speeu setung	\$6 a m M - \$6 a m - \$6 a	\$t = 2 = \$t =	\$t a # # - \$t a #			
Standard	Hi — Mid — Lo	Hi — Lo	Hi — Mid			
High speed 1 • 2	UHi — Hi — Mid	UHi — Mid	UHi — Hi			
nitial setting of some indoor unit is "High speed".						

Note 3: As for plural indoor unit, set indoor functions to each master and slave indoor unit. But only master indoor unit is received the setting change of indoor unit function "07 Operation permission/ prohibition" and "08 External input".



12.3 Filter kit (FDUM series)

PJZ012D076A

This manual contains installation points and operating instructions for the filter kit manufactured by MHI. Carry out the work following the instructions below.

This manual also contains information on the usage after installation,

so keep this manual properly with USER'S MANUAL provided with the indoor unit.



· After unpacking, carry out this work on the ground.

- Do not carry out the work during operation, or there is a danger of being entangled in the rotating parts and getting injured.
- Clean the air filter regularly.
- · Be sure to entrust qualified serviceman to performance on the air filter.
- · Be sure to cut off the power and stop the unit before performing maintenance.

1. Table of filter kit parts No. and corresponding object models


	Small model	Medium model	Large model
Single type	40, 50	60, 71	100 - 140
Multi type	22 - 56	71, 90	112 - 160
Filter Kit	UM-FL1EF	UM-FL2EF	UM-FL3EF

2. Parts list of filter kit

Filte	r	Rail	Insulation				
1pc	;	2рс	2pc				
Bracket		Parts set (screw)					
	000	ר פ י רפי רפי	ବ୍ <mark></mark> କୃତ୍କୃତ୍କ ବୃତ୍କୃତ୍କୁ				
	small and model	: 5pcs.	arge model : 7pcs.				
1pc		1pc					


3. Installation Points

(1) Stick the insulation on both inner sides of the duct, leaving no space up and down.




(*) After unpacking, bottom side of the unit is located at the upper side.


(2) Install the rail on both inner sides of the duct with the screw.




(3) Install the air filter on the rails.



(4) Install the bracket on the rail with the screw.







Installation procesure

(**) When the unit is installed, bottom side of the unit is located at the lower side.

12.4 Interface kit (SC-BIKN-E)

RKZ012A088B








Installation check items

□ Are the connection cables connected securely to the terminal blocks and connectors?

 \Box Are the thickness and length of the connection cables conformed with the standard?







PJZ012D029F

12.5 Super link E board (SC-ADNA-E)

Read and understand the instructions completely before starting installation. • Refer to the instructions for both indoor and outdoor units.

Safety precautions

Carefully read "Safety precautions" first. Follow the instructions for installation.

- Precautions are grouped into "Warning A" and "Caution A". The "Warning A" group includes items that may lead to serious injury or death if not observed. The items included in the "Caution^A"</sup> group also may lead to serious results under certain conditions. Both groups are crucial for safety installation. Read and understand them carefully. • After installation, conduct the test operation of the device to check for any abnormalities. Describe how to operate the device to the customer following the installation instruc-
- tion manual. Instruct the customer to keep this installation instruction for future reference.


Warning

- This device should be installed by the dealer where you purchase the device or a licensed professional shop. If the device is incorrectly installed by the ustomer, it may result in electric shock or fire.
 Install the device carefully following the installation instruction. If the device is
- incorrectly installed, it may result in electric shock or fire.
- Use the accessory parts and specified parts for installation. If any parts that do not match the specifications are used, it may result in electric shock or fire.
- A person with the electrical service certification should conduct the service based on the "Technical standards for electrical facilities", "Electrical Wiring Code", and the installation instruction. If the work is done incorrectly, it may result in electric shock or fire.
- Wiring should be securely connected using the specified types of wire. No external force on the wire should be applied to any terminals. If a secure connection is not achieved, it may result in electric shock or fire.

1 Application

Indoor-to-outdoor three core communication specification type 3 (since October 2007)

2 Accessories



3 Function

Allowing the center console SL1N-E, SL2N-E, and SL3N-AE/BE to control and monitor the commercial air conditioning unit.

4 Control switching

Settings can be changed by the switch SW3 on the SL E board as in the following

Switch	Symbol	Switch	Remarks	
	1	ON	Master	
	I	OFF (default)	Slave	
		ON	Fixed previous protocol	
	2		OFF (default)	Automatic adjustment of Super Link protocol
SW3	0		ON	Indicates the forced operation stop when abnormality has occurred.
	3	OFF (default)	Indicates the status of running/stop as it is, when abnormality has occurred.	
	4	ON	The hundredth address activated "1"	
	4	OFF (default)	The hundredth address activated "0"	


∧Caution


- Provide around connection. The ground line should never be connected to the gas supply piping, the water supply piping, the lightning conductor rod, nor the telephone ground. If the grounding is improper, it may result in electric shock.
- Do not install the device in the following locations.
- 1.Where there is mist/spray of oil or steam such as kitchens. 2.Where there is corrosive gases such as sulfurous acid gas. 3.Where there is a device generating electromagnetic waves. These may interfere with the control system resulting in the device becoming uncontrollable.
- 4.Where flammable volatile materials such as paint thinner and gasoline may exist or where they are handled. This may cause a fire.

5 Connection Outline

Note for setting the address

- Set the address between 00 and 47 for the previous Super Link connection
- and between 000 and 127 for the new Super Link connection. (*1)
- Do not set the address overlapping with those of the other devices in the





(*1) Whether the actual link is either the new Super Link or the previous Super Link depends on the models of the connected outdoor and indoor units. Consult the agent or the dealer.

Signal line specification

Communication method	Previous Super Link	New Super Link
Line type	MVVS	MVVS
Line diameter	0.75 - 1.25mm ²	0.75/1.25mm ²
Signal line (total length)	up to 1000m	up to 1500/1000m (*2)
Signal line (maximum length)	up to 1000m	up to 1000m


(*2) Up to 1500 m for 0.75 mm², and up to 1000 m for 1.25 mm². Do not use 2.0 mm². It may cause an error.

(*3) Connect grounding on both ends of the shielding wire.

For the grounding method, refer to the section "6 Installation".

- 164 -

- Set the Super Link network address with SW1 (tens place), SW2 (ones place), and SW3 (hundreds place).
- (2) Set the SL E board SW3-1 to be ON (Master) when using this without any remote control (no wired remote control nor wireless remote control).
- (3) Set up the plural master/slave device using the dip switches on the indoor unit board.
- (4) Set up the remote control master/slave device using the slide switch on the remote control board.
- (5) Set up "0" to "F" using the address rotary switch on the indoor unit board when controlling the indoor unit with the multiple remote control.




6 Installation


1. When using the metal box (mounted on the indoor unit / mounted on the back of the remote control):

- Mount the SL E board in the metal box using the locking supports.
 Minima should be through the metal does using the locking supports.
- (2) Wiring should go through the provided grommet since then through the wiring to the hole on the Metal box.


Secure the grommet after inserting the grommet into the Metal box as shown in below figure, then tie the wiring at the outlet of the unit using a binding band.




When installed outside the indoor unit, put the metal cover on.




▲ When installed on the back of the remote control, mount it directly on the remote control bottom case.



Connect grounding. Connect grounding for the power line to Ground (), and grounding for the signal line to Ground (2) or to the Ground on the indoor unit control box.



- When connecting to the indoor unit control box (ceiling-concealed type and FDT type only):
 - (1) Mount the SL E board in the control box using the locking supports.
 - (2) Remove 6 bands from the box and put the wiring through the bands to be secured.



Electrical shock hazard! Make sure to turn the power off for servicing. Be cautious so that no abnormal force should be applied to the wiring. Do not let the SL E board hung by the wiring. Do not damage the board with a screw driver.

The board is sensitive to static electricity. Release the static electricity of your body before servicing.

(you can do this by touching the control board which is grounded).

Location of installation

Install the device at the location where there are no electromagnetic waves nor where there is water and dust. The specified temperature range of the device is 0 to 40°C. Install the device at the location where the ambient temperature stays within the range. If it exceeds the specification, make sure to provide solution such as installing a cooling fan. When used outside of the range, it may cause abnormal operation.

7 Indicator display

Check the LED 3 (green) and LED 2 (red) on the SL E board for flashing.

SL E boa	ard LEDs		Display on the
Red	Green	Inspection mode	integrated network control device
Off	Flashing	Normal communication	
Off	Off	Disconnection in the remote control communication line (X or Y) Short-circuit in the remote control communication line (between X and Y) Faulty indoor unit remote control power Faulty remote control communication circuit Faulty CPU on SL E board	No corresponding unit number
One flash	Flashing	Disconnection in the Super Link signal line (A or B) Short-circuit in the Super Link signal line (between A and B) Faulty Super Link signal circuit	
Two flashes	Flashing	Faulty address setting for the SL E board (Set up the address for previous SL E board : more than 48 new SL E board : more than 128)	
Three flashes	Flashing	 SL E board parent not set up when used without a remote control Faulty remote control communication circuit 	E1
Four flashes	Flashing	Address overlapping for the SL E board and the Super Link network connected indoor unit	E2
Off	Flashing	 Number of connected devices exceeds the specification for the multiple indoor unit control 	E10

PJZ012D029C

13. TECHNICAL INFORMATION

(1) Ceiling cassette-4way type (FDT)

Model FDT71VNPVF1

Information to identify the model(s) to which		n relates to:	If function includes heating: Indicate the heating		
Indoor unit model name	FDT71VF1		information relates to. Indicated values show		
Outdoor unit model name	FDC71VNP		heating season at a time. Include at least th	e heating s	eason 'Average'.
Function(indicate if present)			Average(mandatory)	Yes	
cooling	Yes		Warmer(if designated)	No	
heating	Yes		Colder(if designated)	No	
Item	symbol val	ue unit	Item	symbol	value class
Design load			Seasonal efficiency and energy efficiency cl		
cooling	· · –	7.1 kW	cooling	SEER	6.14 A++
heating / Average	~ <u> </u>	5.7 kW	heating / Average	SCOP/A	4.27 A+
heating / Warmer	Pdesignh	- kW	heating / Warmer	SCOP/W	• -
heating / Colder	Pdesignh	- kW	heating / Colder	SCOP/C	 unit
Declared capacity at outdoor temperature	Tdesianh		Back up heating capacity at outdoor temper	ature Tdesi	
heating / Average (-10°C)		5.70 kW	heating / Average (-10°C)	elbu	0 kW
heating / Warmer (2°C)	Pdh	- kW	heating / Warmer (2°C)	elbu	- kW
heating / Colder (-22°C)	Pdh	- kW	heating / Colder (-22°C)	elbu	- kW
			· · ·		
Declared capacity for cooling, at indoor te	mperature 27(19)	C and	Declared energy efficiency ratio, at indoor to	emperature	27(19)°C and
outdoor temperature Tj			outdoor temperature Tj		
Tj=35°C		7.10 kW	Tj=35°C	EERd	2.84 -
Tj=30°C		5.20 kW	Tj=30°C	EERd	4.80 -
Tj=25°C		3.40 kW 1.50 kW	Tj=25°C	EERd	7.70 -
Tj=20°C	Pdc	1.50 kW	Tj=20°C	EERd	11.00 -
Declared capacity for heating / Average se	ason, at indoor		Declared coefficient of performance / Average	de season	at indoor
temperature 20°C and outdoor temperature			temperature 20°C and outdoor temperature		
Tj=-7°C		5.00 kW	Tj=-7°C	COPd	2.70 -
Tj=2°C		3.00 kW	Tj=2°C	COPd	4.10 -
Tj=7°C		2.00 kW	Tj=7°C	COPd	5.80 -
Tj=12°C		1.30 kW	Tj=12°C	COPd	6.60 -
Tj=bivalent temperature		5.70 kW	Tj=bivalent temperature	COPd	2.50 -
Tj=operating limit	Pdh	5.10 kW	Tj=operating limit	COPd	2.30 -
Declared capacity for heating / Warmer set temperature 20°C and outdoor temperature			Declared coefficient of performance / Warm temperature 20°C and outdoor temperature		at Indoor
Tj=2°C	Pdh	- kW	Ti=2°C	COPd	- -
Ti=7°C	Pdh	- kW	Tj=7°C	COPd	
Ti=12°C	Pdh	- kW	Tj=12℃	COPd	
Tj=bivalent temperature	Pdh	- kW	Tj=bivalent temperature	COPd	
Tj=operating limit	Pdh	- kW	Tj=operating limit	COPd	
Declared capacity for heating / Colder seas	son, at indoor		Declared coefficient of performance / Colder	r season, at	tindoor
temperature 20°C and outdoor temperature			temperature 20°C and outdoor temperature		
Tj=-7°C	Pdh	- kW	Tj=-7°C	COPd	
Tj=2°C	Pdh	- kW	Tj=2°C	COPd	
Tj=7°C	Pdh	- kW	Tj=7°C	COPd	
Tj=12°C Tj=bivalent temperature	Pdh Pdh	- kW - kW	Tj=12°C Tj=bivalent temperature	COPd COPd	
Tj=operating limit	Pdh	- kW	Tj=operating limit	COPd	
Tj=-15℃	Pdh	- kW	Tj=-15°C	COPd	
1 100	, and			00.0	1
Bivalent temperature			Operating limit temperature		
heating / Average	Tbiv	-10 °C	heating / Average	Tol	-15 ℃
heating / Warmer	Tbiv	- °C	heating / Warmer	Tol	°C
heating / Colder	Tbiv	- °C	heating / Colder	Tol	- °C
Cycling interval capacity		1.344	Cycling interval efficiency		
for cooling	Pcycc	- kW	for cooling	EERcyc	
for heating	Pcych	- kW	for heating	COPcyc	
Degradation coefficient]	Degradation coefficient		
cooling	Cdc	0.25 -	heating	Cdh	0.25 -
	040		Inodanig	oun	0.20
Electric power input in power modes other	r than 'active mod	de'	Annual electricity consumption		
off mode	Poff	11 W	cooling	Qce	405 kWh/a
standby mode	Psb	11 W	heating / Average	Qhe	1871 kWh/a
thermostat-off mode	Pto	16 W	heating / Warmer	Qhe	- kWh/a
crankcase heater mode	Pck	0 W	heating / colder	Qhe	- kWh/a
		1	Others items		
Capacity control(indicate one of three optic	ons)		Other items	Luca	
			Sound power level(indoor) Sound power level(outdoor)	Lwa Lwa	64 dB(A) 67 dB(A)
fixed	No		Global warming potential	GWP	1975 kgCO2eq.
staged	No		Rated air flow(indoor)	-	1680 m ³ /h
variable	Yes		Rated air flow(outdoor)	-	2160 m ³ /h
					· · · · · · · · · · · · · · · · · · ·
Contact details for obtaining			acturer or of its authorised representative.		
		es Air-Conditioning			
		ockley Park, Uxbrid	lge, Middlesex, UB11 1AX.		
United K	Ingdom				

Model FDT90VNPVF1

Information to identify the model((s) to which the inform	ation relates to:	If function includes heating: Indicate	the heating seasor	n the
Indoor unit model name	FDT100V		information relates to. Indicated valu	•	
Outdoor unit model name	FDC90VN	IP	heating season at a time. Include at	least the heating se	eason 'Average'.
Function(indicate if present)			Average(mandatory)	Yes	
cooling	Yes		Warmer(if designated)	No	
heating	Yes		Colder(if designated)	No	
Item	symbol	value unit	Item	symbol	value class
Design load	Symbol	value unit	Seasonal efficiency and energy efficiency		Value Class
cooling	Pdesignc	9.0 kW	cooling	SEER	6.73 A++
heating / Average	Pdesignh	8.1 kW	heating / Average	SCOP/A	4.11 A+
heating / Warmer	Pdesignh		heating / Warmer	SCOP/W	
heating / Colder	Pdesignh		heating / Colder	SCOP/C	
					unit
Declared capacity at outdoor tem	perature Tdesignh		Back up heating capacity at outdoor	temperature Tdesig	gnh
heating / Average (-10°C)	Pdh	8.10 kW	heating / Average (-10°C)	elbu	0 kW
heating / Warmer (2°C)	Pdh	- kW	heating / Warmer (2°C)	elbu	- kW
heating / Colder (-22°C)	Pdh	- kW	heating / Colder (-22°C)	elbu	- kW
Declared capacity for cooling, at	indoor temperature 2	7(19)C and	Declared energy efficiency ratio, at in	ndoor temperature	27(19)°C and
outdoor temperature Tj			outdoor temperature Tj		
Tj=35°C	Pdc	9.00 kW	Tj=35°C	EERd	3.37 -
Tj=30°C	Pdc	6.60 kW	Tj=30°C	EERd	5.10 -
Tj=25°C Tj=20°C	Pdc Pdc	4.30 kW 1.90 kW	Tj=25°C Tj=20°C	EERd EERd	8.20 - 12.10 -
I]=20 C	Puc	1.90 KVV		EERU	12.10 -
Declared capacity for heating / Av	verage season at inde	or	Declared coefficient of performance	/ Average season	at indoor
temperature 20°C and outdoor ter			temperature 20°C and outdoor temp		
Tj=-7°C	Pdh	7.10 kW	Ti=-7°C	COPd	2.85 -
Tj=2°C	Pdh	4.30 kW	Tj=2°C	COPd	4.00 -
Tj=7°C	Pdh	2.70 kW	Tj=7°C	COPd	5.35 -
Tj=12°C	Pdh	1.30 kW	Tj=12°C	COPd	5.00 -
Tj=bivalent temperature	Pdh	8.10 kW	Tj=bivalent temperature	COPd	2.50 -
Tj=operating limit	Pdh	7.10 kW	Tj=operating limit	COPd	2.20 -
Declared capacity for heating / W		or	Declared coefficient of performance		at indoor
temperature 20°C and outdoor ter			temperature 20°C and outdoor temp		
Tj=2°C	Pdh	- kW	Tj=2°C	COPd	
Tj=7°C	Pdh	- kW	Tj=7°C	COPd	
Tj=12°C	Pdh	- kW	Tj=12°C	COPd	
Tj=bivalent temperature	Pdh	- kW	Tj=bivalent temperature	COPd	
Ti apparenting limit	Dah	100/			
Tj=operating limit	Pdh	- kW	Tj=operating limit	COPd	
			Tj=operating limit	COPd	
Declared capacity for heating / Co	older season, at indoo		Tj=operating limit Declared coefficient of performance	COPd / Colder season, at	
Declared capacity for heating / Co temperature 20°C and outdoor ter	older season, at indoo mperature Tj	r	Tj=operating limit Declared coefficient of performance temperature 20°C and outdoor temp	COPd / Colder season, at erature Tj	
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C	older season, at indoo		Tj=operating limit Declared coefficient of performance temperature 20°C and outdoor temp Tj=-7°C	COPd / Colder season, at erature Tj COPd	
Declared capacity for heating / Co temperature 20°C and outdoor ter	older season, at indoo mperature Tj Pdh	r kW	Tj=operating limit Declared coefficient of performance temperature 20°C and outdoor temp Tj=-7°C Tj=2°C	COPd / Colder season, at erature Tj	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter $T_{j=-7$ °C $T_{j=2}$ °C	older season, at indoo mperature Tj Pdh Pdh	r kW kW	Tj=operating limit Declared coefficient of performance temperature 20°C and outdoor temp Tj=-7°C	COPd / Colder season, at erature Tj COPd COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter $T_{j=-7^{\circ}C}$ $T_{j=2^{\circ}C}$ $T_{j=7^{\circ}C}$	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh	r kW kW kW	Tj=operating limit Declared coefficient of performance temperature 20°C and outdoor temp Tj=-7°C Tj=2°C Tj=7°C	COPd / Colder season, at erature Tj COPd COPd COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=7°C Tj=12°C	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh	r - kW - kW - kW - kW	Tj=operating limit Declared coefficient of performance. temperature 20°C and outdoor temp Tj=-7°C Tj=2°C Tj=7°C Tj=12°C	COPd / Colder season, at erature Tj COPd COPd COPd COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=7°C Tj=12°C Tj=bivalent temperature	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh	r - kW - kW - kW - kW - kW	Tj=operating limit Declared coefficient of performance temperature 20°C and outdoor temp Tj=-7°C Tj=2°C Tj=7°C Tj=12°C Tj=bivalent temperature	COPd / Colder season, at erature Tj COPd COPd COPd COPd COPd COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh	r - kW - kW - kW - kW - kW	Tj=operating limit Declared coefficient of performance temperature 20°C and outdoor temp Tj=-7°C Tj=2°C Tj=7°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C	COPd / Colder season, at erature Tj COPd COPd COPd COPd COPd COPd COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh	r - kW - kW - kW - kW - kW - kW - kW	Tj=operating limit Declared coefficient of performance, temperature 20°C and outdoor temp Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature	COPd / Colder season, at erature Tj COPd COPd COPd COPd COPd COPd COPd COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv	r - kW - kW - kW - kW - kW - kW - kW - kW	Tj=operating limit Declared coefficient of performance, temperature 20°C and outdoor temp Tj=-7°C Tj=2°C Tj=12°C Tj=operating limit Tj=operating limit Tj=-15°C Operating limit temperature heating / Average	COPd / Colder season, at erature Tj COPd COPd COPd COPd COPd COPd COPd COPd COPd COPd COPd COPd COPd COPd COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Warmer	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv	r - kW - kW - kW - kW - kW - kW - kW - kW - kW	Tj=operating limit Declared coefficient of performance is temperature 20°C and outdoor temp Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=-15°C Operating limit temperature heating / Average heating / Warmer	COPd / Colder season, at verature Tj COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv	r - kW - kW - kW - kW - kW - kW - kW - kW	Tj=operating limit Declared coefficient of performance, temperature 20°C and outdoor temp Tj=-7°C Tj=2°C Tj=12°C Tj=operating limit Tj=operating limit Tj=-15°C Operating limit temperature heating / Average	COPd / Colder season, at erature Tj COPd COPd COPd COPd COPd COPd COPd COPd COPd COPd COPd COPd COPd COPd COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Warmer heating / Colder	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv	r - kW - kW - kW - kW - kW - kW - kW - kW - kW	$\begin{tabular}{ c c c c }\hline Tj=operating limit \\ \hline Declared coefficient of performance, temperature 20°C and outdoor temp Tj=-7°C \\ Tj=2°C \\ Tj=2°C \\ Tj=bivalent temperature \\ Tj=operating limit \\ Tj=-15°C \\ \hline \hline Operating limit temperature heating / Average heating / Warmer heating / Colder \\ \hline \hline \end{tabular}$	COPd / Colder season, at verature Tj COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Warmer heating / Colder	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv	r - kW - kW - kW - kW - kW - kW - kW - kW - kW - c - c	Tj=operating limit Declared coefficient of performance, temperature 20°C and outdoor temp Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Warmer heating / Colder Cycling interval efficiency	COPd / Colder season, at erature Tj COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Warmer heating / Colder Cycling interval capacity for cooling	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv	r - kW - kW - kW - kW - kW - kW - kW - kW - kW - kW	Tj=operating limit Declared coefficient of performance, temperature 20°C and outdoor temp Tj=-7°C Tj=2°C Tj=12°C Tj=operating limit Tj=operating limit Tj=operating limit Tj=operating limit temperature heating / Average heating / Colder Cycling interval efficiency for cooling	COPd / Colder season, at erature Tj COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Warmer heating / Colder	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv	r - kW - kW	Tj=operating limit Declared coefficient of performance, temperature 20°C and outdoor temp Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Warmer heating / Colder Cycling interval efficiency	COPd / Colder season, at erature Tj COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv	r - kW - kW - kW - kW - kW - kW - kW - kW - kW - kW	Tj=operating limit Declared coefficient of performance, temperature 20°C and outdoor temp Tj=-7°C Tj=2°C Tj=12°C Tj=isualent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Colder Cycling interval efficiency for cooling for heating	COPd / Colder season, at erature Tj COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Colder Cycling interval capacity for cooling	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv	r - kW - kW - kW - kW - kW - kW - kW - kW - kW - kW	Tj=operating limit Declared coefficient of performance, temperature 20°C and outdoor temp Tj=-7°C Tj=2°C Tj=12°C Tj=operating limit Tj=operating limit Tj=operating limit Tj=operating limit temperature heating / Average heating / Colder Cycling interval efficiency for cooling	COPd / Colder season, at erature Tj COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Chiv Chiv Chiv	r - kW - kW	Tj=operating limit Declared coefficient of performance, temperature 20°C and outdoor temp Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Warmer heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient	COPd / Colder season, at erature Tj COPd COPC COP	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=2°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Cdc Cdc	r - kW - kW	Tj=operating limit Declared coefficient of performance, temperature 20°C and outdoor temp Tj=-7°C Tj=2°C Tj=12°C Tj=isvalent temperature Tj=-15°C Operating limit temperature Tj=-15°C Operating limit temperature heating / Average heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating Annual electricity consumption	COPd / Colder season, at ierature Tj COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Cdc Cdc	r - kW - k	Tj=operating limit Declared coefficient of performance, temperature 20°C and outdoor temp Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Warmer heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating Annual electricity consumption cooling	COPd / Colder season, at erature Tj COPd COPcyc	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Cdc Cdc Poff Psb	r - kW - c - °C - °C	Tj=operating limit Declared coefficient of performance, temperature 20°C and outdoor temp Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Warmer heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating Annual electricity consumption cooling heating / Average	COPd / Colder season, at erature Tj COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=7°C Tj=2°C Tj=bivalent temperature Tj=operating limit Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Cdc Cdc Poff Psb Pto	r - kW - k	Tj=operating limit Declared coefficient of performance, temperature 20°C and outdoor temp Tj=-7°C Tj=2°C Tj=12°C Tj=operating limit Tj=operating limit Tj=operating limit temperature Tj=operating limit temperature heating / Average heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating Annual electricity consumption cooling heating / Average heating / Average heating	COPd / Colder season, at erature Tj COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Cdc Cdc Poff Psb	r - kW - c - °C - °C	Tj=operating limit Declared coefficient of performance, temperature 20°C and outdoor temp Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Warmer heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating Annual electricity consumption cooling heating / Average	COPd / Colder season, at erature Tj COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode crankcase heater mode	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Cdc Cdc odes other than 'active Poff Psb Pto Pck	r - kW - k	Tj=operating limit Declared coefficient of performance, temperature 20°C and outdoor temp Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=12°C Operating limit temperature heating / Average heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating / Average heating Annual electricity consumption cooling heating / Average heating / Average heating	COPd / Colder season, at erature Tj COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=7°C Tj=2°C Tj=bivalent temperature Tj=operating limit Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Cdc Cdc odes other than 'active Poff Psb Pto Pck	r - kW - k	Tj=operating limit Declared coefficient of performance, temperature 20°C and outdoor temp Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Warmer heating / Colder Cycling interval efficiency for cooling to reating Degradation coefficient heating Annual electricity consumption cooling heating / Average heating / Warmer heating Other items	COPd / Colder season, at erature Tj COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode crankcase heater mode	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Cdc Cdc odes other than 'active Poff Psb Pto Pck	r - kW - k	Tj=operating limit Declared coefficient of performance, temperature 20°C and outdoor temp Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating / Average heating Manual electricity consumption cooling heating / Average heating / Average heating / Colder	COPd / Colder season, at erature Tj COPd CDA COPd COPd COPd CDA CDA CDA CDA CDA CDA CDA CDA	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode crankcase heater mode Capacity control(indicate one of the standby control(indicate one	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Cdc Cdc vdes other than 'active Poff Psb Pto Pck	r - kW - k	Tj=operating limit Declared coefficient of performance, temperature 20°C and outdoor temp Tj=-7°C Tj=2°C Tj=12°C Tj==12°C Tj=ibivalent temperature Tj=-15°C Operating limit temperature heating / Average heating Cycling interval efficiency for cooling for heating Degradation coefficient heating / Average heating / Colder Operating limit temperature for cooling heating for heating Annual electricity consumption cooling heating / Average heating / Warmer heating / Colder Other items Sound power level(indoor) Sound power level(outdoor)	COPd / Colder season, at ierature Tj COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode crankcase heater mode Capacity control(indicate one of the fixed	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Cdc Cdc odes other than 'active Poff Psb Pto Pck hree options)	r - kW - k	Tj=operating limit Declared coefficient of performance, temperature 20°C and outdoor temp Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating / Average heating Operating limit remperature heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating / Average heating / Average heating / Average heating / Colder Other items Sound power level(indoor) Sound power level(outdoor) Global warming potential	COPd / Colder season, at erature Tj COPd CDA COPd COPd COPd CDA CDA CDA CDA CDA CDA CDA CDA	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode crankcase heater mode Capacity control(indicate one of the fixed staged	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Cdc Cdc vdes other than 'active Poff Psb Pto Pck	r - kW - k	Tj=operating limit Declared coefficient of performance, temperature 20°C and outdoor temp Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating / Average heating Annual electricity consumption cooling heating / Average heating / Warmer heating Other items Sound power level(indoor) Sound power level(indoor) Global warming potential Rated air flow(indoor)	COPd / Colder season, at ierature Tj COPd COP CDP CDP CDP CDP CDP CDP CDP CD	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode crankcase heater mode Capacity control(indicate one of the fixed	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Cdc Cdc Cdc odes other than 'active Poff Psb Pto Pck hree options)	r - kW - k	Tj=operating limit Declared coefficient of performance, temperature 20°C and outdoor temp Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating / Average heating Operating limit remperature heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating / Average heating / Average heating / Average heating / Colder Other items Sound power level(indoor) Sound power level(outdoor) Global warming potential	COPd / Colder season, at ierature Tj COPd COP CDP CDP CDP CDP CDP CDP CDP CD	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode crankcase heater mode Capacity control(indicate one of the fixed staged	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Cdc Cdc Odes other than 'active Poff Psb Pto Pck hree options)	r - kW - kW - kW - kW - kW - kW - kW - kW - c - °C - °C	Tj=operating limit Declared coefficient of performance, temperature 20°C and outdoor temp Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating / Average heating Annual electricity consumption cooling heating / Average heating / Warmer heating Other items Sound power level(indoor) Sound power level(indoor) Global warming potential Rated air flow(indoor)	COPd / Colder season, at ierature Tj COPd COP COP COP COP COP COP COP COP	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode crankcase heater mode Capacity control(indicate one of the fixed staged variable	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Cdc Cdc Odes other than 'active Poff Psb Pto Pck hree options)	r 	Tj=operating limit Declared coefficient of performance, temperature 20°C and outdoor temp Tj=-7°C Tj=2°C Tj=12°C Tj=12°C Tj=ibivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Average heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating / Average heating / Warmer heating Annual electricity consumption cooling heating / Average heating / Warmer heating / Colder Other items Sound power level(indoor) Sound power level(indoor) Sound power level(indoor) Rated air flow(indoor) Rated air flow(outdoor) ufacturer or of its authorised representat	COPd / Colder season, at ierature Tj COPd COP COP COP COP COP COP COP COP	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode crankcase heater mode Capacity control(indicate one of the fixed staged variable Contact details for obtaining	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh	- kW - %C - %W -	Tj=operating limit Declared coefficient of performance, temperature 20°C and outdoor temp Tj=-7°C Tj=2°C Tj=12°C Tj=12°C Tj=ibivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Average heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating / Average heating / Warmer heating Annual electricity consumption cooling heating / Average heating / Warmer heating / Colder Other items Sound power level(indoor) Sound power level(indoor) Sound power level(indoor) Rated air flow(indoor) Rated air flow(outdoor) ufacturer or of its authorised representat	COPd / Colder season, at ierature Tj COPd COP COP COP COP COP COP COP COP	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode crankcase heater mode Capacity control(indicate one of the fixed staged variable Contact details for obtaining	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Tbiv Cdc Cdc Odes other than 'active Poff Psb Pto Pck hree options) No Yes Name an Mitsubishi Heavy Ind	- kW - %C - %W -	Tj=operating limit Declared coefficient of performance, temperature 20°C and outdoor temp Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Warmer heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating Annual electricity consumption cooling heating / Average heating / Warmer heating / Colder Other items Sound power level(indoor) Sound power level(indoor) Global warming potential Rated air flow(indoor) Rated air flow(outdoor) ufacturer or of its authorised representating Europe, Ltd.	COPd / Colder season, at ierature Tj COPd COP COP COP COP COP COP COP COP	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode crankcase heater mode Capacity control(indicate one of the fixed staged variable Contact details for obtaining	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh	- kW - %C - %W -	Tj=operating limit Declared coefficient of performance, temperature 20°C and outdoor temp Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Warmer heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating Annual electricity consumption cooling heating / Average heating / Warmer heating / Colder Other items Sound power level(indoor) Sound power level(indoor) Global warming potential Rated air flow(indoor) Rated air flow(outdoor) ufacturer or of its authorised representating Europe, Ltd.	COPd / Colder season, at ierature Tj COPd COP COP COP COP COP COP COP COP	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode crankcase heater mode Capacity control(indicate one of the fixed staged variable Contact details for obtaining	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh	- kW - %C - %W -	Tj=operating limit Declared coefficient of performance, temperature 20°C and outdoor temp Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Warmer heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating Annual electricity consumption cooling heating / Average heating / Warmer heating / Colder Other items Sound power level(indoor) Sound power level(indoor) Global warming potential Rated air flow(indoor) Rated air flow(outdoor) ufacturer or of its authorised representating Europe, Ltd.	COPd / Colder season, at erature Tj COPd	indoor

Model FDT90VNPVF2

Information to identify the model(s) to whi	ch the inform	ation relates to:	If function includes heating: Indicate the he	ating seaso	on the
Indoor unit model name	FDT100V		information relates to. Indicated values sho		
Outdoor unit model name	FDC90VN				
Outdoor unit model name	FDC90VN	P	heating season at a time. Include at least t	ne neating s	season Average.
Function(indicate if present)			Average(mandatory)	Yes	
cooling	Yes		Warmer(if designated)	No	
heating	Yes		Colder(if designated)	No	
Item	symbol	value unit	Item	symbol	value class
Design load			Seasonal efficiency and energy efficiency of	lass	
cooling	Pdesignc	9.0 kW	cooling	SEER	6.73 A++
heating / Average	Pdesignh	8.1 kW	heating / Average	SCOP/A	4.11 A+
heating / Warmer	Pdesignh	- kW	heating / Warmer	SCOP/W	
5					
heating / Colder	Pdesignh	- kW	heating / Colder	SCOP/C	
					unit
Declared capacity at outdoor temperature	0		Back up heating capacity at outdoor tempe		
heating / Average (-10°C)	Pdh	8.10 kW	heating / Average (-10°C)	elbu	0 kW
heating / Warmer (2°C)	Pdh	- kW	heating / Warmer (2°C)	elbu	- kW
heating / Colder (-22°C)	Pdh	- kW	heating / Colder (-22°C)	elbu	- kW
Declared capacity for cooling, at indoor te	mperature 2	7(19°C and	Declared energy efficiency ratio, at indoor	temperature	27(19°C and
outdoor temperature Tj			outdoor temperature Tj	tomporatare	
	D 1				
Tj=35°C	Pdc	9.00 kW	Tj=35°C	EERd	3.37 -
Tj=30°C	Pdc	6.60 kW	Tj=30°C	EERd	5.10 -
Tj=25°C	Pdc	4.30 kW	Tj=25°C	EERd	8.20 -
Tj=20°C	Pdc	1.90 kW	Tj=20°C	EERd	12.10 -
Declared capacity for heating / Average se	eason. at inde	or	Declared coefficient of performance / Avera	lae season	at indoor
temperature 20°C and outdoor temperatur			temperature 20°C and outdoor temperature		
		7 10	11 .		2.85
Tj=-7°C	Pdh	7.10 kW	Tj=-7°C	COPd	2.85 -
Tj=2°C	Pdh	4.30 kW	Tj=2°C	COPd	4.00 -
Tj=7°C	Pdh	2.70 kW	Tj=7°C	COPd	5.35 -
Tj=12°C	Pdh	1.30 kW	Tj=12°C	COPd	5.00 -
Tj=bivalent temperature	Pdh	8.10 kW	Tj=bivalent temperature	COPd	2.50 -
Tj=operating limit	Pdh	7.10 kW	Tj=operating limit	COPd	2.20 -
	1 GIT	1110		0010	2.20
Declared capacity for heating / Warmer se	acon at inda	or	Declared coefficient of performance / Warn		atindaar
		Or		,	at muoor
temperature 20°C and outdoor temperatur			temperature 20°C and outdoor temperature		
Tj=2°C	Pdh	- kW	Tj=2°C	COPd	
Tj=7°C	Pdh	- kW	Tj=7°C	COPd	
Ti=12°C	Pdh	- kW	Tj=12°C	COPd	
Tj=bivalent temperature	Pdh	- kW	Tj=bivalent temperature	COPd	
Tj=operating limit	Pdh	- kW	Tj=operating limit	COPd	
	run			COLU	
Declared capacity for heating / Colder sea	oon at indea		Declared coefficient of performance / Colde		tindoor
		I			
temperature 20°C and outdoor temperatur]	temperature 20°C and outdoor temperature		
Tj=-7°C	Pdh	- kW	Tj=-7°C	COPd	
Tj=2°C	Pdh	- kW	Tj=2°C	COPd	
Tj=7°C	Pdh	- kW	Tj=7°C	COPd	
Ti=12°C	Pdh	- kW	Tj=12°C	COPd	
Tj=bivalent temperature	Pdh	- kW	Tj=bivalent temperature	COPd	
Tj=operating limit	Pdh	- kW	Tj=operating limit	COPd	
	Pdh	- kW		COPd	
Tj=-15°C	Pun	- KVV	Tj=-15°C	COPU	
Divelant to see a wet we			On a watting a line it to grad a wat was		
Bivalent temperature	T L:		Operating limit temperature	T-1	45 00
heating / Average	Tbiv	-10 °C	heating / Average	Tol	15 ℃
heating / Warmer	Tbiv	- °C	heating / Warmer	Tol	- °C
heating / Colder	Tbiv	- °C	heating / Colder	Tol	- °C
Cycling interval capacity			Cycling interval efficiency		
for cooling	Pcycc	- kW	for cooling	EERcyc	
for heating	Pcych	- kW	for heating	COPcyc	
	. 5,011				
Degradation coefficient			Degradation coefficient		
cooling	Cdc	0.25 -	heating	Cdh	0.25 -
cooling	Cuc	0.25	Treating	Cun	0.25
Electric power input in newer moder at		modo'	Annual electricity consumption		
Electric power input in power modes othe	rthan 'coth-	noue	I IANNUU EIECTICILY CONSUMPTION		
off mode				0	460
standby mode	Poff	10 W	cooling	Qce	468 kWh/a
	Poff Psb	10 W 10 W	cooling heating / Average	Qhe	2756 kWh/a
thermostat-off mode	Poff	10 W 10 W 30 W	cooling heating / Average heating / Warmer		
	Poff Psb	10 W 10 W	cooling heating / Average	Qhe	2756 kWh/a
thermostat-off mode	Poff Psb Pto	10 W 10 W 30 W	cooling heating / Average heating / Warmer	Qhe Qhe	2756 kWh/a - kWh/a
thermostat-off mode crankcase heater mode	Poff Psb Pto Pck	10 W 10 W 30 W	cooling heating / Average heating / Warmer	Qhe Qhe	2756 kWh/a - kWh/a
thermostat-off mode	Poff Psb Pto Pck	10 W 10 W 30 W	cooling heating / Average heating / Warmer heating / colder	Qhe Qhe Qhe	2756 kWh/a - kWh/a - kWh/a
thermostat-off mode crankcase heater mode	Poff Psb Pto Pck	10 W 10 W 30 W	cooling heating / Average heating / Warmer heating / colder	Qhe Qhe Qhe	2756 kWh/a - kWh/a - kWh/a
thermostat-off mode crankcase heater mode Capacity control(indicate one of three opti	Poff Psb Pto Pck ons)	10 W 10 W 30 W	cooling heating / Average heating / Warmer heating / colder Other items Sound power level(indoor) Sound power level(outdoor)	Qhe Qhe Lwa Lwa	2756 kWh/a - kWh/a - kWh/a - kWh/a 65 dB(A) 69 dB(A)
thermostat-off mode crankcase heater mode Capacity control(indicate one of three opti fixed	Poff Psb Pto Pck ons)	10 W 10 W 30 W	cooling heating / Average heating / Warmer heating / colder Other items Sound power level(indoor) Sound power level(outdoor) Global warming potential	Qhe Qhe Qhe	2756 kWh/a - kWh/a - kWh/a 65 dB(A) 69 dB(A) 1975 kgCO2e
thermostat-off mode crankcase heater mode Capacity control(indicate one of three opti fixed staged	Poff Psb Pto Pck ons)	10 W 10 W 30 W	cooling heating / Average heating / Warmer heating / colder Other items Sound power level(indoor) Sound power level(outdoor) Global warming potential Rated air flow(indoor)	Qhe Qhe Lwa Lwa	2756 kWh/a - kWh/a - kWh/a - kWh/a - dB(A) 1975 kgCO2e 2220 m³/h
thermostat-off mode crankcase heater mode Capacity control(indicate one of three opti fixed	Poff Psb Pto Pck ons)	10 W 10 W 30 W	cooling heating / Average heating / Warmer heating / colder Other items Sound power level(indoor) Sound power level(outdoor) Global warming potential	Qhe Qhe Lwa Lwa	2756 kWh/a - kWh/a - kWh/a 65 dB(A) 69 dB(A) 1975 kgCO2e
thermostat-off mode crankcase heater mode Capacity control(indicate one of three opti fixed staged	Poff Psb Pto Pck ons)	10 W 10 W 30 W	cooling heating / Average heating / Warmer heating / colder Other items Sound power level(indoor) Sound power level(outdoor) Global warming potential Rated air flow(indoor)	Qhe Qhe Qhe Lwa GWP	2756 kWh/a - kWh/a - kWh/a - kWh/a - dB(A) 1975 kgCO2e 2220 m³/h
thermostat-off mode crankcase heater mode Capacity control(indicate one of three opti fixed staged	Poff Psb Pto Pck ons) No Yes	10 W 30 W 0	cooling heating / Average heating / Warmer heating / colder Other items Sound power level(indoor) Sound power level(outdoor) Global warming potential Rated air flow(indoor)	Qhe Qhe Qhe Lwa GWP	2756 kWh/a - kWh/a - kWh/a - kWh/a - dB(A) 1975 kgCO2e 2220 m³/h
thermostat-off mode crankcase heater mode Capacity control(indicate one of three opti fixed staged variable Contact details for obtaining	Poff Psb Pto Pck ons) No Yes Name and	10 W 30 W 0	cooling heating / Average heating / Warmer heating / colder Other items Sound power level(indoor) Sound power level(outdoor) Global warming potential Rated air flow(indoor) Rated air flow(outdoor) facturer or of its authorised representative.	Qhe Qhe Qhe Lwa GWP	2756 kWh/a - kWh/a - kWh/a - kWh/a - dB(A) 1975 kgCO2e 2220 m³/h
thermostat-off mode crankcase heater mode Capacity control(indicate one of three opti fixed staged variable Contact details for obtaining more information	Poff Psb Pto Pck ons) No Yes Name an- shi Heavy Ind	10 W 10 W 30 W 0 W	cooling heating / Average heating / Warmer heating / colder Other items Sound power level(indoor) Sound power level(outdoor) Global warming potential Rated air flow(indoor) Rated air flow(outdoor) facturer or of its authorised representative. g Europe, Ltd.	Qhe Qhe Qhe Lwa GWP	2756 kWh/a - kWh/a - kWh/a - kWh/a - dB(A) 1975 kgCO2e 2220 m³/h
thermostat-off mode crankcase heater mode Capacity control(indicate one of three opti fixed staged variable Contact details for obtaining more information Mitsubia 7 Round	Poff Psb Pto Pck ons) No Yes Name and shi Heavy Ind	10 W 10 W 30 W 0 W	cooling heating / Average heating / Warmer heating / colder Other items Sound power level(indoor) Sound power level(outdoor) Global warming potential Rated air flow(indoor) Rated air flow(outdoor) facturer or of its authorised representative.	Qhe Qhe Qhe Lwa GWP	2756 kWh/a - kWh/a - kWh/a - kWh/a - dB(A) 1975 kgCO2e 2220 m³/h
thermostat-off mode crankcase heater mode Capacity control(indicate one of three opti fixed staged variable Contact details for obtaining more information Mitsubia 7 Round	Poff Psb Pto Pck ons) No Yes Name an- shi Heavy Ind	10 W 10 W 30 W 0 W	cooling heating / Average heating / Warmer heating / colder Other items Sound power level(indoor) Sound power level(outdoor) Global warming potential Rated air flow(indoor) Rated air flow(outdoor) facturer or of its authorised representative. g Europe, Ltd.	Qhe Qhe Qhe Lwa GWP	2756 kWh/a - kWh/a - kWh/a - kWh/a - dB(A) 1975 kgCO2e 2220 m³/h

PJF000Z314

(2) Ceiling suspended type (FDEN) Model FDEN71VNPVF1

Information to identify the model(s		lates to:	If function includes heating: Indicate th	0	
Indoor unit model name	FDEN71VF1		information relates to. Indicated values		
Outdoor unit model name	FDC71VNP		heating season at a time. Include at lea	ast the heating se	eason 'Average'.
Function(indicate if present)			Average(mandatory)	Yes	
cooling	Yes		Warmer(if designated)	No	
heating	Yes		Colder(if designated)	No	
		.,			
Item Design load	symbol value	unit	Item Seasonal efficiency and energy efficier	symbol	value class
cooling	Pdesignc 7.1	kW	cooling	SEER	5.70 A+
heating / Average	Pdesignh 5.7		heating / Average	SCOP/A	4.00 A+
heating / Warmer	Pdesignh -	kW	heating / Warmer	SCOP/W	
heating / Colder	Pdesignh -	kW	heating / Colder	SCOP/C	
					unit
Declared capacity at outdoor temp			Back up heating capacity at outdoor ter		
heating / Average (-10°C) heating / Warmer (2°C)	Pdh 5.70 Pdh -	0 kW kW	heating / Average (-10°C) heating / Warmer (2°C)	elbu elbu	0 kW - kW
heating / Colder (-22°C)	Pdh -	kW	heating / Colder (-22°C)	elbu	- kW
	. un			0.54	
Declared capacity for cooling, at in	ndoor temperature 27(19)°C a	Ind	Declared energy efficiency ratio, at ind	oor temperature	27(19)°C and
outdoor temperature Tj			outdoor temperature Tj		
Tj=35°C	Pdc 7.10		Tj=35°C	EERd	2.84 -
Tj=30°C	Pdc 5.20		Tj=30°C	EERd	4.30 -
Tj=25℃ Tj=20℃	Pdc 3.40 Pdc 1.50		Tj=25°C Tj=20°C	EERd EERd	6.90 - 11.50 -
1]=20 0	100 1.0		1]=20 0	LLIIU	11.50
Declared capacity for heating / Ave	erage season, at indoor		Declared coefficient of performance / A	verage season,	at indoor
temperature 20°C and outdoor tem	perature Tj		temperature 20°C and outdoor temperature		
Tj=-7°C	Pdh 5.0		Tj=-7°C	COPd	2.50 -
Tj=2°C	Pdh 3.00		Tj=2°C	COPd	4.00 -
Tj=7°C Tj=12°C	Pdh 2.0 Pdh 1.4		Tj=7°C Tj=12°C	COPd COPd	<u>5.20</u> - 5.90 -
Tj=bivalent temperature	Pdh 1.40		Tj=12 C	COPd	2.30 -
Ti=operating limit	Pdh 4.9		Tj=operating limit	COPd	2.20 -
Declared capacity for heating / Wa	· ·		Declared coefficient of performance / V	,	at indoor
temperature 20°C and outdoor tem			temperature 20°C and outdoor temperature		
Tj=2°C	Pdh -	kW kW	$T_{j=2}^{\circ}C$	COPd COPd	
Tj=7°C Tj=12°C	Pdh - Pdh -	kW kW	Tj=7°C Tj=12°C	COPd	
Tj=bivalent temperature	Pdh -	kW	Tj=bivalent temperature	COPd	
Tj=operating limit	Pdh -	kW	Tj=operating limit	COPd	
Declared capacity for heating / Col			Declared coefficient of performance / C		indoor
temperature 20°C and outdoor tem		1.34/	temperature 20°C and outdoor temperature		
Tj=-7°C Tj=2°C	Pdh - Pdh -	kW kW	Tj=-7°C Tj=2°C	COPd COPd	
Tj=7°C	Pdh -	kW	$T_{i}=7^{\circ}C$	COPd	
Tj=12°C	Pdh -	kW	Ti=12°C	COPd	
Tj=bivalent temperature	Pdh -	kW	Tj=bivalent temperature	COPd	
Tj=operating limit	Pdh -	kW	Tj=operating limit	COPd	
Tj=-15°C	Pdh -	kW	Tj=-15°C	COPd	
Bivalent temperature			Operating limit temperature		
heating / Average	Tbiv -10	o°⊂	heating / Average	Tol	-15 °C
heating / Warmer	Tbiv -	°C	heating / Warmer	Tol	- °C
heating / Colder	Tbiv -	°C	heating / Colder	Tol	- °C
Cycling interval capacity	Davaa	kW	Cycling interval efficiency	FFD ava	
for cooling for heating	Pcycc - Pcych -	kW kW	for cooling for heating	EERcyc COPcyc	
			lor reating	001 090	
Degradation coefficient			Degradation coefficient		
cooling	Cdc 0.2	5 -	heating	Cdh	0.25 -
Electric power input in power mod off mode	es other than 'active mode' Poff 10	w	Annual electricity consumption	Qce	437 kWh/a
standby mode	Poli 10 Psb 10		heating / Average	Qhe	1997 kWh/a
thermostat-off mode	Pto 50		heating / Warmer	Qhe	- kWh/a
crankcase heater mode	Pck 0		heating / colder	Qhe	- kWh/a
Capacity control(indicate one of the	ree options)		Other items		
			Sound power level(indoor) Sound power level(outdoor)	Lwa Lwa	62 dB(A) 67 dB(A)
fixed	No		Global warming potential	GWP	1975 kgCO2eq.
staged	No		Rated air flow(indoor)	-	1200 m ³ /h
variable	Yes		Rated air flow(outdoor)	-	2160 m ³ /h
Contact details for obtaining			ufacturer or of its authorised representative	э.	
	Vitsubishi Heavy Industries				
	Inited Kingdom	uey rark, UXI	oridge, Middlesex, UB11 1AX.		
I					^
			160	PFA(003Z973 <u>/</u> B

Model FDEN90VNPVF1

Information to identify the model(s) to which	n the information	relates to:	If function includes heating: Indicate the heat	ating seaso	n the
Indoor unit model name	FDEN100VF1		information relates to. Indicated values show	•	
Outdoor unit model name	FDC90VNP		heating season at a time. Include at least th	e heating s	eason 'Average'.
				0	0
Function(indicate if present)			Average(mandatory)	Yes	
cooling	Yes		Warmer(if designated)	No	
heating	Yes		Colder(if designated)	No	
Item	symbol valu	ue unit	Item	symbol	value class
Design load			Seasonal efficiency and energy efficiency cl	ass	
cooling	Pdesignc	9.0 kW	cooling	SEER	6.18 A++
heating / Average	Pdesignh	8.1 kW	heating / Average	SCOP/A	4.10 A+
heating / Warmer	Pdesignh	- kW	heating / Warmer	SCOP/W	
heating / Colder	Pdesignh	- kW	heating / Colder	SCOP/C	
	0				unit
Declared capacity at outdoor temperature T	designh		Back up heating capacity at outdoor tempera	ature Tdesi	gnh
heating / Average (-10°C)		3.10 kW	heating / Average (-10°C)	elbu	0 kW
heating / Warmer (2°C)	Pdh	- kW	heating / Warmer (2°C)	elbu	- kW
heating / Colder (-22°C)	Pdh	- kW	heating / Colder (-22°C)	elbu	- kW
Declared capacity for cooling, at indoor ten	nperature 27(19)	C and	Declared energy efficiency ratio, at indoor to	emperature	27(19)°C and
outdoor temperature Tj	,		outdoor temperature Tj	·	· · /
Ti=35°C	Pdc 9	9.00 kW	Ti=35℃	EERd	3.27 -
Tj=30°C		6.60 kW	Tj=30°C	EERd	4.80 -
Tj=25°C		4.30 kW	Tj=25℃	EERd	8.00 -
Tj=20°C		2.20 kW	Tj=20°C	EERd	10.60 -
			<u> </u>		
Declared capacity for heating / Average sea	ison, at indoor]	Declared coefficient of performance / Average	ae season	at indoor
temperature 20°C and outdoor temperature			temperature 20°C and outdoor temperature		
$T_{i}=-7^{\circ}C$		7.10 kW	Ti=-7°C	COPd	2.80 -
Tj=2°C		1.30 kW	Tj=2°C	COPd	4.10 -
Tj=7°C		2.70 kW	Tj=7°C	COPd	5.20 -
Tj=12°C		2.00 kW	Tj=12℃	COPd	5.40 -
Tj=bivalent temperature		3.10 kW	Tj=bivalent temperature	COPd	2.50 -
		7.10 kW		COPd	2.20 -
Tj=operating limit	Pun	7.10 KVV	Tj=operating limit	COPU	2.20 -
Declared capacity for heating / Warmer sea	son at indoor		Declared coefficient of performance / Warm	ar saason	at indoor
temperature 20°C and outdoor temperature			temperature 20°C and outdoor temperature		
Tj=2°C	Pdh	- kW	Ti=2°C	COPd	
Tj=7°C	Pdh	- kW	Tj=7°C	COPd	
	-				
Tj=12°C	Pdh	- kW	Tj=12°C	COPd	
Tj=bivalent temperature	Pdh		Tj=bivalent temperature	COPd	
Tj=operating limit	Pdh	- kW	Tj=operating limit	COPd	
Dealand are a the family a time (Oaldan area			Dealers dealefficient of a stranger (Ooldes		lunda au
Declared capacity for heating / Colder seas			Declared coefficient of performance / Colder		Indoor
temperature 20°C and outdoor temperature			temperature 20°C and outdoor temperature		
Tj=-7°C	Pdh	- kW	Tj=-7°C	COPd	
Tj=2°C	Pdh	- kW	Tj=2°C	COPd	
Tj=7°C	Pdh	- kW	Tj=7°C	COPd	
Tj=12°C	Pdh	- kW	Tj=12°C	COPd	
Tj=bivalent temperature	Pdh		Tj=bivalent temperature	COPd	
Tj=operating limit	Pdh		Tj=operating limit	COPd	
Tj=-15°C	Pdh	- kW	Tj=-15°C	COPd	
Bivalent temperature			Operating limit temperature		
heating / Average	Tbiv	<u>-10</u> °C	heating / Average	Tol	-15 °C
heating / Warmer	Tbiv	- °C	heating / Warmer	Tol	- °C
heating / Colder	Tbiv	- °C	heating / Colder	Tol	- °C
Cycling interval capacity			Cycling interval efficiency		
for cooling	Pcycc	- kW	for cooling	EERcyc	
for heating	Pcych	- kW	for heating	COPcyc	
Degradation coefficient	<u> </u>		Degradation coefficient	0.1	
cooling	Cdc	0.25 -	heating	Cdh	0.25 -
Electric power input in power modes other			Annual electricity consumption	0	540
off mode	Poff	10 W	cooling	Qce	510 kWh/a
standby mode	Psb	10 W	heating / Average	Qhe	2766 kWh/a
thermostat-off mode	Pto	85 W	heating / Warmer	Qhe	- kWh/a
crankcase heater mode	Pck	0 W	heating / colder	Qhe	- kWh/a
Capacity control(indicate one of three option	ns)		Other items		
			Sound power level(indoor)	Lwa	64 dB(A)
			Sound power level(outdoor)	Lwa	69 dB(A)
fixed	No		Global warming potential	GWP	1975 kgCO2eq.
staged	No		Rated air flow(indoor)	-	1680 m ³ /h
variable	Yes		Rated air flow(outdoor)	-	3780 m ³ /h
Contact details for obtaining			acturer or of its authorised representative.		
		es Air-Conditioning			
		ockley Park, Uxbrid	lge, Middlesex, UB11 1AX.		
United Ki	ngdom				

PFA003Z973

(3) Duct connected-High static pressure type (FDU) Model FDU71VNPVF1

Information to identify the model(s) to which the informa	tion relates to:	If function includes heating: Indicate the h	eating seaso	n the	
Indoor unit model name	FDU71VF1		information relates to. Indicated values sh			
Outdoor unit model name	FDC71VNF)	heating season at a time. Include at least	the heating s	eason 'Aver	age'.
						-
Function(indicate if present)			Average(mandatory)	Yes		
cooling	Yes		Warmer(if designated)	No		
heating	Yes		Colder(if designated)	No		
Item	symbol	value unit	Item	symbol	value	class
Design load	.		Seasonal efficiency and energy efficiency			
cooling	Pdesignc	7.1 kW	cooling	SEER	5.71	A+
heating / Average	Pdesignh	5.7 kW	heating / Average	SCOP/A	4.00	A+
heating / Warmer	Pdesignh	- kW	heating / Warmer	SCOP/W	-	-
heating / Colder	Pdesignh	- kW	heating / Colder	SCOP/C	-	
Declared capacity at outdoor tomo	avatura Tdaajanh		Deals up beating capacity at autology temp	aratura Tdaai	anh	unit
Declared capacity at outdoor temp		F 70	Back up heating capacity at outdoor temp			1
heating / Average (-10°C) heating / Warmer (2°C)	Pdh	5.70 kW	heating / Average (-10°C) heating / Warmer (2°C)	elbu	0	kW
heating / Colder (-22°C)	Pdh Pdh	- kW - kW	heating / Colder (-22°C)	elbu elbu	-	kW kW
	Full	- 1600	Treating / Colder (-22 C)	eibu	-	KVV
Declared capacity for cooling, at ir	ndoor temperature 27(10°C and	Declared energy efficiency ratio, at indoor		27/19°C an	d
outdoor temperature Tj		10)0 and	outdoor temperature Tj	temperature	, 27 (15) O an	u
Tj=35℃	Pdc	7.10 kW	Ti=35°C	EERd	2.70	1_
Tj=30°C	Pdc	5.20 kW	Ti=30°C	EERd	4.30	1_
Tj=25°C	Pdc	3.40 kW	Ti=25°C	EERd	7.40	1_
Tj=20°C	Pdc	1.50 kW	Tj=20°C	EERd	9.80	_
	1.40				0.00	
Declared capacity for heating / Ave	erage season, at indoc	or	Declared coefficient of performance / Ave	rage season	at indoor	
temperature 20°C and outdoor tem			temperature 20°C and outdoor temperatu	U ,		
Tj=-7°C	Pdh	5.00 kW	Ti=-7°C	COPd	2.50]-
Tj=2°C	Pdh	3.00 kW	Tj=2°C	COPd	3.90	1_
Tj=7°C	Pdh	2.00 kW	Ti=7°C	COPd	5.40	1_
Tj=12°C	Pdh	1.40 kW	Ti=12°C	COPd	6.00	1_
Ti=bivalent temperature	Pdh	5.70 kW	Tj=bivalent temperature	COPd	2.40	1_
Tj=operating limit	Pdh	5.10 kW	Tj=operating limit	COPd	2.10	-
Declared capacity for heating / Wa	rmer season, at indoo	r	Declared coefficient of performance / War	mer season, a	at indoor	
temperature 20°C and outdoor tem			temperature 20°C and outdoor temperatu			
Tj=2°C	Pdh	- kW	Tj=2°C	COPd	-]-
Tj=7℃	Pdh	- kW	Tj=7°C	COPd	-	1_
Tj=12°C	Pdh	- kW	Ti=12°C	COPd	-	1_
Tj=bivalent temperature	Pdh	- kW	Tj=bivalent temperature	COPd	-	1_
Tj=operating limit	Pdh	- kW	Tj=operating limit	COPd	-	1_
Declared capacity for heating / Col	der season, at indoor		Declared coefficient of performance / Colo	ler season, at	t indoor	
temperature 20°C and outdoor tem	iperature Tj		temperature 20°C and outdoor temperatu	re Tj		
Tj=-7°C	Pdh	- kW	Tj=-7°C	COPd	-]-
Tj=2°C	Pdh	- kW	Tj=2°C	COPd	-]-
Tj=7°C	Pdh	- kW	Tj=7°C	COPd	-	1-
Tj=12°C	Pdh	- kW	Tj=12°C	COPd	-	1-
Tj=bivalent temperature	Pdh	- kW	Tj=bivalent temperature	COPd	-]-
Tj=operating limit	Pdh	- kW	Tj=operating limit	COPd	-]-
Tj=-15°C	Pdh	- kW	Tj=-15°C	COPd	-	-
Bivalent temperature	-		Operating limit temperature			
heating / Average	Tbiv	-10 ℃	heating / Average	Tol	-15	°C
heating / Warmer	Tbiv	- °C	heating / Warmer	Tol	-	°C
heating / Colder	Tbiv	- °C	heating / Colder	Tol	-	°C
Cycling interval capacity			Cycling interval efficiency			1
for cooling	Pcycc		for cooling	EERcyc	-	-
for heating	Pcych	- kW	for heating	COPcyc	-	-
De sue detiens en efficient			De sur detien er efficient	-		
Degradation coefficient	Cdc	0.25 -	Degradation coefficient	Cdh	0.25	1
cooling	Các	0.25	heating	Can	0.25	-
Electric power input in power mod	loo other then looting r	madal	Annual electricity consumption			
off mode	Poff	10 W	cooling	Qce	436	kWh/a
standby mode	Psb	10 W		Qte Qhe	1996	kWh/a
thermostat-off mode	Pto	25 W	heating / Average heating / Warmer	Qhe		kWh/a
crankcase heater mode	Pio	0 W	heating / colder	Qhe	-	kWh/a
	TCK	0 100	neating / colder	QIIE	-	KWII/a
Capacity control(indicate one of the	ree ontions)		Other items			
			Sound power level(indoor)	Lwa	65	dB(A)
			Sound power level(outdoor)	Lwa	67	dB(A)
fixed	No		Global warming potential	GWP	1975	kgCO2eq.
staged	No		Rated air flow(indoor)	-	1440	m ³ /h
variable	Yes		Rated air flow(indoor)	-	2160	m ³ /h
	162				2100	parzn
Contact details for obtaining	Name and	address of the mar	nufacturer or of its authorised representative.			
	Vitsubishi Heavy Indu					
			bridge, Middlesex, UB11 1AX.			
	Jnited Kingdom	, croonicy i air, UXI				
L						•
				PIG	000Z1	60Æ
			170			

Model FDU90VNPVF1

Information to identify the model	(s) to which the inform	ation relates to:	If function includes heating: Indicate t	he heating seasor	n the
Indoor unit model name	FDU100V		information relates to. Indicated value	•	
Outdoor unit model name	FDC90VN	IP	heating season at a time. Include at le	east the heating se	eason 'Average'.
Function(indicate if present)			Average(mandatory)	Yes	
cooling	Yes		Warmer(if designated)	No	
heating	Yes		Colder(if designated)	No	
Item	symbol	value unit	Item	symbol	value class
Design load	Symbol	value unit	Seasonal efficiency and energy efficie		
cooling	Pdesignc	9.0 kW	cooling	SEER	6.86 A++
heating / Average	Pdesignh		heating / Average	SCOP/A	4.20 A+
heating / Warmer	Pdesignh		heating / Warmer	SCOP/W	
heating / Colder	Pdesignh		heating / Colder	SCOP/C	
					unit
Declared capacity at outdoor tem	perature Tdesignh		Back up heating capacity at outdoor te	emperature Tdesig	gnh
heating / Average (-10°C)	Pdh	8.10 kW	heating / Average (-10°C)	elbu	0 kW
heating / Warmer (2°C)	Pdh	- kW	heating / Warmer (2°C)	elbu	– kW
heating / Colder (-22°C)	Pdh	- kW	heating / Colder (-22°C)	elbu	- kW
				*	
Declared capacity for cooling, at	indoor temperature 2	7(19)°C and	Declared energy efficiency ratio, at inc	door temperature	27(19)°C and
outdoor temperature Tj	D.		outdoor temperature Tj		
Tj=35°C	Pdc	9.00 kW	Tj=35°C	EERd	3.40 -
Tj=30°C	Pdc	6.60 kW	Tj=30°C	EERd	5.30 -
Tj=25°C Tj=20°C	Pdc Pdc	4.30 kW 2.20 kW	Tj=25°C Tj=20°C	EERd EERd	8.20 - 14.00 -
I]=20 C	Puc	2.20 KVV		EERU	14.00 -
Declared capacity for heating / Av	verage season at inde	oor	Declared coefficient of performance /	Average season	at indoor
temperature 20°C and outdoor ter			temperature 20°C and outdoor tempe		
Tj=-7°C	Pdh	7.10 kW	Ti=-7°C	COPd	2.80 -
Tj=2°C	Pdh	4.30 kW	Tj=2°C	COPd	4.10 -
Tj=7°C	Pdh	2.70 kW	Ti=7°C	COPd	5.50 -
Tj=12°C	Pdh	1.80 kW	Tj=12°C	COPd	5.90 -
Tj=bivalent temperature	Pdh	8.10 kW	Tj=bivalent temperature	COPd	2.40 -
Tj=operating limit	Pdh	7.10 kW	Tj=operating limit	COPd	2.30 -
Declared capacity for heating / W		or	Declared coefficient of performance /		at indoor
temperature 20°C and outdoor ter			temperature 20°C and outdoor tempe		
Tj=2°C	Pdh	- kW	Tj=2°C	COPd	
Tj=7°C	Pdh	- kW	Tj=7°C	COPd	
Tj=12°C	Pdh	- kW	Tj=12°C	COPd	
Tj=bivalent temperature	Pdh		Tj=bivalent temperature Tj=operating limit	COPd COPd	
Tj=operating limit	Pdh	- kW		COPu	
Declared capacity for heating / Co	older season at indoo	r		Colder season, at	indoor
Declared capacity for heating / Co		r	Declared coefficient of performance /		indoor
temperature 20°C and outdoor ter	mperature Tj		Declared coefficient of performance / temperature 20°C and outdoor tempe	rature Tj	indoor
temperature 20°C and outdoor ter $Tj=-7$ °C		or - kW - kW	Declared coefficient of performance / temperature 20°C and outdoor tempe Tj=-7°C	rature Tj COPd	indoor
temperature 20°C and outdoor ter	mperature Tj Pdh	- kW	Declared coefficient of performance / temperature 20°C and outdoor tempe	rature Tj	
temperature 20°C and outdoor ter Tj=-7°C Tj=2°C	mperature Tj Pdh Pdh	- kW - kW	Declared coefficient of performance / temperature 20°C and outdoor tempe Tj=-7°C Tj=2°C	rature Tj COPd COPd	
temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=7°C	mperature Tj Pdh Pdh Pdh Pdh	- kW - kW - kW	Declared coefficient of performance / temperature 20°C and outdoor tempe Tj=-7°C Tj=2°C Tj=7°C	rature Tj COPd COPd COPd	
temperature 20°C and outdoor ter $T_{j=-7^{\circ}C}$ $T_{j=2^{\circ}C}$ $T_{j=7^{\circ}C}$ $T_{j=12^{\circ}C}$	mperature Tj Pdh Pdh Pdh Pdh Pdh	- kW - kW - kW - kW	Declared coefficient of performance / temperature 20°C and outdoor tempe Tj=-7°C Tj=2°C Tj=12°C	rature Tj COPd COPd COPd COPd	
temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=7°C Tj=12°C Tj=bivalent temperature	mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh	- KW - KW - KW - KW - KW	Declared coefficient of performance / temperature 20°C and outdoor tempe Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature	rature Tj COPd COPd COPd COPd COPd COPd	
temperature 20°C and outdoor ter $T_{j=-7^{\circ}C}$ $T_{j=2^{\circ}C}$ $T_{j=12^{\circ}C}$ $T_{j=bivalent}$ temperature $T_{j=operating limit}$ $T_{j=-15^{\circ}C}$	mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh	- kW - kW - kW - kW - kW - kW	Declared coefficient of performance / temperature 20°C and outdoor tempe Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C	rature Tj COPd COPd COPd COPd COPd COPd	
temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature	mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh	- kW - kW - kW - kW - kW - kW - kW	Declared coefficient of performance / temperature 20°C and outdoor tempe Tj=-7°C Tj=2°C Tj=12°C Tj=operating limit Tj=-15°C Operating limit temperature	rature Tj COPd COPd COPd COPd COPd COPd COPd	
temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=7°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average	mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv	- kW - kW - kW - kW - kW - kW - kW	Declared coefficient of performance // temperature 20°C and outdoor tempe Tj=-7°C Tj=2°C Tj=12°C Tj=operating limit Tj=-15°C Operating limit temperature heating / Average	rature Tj COPd COPd COPd COPd COPd COPd COPd COPd	
temperature 20°C and outdoor ter $T_{j=-7^{\circ}C}$ $T_{j=2^{\circ}C}$ $T_{j=7^{\circ}C}$ $T_{j=2^{\circ}C}$ $T_{j=2^{\circ}C}$ $T_{j=2^{\circ}C}$ $T_{j=0}$	mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv	- kW - kW - kW - kW - kW - kW - kW - kW	Declared coefficient of performance // temperature 20°C and outdoor tempe Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=-0perating limit Tj=-15°C Operating limit temperature heating / Average heating / Warmer	rature Tj COPd COPd COPd COPd COPd COPd COPd COPd	
temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=7°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average	mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv	- kW - kW - kW - kW - kW - kW - kW	Declared coefficient of performance // temperature 20°C and outdoor tempe Tj=-7°C Tj=2°C Tj=12°C Tj=operating limit Tj=-15°C Operating limit temperature heating / Average	rature Tj COPd COPd COPd COPd COPd COPd COPd COPd	
temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Warmer heating / Colder	mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv	- kW - kW - kW - kW - kW - kW - kW - kW	Declared coefficient of performance / temperature 20°C and outdoor tempe Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Warmer heating / Colder	rature Tj COPd COPd COPd COPd COPd COPd COPd COPd	
temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Warmer heating / Colder Cycling interval capacity	mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv	- KW - kW - kW - kW - kW - KW - KW - KW - C - °C	Declared coefficient of performance // temperature 20°C and outdoor tempe Tj=-7°C Tj=2°C Tj=12°C Tj=operating limit Tj=-r5°C Operating limit temperature heating / Average heating / Warmer heating / Colder Cycling interval efficiency	rature Tj COPd COPd COPd COPd COPd COPd COPd COPd	
temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=7°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Warmer heating / Colder Cycling interval capacity for cooling	mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Pcycc	- kW - kW - kW - kW - kW - kW - kW - kW	Declared coefficient of performance // temperature 20°C and outdoor tempe Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Colder Cycling interval efficiency for cooling	rature Tj COPd COPd COPd COPd COPd COPd COPd COPd	
temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Warmer heating / Colder Cycling interval capacity	mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv	- kW - kW - kW - kW - kW - kW - kW - kW	Declared coefficient of performance // temperature 20°C and outdoor tempe Tj=-7°C Tj=2°C Tj=12°C Tj=operating limit Tj=-r5°C Operating limit temperature heating / Average heating / Warmer heating / Colder Cycling interval efficiency	rature Tj COPd COPd COPd COPd COPd COPd COPd COPd	
temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=7°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Warmer heating / Colder Cycling interval capacity for cooling	mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Pcycc	- kW - kW - kW - kW - kW - kW - kW - kW	Declared coefficient of performance // temperature 20°C and outdoor tempe Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Colder Cycling interval efficiency for cooling	rature Tj COPd COPd COPd COPd COPd COPd COPd COPd	
temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating	mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Pcycc	- kW - kW - kW - kW - kW - kW - kW - kW	Declared coefficient of performance / temperature 20°C and outdoor tempe Tj=-7°C Tj=2°C Tj=12°C Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Colder Cycling interval efficiency for cooling for heating	rature Tj COPd COPd COPd COPd COPd COPd COPd COPd	
temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient	mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Pcycc Pcych	- KW - KW - KW - KW - KW - KW - KW - C - °C - °C - °C	Declared coefficient of performance // temperature 20°C and outdoor tempe Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating	rature Tj COPd COPd COPd COPd COPd COPd COPd COPd	
temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling	mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Cdc	- kW - kW - kW - kW - kW - kW - kW - kW - c - c - c - c - c - c - c - c	Declared coefficient of performance / i temperature 20°C and outdoor tempe Tj=-7°C Tj=2°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating	rature Tj COPd COPd COPd COPd COPd COPd COPd Tol Tol Tol Tol Tol EERcyc COPcyc	
temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode	mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Cdc Cdc	- kW - kW - kW - kW - kW - kW - kW - kW - kW - c - c - c - c - c - c - c - c	Declared coefficient of performance // temperature 20°C and outdoor tempe Tj=-7°C Tj=2°C Tj=12°C Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Warmer heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating Annual electricity consumption cooling	rature Tj COPd COPd COPd COPd COPd COPd COPd COPd	
temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode	mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Tbiv Cdc Cdc	- KW - KW - KW - KW - KW - KW - KW - C - °C - °C - °C - °C - °C - °C - °C	Declared coefficient of performance // temperature 20°C and outdoor tempe Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=-15°C Operating limit Tj=-15°C Operating limit temperature heating / Average heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating Annual electricity consumption cooling heating / Average	rature Tj COPd COPd COPd COPd COPd COPd COPd COPd	
temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode	mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Cdc Cdc edes other than 'active Psb Pto	- kW - kW - kW - kW - kW - kW - kW - kW	Declared coefficient of performance // temperature 20°C and outdoor tempe Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating / Average heating Manual electricity consumption cooling heating / Average heating / Warmer	rature Tj COPd COPd COPd COPd COPd COPd COPd Tol Tol Tol Tol Tol Tol CoPcyc COPcyc	
temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode	mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Tbiv Cdc Cdc	- KW - KW - KW - KW - KW - KW - KW - C - °C - °C - °C - °C - °C - °C - °C	Declared coefficient of performance // temperature 20°C and outdoor tempe Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=-15°C Operating limit Tj=-15°C Operating limit temperature heating / Average heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating Annual electricity consumption cooling heating / Average	rature Tj COPd COPd COPd COPd COPd COPd COPd COPd	
temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode crankcase heater mode	mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Cdc Cdc odes other than 'active Poff Psb Pto Pck	- kW - kW - kW - kW - kW - kW - kW - kW	Declared coefficient of performance // temperature 20°C and outdoor tempe Tj=-7°C Tj=2°C Tj=12°C Tj=operating limit Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Warmer heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating Annual electricity consumption cooling heating / Warmer heating / Warmer heating / Warmer heating / Warmer heating / Colder	rature Tj COPd COPd COPd COPd COPd COPd COPd Tol Tol Tol Tol Tol Tol CoPcyc COPcyc	
temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode	mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Cdc Cdc odes other than 'active Poff Psb Pto Pck	- kW - kW - kW - kW - kW - kW - kW - kW	Declared coefficient of performance // temperature 20°C and outdoor tempe Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=5°C Operating limit Tj=-15°C Operating limit temperature heating / Average heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating / Average heating Operadation coefficient heating / Average heating Operadation coefficient heating Outperating / Average heating / Average heating / Oolder Other items	rature Tj COPd COPd COPd COPd COPd COPd COPd COPd	- - - - - - - - - - - - - °C - °C - °C - - 0.25 - 459 kWh/a 2703 kWh/a - kWh/a
temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode crankcase heater mode	mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Cdc Cdc Cdc	- kW - kW - kW - kW - kW - kW - kW - kW	Declared coefficient of performance // temperature 20°C and outdoor tempe Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Oclder Cycling interval efficiency for cooling for heating Degradation coefficient heating / Average heating Degradation coefficient heating / Average heating / Average heating / Average heating / Oclder	rature Tj COPd COPd COPd COPd COPd COPd COPd Tol Tol Tol Tol Tol Tol CoPcyc COPcyc COPcyc	- - - -
temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Warmer heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode crankcase heater mode Capacity control(indicate one of the standby control(indicate one	mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Cdc Cdc Cdc Cdc wdes other than 'active Poff Psb Pto Pck hree options)	- kW - kW - kW - kW - kW - kW - kW - kW	Declared coefficient of performance // temperature 20°C and outdoor tempe Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating / Average heating / colder Other items Sound power level(indoor) Sound power level(outdoor)	rature Tj COPd COPd COPd COPd COPd COPd COPd COPd	- - - -
temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode crankcase heater mode Capacity control(indicate one of the fixed	mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Cdc Cdc Cdc Cdc vdes other than 'active Poff Psb Pto Pck hree options)	- kW - kW - kW - kW - kW - kW - kW - kW	Declared coefficient of performance // temperature 20°C and outdoor tempe Tj=-7°C Tj=2°C Tj=12°C Tj=operating limit Tj=operating limit temperature Tj=operating limit temperature heating / Average heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating / Average heating Operadation coefficient heating / Average heating Other ating Other items Sound power level(indoor) Sound power level(outdoor) Global warming potential	rature Tj COPd COPd COPd COPd COPd COPd COPd Tol Tol Tol Tol Tol Tol CoPcyc COPcyc COPcyc	- - - -
temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode crankcase heater mode Capacity control(indicate one of the fixed staged	mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Cdc Cdc Cdc Cdc wdes other than 'active Poff Psb Pto Pck hree options)	- kW - kW - kW - kW - kW - kW - kW - kW	Declared coefficient of performance // temperature 20°C and outdoor tempe Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Older Cycling interval efficiency for cooling for heating Degradation coefficient heating / Average heating Operadation coefficient heating / Average heating Obegradation coefficient heating / Average heating / Average heating / Average heating / colder Other items Sound power level(indoor) Sound power level(outdoor) Global warming potential Rated air flow(indoor)	rature Tj COPd COPd COPd COPd COPd COPd COPd Tol Tol Tol Tol Tol EERcyc COPcyc COPcyc	- - - - - - - - - - - - - °C - °C - °C - °C - - 0.25 - 459 kWh/a 2703 kWh/a - kWh/a 65 dB(A) 1975 kgCO2eq 2160 m³/h
temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode crankcase heater mode Capacity control(indicate one of the fixed	mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh	- kW - kW - kW - kW - kW - kW - kW - kW	Declared coefficient of performance // temperature 20°C and outdoor tempe Tj=-7°C Tj=2°C Tj=12°C Tj=operating limit Tj=operating limit temperature Tj=operating limit temperature heating / Average heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating / Average heating Operadation coefficient heating / Average heating Other ating Other items Sound power level(indoor) Sound power level(outdoor) Global warming potential	rature Tj COPd COPd COPd COPd COPd COPd COPd Tol Tol Tol Tol Tol EERcyc COPcyc COPcyc	- - - - - - - - - - - - - °C - °C - °C - °C - - 0.25 - 459 kWh/a 2703 kWh/a - kWh/a 65 dB(A) 1975 kgCO2eq 2160 m³/h
temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode crankcase heater mode Capacity control(indicate one of the fixed staged	mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Cdc Cdc Cdc Cdc Cdc No Pck No Yes	- kW - °C - kW 0.255 - - 10 W 0 0 W	Declared coefficient of performance // temperature 20°C and outdoor tempe Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Older Cycling interval efficiency for cooling for heating Degradation coefficient heating / Average heating Operadation coefficient heating / Average heating Obegradation coefficient heating / Average heating / Average heating / Average heating / colder Other items Sound power level(indoor) Sound power level(outdoor) Global warming potential Rated air flow(indoor)	rature Tj COPd COPd COPd COPd COPd COPd COPd Tol Tol Tol Tol Tol Tol CoPcyc COPcyc COPcyc Cdh Qhe Qhe Qhe Qhe Qhe Qhe Qhe Qhe Che Che CoPd COPd COPd COPd COPd COPd COPd COPd CO	- - - - - - - - - - - - - °C - °C - °C - °C - - 0.25 - 459 kWh/a 2703 kWh/a - kWh/a 65 dB(A) 1975 kgCO2eq 2160 m³/h
temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Warmer heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode crankcase heater mode Capacity control(indicate one of the fixed staged variable	mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh	- kW - °C - kW 0.255 - - 10 W 0 0 W	Declared coefficient of performance // temperature 20°C and outdoor tempe Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating / Warmer heating Degradation coefficient heating / Average heating Other ating Other items Sound power level(indoor) Sound power level(outdoor) Global warming potential Rated air flow(undoor) Rated air flow(outdoor) ufacturer or of its authorised representation	rature Tj COPd COPd COPd COPd COPd COPd COPd Tol Tol Tol Tol Tol Tol CoPcyc COPcyc COPcyc Cdh Qhe Qhe Qhe Qhe Qhe Qhe Qhe Qhe Che Che CoPd COPd COPd COPd COPd COPd COPd COPd CO	- - - - - - - - - - - - - °C - °C - °C - °C - - 0.25 - 459 kWh/a 2703 kWh/a - kWh/a 65 dB(A) 1975 kgCO2eq 2160 m³/h
temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode crankcase heater mode Capacity control(indicate one of the fixed staged variable Contact details for obtaining	mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh	- KW - KW - KW - KW - KW - KW - KW - KW	Declared coefficient of performance // temperature 20°C and outdoor tempe Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating / Warmer heating Degradation coefficient heating / Average heating Other ating Other items Sound power level(indoor) Sound power level(outdoor) Global warming potential Rated air flow(undoor) Rated air flow(outdoor) ufacturer or of its authorised representation	rature Tj COPd COPd COPd COPd COPd COPd COPd Tol Tol Tol Tol Tol Tol CoPcyc COPcyc COPcyc Cdh Qhe Qhe Qhe Qhe Qhe Qhe Qhe Qhe Che Che CoPd COPd COPd COPd COPd COPd COPd COPd CO	- - - - - - - - - - - - - °C - °C - °C - °C - - 0.25 - 459 kWh/a 2703 kWh/a - kWh/a 65 dB(A) 1975 kgCO2eq 2160 m³/h
temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode crankcase heater mode Capacity control(indicate one of the fixed staged variable Contact details for obtaining	mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh	- KW - KW - KW - KW - KW - KW - KW - KW	Declared coefficient of performance // temperature 20°C and outdoor tempe Tj=-7°C Tj=2°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Odder Cycling interval efficiency for cooling for heating Degradation coefficient heating / Average heating Manual electricity consumption cooling heating / Average heating / Average heating / Average heating / Average heating / colder Other items Sound power level(indoor) Sound power level(outdoor) Global warming potential Rated air flow(indoor) Rated air flow(indoor) Rated air flow(indoor) Rated air flow(eutdoor) ufacturer or of its authorised representation	rature Tj COPd COPd COPd COPd COPd COPd COPd Tol Tol Tol Tol Tol Tol CoPcyc COPcyc COPcyc Cdh Qhe Qhe Qhe Qhe Qhe Qhe Qhe Qhe Che Che CoPd COPd COPd COPd COPd COPd COPd COPd CO	- - - - - - - - - - - - - °C - °C - °C - °C - - 0.25 - 459 kWh/a 2703 kWh/a - kWh/a 65 dB(A) 1975 kgCO2eq 2160 m³/h
temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode crankcase heater mode Capacity control(indicate one of the fixed staged variable Contact details for obtaining	mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Cdc Cdc Cdc des other than 'active Poff Psb Pto Pck hree options) No Yes Name an Mitsubishi Heavy Ind 7 Roundwood Avenu	- KW - KW - KW - KW - KW - KW - KW - KW	Declared coefficient of performance // temperature 20°C and outdoor tempe Tj=-7°C Tj=2°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Odder Cycling interval efficiency for cooling for heating Degradation coefficient heating / Average heating Manual electricity consumption cooling heating / Average heating / Average heating / Average heating / Average heating / colder Other items Sound power level(indoor) Sound power level(outdoor) Global warming potential Rated air flow(indoor) Rated air flow(indoor) Rated air flow(indoor) Rated air flow(eutdoor) ufacturer or of its authorised representation	rature Tj COPd COPd COPd COPd COPd COPd COPd Tol Tol Tol Tol Tol Tol CoPcyc COPcyc COPcyc Cdh Qhe Qhe Qhe Qhe Qhe Qhe Qhe Qhe Che Che CoPd COPd COPd COPd COPd COPd COPd COPd CO	- - - - - - - - - - - - - °C - °C - °C - °C - - 0.25 - 459 kWh/a 2703 kWh/a - kWh/a 65 dB(A) 1975 kgCO2eq 2160 m³/h
temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode crankcase heater mode Capacity control(indicate one of the fixed staged variable Contact details for obtaining	mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Cdc Cdc Cdc des other than 'active Poff Psb Pto Pck hree options) No Yes Name an Mitsubishi Heavy Ind 7 Roundwood Avenu	- KW - KW - KW - KW - KW - KW - KW - KW	Declared coefficient of performance // temperature 20°C and outdoor tempe Tj=-7°C Tj=2°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Odder Cycling interval efficiency for cooling for heating Degradation coefficient heating / Average heating Manual electricity consumption cooling heating / Average heating / Average heating / Average heating / Average heating / colder Other items Sound power level(indoor) Sound power level(outdoor) Global warming potential Rated air flow(indoor) Rated air flow(indoor) Rated air flow(indoor) Rated air flow(eutdoor) ufacturer or of its authorised representation	rature Tj COPd COPd COPd COPd COPd COPd COPd Tol Tol Tol Tol Tol Tol Tol CoPcyc COPcyc Cdh Qhe Qhe Qhe Qhe Qhe Qhe Qhe Che Cdh CCP CCP CCP CCP CCP CCP CCP CCP CCP CC	- - - - - - - - - - - - - °C - °C - °C - °C - - 0.25 - 459 kWh/a 2703 kWh/a - kWh/a 65 dB(A) 1975 kgCO2eq 2160 m³/h

Model FDU90VNPVF2

Information to identify the model(s) to wh	ich the inform	ation relates to:	If function includes heating: Indicate the	heating seaso	n the
Indoor unit model name	FDU100V		information relates to. Indicated values s		
Outdoor unit model name	FDC90VN	Р	heating season at a time. Include at least		
				5	
Function(indicate if present)			Average(mandatory)	Yes	
cooling	Yes		Warmer(if designated)	No	
heating	Yes		Colder(if designated)	No	
Item	symbol	value unit	Item	symbol	value class
Design load			Seasonal efficiency and energy efficiency		
cooling	Pdesignc	9.0 kW	cooling	SEER	6.86 A++
heating / Average	Pdesignh	8.1 kW	heating / Average	SCOP/A	4.20 A+
heating / Warmer	Pdesignh	- kW	heating / Warmer	SCOP/W	
heating / Colder	Pdesignh	- kW	heating / Colder	SCOP/C	
	1 doolgiiii		Housing / Coldor	0001/0	unit
Declared capacity at outdoor temperature	Tdesignh		Back up heating capacity at outdoor temp	perature Tdesi	
heating / Average (-10°C)	Pdh	8.10 kW	heating / Average (-10°C)	elbu	0 kW
heating / Warmer (2°C)	Pdh	- kW	heating / Warmer (2°C)	elbu	- kW
heating / Colder (-22°C)	Pdh	- kW	heating / Colder (-22°C)	elbu	- kW
Treating / Colder (-22 C)	Full	- KVV		eibu	- KVV
Declared consolity for eaching, at indeer to	ana aratura 07	7/10%C and	Deplaced approxy officiancy ratio at indep	r tomporatura	07/10 ⁹ C and
Declared capacity for cooling, at indoor to	emperature 21	(19)C and	Declared energy efficiency ratio, at indoc	or temperature	27(19) C and
outdoor temperature Tj	Dele	0.00	outdoor temperature Tj		0.40
Tj=35℃	Pdc	9.00 kW	Tj=35°C	EERd	3.40 -
Tj=30°C	Pdc	6.60 kW	Tj=30°C	EERd	5.30 -
Tj=25°C	Pdc	4.30 kW	Tj=25°C	EERd	8.20 -
Tj=20°C	Pdc	2.20 kW	Tj=20℃	EERd	14.00 -
-					
Declared capacity for heating / Average s		or	Declared coefficient of performance / Ave		at indoor
temperature 20°C and outdoor temperature			temperature 20°C and outdoor temperatu		
Tj=-7°C	Pdh	7.10 kW	Tj=-7°C	COPd	2.80 -
Tj=2°C	Pdh	4.30 kW	Tj=2°C	COPd	4.10 -
Tj=7°C	Pdh	2.70 kW	Tj=7°C	COPd	5.50 -
Tj=12°C	Pdh	1.80 kW	Tj=12°C	COPd	5.90 -
Tj=bivalent temperature	Pdh	8.10 kW	Tj=bivalent temperature	COPd	2.40 -
Tj=operating limit	Pdh	7.10 kW	Tj=operating limit	COPd	2.30 -
Declared capacity for heating / Warmer se	eason, at indo	or	Declared coefficient of performance / Wa	rmer season, a	at indoor
temperature 20°C and outdoor temperatur			temperature 20°C and outdoor temperatu		
Tj=2°C	Pdh	- kW	Tj=2°C	COPd	- -
Tj=7°C	Pdh	- kW	Tj=7°C	COPd	
Tj=12℃	Pdh	- kW	Ti=12°C	COPd	
Tj=bivalent temperature	Pdh	- kW	Tj=bivalent temperature	COPd	
Tj=operating limit	Pdh	- kW	Ti=operating limit	COPd	
	run			001 u	
Declared capacity for heating / Colder sec	son at indoo	r	Declared coefficient of performance / Col	der season at	indoor
Declared capacity for heating / Colder sea		r	Declared coefficient of performance / Col		indoor
temperature 20°C and outdoor temperature	re Tj		temperature 20°C and outdoor temperatu	ure Tj	
temperature 20°C and outdoor temperature Tj=-7°C	re Tj Pdh	- kW	temperature 20°C and outdoor temperatu Tj=-7°C	ure Tj COPd	
temperature 20°C and outdoor temperature $T_{J=-7}^{\circ}C$ Tj=2°C	re Tj Pdh Pdh	- kW - kW	temperature 20°C and outdoor temperatu Tj=-7°C Tj=2°C	ure Tj COPd COPd	
temperature 20°C and outdoor temperature $T_{j=-7^{\circ}C}$ T $_{j=2^{\circ}C}$ T $_{j=7^{\circ}C}$	re Tj Pdh Pdh Pdh Pdh	- kW - kW - kW	temperature 20°C and outdoor temperature $T_{j=-7}^{\circ}C$ Tj=2°C Tj=7°C	ure Tj COPd COPd COPd	
temperature 20°C and outdoor temperature Tj=-7°C Tj=2°C Tj=7°C Tj=7°C Tj=12°C	re Tj Pdh Pdh Pdh Pdh Pdh	- KW - KW - KW - KW	temperature 20°C and outdoor temperature Tj=-7°C Tj=2°C Tj=7°C Tj=7°C Tj=12°C	Ure Tj COPd COPd COPd COPd COPd	
temperature 20°C and outdoor temperature Tj=-7°C Tj=2°C Tj=7°C Tj=12°C Tj=bivalent temperature	re Tj Pdh Pdh Pdh Pdh Pdh Pdh	- kW - kW - kW - kW - kW	temperature 20°C and outdoor temperature Tj=-7°C Tj=2°C Tj=7°C Tj=12°C Tj=12°C Tj=bivalent temperature	ure Tj COPd COPd COPd COPd COPd COPd	
temperature 20°C and outdoor temperature Tj=-7°C Tj=2°C Tj=7°C Tj=12°C Tj=bivalent temperature Tj=operating limit	re Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh	- kW - kW - kW - kW - kW	temperature 20°C and outdoor temperature $Tj=-7^{\circ}C$ $Tj=2^{\circ}C$ $Tj=7^{\circ}C$ $Tj=12^{\circ}C$ $Tj=12^{\circ}C$ Tj=bivalent temperature Tj=operating limit	ure Tj COPd COPd COPd COPd COPd COPd COPd	
temperature 20°C and outdoor temperature Tj=-7°C Tj=2°C Tj=7°C Tj=12°C Tj=bivalent temperature	re Tj Pdh Pdh Pdh Pdh Pdh Pdh	- kW - kW - kW - kW - kW	temperature 20°C and outdoor temperature Tj=-7°C Tj=2°C Tj=7°C Tj=12°C Tj=12°C Tj=bivalent temperature	ure Tj COPd COPd COPd COPd COPd COPd	
temperature 20°C and outdoor temperature $T_{J=-7^{\circ}C}$ $T_{J=2^{\circ}C}$ $T_{J=12^{\circ}C}$ $T_{J=12^{\circ}C}$ $T_{J=bivalent}$ temperature $T_{J=operating}$ limit $T_{J=-15^{\circ}C}$	re Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh	- kW - kW - kW - kW - kW	temperature 20°C and outdoor temperature $T_{j=-7^{\circ}C}$ $T_{j=2^{\circ}C}$ $T_{j=7^{\circ}C}$ $T_{j=12^{\circ}C}$ $T_{j=\text{bivalent temperature}}$ $T_{j=\text{operating limit}}$ $T_{j=-15^{\circ}C}$	ure Tj COPd COPd COPd COPd COPd COPd COPd	
temperature 20°C and outdoor temperatur Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature	re Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh	- kW - kW - kW - kW - kW - kW	temperature 20°C and outdoor temperature $T_j=-7^{\circ}C$ $T_j=2^{\circ}C$ $T_j=12^{\circ}C$ $T_j=bivalent temperature$ $T_j=operating limit$ $T_j=-15^{\circ}C$ Operating limit temperature	ure Tj COPd COPd COPd COPd COPd COPd COPd	
temperature 20°C and outdoor temperature Tj=-7°C Tj=2°C Tj=7°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average	re Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv	- kW - kW - kW - kW - kW - kW - kW	$\label{eq:constraint} \begin{array}{c} \mbox{temperature 20°C and outdoor temperature } \\ Tj=-7°C \\ Tj=2°C \\ Tj=7°C \\ Tj=bivalent temperature \\ Tj=operating limit \\ Tj=-15°C \\ \end{array}$	ure Tj COPd COPd COPd COPd COPd COPd COPd COPd	
temperature 20°C and outdoor temperature Tj=-7°C Tj=2°C Tj=7°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Warmer	re Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv	- kW - kW - kW - kW - kW - kW - kW - kW	temperature 20°C and outdoor temperature Tj=-7°C Tj=2°C Tj=12°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Warmer	ure Tj COPd COPd COPd COPd COPd COPd COPd COPd	
temperature 20°C and outdoor temperature Tj=-7°C Tj=2°C Tj=7°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average	re Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv	- kW - kW - kW - kW - kW - kW - kW	$\label{eq:constraint} \begin{array}{c} \mbox{temperature 20°C and outdoor temperature } \\ Tj=-7°C \\ Tj=2°C \\ Tj=7°C \\ Tj=bivalent temperature \\ Tj=operating limit \\ Tj=-15°C \\ \end{array}$	ure Tj COPd COPd COPd COPd COPd COPd COPd COPd	
temperature 20°C and outdoor temperatur Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Warmer heating / Colder	re Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv	- kW - kW - kW - kW - kW - kW - kW - kW	temperature 20°C and outdoor temperature $T_j=-7^{\circ}C$ $T_j=2^{\circ}C$ $T_j=12^{\circ}C$ $T_j=bivalent temperature$ $T_j=operating limit$ $T_j=-15^{\circ}C$ Operating limit temperature heating / Average heating / Warmer heating / Colder	ure Tj COPd COPd COPd COPd COPd COPd COPd COPd	
temperature 20°C and outdoor temperatur Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Warmer heating / Colder Cycling interval capacity	re Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv	- kW - kW - kW - kW - kW - kW - kW - kW	temperature 20°C and outdoor temperature Tj=-7°C Tj=7°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Varmer heating / Colder Ocycling interval efficiency	ure Tj COPd COPd COPd COPd COPd COPd COPd COPd	
temperature 20°C and outdoor temperatur Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Warmer heating / Colder	re Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv	- kW - kW - kW - kW - kW - kW - kW - kW	temperature 20°C and outdoor temperature $T_j=-7^{\circ}C$ $T_j=2^{\circ}C$ $T_j=12^{\circ}C$ $T_j=bivalent temperature$ $T_j=operating limit$ $T_j=-15^{\circ}C$ Operating limit temperature heating / Average heating / Warmer heating / Colder	ure Tj COPd COPd COPd COPd COPd COPd COPd COPd	
temperature 20°C and outdoor temperatur Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Warmer heating / Colder Cycling interval capacity	re Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv	- kW - kW - kW - kW - kW - kW - kW - kW	temperature 20°C and outdoor temperature Tj=-7°C Tj=7°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Varmer heating / Colder Ocycling interval efficiency	ure Tj COPd COPd COPd COPd COPd COPd COPd COPd	
temperature 20°C and outdoor temperatur Tj=-7°C Tj=2°C Tj=7°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Warmer heating / Colder Cycling interval capacity for cooling	re Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Tbiv	- kW - kW - kW - kW - kW - kW - kW - kW	temperature 20°C and outdoor temperature Tj=-7°C Tj=7°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Varmer heating / Colder Cycling interval efficiency for cooling	ure Tj COPd COPd COPd COPd COPd COPd COPd COPd	
temperature 20°C and outdoor temperatur Tj=-7°C Tj=2°C Tj=7°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Warmer heating / Colder Cycling interval capacity for cooling	re Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Tbiv	- kW - kW - kW - kW - kW - kW - kW - kW	temperature 20°C and outdoor temperature Tj=-7°C Tj=7°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Varmer heating / Colder Cycling interval efficiency for cooling	ure Tj COPd COPd COPd COPd COPd COPd COPd COPd	
temperature 20°C and outdoor temperatur Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating	re Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Tbiv	- kW - kW - kW - kW - kW - kW - kW - kW	temperature 20°C and outdoor temperature Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Average heating / Oclder Cycling interval efficiency for cooling for heating	ure Tj COPd COPd COPd COPd COPd COPd COPd COPd	
temperature 20°C and outdoor temperatur Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient	re Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Pcycc Pcych	- kW - kW - kW - kW - kW - kW - kW - kW	temperature 20°C and outdoor temperature Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient	ure Tj COPd COPd COPd COPd COPd COPd COPd COPd	
temperature 20°C and outdoor temperatur Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient	re Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Tbiv Cbic Cdc	- kW - c - °C - °C - c - kW - kW	temperature 20°C and outdoor temperature Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient	ure Tj COPd COPd COPd COPd COPd COPd COPd COPd	
temperature 20°C and outdoor temperatur Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling	re Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Tbiv Cbic Cdc	- kW - c - °C - °C - c - kW - kW	temperature 20°C and outdoor temperature Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=-15°C Operating limit Tj=-15°C Operating limit temperature heating / Average heating / Varmer heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating	ure Tj COPd COPd COPd COPd COPd COPd COPd COPd	
temperature 20°C and outdoor temperatur Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power modes othe off mode	re Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Tbiv Cdc Cdc	- kW - kW - kW - kW - kW - kW - kW - kW - c - c - c - c - c - c - c - c	temperature 20°C and outdoor temperature Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating Annual electricity consumption cooling	ure Tj COPd COPd COPd COPd COPd COPd COPd COPd	
temperature 20°C and outdoor temperatur Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power modes othe standby mode	re Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Tbiv Tbiv Cbiv Cdc er than 'active Pogb	- kW - kW - kW - kW - kW - kW - kW - kW	temperature 20°C and outdoor temperature Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Older Cycling interval efficiency for cooling for heating Degradation coefficient heating Annual electricity consumption cooling heating / Average	ure Tj COPd COPd COPd COPd COPd COPd COPd COPd	- - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - 0.25 - 459 kWh/a
temperature 20°C and outdoor temperatur Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power modes othe off mode standby mode thermostat-off mode	re Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Tbiv Cbiv Cdc er than 'active Poff Psb Pto	- kW - c - °C - °C - °C - °C - °C - kW - kW	temperature 20°C and outdoor temperature Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=-15°C Operating limit temperature heating / Average heating / Oolder Cycling interval efficiency for cooling for heating Degradation coefficient heating / Average heating Annual electricity consumption cooling heating / Average heating / Average heating / Verage heating / Verage	ure Tj COPd COPd COPd COPd COPd COPd COPd COPd	- - - -
temperature 20°C and outdoor temperatur Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power modes othe standby mode	re Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Tbiv Tbiv Cbiv Cdc er than 'active Pogb	- kW - kW - kW - kW - kW - kW - kW - kW	temperature 20°C and outdoor temperature Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Older Cycling interval efficiency for cooling for heating Degradation coefficient heating Annual electricity consumption cooling heating / Average	ure Tj COPd COPd COPd COPd COPd COPd COPd COPd	- - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - 0.25 - 459 kWh/a
temperature 20°C and outdoor temperatur Tj=-7°C Tj=2°C Tj=12°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power modes othe off mode standby mode thermostat-off mode crankcase heater mode	re Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Tbiv Cdc er than 'active Poff Psb Pto Pck	- kW - c - °C - °C - °C - °C - °C - kW - kW	temperature 20°C and outdoor temperature Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Colder Cycling interval efficiency for heating Degradation coefficient heating Annual electricity consumption cooling heating / Average heating / Average heating / Varmer heating / Varmer	ure Tj COPd COPd COPd COPd COPd COPd COPd COPd	- - - -
temperature 20°C and outdoor temperatur Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power modes othe off mode standby mode thermostat-off mode	re Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Tbiv Cdc er than 'active Poff Psb Pto Pck	- kW - c - °C - °C - °C - °C - °C - kW - kW	temperature 20°C and outdoor temperature Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating / Average heating Or cooling for heating Outperating lectricity consumption cooling heating / Average heating / Average heating Object Other items	ure Tj COPd COPd COPd COPd COPd COPd COPd COPd	- - <
temperature 20°C and outdoor temperatur Tj=-7°C Tj=2°C Tj=12°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power modes othe off mode standby mode thermostat-off mode crankcase heater mode	re Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Tbiv Cdc er than 'active Poff Psb Pto Pck	- kW - c - °C - °C - °C - °C - °C - kW - kW	temperature 20°C and outdoor temperature Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=-15°C Operating limit temperature heating / Average heating / Varmer heating / Colder Outperating limit temperature for cooling for heating Degradation coefficient heating / Average heating Annual electricity consumption cooling heating / Varmer heating / Varmer heating / Average heating / Varmer heating / Average heating / Colder Other items Sound power level(indoor)	Jure Tj COPd COPd COPd COPd COPd COPd COPd COPd	- - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - 0.25 - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - -
temperature 20°C and outdoor temperatur Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power modes othe off mode standby mode thermostat-off mode crankcase heater mode Capacity control(indicate one of three opti	re Tj Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Tbiv Cdc er than 'active Poff Psb Pto Pck	- kW - c - °C - °C - °C - °C - °C - kW - kW	temperature 20°C and outdoor temperature Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=-15°C Operating limit Tj=-15°C Operating limit temperature heating / Average heating / Oolder Cycling interval efficiency for cooling for heating Degradation coefficient heating / Average heating / Average heating / Average for cooling for keating Degradation coefficient heating / Average heating / Varmer heating / Vareage heating / Vareage heating / Vareage heating / Vareage heating / Oolder Other items Sound power level(indoor) Sound power level(outdoor)	Jure Tj COPd COPd COPd COPd COPd COPd COPd Tol Tol Tol Tol Tol Tol Tol Tol COPcyc COPcyc Cdh	- - - -
temperature 20°C and outdoor temperature Tj=-7°C Tj=2°C Tj=12°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power modes othe off mode standby mode thermostat-off mode crankcase heater mode Capacity control(indicate one of three opti	re Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Cdc er than 'active Poff Psb Pto Pck No	- kW - c - °C - °C - °C - °C - °C - kW - kW	temperature 20°C and outdoor temperature Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating / Average heating / Colder Other items Sound power level(indoor) Sound power level(outdoor) Global warming potential	Jure Tj COPd COPd COPd COPd COPd COPd COPd COPd	- - - -
temperature 20°C and outdoor temperatur Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power modes othe off mode standby mode thermostat-off mode crankcase heater mode Capacity control(indicate one of three opti fixed staged	re Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Tbiv Cdc Cdc Cdc er than 'active Poff Psb Pto Pck Sons)	- kW - c - °C - °C - °C - °C - °C - kW - kW	temperature 20°C and outdoor temperature Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating / Average heating / Varmer heating / Average heating / Varrege heating / Average heating / Varrege heating / Varmer heating / colder Other items Sound power level(indoor) Sound power level(indoor) Sound power level(indoor) Sound power level(indoor)	Jure Tj COPd COPd COPd COPd COPd COPd COPd Tol Tol Tol Tol Tol Tol Tol Tol COPcyc COPcyc Cdh	- - - -
temperature 20°C and outdoor temperature Tj=-7°C Tj=2°C Tj=12°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power modes othe off mode standby mode thermostat-off mode crankcase heater mode Capacity control(indicate one of three opti	re Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Cdc er than 'active Poff Psb Pto Pck No	- kW - c - °C - °C - °C - °C - °C - kW - kW	temperature 20°C and outdoor temperature Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating / Average heating / Colder Other items Sound power level(indoor) Sound power level(outdoor) Global warming potential	Jure Tj COPd COPd COPd COPd COPd COPd COPd Tol Tol Tol Tol Tol Tol Tol Tol COPcyc COPcyc Cdh	- - - -
temperature 20°C and outdoor temperature Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power modes othe off mode standby mode thermostat-off mode crankcase heater mode Capacity control(indicate one of three opti fixed staged variable	re Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh	- kW - °C - <td< td=""><td>temperature 20°C and outdoor temperature Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Varrage heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating Annual electricity consumption cooling heating / Varrage heating / colder Other items Sound power level(indoor) Sound power level(outdoor) Global warming potential Rated air flow(indoor) Rated air flow(outdoor)</td><td>Jure Tj COPd COPd COPd COPd COPd COPd COPd Tol Tol Tol Tol Tol Tol Tol Tol COPcyc COPcyc Cdh</td><td>- - - -</td></td<>	temperature 20°C and outdoor temperature Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Varrage heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating Annual electricity consumption cooling heating / Varrage heating / colder Other items Sound power level(indoor) Sound power level(outdoor) Global warming potential Rated air flow(indoor) Rated air flow(outdoor)	Jure Tj COPd COPd COPd COPd COPd COPd COPd Tol Tol Tol Tol Tol Tol Tol Tol COPcyc COPcyc Cdh	- - - -
temperature 20°C and outdoor temperature Tj=-7°C Tj=2°C Tj=12°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power modes othe off mode standby mode thermostat-off mode crankcase heater mode Capacity control(indicate one of three opti fixed staged variable Contact details for obtaining	re Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Tbiv Cdc er than 'active Poych Cdc er than 'active Poff Psb Pto Pck No No No Name and	- kW - kW - kW - kW - kW - kW - kW - kW	temperature 20°C and outdoor temperature Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating / Average heating / Colder Other items Sound power level(indoor) Sound power level(indoor) Sound power level(indoor) Rated air flow(indoor) Rated air flow(outdoor) facturer or of its authorised representative.	Jure Tj COPd COPd COPd COPd COPd COPd COPd Tol Tol Tol Tol Tol Tol Tol Tol COPcyc COPcyc Cdh	- - - -
temperature 20°C and outdoor temperature Tj=-7°C Tj=2°C Tj=12°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power modes othe off mode standby mode thermostat-off mode crankcase heater mode Capacity control(indicate one of three opti fixed staged variable Contact details for obtaining more information Mitsubi	re Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh	- kW - °C - kW - kW - kW - kW - kW - kW - w - w - w - w <	temperature 20°C and outdoor temperature Tj=-7°C Tj=2°C Tj=12°C Tj=12°C Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Odder Cycling interval efficiency for heating Degradation coefficient heating / Average heating Degradation coefficient heating / Verage heating / Verage heating / Verage heating / Verage heating / Average heating / Verage heating / Colder Other items Sound power level(indoor) Sound power level(outdoor) Global warming potential Rated air flow(indoor) Rated air flow(outdoor) facturer or of its authorised representative. g Europe, Ltd.	Jure Tj COPd COPd COPd COPd COPd COPd COPd Tol Tol Tol Tol Tol Tol Tol Tol COPcyc COPcyc Cdh	- - - -
temperature 20°C and outdoor temperature Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power modes othe off mode standby mode thermostat-off mode crankcase heater mode Capacity control(indicate one of three opti fixed staged variable Contact details for obtaining more information Mitsubi 7 Round	re Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Tbiv Tbiv Tbiv	- kW - °C - kW - kW - kW - kW - kW - kW - w - w - w - w <	temperature 20°C and outdoor temperature Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating / Average heating / Colder Other items Sound power level(indoor) Sound power level(indoor) Sound power level(indoor) Rated air flow(indoor) Rated air flow(outdoor) facturer or of its authorised representative.	Jure Tj COPd COPd COPd COPd COPd COPd COPd Tol Tol Tol Tol Tol Tol Tol Tol COPcyc COPcyc Cdh	- - - -
temperature 20°C and outdoor temperature Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power modes othe off mode standby mode thermostat-off mode crankcase heater mode Capacity control(indicate one of three opti fixed staged variable Contact details for obtaining more information Mitsubi 7 Round	re Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh	- kW - °C - kW - kW - kW - kW - kW - kW - w - b - w - w <	temperature 20°C and outdoor temperature Tj=-7°C Tj=2°C Tj=12°C Tj=12°C Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Odder Cycling interval efficiency for heating Degradation coefficient heating / Average heating Degradation coefficient heating / Verage heating / Verage heating / Verage heating / Verage heating / Average heating / Verage heating / Colder Other items Sound power level(indoor) Sound power level(outdoor) Global warming potential Rated air flow(indoor) Rated air flow(outdoor) facturer or of its authorised representative. g Europe, Ltd.	Jure Tj COPd COPd COPd COPd COPd COPd COPd Tol Tol Tol Tol Tol Tol Tol Tol COPcyc COPcyc Cdh	- - - -

PJG000Z160

(4) Duct connected-Low/Midde static pressure type (FDUM) Model FDUM71VNPVF1

Information to identify the model(s) to which the information	relates to:	If function includes heating: Indicate the I	heating seaso	n the
Indoor unit model name	FDUM71VF1		information relates to. Indicated values sh		
Outdoor unit model name	FDC71VNP		heating season at a time. Include at least		
	100/111			the neating st	cason Average.
Function(indicate if present)			Average(mandatory)	Yes	
cooling	Yes		Warmer(if designated)	No	
heating	Yes		Colder(if designated)	No	
Tieating	Tes			NO	
lte			14	e verber el	
Item	symbol val	ue unit	Item	symbol	value class
Design load			Seasonal efficiency and energy efficiency		
cooling	Pdesignc	7.1 kW	cooling	SEER	5.71 A+
heating / Average	Pdesignh	5.7 kW	heating / Average	SCOP/A	4.00 A+
heating / Warmer	Pdesignh	- kW	heating / Warmer	SCOP/W	
heating / Colder	Pdesignh	- kW	heating / Colder	SCOP/C	
			7		unit
Declared capacity at outdoor temp			Back up heating capacity at outdoor temp	erature Tdesig	
heating / Average (-10°C)	Pdh	5.70 kW	heating / Average (-10°C)	elbu	0 kW
heating / Warmer (2°C)	Pdh	- kW	heating / Warmer (2°C)	elbu	- kW
heating / Colder (-22°C)	Pdh	- kW	heating / Colder (-22°C)	elbu	- kW
Declared capacity for cooling, at i	ndoor temperature 27(19)	C and	Declared energy efficiency ratio, at indoo	r temperature	27(19)°C and
outdoor temperature Tj	,		outdoor temperature Tj		()
Tj=35°C	Pdc	7.10 kW	Tj=35°C	EERd	2.70 -
Ti=30°C	Pdc	5.20 kW	Ti=30°C	EERd	4.30 -
Tj=25°C		3.40 kW	Ti=25°C	EERd	7.40 -
Tj=20°C		1.50 kW	Tj=20°C	EERd	9.80 -
,					
Declared capacity for heating / Av	erade season at indoor		Declared coefficient of performance / Ave	rade season	at indoor
temperature 20°C and outdoor ter			temperature 20°C and outdoor temperature		
Tj=-7°C	· · ·	5.00 kW	Ti=-7°C	COPd	2.50 -
Tj=2°C		3.00 kW	$T_{j=2}^{r}C$	COPd	3.90 -
Tj=7°C		2.00 kW	Ti=7°C	COPd	
					5.40 -
Tj=12°C		1.40 kW	Tj=12°C	COPd	6.00 -
Tj=bivalent temperature		5.70 kW	Tj=bivalent temperature	COPd	2.40 -
Tj=operating limit	Pdh	5.10 kW	Tj=operating limit	COPd	2.10 -
			1		
Declared capacity for heating / Wa			Declared coefficient of performance / War		at indoor
temperature 20°C and outdoor ter	nperature Tj		temperature 20°C and outdoor temperatu		
Tj=2°C	Pdh	- kW	Tj=2°C	COPd	
Tj=7°C	Pdh	- kW	Tj=7°C	COPd	
Tj=12°C	Pdh	- kW	Tj=12°C	COPd	
Tj=bivalent temperature	Pdh	- kW	Tj=bivalent temperature	COPd	
Tj=operating limit	Pdh	- kW	Tj=operating limit	COPd	
Declared capacity for heating / Co	older season, at indoor		Declared coefficient of performance / Co	lder season, a	t indoor
temperature 20°C and outdoor ter			temperature 20°C and outdoor temperature		
Tj=-7°C	Pdh	- kW	Tj=-7°C	COPd	
Tj=2°C	Pdh	- kW	Tj=2°C	COPd	
Tj=7°C	Pdh	- kW	Ti=7°C	COPd	
Tj=12°C	Pdh	- kW	Ti=12°C	COPd	
Tj=bivalent temperature	Pdh	- kW	Tj=bivalent temperature	COPd	
Tj=operating limit	Pdh	- kW	Tj=operating limit	COPd	
Tj=-15°C	Pdh	- kW	Tj=-15℃	COPd	
1 <u>j</u> = 13 0	1 dil		[1]= 10 0	0010	_
Rivelant tomporature			Operating limit temperature		
Bivalent temperature	Tbiv	-10 °C	heating / Average	Tol	-15 °C
heating / Average	Tbiv	- °C		Tol	-15 C
heating / Warmer			heating / Warmer		
heating / Colder	Tbiv	- °C	heating / Colder	Tol	- °C
Cycling interval capacity		1.3.47	Cycling interval efficiency	555	
for cooling	Pcycc	- kW	for cooling	EERcyc	⊢ – – -
for heating	Pcych	- kW	for heating	COPcyc	- -
Degradation coefficient		0.05	Degradation coefficient	0 "	
cooling	Cdc	0.25 -	heating	Cdh	0.25 -
Electric power input in power mo			Annual electricity consumption		
off mode	Poff	10 W	cooling	Qce	436 kWh/a
standby mode	Psb	10 W	heating / Average	Qhe	1996 kWh/a
thermostat-off mode	Pto	25 W	heating / Warmer	Qhe	- kWh/a
crankcase heater mode	Pck	0 W	heating / colder	Qhe	- kWh/a
	TOK				
Capacity control(indicate one of th	T CK				
			Other items		
			Other items Sound power level(indoor)	Lwa	65 dB(A)
				Lwa Lwa	65 dB(A) 67 dB(A)
fixed			Sound power level(indoor)		
	iree options)		Sound power level(indoor) Sound power level(outdoor) Global warming potential	Lwa	67 dB(A) 1975 kgCO2eq.
staged	nree options)		Sound power level(indoor) Sound power level(outdoor) Global warming potential Rated air flow(indoor)	Lwa	67 dB(A) 1975 kgCO2eq. 1440 m ³ /h
	nree options)		Sound power level(indoor) Sound power level(outdoor) Global warming potential	Lwa GWP -	67 dB(A) 1975 kgCO2eq.
staged variable	No No Yes	dress of the manual	Sound power level(indoor) Sound power level(outdoor) Global warming potential Rated air flow(indoor) Rated air flow(outdoor)	Lwa GWP -	67 dB(A) 1975 kgCO2eq. 1440 m ³ /h
staged variable Contact details for obtaining	No No Yes Name and ad		Sound power level(indoor) Sound power level(outdoor) Global warming potential Rated air flow(indoor) Rated air flow(outdoor) facturer or of its authorised representative.	Lwa GWP -	67 dB(A) 1975 kgCO2eq. 1440 m ³ /h
staged variable Contact details for obtaining more information	No No Yes Name and ad Mitsubishi Heavy Industri	es Air-Conditionin	Sound power level(indoor) Sound power level(outdoor) Global warming potential Rated air flow(indoor) Rated air flow(outdoor) facturer or of its authorised representative. g Europe, Ltd.	Lwa GWP -	67 dB(A) 1975 kgCO2eq. 1440 m ³ /h
staged variable Contact details for obtaining more information	No No Yes Name and ad Mitsubishi Heavy Industri 7 Roundwood Avenue, Si	es Air-Conditionin	Sound power level(indoor) Sound power level(outdoor) Global warming potential Rated air flow(indoor) Rated air flow(outdoor) facturer or of its authorised representative.	Lwa GWP -	67 dB(A) 1975 kgCO2eq. 1440 m ³ /h
staged variable Contact details for obtaining more information	No No Yes Name and ad Mitsubishi Heavy Industri	es Air-Conditionin	Sound power level(indoor) Sound power level(outdoor) Global warming potential Rated air flow(indoor) Rated air flow(outdoor) facturer or of its authorised representative. g Europe, Ltd.	Lwa GWP -	67 dB(A) 1975 kgCO2eq. 1440 m ³ /h
staged variable Contact details for obtaining more information	No No Yes Name and ad Mitsubishi Heavy Industri 7 Roundwood Avenue, Si	es Air-Conditionin	Sound power level(indoor) Sound power level(outdoor) Global warming potential Rated air flow(indoor) Rated air flow(outdoor) facturer or of its authorised representative. g Europe, Ltd.	Lwa GWP -	67 dB(A) 1975 kgCO2eq. 1440 m ³ /h
staged variable Contact details for obtaining more information	No No Yes Name and ad Mitsubishi Heavy Industri 7 Roundwood Avenue, Si	es Air-Conditionin	Sound power level(indoor) Sound power level(outdoor) Global warming potential Rated air flow(indoor) Rated air flow(outdoor) facturer or of its authorised representative. g Europe, Ltd.	Lwa GWP - -	67 dB(A) 1975 kgCO2eq. 1440 m ³ /h

Model FDUM90VNPVF1

Information to identify the model	(s) to which the inform	ation relates to:	If function includes heating: Indicate	the heating seasor	n the
Indoor unit model name	FDUM100		information relates to. Indicated value		
Outdoor unit model name	FDC90VN	IP	heating season at a time. Include at I	east the heating se	eason 'Average'.
Function(indicate if present)			Average(mandatory)	Yes	
cooling	Yes		Warmer(if designated)	No	
heating	Yes		Colder(if designated)	No	
Item	symbol	value unit	Item	symbol	value class
Design load	Symbol	value unit	Seasonal efficiency and energy efficiency		
cooling	Pdesignc	9.0 kW	cooling	SEER	6.86 A++
heating / Average	Pdesignh	8.1 kW	heating / Average	SCOP/A	4.20 A+
heating / Warmer	Pdesignh		heating / Warmer	SCOP/W	
heating / Colder	Pdesignh		heating / Colder	SCOP/C	
					unit
Declared capacity at outdoor temp	perature Tdesignh		Back up heating capacity at outdoor t	temperature Tdesig	gnh
heating / Average (-10°C)	Pdh	8.10 kW	heating / Average (-10°C)	elbu	0 kW
heating / Warmer (2°C)	Pdh	- kW	heating / Warmer (2°C)	elbu	- kW
heating / Colder (-22°C)	Pdh	- kW	heating / Colder (-22°C)	elbu	- kW
Declared capacity for cooling, at	indoor temperature 2	7(19)°C and	Declared energy efficiency ratio, at in	ndoor temperature	27(19)°C and
outdoor temperature Tj	5.		outdoor temperature Tj		
Tj=35°C	Pdc	9.00 kW	Tj=35°C	EERd	3.40 -
Tj=30°C	Pdc	6.60 kW	Tj=30°C	EERd	5.30 -
Tj=25°C Tj=20°C	Pdc Pdc	4.30 kW 2.20 kW	Tj=25°C Tj=20°C	EERd EERd	8.20 - 14.00 -
I]=20 C	Puc	2.20 KVV		EERU	14.00 -
Declared capacity for heating / Av	verage season at inde	or	Declared coefficient of performance /	Average season	at indoor
temperature 20°C and outdoor ter			temperature 20°C and outdoor temperature		
Tj=-7°C	Pdh	7.10 kW	Ti=-7°C	COPd	2.80 -
Tj=2°C	Pdh	4.30 kW	Tj=2°C	COPd	4.10 -
Tj=7℃	Pdh	2.70 kW	Tj=7℃	COPd	5.50 -
Tj=12°C	Pdh	1.80 kW	Tj=12°C	COPd	5.90 -
Tj=bivalent temperature	Pdh	8.10 kW	Tj=bivalent temperature	COPd	2.40 -
Tj=operating limit	Pdh	7.10 kW	Tj=operating limit	COPd	2.30 -
Declared capacity for heating / Wa		or	Declared coefficient of performance /		at indoor
temperature 20°C and outdoor ter			temperature 20°C and outdoor temperature		
Tj=2°C	Pdh		Tj=2°C	COPd	
Tj=7°C	Pdh	- kW	Tj=7°C	COPd	
Tj=12°C	Pdh	- kW	Tj=12°C	COPd	
Tj=bivalent temperature	Pdh Pdh	- kW - kW	Tj=bivalent temperature	COPd	
Tj=operating limit	1 UII	- 100	Tj=operating limit	COPd	
Declared capacity for heating / Co	older season, at indoo		Declared coefficient of performance /	Colder season, at	
Declared capacity for heating / Co temperature 20°C and outdoor ter	older season, at indoo mperature Tj	r	Declared coefficient of performance / temperature 20°C and outdoor temperature	' Colder season, at erature Tj	
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C	older season, at indoo		Declared coefficient of performance / temperature 20°C and outdoor tempe Tj=-7°C	^r Colder season, at erature Tj COPd	
Declared capacity for heating / Co temperature 20°C and outdoor ter	older season, at indoo mperature Tj Pdh	r kW	Declared coefficient of performance / temperature 20°C and outdoor temper Tj=-7°C Tj=2°C	' Colder season, at erature Tj	indoor
Declared capacity for heating / Cc temperature 20°C and outdoor ter $T_{j=-7$ °C $T_{j=2}$ °C	older season, at indoo mperature Tj Pdh Pdh	r - kW - kW	Declared coefficient of performance / temperature 20°C and outdoor tempe Tj=-7°C	[′] Colder season, at erature Tj COPd COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter $T_{j=-7^{\circ}C}$ $T_{j=2^{\circ}C}$ $T_{j=7^{\circ}C}$	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh	r kW kW kW	Declared coefficient of performance / temperature 20°C and outdoor temper Tj=-7°C Tj=2°C Tj=7°C	Colder season, at erature Tj COPd COPd COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=7°C Tj=12°C	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh	r - kW - kW - kW - kW	Declared coefficient of performance / temperature 20°C and outdoor temper Tj=-7°C Tj=-7°C Tj=12°C	Colder season, at erature Tj COPd COPd COPd COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter $T_{j=-7^{\circ}C}$ $T_{j=2^{\circ}C}$ $T_{j=7^{\circ}C}$ $T_{j=12^{\circ}C}$ $T_{j=bivalent}$ temperature	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh	r - kW - kW - kW - kW - kW	Declared coefficient of performance / temperature 20°C and outdoor temper Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature	Colder season, at erature Tj COPd COPd COPd COPd COPd COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter $T_{j=-7^{\circ}C}$ $T_{j=2^{\circ}C}$ $T_{j=12^{\circ}C}$ $T_{j=12^{\circ}C}$ $T_{j=bivalent}$ temperature $T_{j=operating}$ limit $T_{j=-15^{\circ}C}$	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh	r - KW - KW - KW - KW - KW	Declared coefficient of performance / temperature 20°C and outdoor temper Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C	Colder season, at erature Tj COPd COPd COPd COPd COPd COPd COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh	r - kW - kW - kW - kW - kW - kW - kW	Declared coefficient of performance / temperature 20°C and outdoor temperature Tj=-7°C Tj=7°C Tj=12°C Tj=operating limit Tj=-15°C Operating limit temperature	Colder season, at erature Tj COPd COPd COPd COPd COPd COPd COPd COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter $T_{j=-7}^{\circ}C$ $T_{j=2}^{\circ}C$ $T_{j=12}^{\circ}C$ $T_{j=bivalent}$ temperature $T_{j=operating}$ limit $T_{j=-15}^{\circ}C$ Bivalent temperature heating / Average	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv	r - KW - KW - KW - KW - KW - KW - KW - KW	Declared coefficient of performance / temperature 20°C and outdoor temperature Tj=-7°C Tj=2°C Tj=12°C Tj=operating limit Tj=-5°C Operating limit temperature heating / Average	Colder season, at COPd COPd COPd COPd COPd COPd COPd COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=5°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Warmer	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv	r - kW - kW - kW - kW - kW - kW - kW - kW - kW	Declared coefficient of performance / temperature 20°C and outdoor temperature Tj=-7°C Tj=12°C Tj=bivalent temperature Tj=-0perating limit Tj=-15°C Operating limit temperature heating / Average heating / Warmer	Colder season, at erature Tj COPd COPd COPd COPd COPd COPd COPd COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter $T_{j=-7}^{\circ}C$ $T_{j=2}^{\circ}C$ $T_{j=12}^{\circ}C$ $T_{j=bivalent}$ temperature $T_{j=operating}$ limit $T_{j=-15}^{\circ}C$ Bivalent temperature heating / Average	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv	r - KW - KW - KW - KW - KW - KW - KW - KW	Declared coefficient of performance / temperature 20°C and outdoor temperature Tj=-7°C Tj=2°C Tj=12°C Tj=operating limit Tj=-5°C Operating limit temperature heating / Average	Colder season, at COPd COPd COPd COPd COPd COPd COPd COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Warmer heating / Colder	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv	r - kW - kW - kW - kW - kW - kW - kW - kW - kW	Declared coefficient of performance / temperature 20°C and outdoor temperature 20°C Tj=-7°C Tj=2°C Tj=12°C Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Warmer heating / Colder	Colder season, at erature Tj COPd COPd COPd COPd COPd COPd COPd COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Warmer heating / Colder	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv	r - KW - KW - KW - KW - KW - KW - KW - KW - KW - C - °C	Declared coefficient of performance / temperature 20°C and outdoor temperature 20°C Tj=-7°C Tj=2°C Tj=12°C Tj=operating limit Tj=-5°C Operating limit temperature heating / Average heating / Warmer heating / Colder Cycling interval efficiency	Colder season, at COPd COPd COPd COPd COPd COPd COPd COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Colder Cycling interval capacity for cooling	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv	r 	Declared coefficient of performance / temperature 20°C and outdoor temperature Tj=-7°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Odder Cycling interval efficiency for cooling	Colder season, at erature Tj COPd COPd COPd COPd COPd COPd COPd Tol Tol Tol Tol Tol Tol	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Warmer heating / Colder	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv	r 	Declared coefficient of performance / temperature 20°C and outdoor temperature 20°C Tj=-7°C Tj=2°C Tj=12°C Tj=operating limit Tj=-5°C Operating limit temperature heating / Average heating / Warmer heating / Colder Cycling interval efficiency	Colder season, at COPd COPd COPd COPd COPd COPd COPd COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Colder Cycling interval capacity for cooling	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv	r 	Declared coefficient of performance / temperature 20°C and outdoor temperature Tj=-7°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Odder Cycling interval efficiency for cooling	Colder season, at erature Tj COPd COPd COPd COPd COPd COPd COPd Tol Tol Tol Tol Tol Tol	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Warmer heating / Colder Cycling interval capacity for cooling for heating	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv	r 	Declared coefficient of performance / temperature 20°C and outdoor temperature 20°C Tj=-7°C Tj=2°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Colder Cycling interval efficiency for cooling for heating	Colder season, at erature Tj COPd COPd COPd COPd COPd COPd COPd Tol Tol Tol Tol Tol Tol	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Chiv Chiv	r 	Declared coefficient of performance / temperature 20°C and outdoor temperature 20°C Tj=-7°C Tj=2°C Tj=12°C Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient	Colder season, at coPd COPd COPd COPd COPd COPd COPd COPd CO	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Cdc Cdc	r - kW - kW	Declared coefficient of performance / temperature 20°C and outdoor temperature 20°C Tj=-7°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Older Cycling interval efficiency for cooling for heating Degradation coefficient heating Annual electricity consumption	Colder season, at erature Tj COPd COPd COPd COPd COPd COPd COPd COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Cdc Cdc	r - KW - K	Declared coefficient of performance / temperature 20°C and outdoor temperature 20°C Tj=-7°C Tj=2°C Tj=12°C Tj=operating limit Tj=-5°C Operating limit temperature theating / Average heating / Average heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating Annual electricity consumption cooling	Colder season, at erature Tj COPd COPd COPd COPd COPd COPd COPd COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Cdc Cdc	r 	Declared coefficient of performance / temperature 20°C and outdoor temperature 20°C Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Average heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating Annual electricity consumption cooling heating / Average	Colder season, at erature Tj COPd COPd COPd COPd COPd COPd COPd COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=7°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Cdc Cdc Poff Psb Pto	r 	Declared coefficient of performance / temperature 20°C and outdoor temper Tj=-7°C Tj=2°C Tj=12°C Tj=5°C Operating limit temperature heating / Average heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating / Average heating / Colder	Colder season, at erature Tj COPd COPd COPd COPd COPd COPd COPd COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Cdc Cdc	r 	Declared coefficient of performance / temperature 20°C and outdoor temperature 20°C Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Average heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating Annual electricity consumption cooling heating / Average	Colder season, at erature Tj COPd COPd COPd COPd COPd COPd COPd COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode crankcase heater mode	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Cdc Cdc cdc sdes other than 'active Poff Psb Pto Pck	r 	Declared coefficient of performance / temperature 20°C and outdoor temperature 20°C Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Average heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating / Average heating Manual electricity consumption cooling heating / Warmer heating / Merage heating / Colder	Colder season, at erature Tj COPd COPd COPd COPd COPd COPd COPd COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=7°C Tj=5°C Tj=bivalent temperature Tj=operating limit Tj=-0 Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Cdc Cdc cdc sdes other than 'active Poff Psb Pto Pck	r 	Declared coefficient of performance / temperature 20°C and outdoor temperature 20°C Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating / Average heating / Average heating / Average heating Operaduation coefficient heating / Average heating / Average heating / Average heating / Colder Other items	Colder season, at erature Tj COPd COPd COPd COPd COPd COPd COPd COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode crankcase heater mode	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Cdc Cdc cdc sdes other than 'active Poff Psb Pto Pck	r 	Declared coefficient of performance / temperature 20°C and outdoor temperature 20°C Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating / Average heating / Average heating / Average heating / Colder Other items Sound power level(indoor)	Colder season, at erature Tj COPd COPd COPd COPd COPd COPd COPd COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=2°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode crankcase heater mode Capacity control(indicate one of the content of the conten	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Cdc Cdc vdes other than 'active Poff Psb Pto Pck	r 	Declared coefficient of performance / temperature 20°C and outdoor temperature 20°C Tj=-7°C Tj=2°C Tj=12°C Tj=5r°C Operating limit temperature Tj=-15°C Operating limit temperature heating / Average heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating / Average heating Degradation coefficient heating / Average heating / Average heating / Average heating / Average heating / Other items Sound power level(indoor) Sound power level(outdoor)	Colder season, at erature Tj COPd COPd COPd COPd COPd COPd COPd COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode crankcase heater mode Capacity control(indicate one of the fixed	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Cdc Cdc cdc odes other than 'active Poff Psb Pto Pck hree options)	r 	Declared coefficient of performance / temperature 20°C and outdoor temperature 20°C Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Average heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating / Average heating / Average heating / Warmer heating Operadation coefficient heating / Average heating / Warmer heating / Warmer heating / Colder Other items Sound power level(indoor) Sound power level(outdoor) Global warming potential	Colder season, at erature Tj COPd COPd COPd COPd COPd COPd COPd COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=1°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode crankcase heater mode Capacity control(indicate one of the fixed staged	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Cdc Cdc vdes other than 'active Poff Psb Pto Pck	r 	Declared coefficient of performance / temperature 20°C and outdoor temperature 20°C Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating / Average heating / Average heating / Average heating / Colder Other neating Other items Sound power level(indoor) Sound power level(outdoor) Global warming potential Rated air flow(indoor)	Colder season, at erature Tj COPd COPd COPd COPd COPd COPd COPd COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode crankcase heater mode Capacity control(indicate one of the fixed	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Cdc Cdc Cdc des other than 'active Poff Psb Pto Pck hree options)	r 	Declared coefficient of performance / temperature 20°C and outdoor temperature 20°C Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Warmer heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating / Average heating / Average heating / Warmer heating Operadation coefficient heating / Average heating / Warmer heating / Warmer heating / Colder Other items Sound power level(indoor) Sound power level(outdoor) Global warming potential	Colder season, at erature Tj COPd COPd COPd COPd COPd COPd COPd COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=1°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode crankcase heater mode Capacity control(indicate one of the fixed staged	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Cdc Cdc des other than 'active Poff Psb Pto Pck hree options)	r 	Declared coefficient of performance / temperature 20°C and outdoor temperature 20°C Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating / Average heating / Average heating / Average heating / Colder Other neating Other items Sound power level(indoor) Sound power level(outdoor) Global warming potential Rated air flow(indoor)	Colder season, at erature Tj COPd COPd COPd COPd COPd COPd COPd COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=7°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode crankcase heater mode Capacity control(indicate one of the fixed staged variable	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Cdc Cdc des other than 'active Poff Psb Pto Pck hree options)	r 	Declared coefficient of performance / temperature 20°C and outdoor temperature 20°C Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating / Average heating / Average heating / Average heating / Colder Other items Sound power level(indoor) Sound power level(outdoor) Global warming potential Rated air flow(utdoor) Rated air flow(outdoor)	Colder season, at erature Tj COPd COPd COPd COPd COPd COPd COPd COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode crankcase heater mode Capacity control(indicate one of the fixed staged variable Contact details for obtaining	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Cdc Cdc Cdc Cdc Cdc des other than 'active Poff Psb Pto Pck hree options) No Yes Name an Mitsubishi Heavy Ind 7 Roundwood Avenu	- kW - %C - %W - %C - %W -	Declared coefficient of performance / temperature 20°C and outdoor temperature 20°C Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating / Average heating / Average heating / Average heating / Colder Other items Sound power level(indoor) Sound power level(outdoor) Global warming potential Rated air flow(utdoor) Rated air flow(outdoor)	Colder season, at erature Tj COPd COPd COPd COPd COPd COPd COPd COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode crankcase heater mode Capacity control(indicate one of the fixed staged variable Contact details for obtaining	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Cdc Cdc Cdc des other than 'active Poff Psb Pto Pck hree options) No Yes	- kW - %C - %W - %C - %W -	Declared coefficient of performance / temperature 20°C and outdoor temperature 20°C Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating / Average heating / colder Other items Sound power level(indoor) Sound power level(outdoor) Global warming potential Rated air flow(indoor) Rated air flow(indoor) Rated air flow(indoor) utfacturer or of its authorised representation	Colder season, at erature Tj COPd COPd COPd COPd COPd COPd COPd COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode crankcase heater mode Capacity control(indicate one of the fixed staged variable Contact details for obtaining	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Cdc Cdc Cdc Cdc Cdc des other than 'active Poff Psb Pto Pck hree options) No Yes Name an Mitsubishi Heavy Ind 7 Roundwood Avenu	- kW - %C - %W - %C - %W -	Declared coefficient of performance / temperature 20°C and outdoor temperature 20°C Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating / Average heating / colder Other items Sound power level(indoor) Sound power level(outdoor) Global warming potential Rated air flow(indoor) Rated air flow(indoor) Rated air flow(indoor) utfacturer or of its authorised representation	Colder season, at erature Tj COPd COPd COPd COPd COPd COPd COPd COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode crankcase heater mode Capacity control(indicate one of the fixed staged variable Contact details for obtaining	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Cdc Cdc Cdc Cdc Cdc des other than 'active Poff Psb Pto Pck hree options) No Yes Name an Mitsubishi Heavy Ind 7 Roundwood Avenu	- kW - %C - %W - %C - %W -	Declared coefficient of performance / temperature 20°C and outdoor temperature 20°C Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating / Average heating / colder Other items Sound power level(indoor) Sound power level(outdoor) Global warming potential Rated air flow(indoor) Rated air flow(indoor) Rated air flow(indoor) utfacturer or of its authorised representation	Colder season, at erature Tj COPd COPd COPd COPd COPd COPd COPd COPd	indoor

Model FDUM90VNPVF2

Information to identify the model(s) to	which the informat	ion relates to:	If function includes heating: Indicate	the heating season the
Indoor unit model name	FDUM100V		information relates to. Indicated value	
Outdoor unit model name	FDC90VNP		heating season at a time. Include at le	
				g
Function(indicate if present)			Average(mandatory)	Yes
cooling	Yes		Warmer(if designated)	No
heating	Yes		Colder(if designated)	No
Item	symbol v	/alue unit	Item	symbol value class
Design load			Seasonal efficiency and energy efficiency	ency class
cooling	Pdesignc	9.0 kW	cooling	SEER 6.86 A++
heating / Average	Pdesignh	8.1 kW	heating / Average	SCOP/A 4.20 A+
heating / Warmer	Pdesignh	- kW	heating / Warmer	SCOP/W
heating / Colder	Pdesignh	- kW	heating / Colder	SCOP/C
				unit
Declared capacity at outdoor tempera	ature Tdesignh		Back up heating capacity at outdoor t	emperature Tdesignh
heating / Average (-10°C)	Pdh	8.10 kW	heating / Average (-10°C)	elbu 0 kW
heating / Warmer (2°C)	Pdh	- kW	heating / Warmer (2°C)	elbu - kW
heating / Colder (-22°C)	Pdh	- kW	heating / Colder (-22°C)	elbu - kW
Declared capacity for cooling, at inde	oor temperature 27(19°C and	Declared energy efficiency ratio, at in	door temperature 27(19)°C and
outdoor temperature Tj	-		outdoor temperature Tj	
Tj=35°C	Pdc	9.00 kW	Tj=35°C	EERd 3.40 -
Tj=30°C	Pdc	6.60 kW	Tj=30°C	EERd 5.30 -
Tj=25°C	Pdc	4.30 kW	Tj=25°C	EERd 8.20 -
Tj=20°C	Pdc	2.20 kW	Tj=20°C	EERd 14.00 -
Declared capacity for heating / Average		r	Declared coefficient of performance /	
temperature 20°C and outdoor temperature	· · ·	740	temperature 20°C and outdoor tempe	
Tj=-7°C	Pdh	7.10 kW	Tj=-7°C	COPd 2.80 -
Tj=2°C	Pdh	4.30 kW	Tj=2°C	COPd 4.10 -
Tj=7°C	Pdh	2.70 kW	Tj=7°C	COPd 5.50 -
Tj=12°C	Pdh	1.80 kW	Tj=12°C	COPd 5.90 -
Tj=bivalent temperature	Pdh	8.10 kW	Tj=bivalent temperature	COPd 2.40 -
Tj=operating limit	Pdh	7.10 kW	Tj=operating limit	COPd 2.30 -
Dealana di asusasitu fan haastinan (Wanna			De alore el ocofficio est of receformente a	M/
Declared capacity for heating / Warm			Declared coefficient of performance /	
temperature 20°C and outdoor tempe	· · -	- kW	temperature 20°C and outdoor tempe	
Tj=2°C	Pdh _	- kW - kW	Tj=2°C	COPd COPd
Tj=7°C	Pdh		Tj=7°C	
Tj=12°C	Pdh	- kW - kW	Tj=12°C	COPd COPd
Tj=bivalent temperature	Pdh		Tj=bivalent temperature	
Tj=operating limit	Pdh	- kW	Tj=operating limit	COPd
Declared capacity for beating (Colda)	raaaaan at indoor		Declared coefficient of performance /	Colder access at indeer
Declared capacity for heating / Colder			Declared coefficient of performance /	
temperature 20°C and outdoor tempe	· · ·	- kW	temperature 20°C and outdoor tempe	COPd
Tj=-7°C Tj=2°C	Pdh Pdh	- kW	Tj=7°C	COPd
Tj=7°C	Pdh	- kW	$T_{j=2}^{j=2}$ C	COPd
Tj=7°C	Pdh	- kW	Tj=12°C	COPd
Tj=bivalent temperature	Pdh	- kW	Tj=bivalent temperature	COPd
Tj=operating limit	Pdh	- kW	Tj=operating limit	COPd
Tj=-15°C	Pdh	- kW	Ti=-15°C	COPd
	run	- 1600	[1]=-13.6	
Bivalent temperature			Operating limit temperature	
heating / Average	Tbiv	-10 °C	heating / Average	Tol -15 °C
heating / Warmer	Tbiv	- °C	heating / Warmer	Tol - °C
heating / Colder	Tbiv	- °C	heating / Colder	Tol - °C
		1.0		
Cycling interval capacity			Cycling interval efficiency	
for cooling	Pcycc	- kW	for cooling	EERcyc
for heating	Pcych	- kW	for heating	COPcyc
	, ,			ř
Degradation coefficient			Degradation coefficient	
cooling	Cdc	0.25 -	heating	Cdh 0.25 -
Electric power input in power modes	other than 'active n		Annual electricity consumption	
off mode	Poff	10 W	cooling	Qce 459 kWh/a
standby mode	Psb	10 W	heating / Average	Qhe 2703 kWh/a
thermostat-off mode	Pto	50 W	heating / Warmer	Qhe - kWh/a
crankcase heater mode	Pck	0 W	heating / colder	Qhe - kWh/a
Capacity control(indicate one of three	options)		Other items	
			Sound power level(indoor)	Lwa 65 dB(A)
	-		Sound power level(outdoor)	Lwa <u>69</u> dB(A)
fixed	No		Global warming potential	GWP 1975 kgCO2eq.
staged	No		Rated air flow(indoor)	- 2160 m ³ /h
variable	Yes		Rated air flow(outdoor)	- 3780 m ³ /h
	•			
Contact details for obtaining			anufacturer or of its authorised representation	ve.
	subishi Heavy Indus			
		Stockley Park, l	Ixbridge, Middlesex, UB11 1AX.	
Unr	ted Kingdom			
1				

(5) Floor standing type (FDF) Model FDF71VNPVD1

Information to identify the model(s) to w	hich the information	tion relates to:	If function includes heating: Indicate the	heating seasor	n the
Indoor unit model name	FDF71VD1		information relates to. Indicated values	should relate to	one
Outdoor unit model name	FDC71VNP	•	heating season at a time. Include at leas	st the heating se	eason 'Average'.
Function(indicate if present)			Average(mandatory)	Yes	
cooling	Yes		Warmer(if designated)	No	
heating	Yes		Colder(if designated)	No	
Item	symbol	value unit	Item	symbol	value class
Design load	Symbol	value unit	Seasonal efficiency and energy efficience		value class
cooling	Pdesignc	7.1 kW	cooling	SEER	5.24 A
heating / Average	Pdesignh	5.5 kW	heating / Average	SCOP/A	3.91 A
heating / Warmer	Pdesignh	- kW	heating / Warmer	SCOP/W	
heating / Colder	Pdesignh	- kW	heating / Colder	SCOP/C	
	i deoigini			000170	unit
Declared capacity at outdoor temperatur	re Tdesianh		Back up heating capacity at outdoor tem	perature Tdesid	
heating / Average (-10°C)	Pdh	5.50 kW	heating / Average (-10°C)	elbu	0 kW
heating / Warmer (2°C)	Pdh	- kW	heating / Warmer (2°C)	elbu	- kW
heating / Colder (-22°C)	Pdh	- kW	heating / Colder (-22°C)	elbu	- kW
Declared capacity for cooling, at indoor	temperature 27(19°C and	Declared energy efficiency ratio, at indo	or temperature	27(19)°C and
outdoor temperature Tj			outdoor temperature Tj		
Tj=35°C	Pdc	7.10 kW	Tj=35°C	EERd	2.70 -
Tj=30°C	Pdc	5.20 kW	Tj=30°C	EERd	3.90 -
Tj=25°C	Pdc	3.40 kW	Tj=25°C	EERd	6.60 -
Tj=20°C	Pdc	1.50 kW	Tj=20°C	EERd	8.90 -
Declared capacity for heating / Average		r	Declared coefficient of performance / Av		at indoor
temperature 20°C and outdoor temperate	ure Tj		temperature 20°C and outdoor temperat		
Tj=-7°C	Pdh	4.90 kW	Tj=-7°C	COPd	2.40 -
Tj=2°C	Pdh	3.00 kW	Tj=2°C	COPd	3.80 -
Tj=7°C	Pdh	1.90 kW	Tj=7°C	COPd	5.30 -
Tj=12°C	Pdh	1.20 kW	Tj=12°C	COPd	6.00 -
Tj=bivalent temperature	Pdh	5.50 kW	Tj=bivalent temperature	COPd	2.30 -
Tj=operating limit	Pdh	4.90 kW	Tj=operating limit	COPd	2.20 -
Declared capacity for heating / Warmer		r	Declared coefficient of performance / Wa	,	at indoor
temperature 20°C and outdoor temperate	· · ·		temperature 20°C and outdoor temperat		
Tj=2°C	Pdh	- kW	Tj=2°C	COPd	
Tj=7°C	Pdh	- kW	Tj=7°C	COPd	
Tj=12°C	Pdh	- kW	Tj=12°C	COPd	
Tj=bivalent temperature	Pdh	- kW	Tj=bivalent temperature	COPd	
Tj=operating limit	Pdh	- kW	Tj=operating limit	COPd	
Declared capacity for heating / Colder se			Declared coefficient of performance / Co		indoor
Declared capacity for heating / Colder set temperature 20°C and outdoor temperature	ure Tj		temperature 20°C and outdoor temperat	ure Tj	indoor
Declared capacity for heating / Colder set temperature 20°C and outdoor temperatur Tj=-7°C	ure Tj Pdh	- kW	temperature 20°C and outdoor temperat $T_{j=-7}^{\circ}C$	ure Tj COPd	
Declared capacity for heating / Colder set temperature 20°C and outdoor temperatur $T_{j=-7$ °C $T_{j=2}$ °C	ure Tj Pdh [Pdh]	- kW	temperature 20°C and outdoor temperat $T_{j=-7}^{\circ}C$ $T_{j=2}^{\circ}C$	cure Tj COPd COPd	indoor
Declared capacity for heating / Colder set temperature 20°C and outdoor temperature $T_{j=-7^{\circ}C}$ $T_{j=2^{\circ}C}$ $T_{j=7^{\circ}C}$	ure Tj Pdh [Pdh [Pdh [- kW - kW	temperature 20°C and outdoor temperat Tj=-7°C Tj=2°C Tj=7°C	ure Tj COPd COPd COPd	
Declared capacity for heating / Colder set temperature 20°C and outdoor temperate Tj=-7°C Tj=2°C Tj=7°C Tj=12°C	ure Tj Pdh Pdh Pdh Pdh Pdh	- kW - kW - kW	temperature 20°C and outdoor temperat $T_{j=-7}^{\circ}C$ $T_{j=2}^{\circ}C$ $T_{j=7}^{\circ}C$ $T_{j=12}^{\circ}C$	COPd COPd COPd COPd COPd COPd	
Declared capacity for heating / Colder set temperature 20°C and outdoor temperati Tj=-7°C Tj=2°C Tj=7°C Tj=12°C Tj=bivalent temperature	ure Tj Pdh Pdh Pdh Pdh Pdh Pdh	- kW - kW - kW - kW	temperature 20°C and outdoor temperat Tj=-7°C Tj=2°C Tj=7°C Tj=12°C Tj=12°C Tj=bivalent temperature	COPd COPd COPd COPd COPd COPd COPd	
Declared capacity for heating / Colder set temperature 20°C and outdoor temperatur Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit	ure Tj Pdh [Pdh [Pdh] Pdh [Pdh] Pdh]	- kW - kW - kW - kW - kW	temperature 20°C and outdoor temperat $T_{j=-7}^{\circ}C$ $T_{j=2}^{\circ}C$ $T_{j=12}^{\circ}C$ $T_{j=12}^{\circ}C$ $T_{j=bivalent}$ temperature $T_{j=operating}$ limit	COPd COPd COPd COPd COPd COPd COPd COPd	
Declared capacity for heating / Colder set temperature 20°C and outdoor temperati Tj=-7°C Tj=2°C Tj=7°C Tj=12°C Tj=bivalent temperature	ure Tj Pdh Pdh Pdh Pdh Pdh Pdh	- kW - kW - kW - kW	temperature 20°C and outdoor temperat Tj=-7°C Tj=2°C Tj=7°C Tj=12°C Tj=12°C Tj=bivalent temperature	COPd COPd COPd COPd COPd COPd COPd	
Declared capacity for heating / Colder set temperature 20°C and outdoor temperatur Tj=-7°C Tj=2°C Tj=7°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C	ure Tj Pdh [Pdh [Pdh] Pdh [Pdh] Pdh]	- kW - kW - kW - kW - kW	temperature 20°C and outdoor temperat $T_{j=-7}^{\circ}C$ $T_{j=2}^{\circ}C$ $T_{j=12}^{\circ}C$ $T_{j=12}^{\circ}C$ $T_{j=bivalent}$ temperature $T_{j=operating}$ limit $T_{j=-15}^{\circ}C$	COPd COPd COPd COPd COPd COPd COPd COPd	
Declared capacity for heating / Colder set temperature 20°C and outdoor temperatur Tj=-7°C Tj=2°C Tj=12°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature	ure Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh	- kW - kW - kW - kW - kW - kW	temperature 20°C and outdoor temperat $T_{j=-7}^{\circ}C$ $T_{j=2}^{\circ}C$ $T_{j=12}^{\circ}C$ $T_{j=bivalent}$ temperature $T_{j=operating}$ limit $T_{j=-15}^{\circ}C$ Operating limit temperature	ure Tj COPd COPd COPd COPd COPd COPd COPd COPd	
Declared capacity for heating / Colder set temperature 20°C and outdoor temperatur Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average	ure Tj Pdh [Pdh] Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh	- kW - kW - kW - kW - kW - kW - kW - kW	temperature 20°C and outdoor temperature Tj=-7°C Tj=2°C Tj=7°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average	Ture Tj COPd COPd COPd COPd COPd COPd COPd COPd	
Declared capacity for heating / Colder set temperature 20°C and outdoor temperatur Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Warmer	ure Tj Pdh [Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh	- kW - kW - kW - kW - kW - kW - kW - c	temperature 20°C and outdoor temperature Tj=-7°C Tj=2°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Warmer	Ture Tj COPd COPd COPd COPd COPd COPd COPd COPd	
Declared capacity for heating / Colder set temperature 20°C and outdoor temperatur Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average	ure Tj Pdh [Pdh] Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh	- kW - kW - kW - kW - kW - kW - kW - kW	temperature 20°C and outdoor temperature Tj=-7°C Tj=2°C Tj=7°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average	Ture Tj COPd COPd COPd COPd COPd COPd COPd COPd	
Declared capacity for heating / Colder set temperature 20°C and outdoor temperatur Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Warmer heating / Colder	ure Tj Pdh [Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh	- kW - kW - kW - kW - kW - kW - kW - c	temperature 20°C and outdoor temperat Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Warmer heating / Colder	Ture Tj COPd COPd COPd COPd COPd COPd COPd COPd	
Declared capacity for heating / Colder set temperature 20°C and outdoor temperatur Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Warmer heating / Colder	ure Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv	- kW - kW - kW - kW - kW - kW - kW - kW - c - c - c - c	temperature 20°C and outdoor temperat Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Warmer heating / Colder Cycling interval efficiency	Ture Tj COPd COPd COPd COPd COPd COPd COPd COPd	
Declared capacity for heating / Colder set temperature 20°C and outdoor temperatur Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Warmer heating / Colder Cycling interval capacity for cooling	ure Tj Pdh [Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh	- kW - kW	temperature 20°C and outdoor temperat Tj=-7°C Tj=2°C Tj=12°C Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Older Cycling interval efficiency for cooling	Ture Tj COPd COPd COPd COPd COPd COPd COPd COPd	
Declared capacity for heating / Colder set temperature 20°C and outdoor temperatur Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Warmer heating / Colder	ure Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv	- kW - kW - kW - kW - kW - kW - kW - kW - c - c - c - c	temperature 20°C and outdoor temperat Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Warmer heating / Colder Cycling interval efficiency	Ture Tj COPd COPd COPd COPd COPd COPd COPd COPd	
Declared capacity for heating / Colder set temperature 20°C and outdoor temperatur Tj=-7°C Tj=2°C Tj=2°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Warmer heating / Colder Cycling interval capacity for cooling for heating	ure Tj Pdh [Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh	- kW - kW	temperature 20°C and outdoor temperat Tj=-7°C Tj=2°C Tj=2°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Warmer heating / Colder Cycling interval efficiency for cooling for heating	Ture Tj COPd COPd COPd COPd COPd COPd COPd COPd	
Declared capacity for heating / Colder set temperature 20°C and outdoor temperatur Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient	ure Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Pcycc Pcych	- kW - kW	temperature 20°C and outdoor temperat Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient	Tol Tol Tol Tol EERcyc COPcyc	
Declared capacity for heating / Colder set temperature 20°C and outdoor temperatur Tj=-7°C Tj=2°C Tj=2°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Warmer heating / Colder Cycling interval capacity for cooling for heating	ure Tj Pdh [Pdh] Pdh Pdh Pdh Pdh Pdh Pdh Pdh [Pdh Pdh Pdh Pdh [Tbiv Tbiv Tbiv Tbiv Tbiv Pdiv [Tbiv Tbiv [- kW - kW	temperature 20°C and outdoor temperat Tj=-7°C Tj=2°C Tj=2°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Warmer heating / Colder Cycling interval efficiency for cooling for heating	Ture Tj COPd COPd COPd COPd COPd COPd COPd COPd	
Declared capacity for heating / Colder set temperature 20°C and outdoor temperatur Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling	ure Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Pcycc Pcych	- kW - kW - kW - kW - kW - kW - kW - kW - c - °C - °C - °C - °C - °C - °C - °C - °C - °C	temperature 20°C and outdoor temperat Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Average heating / Warmer heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating	Tol Tol Tol Tol EERcyc COPcyc	
Declared capacity for heating / Colder set temperature 20°C and outdoor temperatur Tj=-7°C Tj=2°C Tj=2°C Tj=5°C Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power modes ott	ure Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Tbiv Cdc	- kW - kW - kW - kW - kW - kW - kW - c - °c - °c - °c - °c - % - kW - kW - kW - kW	temperature 20°C and outdoor temperat Tj=-7°C Tj=2°C Tj=12°C Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Warmer heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating	Tol Tol Tol Tol EERcyc COPcyc	
Declared capacity for heating / Colder set temperature 20°C and outdoor temperatur Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power modes oth off mode	ure Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Cby Cdc	- kW - kW - kW - kW - kW - kW - KW - KW - C - C - C - C - C - C - C - C	temperature 20°C and outdoor temperat Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Oolder Cycling interval efficiency for cooling for heating Degradation coefficient heating Annual electricity consumption cooling	Tol Tol Tol Tol EERcyc COPcyc COPcyc	15 °C 15 °C
Declared capacity for heating / Colder se temperature 20°C and outdoor temperatur Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power modes oth off mode standby mode	ure Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Cby Cdc	- kW - kW - kW - kW - kW - kW - kW - kW - kW - c - °C -	temperature 20°C and outdoor temperat Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Older Cycling interval efficiency for cooling for heating Degradation coefficient heating Annual electricity consumption cooling heating / Average	Tol Tol Tol Tol EERcyc COPcyc COPcyc Tol Tol Tol Tol Tol Tol COPcyc	- - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - 0.25 - 475 kWh/a 1972 kWh/a
Declared capacity for heating / Colder set temperature 20°C and outdoor temperatur Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power modes oth off mode standby mode thermostat-off mode	ure Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Tbiv Cbc Pcych Pcych	- kW - kW - kW - kW - kW - kW - kW - kW - c - °C -	temperature 20°C and outdoor temperat Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=-15°C Operating limit temperature heating / Average heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating / Average heating	Tol Tol Tol Tol Tol Tol Tol Tol Tol COPd COPd COPd COPd COPd COPd COPd COPd	- - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - 0.25 - 475 kWh/a 4972 kWh/a
Declared capacity for heating / Colder set temperature 20°C and outdoor temperatur Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power modes oth off mode standby mode	ure Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Cby Cdc	- kW - kW - kW - kW - kW - kW - kW - kW - c - °C -	temperature 20°C and outdoor temperat Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Older Cycling interval efficiency for cooling for heating Degradation coefficient heating Annual electricity consumption cooling heating / Average	Tol Tol Tol Tol EERcyc COPcyc COPcyc Tol Tol Tol Tol Tol Tol COPcyc	- - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - 0.25 - 475 kWh/a yWh/a -
Declared capacity for heating / Colder set temperature 20°C and outdoor temperatur Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power modes oth off mode standby mode thermostat-off mode crankcase heater mode	ure Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Cdc Cdc Cdc Cdc Pcych her than 'active r Posb Pto Pck	- kW - kW - kW - kW - kW - kW - kW - kW - c - °C -	temperature 20°C and outdoor temperat Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=-15°C Operating limit temperature heating / Average heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating / Average heating	Tol Tol Tol Tol Tol Tol Tol Tol Tol COPd COPd COPd COPd COPd COPd COPd COPd	- - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - 0.25 - 475 kWh/a 4972 kWh/a
Declared capacity for heating / Colder set temperature 20°C and outdoor temperatur Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power modes oth off mode standby mode thermostat-off mode	ure Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Cdc Cdc Cdc Cdc Pcych her than 'active r Posb Pto Pck	- kW - kW - kW - kW - kW - kW - kW - kW - c - °C -	temperature 20°C and outdoor temperat Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating / Average heating Or cooling for heating Outer temperature heating / Other items	Tol Tol Tol Tol Tol Tol EERcyc COPcyc COPcyc	- - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - 0.25 - 475 kWh/a - kWh/a - kWh/a
Declared capacity for heating / Colder set temperature 20°C and outdoor temperatur Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power modes oth off mode standby mode thermostat-off mode crankcase heater mode	ure Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Cdc Cdc Cdc Cdc Pcych her than 'active r Posb Pto Pck	- kW - kW - kW - kW - kW - kW - kW - kW - c - °C -	temperature 20°C and outdoor temperat Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=-15°C Operating limit temperature heating / Average heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating / Average heating Annual electricity consumption cooling heating / Warmer heating / Average heating / Warmer heating / Other Other items Sound power level(indoor)	Tol Tol Tol Tol Tol Tol Tol Tol Tol COPd COPd COPd COPd COPd COPd COPd COPd	- - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - 0.25 - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - -
Declared capacity for heating / Colder set temperature 20°C and outdoor temperatur Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power modes oth off mode standby mode thermostat-off mode crankcase heater mode	ure Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Cdc Cdc Cdc Cdc Pcych her than 'active r Posb Pto Pck	- kW - kW - kW - kW - kW - kW - kW - kW - c - °C -	temperature 20°C and outdoor temperat Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=-15°C Operating limit Tj=-15°C Operating limit temperature heating / Average heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating / Average heating / Other Other items Sound power level(indoor) Sound power level(outdoor)	Tol Tol Tol Tol Tol Tol Tol Tol Tol COPd COPd COPd COPd COPd COPd COPd COPd	- - - - - - - - - - - - - - - - - - - - - - - - - - 0.25 - 0.25 - 0.25 - 0.25 - 0.25 - 0.25 - 0.25 - 0.25 - 0.25 - 0.25 - 0.25 - 0.25 - 0.25 - 0.25 - 0.25 - 0.25 - 0.25 - 0.26 - 0.27 - 0.28 - 0.29 - 0.20 <td< td=""></td<>
Declared capacity for heating / Colder set temperature 20°C and outdoor temperatur Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power modes oth off mode standby mode thermostat-off mode crankcase heater mode Capacity control(indicate one of three op	ure Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Tbiv Cdc Cdc Cdc Pcych her than 'active r Poff Psb Pto Pck	- kW - kW - kW - kW - kW - kW - kW - kW - c - °C -	temperature 20°C and outdoor temperat Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=-15°C Operating limit temperature heating / Average heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating / Average heating Annual electricity consumption cooling heating / Warmer heating / Average heating / Warmer heating / Other Other items Sound power level(indoor)	Tol COPd COPd COPd COPd COPd COPd COPd COPd	- - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - 0.25 - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - -
Declared capacity for heating / Colder set temperature 20°C and outdoor temperatur Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power modes oth off mode standby mode thermostat-off mode crankcase heater mode Capacity control(indicate one of three op fixed	ure Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Cdc Cdc Cdc Cdc Pcych Cdc Pcych Pcych Pcych Pcych Cdc	- kW - kW - kW - kW - kW - kW - kW - kW - c - °C -	temperature 20°C and outdoor temperat Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating / Average heating / Colder Other items Sound power level(indoor) Sound power level(outdoor) Global warming potential	Tol COPd COPd COPd COPd COPd COPd COPd COPd	- - - -
Declared capacity for heating / Colder set temperature 20°C and outdoor temperatur Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power modes oth off mode standby mode thermostat-off mode crankcase heater mode Capacity control(indicate one of three op fixed staged	ure Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Cdc Cdc Cdc Cdc Cdc Pcycch Pcycc Pcycc Pcycc Pcycc Pcycc Cdc	- kW - kW - kW - kW - kW - kW - kW - kW - c - °C -	temperature 20°C and outdoor temperat Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating / Average heating / Degradation coefficient heating / Average heating / Average heating / Average heating / Other items Sound power level(indoor) Sound power level(indoor) Global warming potential Rated air flow(indoor)	Tol COPd COPd COPd COPd COPd COPd COPd COPd	- - - -
Declared capacity for heating / Colder set temperature 20°C and outdoor temperatur Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power modes oth off mode standby mode thermostat-off mode crankcase heater mode Capacity control(indicate one of three op fixed staged	ure Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Tbiv Cdc Cdc Cdc Cdc Pcych Cdc Pcych Pcych Pcych Dtions)	- kW - kW - kW - kW - kW - kW - kW - kW - c - °C - °C - °C - °C - % - kW - kW - kW - W - W - W - W - W - W - W -	temperature 20°C and outdoor temperat Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating / Average heating / Degradation coefficient heating / Average heating / Average heating / Average heating / Other items Sound power level(indoor) Sound power level(indoor) Global warming potential Rated air flow(indoor)	Tol COPd COPd COPd COPd COPd COPd COPd COPd	- - - -
Declared capacity for heating / Colder set temperature 20°C and outdoor temperatur Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power modes ott off mode standby mode thermostat-off mode crankcase heater mode Capacity control(indicate one of three op fixed staged variable Contact details for obtaining more information	ure Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Tbiv Cdc Cdc Cdc Cdc Cdc Pcych Pcych Pcych Pcych Posb Pto Pck Dtions)	- kW - kW - kW - kW - kW - kW - kW - kW - W - w - w - w - w - w - w - w - w	temperature 20°C and outdoor temperat Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Oclder Cycling interval efficiency for heating Degradation coefficient heating / Average heating / Colder Degradation coefficient heating / Average heating / Average heating / Average heating / Varmer heating / Colder Other items Sound power level(indoor) Sound power level(indoor) Sound power level(outdoor) Global warming potential Rated air flow(indoor) Rated air flow(outdoor) acturer or of its authorised representative. g Europe, Ltd.	Tol COPd COPd COPd COPd COPd COPd COPd COPd	- - - -
Declared capacity for heating / Colder set temperature 20°C and outdoor temperature Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power modes oth off mode standby mode thermostat-off mode crankcase heater mode Capacity control(indicate one of three op fixed staged variable Contact details for obtaining more information Mitsut 7 Rout 7 Rout Contact details for obtaining Mitsut 7 Rout Mitsut 7 Rout 7 Rout 1 Mitsut 7 Rout 1 Mitsut 1 Mits	ure Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Tbiv Tbiv Tbiv	- kW - kW - kW - kW - kW - kW - kW - kW - W - w - w - w - w - w - w - w - w	temperature 20°C and outdoor temperat Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating / Average heating / Colder Other items Sound power level(indoor) Sound power level(indoor) Sound power level(outdoor) Global warming potential Rated air flow(indoor) Rated air flow(outdoor)	Tol COPd COPd COPd COPd COPd COPd COPd COPd	- - - -
Declared capacity for heating / Colder set temperature 20°C and outdoor temperatur Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power modes oth off mode standby mode thermostat-off mode crankcase heater mode Capacity control(indicate one of three op fixed staged variable Contact details for obtaining more information Mitsut 7 Roui	ure Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Tbiv Cdc Cdc Cdc Cdc Cdc Pcych Pcych Pcych Pcych Posb Pto Pck Dtions)	- kW - kW - kW - kW - kW - kW - kW - kW - W - w - w - w - w - w - w - w - w	temperature 20°C and outdoor temperat Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Oclder Cycling interval efficiency for heating Degradation coefficient heating / Average heating / Colder Degradation coefficient heating / Average heating / Average heating / Average heating / Varmer heating / Colder Other items Sound power level(indoor) Sound power level(indoor) Sound power level(outdoor) Global warming potential Rated air flow(indoor) Rated air flow(outdoor) acturer or of its authorised representative. g Europe, Ltd.	Tol COPd COPd COPd COPd COPd COPd COPd COPd	- - - -

PGA000Z812

Model FDF90VNPVD1

Information to identify the model	s) to which the inform	ation relates to:	If function includes heating: Indicate	the heating seaso	n the
Indoor unit model name	FDF100VI		information relates to. Indicated valu		
Outdoor unit model name	FDC90VN	Р	heating season at a time. Include at	least the heating se	eason 'Average'.
Function(indicate if present)			Average(mandatory)	Yes	
cooling	Yes		Warmer(if designated)	No	
heating	Yes		Colder(if designated)	No	
Item	symbol	value unit	Item	symbol	value class
Design load	Symbol	value unit	Seasonal efficiency and energy effici		
cooling	Pdesignc	9.0 kW	cooling	SEER	5.69 A+
heating / Average	Pdesignh	8.1 kW	heating / Average	SCOP/A	4.01 A+
heating / Warmer	Pdesignh	- kW	heating / Warmer	SCOP/W	
heating / Colder	Pdesignh	- kW	heating / Colder	SCOP/C	
	0				unit
Declared capacity at outdoor tem	perature Tdesignh		Back up heating capacity at outdoor	temperature Tdesig	gnh
heating / Average (-10°C)	Pdh	8.10 kW	heating / Average (-10°C)	elbu	0 kW
heating / Warmer (2°C)	Pdh	- kW	heating / Warmer (2°C)	elbu	- kW
heating / Colder (-22°C)	Pdh	- kW	heating / Colder (-22°C)	elbu	- kW
Declared capacity for cooling, at	indoor temperature 27	7(19)°C and	Declared energy efficiency ratio, at in	ndoor temperature	27(19)°C and
outdoor temperature Tj			outdoor temperature Tj		
Tj=35°C	Pdc	9.00 kW	Tj=35°C	EERd	3.23 -
Tj=30°C	Pdc	6.60 kW	Tj=30°C	EERd	4.60 -
Tj=25°C	Pdc	4.30 kW	Tj=25°C	EERd	7.30 -
Tj=20°C	Pdc	1.90 kW	Tj=20°C	EERd	8.00 -
Declared capacity for heating / Av	Arada season at inda	or	Declared coefficient of performance		at indoor
temperature 20°C and outdoor ter			temperature 20°C and outdoor temp		
Ti=-7°C	Pdh	7.10 kW	Ti=-7°C	COPd	2.80 -
Tj=2°C	Pdh	4.30 kW	$T_j=2^{\circ}C$	COPd	3.85 -
Tj=7°C	Pdh	2.70 kW	Tj=7°C	COPd	5.30 -
Tj=12°C	Pdh	2.00 kW	Ti=12°C	COPd	5.70 -
Tj=bivalent temperature	Pdh	8.10 kW	Tj=bivalent temperature	COPd	2.40 -
Tj=operating limit	Pdh	7.10 kW	Tj=operating limit	COPd	2.20 -
Declared capacity for heating / W	armer season, at indo	or	Declared coefficient of performance	/Warmer season, a	at indoor
temperature 20°C and outdoor ter	nperature Tj		temperature 20°C and outdoor temp	erature Tj	
Tj=2°C	Pdh	- kW	Tj=2°C	COPd	
Tj=7°C	Pdh	- kW	Tj=7°C	COPd	
Tj=12°C	Pdh	- kW	Tj=12°C	COPd	
Tj=bivalent temperature	Pdh	- kW	Tj=bivalent temperature	COPd	
Tj=operating limit	Pdh	- kW	Tj=operating limit	COPd	
				(0.11	
Declared capacity for heating / Co		r	Declared coefficient of performance		Indoor
temperature 20°C and outdoor ter Ti=-7°C			temperature 20°C and outdoor temp		
Tj=2°C	Pdh Pdh	- kW - kW	$T_j=2^{\circ}C$	COPd COPd	
Tj=7°C	Pdh	- kW	$T_{j=2}^{j=2}$ C	COPd	
Ti=12°C	Pdh	- kW	Ti=12°C	COPd	
Tj=bivalent temperature	Pdh	- kW	Tj=bivalent temperature	COPd	
Tj=operating limit	Pdh	- kW	Tj=operating limit	COPd	
Tj=-15°C	Pdh	- kW	Tj=-15°C	COPd	
Bivalent temperature			Operating limit temperature		
heating / Average	Tbiv	-10 °C	heating / Average	Tol	-15 ℃
heating / Warmer	Tbiv	- °C	heating / Warmer	Tol	- °C
heating / Colder	Tbiv	- °C	heating / Colder	Tol	- °C
Cycling interval capacity					• •
			Cycling interval efficiency		
for cooling	Pcycc	- kW	for cooling	EERcyc	
	Pcycc Pcych	- kW - kW		EERcyc COPcyc	
for cooling for heating			for cooling for heating		
for cooling for heating Degradation coefficient	Pcych	- kW	for cooling for heating Degradation coefficient	COPcyc	
for cooling for heating			for cooling for heating		
for cooling for heating Degradation coefficient cooling	Pcych Cdc	- kW	for cooling for heating Degradation coefficient heating	COPcyc	
for cooling for heating Degradation coefficient cooling Electric power input in power mo	Pcych Cdc des other than 'active	- kW 0.25 - mode'	for cooling for heating Degradation coefficient heating Annual electricity consumption	COPcyc	0.25 -
for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode	Pcych Cdc des other than 'active Poff	- kW 0.25 - mode' 10 W	for cooling for heating Degradation coefficient heating Annual electricity consumption cooling	COPcyc Cdh Qce	
for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode	Pcych Cdc des other than 'active	- kW 0.25 - mode' 10 W 10 W	for cooling for heating Degradation coefficient heating Annual electricity consumption cooling heating / Average	COPcyc	0.25]-
for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode	Pcych Cdc des other than 'active Poff Psb Pto	- kW 0.25 - mode' 10 W 10 W	for cooling for heating Degradation coefficient heating Annual electricity consumption cooling	COPcyc Cdh Qce Qhe	
for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode	Cdc Cdc des other than 'active Poff Psb	- kW 0.25 - 10 W 10 W 65 W	for cooling for heating Degradation coefficient heating Annual electricity consumption cooling heating / Average heating / Warmer	COPcyc Cdh Qce Qhe Qhe	
for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode	Cdc Cdc des other than 'active Poff Psb Pto Pck	- kW 0.25 - 10 W 10 W 65 W	for cooling for heating Degradation coefficient heating Annual electricity consumption cooling heating / Average heating / Warmer	COPcyc Cdh Qce Qhe Qhe	
for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode crankcase heater mode	Cdc Cdc des other than 'active Poff Psb Pto Pck	- kW 0.25 - 10 W 10 W 65 W	for cooling for heating Degradation coefficient heating Annual electricity consumption cooling heating / Average heating / Varmer heating / colder Other items Sound power level(indoor)	COPcyc Cdh Qce Qhe Qhe	- - - - 0.25 - 555 kWh/a 2826 kWh/a - kWh/a - kWh/a - kWh/a 65 dB(A)
for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode crankcase heater mode Capacity control(indicate one of the standard st	Cdc Cdc des other than 'active Poff Psb Pto Pck hree options)	- kW 0.25 - 10 W 10 W 65 W	for cooling for heating Degradation coefficient heating Annual electricity consumption cooling heating / Average heating / Warmer heating / colder Other items Sound power level(indoor) Sound power level(outdoor)	COPcyc Cdh Qce Qhe Qhe Qhe Lwa Lwa	- - - - 0.25 - 555 kWh/a 2826 kWh/a - kWh/a - kWh/a 65 dB(A) 69 dB(A)
for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode crankcase heater mode Capacity control(indicate one of the fixed	Cdc Cdc des other than 'active Poff Psb Pto Pck hree options)	- kW 0.25 - 10 W 10 W 65 W	for cooling for heating Degradation coefficient heating Annual electricity consumption cooling heating / Average heating / Warmer heating / Colder Other items Sound power level(indoor) Sound power level(outdoor) Global warming potential	COPcyc Cdh Qce Qhe Qhe Qhe Lwa	- - - - - - 555 kWh/a 2826 kWh/a - kWh/a
for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode crankcase heater mode Capacity control(indicate one of the fixed staged	Cdc Cdc des other than 'active Poff Psb Pto Pck nree options) No No	- kW 0.25 - 10 W 10 W 65 W	for cooling for heating Degradation coefficient heating Annual electricity consumption cooling heating / Average heating / Warmer heating / colder Other items Sound power level(indoor) Sound power level(indoor) Global warming potential Rated air flow(indoor)	COPcyc Cdh Qce Qhe Qhe Qhe Lwa Lwa	- - - - 0.25 - 555 kWh/a 2826 kWh/a - kWh/a
for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode crankcase heater mode Capacity control(indicate one of the fixed	Cdc Cdc des other than 'active Poff Psb Pto Pck hree options)	- kW 0.25 - 10 W 10 W 65 W	for cooling for heating Degradation coefficient heating Annual electricity consumption cooling heating / Average heating / Warmer heating / Colder Other items Sound power level(indoor) Sound power level(outdoor) Global warming potential	COPcyc Cdh Qce Qhe Qhe Qhe Lwa Lwa	- - - - 0.25 - 555 kWh/a 2826 kWh/a - kWh/a
for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode crankcase heater mode Capacity control(indicate one of the fixed staged variable	Pcych Cdc des other than 'active Poff Psb Pto Pck hree options) No Yes	- kW 0.25 - mode' 10 W 65 W 0 W	for cooling for heating Degradation coefficient heating Annual electricity consumption cooling heating / Average heating / Varmer heating / colder Other items Sound power level(indoor) Sound power level(indoor) Global warming potential Rated air flow(indoor) Rated air flow(indoor)	COPcyc Cdh Qce Qhe Qhe Qhe Qhe Qhe Qhe - -	- - - - - - 0.25 - 555 kWh/a 2826 kWh/a - kWh/a - kWh/a - kWh/a 65 dB(A) 69 dB(A) 1975 kgCO2eq. 1740 m ³ /h
for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode crankcase heater mode Capacity control(indicate one of the fixed staged variable Contact details for obtaining	Pcych Cdc des other than 'active Poff Psb Pto Pck hree options) No Yes Name and	- kW 0.25 - mode' 10 W 65 W 0 W d address of the mar	for cooling for heating Degradation coefficient heating Annual electricity consumption cooling heating / Average heating / Warmer heating / colder Other items Sound power level(indoor) Sound power level(outdoor) Global warming potential Rated air flow(indoor) Rated air flow(outdoor)	COPcyc Cdh Qce Qhe Qhe Qhe Qhe Qhe Qhe - -	- - - - 0.25 - 555 kWh/a 2826 kWh/a - kWh/a
for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode crankcase heater mode Capacity control(indicate one of the fixed staged variable	Pcych Cdc des other than 'active Poff Psb Pto Pck hree options) No Yes Name and Mitsubishi Heavy Ind	- kW 0.25 - mode' 10 W 65 W 0 W d address of the mar ustries Air-Condition	for cooling for heating Degradation coefficient heating Annual electricity consumption cooling heating / Average heating / Warmer heating / colder Other items Sound power level(indoor) Sound power level(outdoor) Global warming potential Rated air flow(indoor) Rated air flow(indoor) utfacturer or of its authorised representat ing Europe, Ltd.	COPcyc Cdh Qce Qhe Qhe Qhe Qhe Qhe Qhe - -	- - - - 0.25 - 555 kWh/a 2826 kWh/a - kWh/a
for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode crankcase heater mode Capacity control(indicate one of the fixed staged variable Contact details for obtaining	Pcych Cdc des other than 'active Poff Psb Pto Pck nree options) No Yes Name and Mitsubishi Heavy Ind 7 Roundwood Avenue	- kW 0.25 - mode' 10 W 65 W 0 W d address of the mar ustries Air-Condition	for cooling for heating Degradation coefficient heating Annual electricity consumption cooling heating / Average heating / Warmer heating / colder Other items Sound power level(indoor) Sound power level(outdoor) Global warming potential Rated air flow(indoor) Rated air flow(outdoor)	COPcyc Cdh Qce Qhe Qhe Qhe Qhe Qhe Qhe - -	- - - - - - 0.25 - 555 kWh/a 2826 kWh/a - kWh/a - kWh/a - kWh/a 65 dB(A) 69 dB(A) 1975 kgCO2eq. 1740 m ³ /h
for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode crankcase heater mode Capacity control(indicate one of the fixed staged variable Contact details for obtaining	Pcych Cdc des other than 'active Poff Psb Pto Pck hree options) No Yes Name and Mitsubishi Heavy Ind	- kW 0.25 - mode' 10 W 65 W 0 W d address of the mar ustries Air-Condition	for cooling for heating Degradation coefficient heating Annual electricity consumption cooling heating / Average heating / Warmer heating / colder Other items Sound power level(indoor) Sound power level(outdoor) Global warming potential Rated air flow(indoor) Rated air flow(indoor) utfacturer or of its authorised representat ing Europe, Ltd.	COPcyc Cdh Qce Qhe Qhe Qhe Qhe Qhe Qhe - -	- - - - - - 0.25 - 555 kWh/a 2826 kWh/a - kWh/a - kWh/a - kWh/a 65 dB(A) 69 dB(A) 1975 kgCO2eq. 1740 m ³ /h
for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode crankcase heater mode Capacity control(indicate one of the fixed staged variable Contact details for obtaining	Pcych Cdc des other than 'active Poff Psb Pto Pck nree options) No Yes Name and Mitsubishi Heavy Ind 7 Roundwood Avenue	- kW 0.25 - mode' 10 W 65 W 0 W d address of the mar ustries Air-Condition	for cooling for heating Degradation coefficient heating Annual electricity consumption cooling heating / Average heating / Warmer heating / colder Other items Sound power level(indoor) Sound power level(outdoor) Global warming potential Rated air flow(indoor) Rated air flow(indoor) utfacturer or of its authorised representat ing Europe, Ltd.	COPcyc Cdh Qce Qhe Qhe Qhe Qhe Qhe Qhe - -	- - - - 0.25 - 555 kWh/a 2826 kWh/a - kWh/a
for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode crankcase heater mode Capacity control(indicate one of the fixed staged variable Contact details for obtaining	Pcych Cdc des other than 'active Poff Psb Pto Pck nree options) No Yes Name and Mitsubishi Heavy Ind 7 Roundwood Avenue	- kW 0.25 - mode' 10 W 65 W 0 W d address of the mar ustries Air-Condition	for cooling for heating Degradation coefficient heating Annual electricity consumption cooling heating / Average heating / Warmer heating / colder Other items Sound power level(indoor) Sound power level(outdoor) Global warming potential Rated air flow(indoor) Rated air flow(indoor) utfacturer or of its authorised representat ing Europe, Ltd.	COPcyc Cdh Qce Qhe Qhe Qhe Lwa Lwa GWP - -	- - - - 0.25 - 555 kWh/a 2826 kWh/a - kWh/a

Model FDF90VNPVD2

Information to identify the model	s) to which the inform	ation relates to:	If function includes heating: Indicate	e the heating seasor	n the
Indoor unit model name	FDF100V		information relates to. Indicated valu		
Outdoor unit model name	FDC90VN	IP	heating season at a time. Include at	least the heating se	eason 'Average'.
			_		
Function(indicate if present)			Average(mandatory)	Yes	
cooling	Yes		Warmer(if designated)	No	
heating	Yes		Colder(if designated)	No	
Item	symbol	value unit	Item	symbol	value class
Design load	Symbol	value unit	Seasonal efficiency and energy effic	,	
cooling	Pdesignc	9.0 kW	cooling	SEER	5.69 A+
heating / Average	Pdesignh	8.1 kW	heating / Average	SCOP/A	4.01 A+
heating / Warmer	Pdesignh		heating / Warmer	SCOP/W	
heating / Colder	Pdesignh		heating / Colder	SCOP/C	
					unit
Declared capacity at outdoor temp	perature Tdesignh		Back up heating capacity at outdoor	temperature Tdesig	gnh
heating / Average (-10°C)	Pdh	8.10 kW	heating / Average (-10°C)	elbu	0 kW
heating / Warmer (2°C)	Pdh	- kW	heating / Warmer (2°C)	elbu	- kW
heating / Colder (-22°C)	Pdh	- kW	heating / Colder (-22°C)	elbu	- kW
				· · ·	
Declared capacity for cooling, at	indoor temperature 2	7(19)°C and	Declared energy efficiency ratio, at i	indoor temperature	27(19)°C and
outdoor temperature Tj	D 1		outdoor temperature Tj		
Tj=35°C	Pdc	9.00 kW	Tj=35°C	EERd	3.23 -
Tj=30°C	Pdc	6.60 kW	Tj=30°C	EERd	4.60
Tj=25°C Tj=20°C	Pdc Pdc	4.30 kW 1.90 kW	Tj=25°C Tj=20°C	EERd EERd	7.30 - 8.00 -
I]=20 C	Puc	1.90 KW	[]=20 C	EERU	0.00 -
Declared capacity for heating / Av	/erage season at inde	or	Declared coefficient of performance	/ Average season	at indoor
temperature 20°C and outdoor ter			temperature 20°C and outdoor temp		
Tj=-7°C	Pdh	7.10 kW	Ti=-7°C	COPd	2.80 -
Tj=2°C	Pdh	4.30 kW	Tj=2°C	COPd	3.85 -
Tj=7℃	Pdh	2.70 kW	Tj=7°C	COPd	5.30 -
Tj=12°C	Pdh	2.00 kW	Tj=12°C	COPd	5.70 -
Tj=bivalent temperature	Pdh	8.10 kW	Tj=bivalent temperature	COPd	2.40 -
Tj=operating limit	Pdh	7.10 kW	Tj=operating limit	COPd	2.20 -
Declared capacity for heating / Wa		or	Declared coefficient of performance		at indoor
temperature 20°C and outdoor ter			temperature 20°C and outdoor temp		
Tj=2°C	Pdh	- kW	Tj=2°C	COPd	
Tj=7°C	Pdh	- kW	Tj=7°C	COPd	
Tj=12°C	Pdh	- kW	Tj=12°C	COPd	
Tj=bivalent temperature	Pdh		Tj=bivalent temperature	COPd	
			Ti operating limit	0004	
Tj=operating limit	Pdh	- kW	Tj=operating limit	COPd	
Declared capacity for heating / Co	older season, at indoo		Declared coefficient of performance	/ Colder season, at	
Declared capacity for heating / Co temperature 20°C and outdoor ter	older season, at indoo mperature Tj	r	Declared coefficient of performance temperature 20°C and outdoor temp	/ Colder season, at perature Tj	
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C	older season, at indoo		Declared coefficient of performance temperature 20°C and outdoor temp Tj=-7°C	/ Colder season, at berature Tj COPd	
Declared capacity for heating / Co temperature 20°C and outdoor ter	older season, at indoo mperature Tj Pdh	r kW	Declared coefficient of performance temperature 20°C and outdoor temp Tj=-7°C Tj=2°C	/ Colder season, at perature Tj	indoor
Declared capacity for heating / Cc temperature 20°C and outdoor ter $T_{j=-7$ °C $T_{j=2}$ °C	older season, at indoo mperature Tj Pdh Pdh	r kW kW	Declared coefficient of performance temperature 20°C and outdoor temp Tj=-7°C	/ Colder season, at berature Tj COPd COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter $T_{j=-7^{\circ}C}$ $T_{j=2^{\circ}C}$ $T_{j=7^{\circ}C}$	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh	r kW kW kW	Declared coefficient of performance temperature 20°C and outdoor temp $T_{J}=-7^{\circ}C$ $T_{J}=2^{\circ}C$ $T_{J}=2^{\circ}C$	/ Colder season, at perature Tj COPd COPd COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=7°C Tj=12°C	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh	r 	Declared coefficient of performance temperature 20°C and outdoor temp Tj=-7°C Tj=2°C Tj=12°C	/ Colder season, at perature Tj COPd COPd COPd COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=7°C Tj=12°C Tj=bivalent temperature	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh	r kW kW kW kW kW	Declared coefficient of performance temperature 20°C and outdoor temp Tj=-7°C Tj=2°C Tj=12°C Tj=12°C Tj=bivalent temperature	/ Colder season, at perature Tj COPd COPd COPd COPd COPd COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter $T_{j=-7^{\circ}C}$ $T_{j=2^{\circ}C}$ $T_{j=12^{\circ}C}$ $T_{j=12^{\circ}C}$ $T_{j=bivalent}$ temperature $T_{j=operating}$ limit $T_{j=-15^{\circ}C}$	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh	r - kW - kW - kW - kW - kW - kW	Declared coefficient of performance temperature 20°C and outdoor temp $Tj=-7^{\circ}C$ $Tj=2^{\circ}C$ $Tj=7^{\circ}C$ $Tj=12^{\circ}C$ Tj=bivalent temperature Tj=operating limit $Tj=-15^{\circ}C$	/ Colder season, at berature Tj COPd COPd COPd COPd COPd COPd COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh	r - kW - kW - kW - kW - kW - kW - kW	Declared coefficient of performance temperature 20°C and outdoor temp Tj=-7°C Tj=2°C Tj=7°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature	/ Colder season, at perature Tj COPd COPd COPd COPd COPd COPd COPd COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv	r - kW - kW - kW - kW - kW - kW - kW - kW	$\begin{tabular}{ c c c c } \hline Declared coefficient of performance temperature 20°C and outdoor temp Tj=-7°C Tj=2°C Tj=7°C Tj=12°C Tj=bixalent temperature Tj=operating limit Tj=-15°C \\ \hline Operating limit temperature heating / Average \\ \hline \end{tabular}$	/ Colder season, at berature Tj COPd COPd COPd COPd COPd COPd COPd COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=5°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Warmer	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv	r - kW - kW - kW - kW - kW - kW - kW - kW - kW	$\begin{tabular}{lllllllllllllllllllllllllllllllllll$	/ Colder season, at perature Tj COPd COPd COPd COPd COPd COPd COPd COPd COPd COPd Tol Tol Tol	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv	r - kW - kW - kW - kW - kW - kW - kW - kW	$\begin{tabular}{ c c c c } \hline Declared coefficient of performance temperature 20°C and outdoor temp Tj=-7°C Tj=2°C Tj=7°C Tj=12°C Tj=bixalent temperature Tj=operating limit Tj=-15°C \\ \hline Operating limit temperature heating / Average \\ \hline \end{tabular}$	/ Colder season, at berature Tj COPd COPd COPd COPd COPd COPd COPd COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Warmer heating / Colder	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv	r - kW - kW - kW - kW - kW - kW - kW - kW - kW	Declared coefficient of performance temperature 20°C and outdoor temp Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Warmer heating / Colder	/ Colder season, at perature Tj COPd COPd COPd COPd COPd COPd COPd COPd COPd COPd Tol Tol Tol	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Warmer heating / Colder	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv	r - kW - c - c - c - c	Declared coefficient of performance temperature 20°C and outdoor temp Tj=-7°C Tj=2°C Tj=12°C Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Warmer heating / Colder Cycling interval efficiency	/ Colder season, at berature Tj COPd COPd COPd COPd COPd COPd COPd COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=bivalent temperature Tj=operating limit Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Colder Cycling interval capacity for cooling	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv	r - kW - kW	Declared coefficient of performance temperature 20°C and outdoor temp Tj=-7°C Tj=2°C Tj=12°C Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Warmer heating / Colder Cycling interval efficiency for cooling	/ Colder season, at perature Tj COPd COPd COPd COPd COPd COPd COPd COPd Tol Tol Tol Tol Tol EERcyc	indoor -
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Warmer heating / Colder	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv	r - kW - kW	Declared coefficient of performance temperature 20°C and outdoor temp Tj=-7°C Tj=2°C Tj=12°C Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Warmer heating / Colder Cycling interval efficiency	/ Colder season, at berature Tj COPd COPd COPd COPd COPd COPd COPd COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv	r - kW - kW	Declared coefficient of performance temperature 20°C and outdoor temp $Tj=-7^{\circ}C$ $Tj=2^{\circ}C$ $Tj=7^{\circ}C$ $Tj=7^{\circ}C$ $Tj=12^{\circ}C$ $Tj=t2^{\circ}C$ <	/ Colder season, at perature Tj COPd COPd COPd COPd COPd COPd COPd COPd Tol Tol Tol Tol Tol EERcyc	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=bivalent temperature Tj=operating limit Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Colder Cycling interval capacity for cooling	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv	r - kW - kW	Declared coefficient of performance temperature 20°C and outdoor temp Tj=-7°C Tj=2°C Tj=12°C Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Warmer heating / Colder Cycling interval efficiency for cooling	/ Colder season, at perature Tj COPd COPd COPd COPd COPd COPd COPd COPd Tol Tol Tol Tol Tol EERcyc	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Chiv Chiv	r - kW - kW	Declared coefficient of performance temperature 20°C and outdoor temp Tj=-7°C Tj=2°C Tj=12°C Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Warmer heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient	/ Colder season, at berature Tj COPd COPd COPd COPd COPd COPd COPd COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=2°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Cdc des other than 'active	r - kW - kW	Declared coefficient of performance temperature 20°C and outdoor temp Tj=-7°C Tj=2°C Tj=12°C Tj=ixoc Departing limit Tj=-15°C Operating limit temperature heating / Average heating / Warmer heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating Annual electricity consumption	/ Colder season, at perature Tj COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Cdc Cdc des other than 'active Poff	r - kW - k	Declared coefficient of performance temperature 20°C and outdoor temp Tj=-7°C Tj=2°C Tj=12°C Tj=operating limit Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Warmer heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating Annual electricity consumption cooling	/ Colder season, at berature Tj COPd COPd COPd COPd COPd COPd COPd COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Cdc Cdc Cdc	r - kW - k	Declared coefficient of performance temperature 20°C and outdoor temp Tj=-7°C Tj=2°C Tj=12°C Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating Annual electricity consumption cooling heating / Average	/ Colder season, at perature Tj COPd COP	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Cdc Cdc Cdc eldes other than 'active Poff Psb Pto	r - kW - k	Declared coefficient of performance temperature 20°C and outdoor temp Tj=-7°C Tj=2°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Warmer heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating Annual electricity consumption cooling heating / Average heating / Warmer	/ Colder season, at perature Tj COPd COPcyc COPcyc	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Cdc Cdc Cdc	r - kW - k	Declared coefficient of performance temperature 20°C and outdoor temp Tj=-7°C Tj=2°C Tj=12°C Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating Annual electricity consumption cooling heating / Average	/ Colder season, at perature Tj COPd COP	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode crankcase heater mode	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Cdc Cdc des other than 'active Poff Psb Pto Pck	r - kW - k	Declared coefficient of performance temperature 20°C and outdoor temp Tj=-7°C Tj=2°C Tj=12°C Tj=operating limit Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Warmer heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating Annual electricity consumption cooling heating / Average heating / Warmer heating / Average heating / Average heating / Colder	/ Colder season, at perature Tj COPd COPcyc COPcyc	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=7°C Tj=bivalent temperature Tj=operating limit Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Cdc Cdc des other than 'active Poff Psb Pto Pck	r - kW - k	Declared coefficient of performance temperature 20°C and outdoor temp Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating Annual electricity consumption cooling heating / Average heating / Warmer heating / colder Other items	/ Colder season, at berature Tj COPd COPd COPd COPd COPd COPd COPd COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode crankcase heater mode	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Cdc Cdc des other than 'active Poff Psb Pto Pck	r - kW - k	Declared coefficient of performance temperature 20°C and outdoor temp Tj=-7°C Tj=2°C Tj=12°C Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Varmer heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating Degradation coefficient heating / Average heating / Other items Sound power level(indoor)	/ Colder season, at perature Tj COPd CDPd CDPd CDPd CDPd CDPd CDPd CDPd CDPd CDPd CDPd CDPd CDPd CDPd CDPd CDPd CDP CDP CDP CDP CDP CDP CDP CDP	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=2°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode crankcase heater mode Capacity control(indicate one of the standby control)	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Cdc Cdc des other than 'active Poff Psb Pto Pck	r - kW - k	Declared coefficient of performance temperature 20°C and outdoor temp Tj=-7°C TJ=2°C Tj=12°C Tj=iz°C Tj=istvalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Varmer heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating / Average heating / Average heating / Average heating / Warmer heating / Other Other items Sound power level(indoor) Sound power level(outdoor)	/ Colder season, at perature Tj COPd COPd COPd COPd COPd COPd COPd COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode crankcase heater mode Capacity control(indicate one of the fixed	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Cdc Cdc des other than 'active Poff Psb Pto Pck hree options)	r - kW - k	Declared coefficient of performance temperature 20°C and outdoor temp Tj=-7°C Tj=2°C Tj=2°C Tj=bivalent temperature Tj=operating limit Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Warmer heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating Degradation coefficient heating Annual electricity consumption cooling heating / Average heating / Warmer heating / colder Other items Sound power level(indoor) Sound power level(outdoor) Global warming potential	/ Colder season, at perature Tj COPd CDPd CDPd CDPd CDPd CDPd CDPd CDPd CDPd CDPd CDPd CDPd CDPd CDPd CDPd CDPd CDP CDP CDP CDP CDP CDP CDP CDP	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode crankcase heater mode Capacity control(indicate one of the fixed staged	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Cdc Cdc des other than 'active Poff Psb Pto Pck	r - kW - k	Declared coefficient of performance temperature 20°C and outdoor temp Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Average heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating / Average heating Degradation coefficient heating / Average heating / Average heating / Colder Other items Sound power level(indoor) Sound power level(outdoor) Global warming potential Rated air flow(indoor)	/ Colder season, at perature Tj COPd COPd COPd COPd COPd COPd COPd COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode crankcase heater mode Capacity control(indicate one of the fixed	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Cdc Cdc des other than 'active Poff Psb Pto Pck hree options)	r - kW - k	Declared coefficient of performance temperature 20°C and outdoor temp Tj=-7°C Tj=2°C Tj=2°C Tj=bivalent temperature Tj=operating limit Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Warmer heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating Degradation coefficient heating Annual electricity consumption cooling heating / Average heating / Warmer heating / colder Other items Sound power level(indoor) Sound power level(outdoor) Global warming potential	/ Colder season, at perature Tj COPd COPd COPd COPd COPd COPd COPd COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode crankcase heater mode Capacity control(indicate one of the fixed staged	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Cdc Cdc des other than 'active Poff Psb Pto Pck hree options)	r - kW - kW - kW - kW - kW - kW - kW - kW - kW - c - c - c - c - c - c - c - c	Declared coefficient of performance temperature 20°C and outdoor temp Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Average heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating / Average heating Degradation coefficient heating / Average heating / Average heating / Colder Other items Sound power level(indoor) Sound power level(outdoor) Global warming potential Rated air flow(indoor)	/ Colder season, at perature Tj COPd COPd COPd COPd COPd COPd COPd COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=2°C Tj=bivalent temperature Tj=operating limit Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode crankcase heater mode Capacity control(indicate one of the fixed staged variable	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Cdc Cdc des other than 'active Poff Psb Pto Pck hree options)	r kW 	Declared coefficient of performance temperature 20°C and outdoor temp Tj=-7°C Tj=2°C Tj=2°C Tj=bivalent temperature Tj=operating limit Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Warmer heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating Degradation coefficient heating Annual electricity consumption cooling heating / Average heating / Warmer heating / colder Other items Sound power level(indoor) Sound power level(outdoor) Global warming potential Rated air flow(indoor) Rated air flow(outdoor) nufacturer or of its authorised representa	/ Colder season, at perature Tj COPd COPd COPd COPd COPd COPd COPd COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode crankcase heater mode Capacity control(indicate one of the fixed staged variable Contact details for obtaining	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Cdc Cdc Cdc Cdc des other than 'active Poff Psb Pto Pck hree options) No Yes Name an Mitsubishi Heavy Ind 7 Roundwood Avenu	- kW - %C - °C - %W -	Declared coefficient of performance temperature 20°C and outdoor temp Tj=-7°C Tj=2°C Tj=2°C Tj=bivalent temperature Tj=operating limit Tj=operating limit Tj=-15°C Operating limit temperature heating / Average heating / Warmer heating / Colder Cycling interval efficiency for cooling for heating Degradation coefficient heating Degradation coefficient heating Annual electricity consumption cooling heating / Average heating / Warmer heating / colder Other items Sound power level(indoor) Sound power level(outdoor) Global warming potential Rated air flow(indoor) Rated air flow(outdoor) nufacturer or of its authorised representa	/ Colder season, at perature Tj COPd COPd COPd COPd COPd COPd COPd COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode crankcase heater mode Capacity control(indicate one of the fixed staged variable Contact details for obtaining	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Tbiv Tbiv Tbiv Tbiv Tbiv Cdc Cdc des other than 'active Poff Psb Pto Pck hree options) No Yes	- kW - %C - °C - %W -	Declared coefficient of performance temperature 20°C and outdoor temp Tj=-7°C Tj=2°C Tj=2°C Tj=bivalent temperature Tj=operating limit Toto Colder Degradation coefficient heating Annual electricity consumption cooling heating / Average heating / colder Other items Sound power level(outdoor)	/ Colder season, at perature Tj COPd COPd COPd COPd COPd COPd COPd COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode crankcase heater mode Capacity control(indicate one of the fixed staged variable Contact details for obtaining	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Cdc Cdc Cdc Cdc des other than 'active Poff Psb Pto Pck hree options) No Yes Name an Mitsubishi Heavy Ind 7 Roundwood Avenu	- kW - %C - °C - %W -	Declared coefficient of performance temperature 20°C and outdoor temp Tj=-7°C Tj=2°C Tj=2°C Tj=bivalent temperature Tj=operating limit Toto Colder Degradation coefficient heating Annual electricity consumption cooling heating / Average heating / colder Other items Sound power level(outdoor)	/ Colder season, at perature Tj COPd COPd COPd COPd COPd COPd COPd COPd	indoor
Declared capacity for heating / Co temperature 20°C and outdoor ter Tj=-7°C Tj=2°C Tj=12°C Tj=bivalent temperature Tj=operating limit Tj=-15°C Bivalent temperature heating / Average heating / Average heating / Average heating / Colder Cycling interval capacity for cooling for heating Degradation coefficient cooling Electric power input in power mo off mode standby mode thermostat-off mode crankcase heater mode Capacity control(indicate one of the fixed staged variable Contact details for obtaining	older season, at indoo mperature Tj Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Pdh Cdc Cdc Cdc Cdc des other than 'active Poff Psb Pto Pck hree options) No Yes Name an Mitsubishi Heavy Ind 7 Roundwood Avenu	- kW - %C - °C - %W -	Declared coefficient of performance temperature 20°C and outdoor temp Tj=-7°C Tj=2°C Tj=2°C Tj=bivalent temperature Tj=operating limit Toto Colder Degradation coefficient heating Annual electricity consumption cooling heating / Average heating / colder Other items Sound power level(outdoor)	/ Colder season, at perature Tj COPd COPd COPd COPd COPd COPd COPd COPd	indoor

(6) Wall mounted type (SRK) Model SRK71VNPZM

Information to identify the model(s) to whether the model is the model			elates to:	If function includes heating: Indicate the			
Indoor unit model name	SRK71ZM			information relates to. Indicated values s			
Outdoor unit model name	FDC71VN	IP		heating season at a time. Include at leas	t the heatir	ng season	'Average'.
Eurotion/indianta if present)				Average (mandatory)	Vee		
Function(indicate if present) cooling	Yes			Average(mandatory) Warmer(if designated)	Yes No		
heating	Yes			Colder(if designated)	No		
Item	symbol	value	unit	Item	symbol	value	class
Design load		-	_	Seasonal efficiency and energy efficienc	y class		
cooling	Pdesignc	7.1	kW	cooling	SEER	6.60	A++
heating / Average	Pdesignh	5.7	kW	heating / Average	SCOP/A	4.47	A+
heating / Warmer	Pdesignh		kW	heating / Warmer	SCOP/W	-	-
heating / Colder	Pdesignh	-	kW	heating / Colder	SCOP/C	-	-
Declared capacity at outdoor temperatur	o Tdesiant	<u> </u>		Back up heating capacity at outdoor tem	nerature Tr	designh	unit
heating / Average (-10°C)	Pdh	4.74	kW	heating / Average (-10°C)	elbu		kW
heating / Warmer (2°C)	Pdh	-	kW	heating / Warmer (2°C)	elbu	-	kW
heating / Colder (-22°C)	Pdh	-	kW	heating / Colder (-22°C)	elbu	-	кW
Declared capacity for cooling, at indoor	emperature	e 27(19)°C	and	Declared energy efficiency ratio, at indoc	or temperat	ure 27(19)°C and
outdoor temperature Tj			_	outdoor temperature Tj			_
Tj=35°C	Pdc	7.10	kW	Tj=35°C	EERd	3.01	-
Tj=30°C	Pdc	5.20	kW	Tj=30°C	EERd	4.80	-
Tj=25°C	Pdc	3.40	kW	Tj=25°C	EERd	8.80	-
Tj=20°C	Pdc	1.60	kW	Tj=20°C	EERd	13.50	-
Declared capacity for heating / Average	season at	indoor		Declared coefficient of performance / Av	erane seas	on at ind	oor
temperature 20°C and outdoor temperat				temperature 20°C and outdoor temperatu		on, at mu	
Tj=-7°C	Pdh	5.00	kW	Tj=-7°C	COPd	2.85	j.
Tj=2°C	Pdh	3.00	kW	Tj=2°C	COPd	4.40	1- I
Tj=7°C	Pdh	2.00	kW	Tj=7°C	COPd	6.00	1-
Tj=12°C	Pdh	1.50	kW	Tj=12°C	COPd	7.00	1-
Tj=bivalent temperature	Pdh	5.00	kW	Tj=bivalent temperature	COPd	2.85]-
Tj=operating limit	Pdh	4.30	kW	Tj=operating limit	COPd	2.20	-
Declared capacity for heating / Warmer		indoor		Declared coefficient of performance / Wa		on, at indo	or
temperature 20°C and outdoor temperat Tj=2°C	Pdh	-	kW	temperature 20°C and outdoor temperature Tj=2°C	COPd	-	ז ו _ו
Tj=7°C	Pdh	-	kW	Tj=2°C	COPd	-	-[
Tj=12°C	Pdh	-	kW	Ti=12°C	COPd		1_
Tj=bivalent temperature	Pdh	-	kW	Tj=bivalent temperature	COPd	-	- I
Tj=operating limit	Pdh	-	kW	Tj=operating limit	COPd	-	1_
	-						
Declared capacity for heating / Colder se	eason, at in	idoor		Declared coefficient of performance / Co	lder seaso	n, at indoc	r
temperature 20°C and outdoor temperat			_	temperature 20°C and outdoor temperate			_
Tj=-7°C	Pdh	-	kW	Tj=-7°C	COPd	-	-
Tj=2°C	Pdh	-	kW	Tj=2°C	COPd	-	-
Tj=7°C	Pdh	-	kW	Tj=7°C	COPd	-	-
Tj=12°C	Pdh	-	kW	Tj=12°C	COPd	-	-
Tj=bivalent temperature Tj=operating limit	Pdh Pdh	-	kW kW	Tj=bivalent temperature Tj=operating limit	COPd COPd	-	-
Tj=-15°C	Pdh	-	kW	Tj=-15℃	COPd	-	-
1]13 C	Tun	-	KVV	1]=-13 6	COLU	-	I ⁻
Bivalent temperature				Operating limit temperature			
heating / Average	Tbiv	-7	l℃	heating / Average	Tol	-15]℃
heating / Warmer	Tbiv	-	°C	heating / Warmer	Tol	-	l℃
heating / Colder	Tbiv	-	°C	heating / Colder	Tol	-	°C
Cycling interval capacity	Davies			Cycling interval efficiency	CED-		, I
for cooling for heating	Pcycc	-	kW kW	for cooling	EERcyc COPcyc	-	-¦⁻
for heating	Pcych	-	KVV	for heating	COPCyc	-	-
Degradation coefficient				Degradation coefficient			
cooling	Cdc	0.25	1-	heating	Cdh	0.25]-
				v			·
Electric power input in power modes oth				Annual electricity consumption			
off mode	Poff	10	W	cooling	Qce	377	kWh/a
standby mode	Psb	10	W	heating / Average	Qhe	1786	kWh/a
thermostat-off mode	Pto	56	W	heating / Warmer	Qhe	-	kWh/a
crankcase heater mode	Pck	0	W	heating / colder	Qhe	-	kWh/a
Canacity control/indicate and of three or	tions)			Other items			
Capacity control(indicate one of three or				Sound power level(indoor)	Lwa	60	dB(A)
				Sound power level(indoor)	Lwa	67	dB(A)
fixed	No			Global warming potential	GWP	1975	kgCO2eq.
staged	No			Rated air flow(indoor)	-	1110	m3/h
variable	Yes			Rated air flow(outdoor)		2160	m3/h
Contact details for obtaining				ufacturer or of its authorised representative	Э.		
				ing Europe, Ltd. bridge, Middlesey, UB11 1AX			
United Ki		ue, Siuckie	∋уганк, UX	bridge, Middlesex, UB11 1AX,			
L							

PCA001Z722

STANDARD INVERTER PACKAGED AIR-CONDITIONERS



MITSUBISHI HEAVY INDUSTRIES THERMAL SYSTEMS, LTD. 16-5 Konan 2-chome, Minato-ku, Tokyo, 108-8215, Japan http://www.mhi-mth.co.jp/

Because of our policy of continuous improvement, we reserve the right to make changes in all specifications without notice. © Copyright MITSUBISHI HEAVY INDUSTRIES THERMAL SYSTEMS, LTD.